

Sprinter

Operating Instructions



Co-driver airbag warning



Example

WARNING Risk of injury or fatal injuries if the front-passenger airbag is enabled

If the front-passenger front airbag is enabled, a child on the front-passenger seat may be struck by the front-passenger airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT AIRBAG, DEATH or SERIOUS INJURY to the CHILD can occur.

Observe the chapter "Children in the vehicle".

Welcome to the world of Mercedes-Benz

Before you first drive off, read these Operating Instructions carefully and familiarize yourself with your vehicle. For your own safety and a longer vehicle life, follow the instructions and warning notices in these Operating Instructions. Disregarding them may result in damage to the vehicle or environment or in personal injury.

Vehicle damage caused by failure to observe the instructions is not covered by the New Vehicle Limited Warranty.

The standard equipment and product description of your vehicle may vary and depends on the following factors:

- Model
- Order
- National version
- Availability

Mercedes-Benz reserves the right to introduce changes in:

- Design
- Equipment
- · Technical features

Therefore, the description may differ from your vehicle in some cases.

The following documents are integral parts of the vehicle:

- · Digital Operator's Manual
- Printed Operating Instructions
- Maintenance Booklet
- · Equipment-dependent supplements

Always keep these documents in the vehicle. If you sell the vehicle, always pass all documents on to the new owner.

Daimler VANS USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company

9075841806

Symbols	4	Electrical step	58
At a glance	6	Anti-thert protection	01
Cockpit			
Instrument cluster		Seats and stowage	
Overhead control panel	11	Correct driver's seat position	64
Door control panel	16	Seats	64
Emergencies and breakdowns	18	Adjusting the steering wheel	
Liner generes and breakdowns	10	Stowage areas	
		Bottle holder	
Digital Operator's Manual	20	Cup holder	78
Calling up the Digital Operating		Ashtray and cigarette lighter	79
Instructions	20	Sockets	80
		Wirelessly charging the mobile phone	
		and coupling with the exterior antenna	82
General notes	21	Installing or removing the floor mats	83
Environmental protection	21		
Mercedes-Benz Genuine Parts	21		
Notes about attachments, add-on		Light and vision	84
equipment, installations and conver-		Exterior lighting	84
sions	22	Adjusting the interior lighting	87
Operating Instructions	23	Changing bulbs	90
Service and vehicle operation	23	Windshield wipers	95
	24	Mirrors	97
Operating safety		Using sun visors	98
Diagnostics connection	25	8	
Notes on changes to the engine output	26		
Qualified specialist workshop	26	Climate control	99
Vehicle registration	26	Overview of climate control systems	99
Correct use of the vehicle	26	Operating climate control systems	101
Multi Purpose Vehicle	26	Operating air vents	104
Information on problems with your		Auxiliary heating	105
vehicle	27	Operating cargo compartment ventila-	100
Reporting safety defects	27	tion	108
Limited Warranty	27		100
QR codes for rescue card	27		
Data storage	28	Driving and parking	109
Copyright	30	Driving	109
		Battery main switch	120
		Automatic transmission	122
Occupant safety	31	All-wheel drive	124
Restraint system	31	DSR (Downhill Speed Regulation)	126
Seat belts	32	Electronic level control	128
Airbags	35	Refueling	133
Safely transporting children in the		Parking	140
vehicle	36		145
Notes on pets in the vehicle	45	Driving and driving safety systems	
		Work mode	168
Onening and closing	16	Trailer operation	169
Opening and closing	46		
SmartKey	46	Instrument Display and on-board	
Doors	49	computer	175
Sliding door	51	Overview of Instrument Display	175
Electric sliding door	52	Overview of the buttons on the steer-	
Rear-end doors	55	ing wheel	176
Partition sliding door	56	G	3

Operating the on-board computer	176		
Overview of the displays on the multi-		Breakdown assistance	292
function display	177	Emergency	292
Setting the instrument lighting	178	Emergency Call System	292
Menus and submenus	178	Flat tire	294
		Battery	294
		Towing or tow-starting	300
Voice Control System	184	Electrical fuses	304
Notes on operating safety	184	Vehicle tool kit	305
Operation	184	Hydraulic jack	306
tively	186	Wheels and tires	308
Basic voice commands	187	Information on noise or unusual driving	300
		characteristics	308
Mercedes PRO	195	Notes on regularly inspecting wheels	
Information about Mercedes PRO		and tires	308
(Mercedes me)	195	Information on driving with summer	
Information about Mercedes PRO con-	.,,	tires	308
nect (Mercedes me connect)	195	Information on M+S tires	309
Calling the Mercedes-Benz Customer		Notes on snow chains	309
Center using the multimedia system	195	Tire pressure	310
Making a call via the overhead control		Loading the vehicle	317
panel	196	Tire labeling	319
Information on the breakdown assis-		Information on definitions (tires and	
tance call via the overhead control		loading)	323
panel	196	Changing a wheel	324
Giving permission for data transfer	196	Spare wheel	332
Transferred data during a service call	196		
		Technical data	337
MBUX multimedia system	198	Information on technical data	337
Overview and operation	198	On-board electronics	337
System settings	209	Vehicle identification plate, vehicle	
Vehicle information	215	identification number (VIN) and engine	
Navigation	216	number	338
Telephone	242	Operating fluids and capacities	340
Online and Internet functions	254	Vehicle data	348
Media	261	Trailer hitch	349
Radio	265	Lashing points and carrier systems	353
Sound	270		
		Display messages and warning and	
Transporting	271	indicator lamps	355
Notes on loading guidelines	271	Display messages	355
Load distribution	272	Indicator and warning lamps	376
Securing loads	272	<u> </u>	
Carrier systems	274		
Using the interior roof carrier system	275	Index	387
Placing a load on the wheel arch	277		
Maintenance and care	278		
ASSYST PLUS service interval display	278		
Engine compartment	278		

Cleaning and care 286

In these Operating Instructions, you will find the following symbols:

A

DANGER Danger due to not observing the warning notices

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

Observe the warning notices.



ENVIRONMENTAL NOTE Environmental damage due to failure to observe environmental notes

Environmental notes include information on environmentally responsible behavior or environmentally responsible disposal.

- Observe environmental notes.
- NOTE Damage to property due to failure to observe notes on material damage

Notes on material damage inform you of risks which may lead to your vehicle being damaged.

- Observe notes on material damage.
- These symbols indicate useful instructions or further information that could be helpful to you.

Instructions

(→ page)

Further information on a topic

Display

Display in the multifunction display/media display


¬→

Highest menu level to be selected in the multimedia system

>>

Corresponding submenus to be selected in the multimedia system

* Indicates a cause




① Combination switch			12 V socket	\rightarrow	80
Turn signals	\rightarrow	85	7 230 V socket		
High beam	\rightarrow	85	Opens and closes the electric	\rightarrow	52
Windshield wipers	\rightarrow	95	sliding door	→	
Rear window wiper	\rightarrow	95	Hazard warning lamps		85
Steering wheel buttons	\rightarrow	176	Vehicles with KEYLESS START: key slot	\rightarrow	110
3 DIRECT SELECT lever	\rightarrow	122	② USB port	\rightarrow	77
Inside rearview mirror	\rightarrow	98	② Start/stop button	\rightarrow	110
Overhead control panel	\rightarrow	87	Right-hand switch panel		
 DIN slot, e.g. for mounting a tachograph or the timer for th stationary heater 	ie		Activates/deactivates all-wheel drive	→	125
Sun screen	\rightarrow	98	Engages/disengages LOW RANGE	\rightarrow	126
Co-driver's power window switch	\rightarrow	60	Activates/deactivates DSR	\rightarrow	127
Central locking	\rightarrow	49	Raises/lowers the vehicle level	\rightarrow	129
Stowage compartment cover	\rightarrow	306	Activates/deactivates power take-off		
Co-driver's stowage compart- ment or tachograph housing			Activates/deactivates working speed control (ADR)	\rightarrow	169
Cup holders	\rightarrow	78	Activates/deactivates cargo	\rightarrow	108
Climate control system	\rightarrow	99	compartment ventilation		
MBUX multimedia system dis- play	→	198	Activates/deactivates the rotating beacon		
MBUX multimedia system cor trol elements	1- →	201	Steering wheel gearshift pad- dles	\rightarrow	124

Opens the hood	\rightarrow	278	Adjusts driver's seat	\rightarrow	66
Left-hand switch panel			Seat heating	\rightarrow	76
Sets the working speed (ADR)	\rightarrow	169	Central locking	\rightarrow	49
Light switch			n Driver's power window switch	\rightarrow	60
Headlamp range adjuster					




	Instrument Display (color display)			Electrical malfunction	\rightarrow	384
				Coolant temperature indicator	\rightarrow	384
1	Speedometer	\rightarrow	175	and 🚛 coolant too hot		
2	€ ESP®	\rightarrow	377	(yellow) Electric parking brake	\rightarrow	37
3	Distance warning	\rightarrow	383		→	
4	Seat belt not fastened	\rightarrow	383	Restraint system	<i>→</i>	3
<u></u>	♦ Turn signal indica-	\rightarrow	85		\rightarrow	8
<u> </u>	tors		00		\rightarrow	84
6	Multifunction display	\rightarrow	377	Parking lights	\rightarrow	84
7	(!) Tire pressure loss warning lamp	\rightarrow	377	Fuel level indicator and fuel reserve with fuel filler cap location indicator	\rightarrow	384
8	Check Engine	\rightarrow	384	location indicator		
9	Preglow and malfunction in preglow system			Fog light	\rightarrow	84
10	Tachometer	\rightarrow	175	② 0‡ Rear fog light	\rightarrow	84
1		\rightarrow	377	3 (1) Brakes (yellow)	\rightarrow	377
	(Canada) parking brake is applied (red)			ABS malfunction	\rightarrow	377
12	BRAKE and (①) (USA) or (①) (Canada) brakes (red)	\rightarrow	377	② FFF ESP® deactivated	\rightarrow	377




	white display) with steering wheel buttons			Assist active and ready to issue warnings / (Red) Lane Keeping Assist issues warning		
1	Speedometer	\rightarrow	175		→	004
2	₹ ESP®	\rightarrow	377	O Check Engine		384
3	A Distance warning	\rightarrow	383	Preglow and malfunction in preglow system		
4	Seat belt not fastened	\rightarrow	383	Tachometer		
5	♦ ♦ Turn signal indicators	\rightarrow	85	(Canada) parking brake is	\rightarrow	377
6	Display of warning and indicator lamps			applied (red)		
	At least one door is not			(Canada) brakes (red)	\rightarrow	377
	completely closed			Reserve fuel	\rightarrow	384
	(!) Tire pressure loss	\rightarrow	377	DEF supply low	\rightarrow	136
	Power-assisted steering malfunction	\rightarrow	383	LOW RANGE active	\rightarrow	126
	Electrical malfunction	\rightarrow	384	(yellow) Electric parking brake	\rightarrow	377
	Sos SOS/emergency call system (Mercedes-Benz emer-			Multifunction display	\rightarrow	377
	gency call system)				\rightarrow	31
	Active Brake Assist deac-			⊞ ☐ High beam	\rightarrow	85
	tivated			D Low beam	\rightarrow	84
	■ ATTENTION ASSIST deactivated			Parking lights	\rightarrow	84
	OFF Lane Keeping Assist inactive			Fog light	\rightarrow	84
	Highbeam Assist	\rightarrow	86	② O‡ Rear fog light	\rightarrow	84

10 At a glance – Instrument cluster

3 (1) Brakes (yellow)	\rightarrow	377
ABS malfunction	\rightarrow	377
⊕ ESP® deactivated □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous description of the continuous description of the continuous description of the continuous description. □ Below the continuous description of the continuous	\rightarrow	377





Version 1 of the overhead control p • Sun visors		98	Switches the rear interior		
Breakdown assistance call but- ton (Mercedes PRO connect)			lighting on/off Switches the right-hand		
Activates/deactivates	\rightarrow	63	reading light on/off		
interior protection		00	Switches the tow-away	\rightarrow	62
Activates/deactivates the bus		alarm on/off			
interior lighting	nterior lighting		Eyeglasses compartment	\rightarrow	78
Switches the left-hand reading light on/off			Sos SOS emergency call system		
(5) Switches automatic light control on/off			ATA indicator lamp		
Switches the front interior lighting on/off					



Version 2 of the overhead control panel

- Sun visors
- ② M Switches the left-hand reading light on/off
- Switches the front interior lighting on/off
- 98 Switches the rear interior lighting on/off
 - (る) 「Yaw Switches the right-hand reading light on/off






Version 4 of the overhead control panel

1 Sun visors


98

Switches the interior lighting on/off



Overhead control panel for vehicles with bus equipment					
① Sun visors	\rightarrow	98	Switches the rear interior	\rightarrow	89
Seakdown assistance call button			lighting on/off		
		Switches the reading light on (off right)			
3 AUTO AUTO	\rightarrow	89	light on/off, right		
Switches the bus function on/off			Switches reading lights in the passenger compartment	\rightarrow	89
④ 番 Switches the reading			on/off		
light on/off, left			Eyeglasses compartment	\rightarrow	78
(5) Switches automatic light control on/off	\rightarrow	89			

Switches the front interior lighting on/off




49

58

58


Door control panel in vehicles with electrically adjustable seats 1 To adjust the outside mirrors 97 6 To open a door ② To activate/deactivate the cen- → 7 To open/close the right-hand tral locking system side window 3 To switch seat heating on/off 76 (3) To open/close the left-hand side window 4 To adjust the front seats elec-67 tronically (5) To operate the memory func-69 tion



Door control panel vehicles without electrically adjustable seats


To adjust the outside mirrors	97 ⑤ To op	oen/clos
② To activate/deactivate the cen- →	50 side	window
tral locking system		en/clos
\odot To switch seat heating on/off \rightarrow	76 side	window
To open a door	49	

(5) To open/close the right-hand side window	\rightarrow	58
6 To open/close the left-hand	\rightarrow	58



Checking and topping up operating fluids	\rightarrow	340
Starting assistance	\rightarrow	295
② Buttons for the SOS emergency call system and roadside assis- tance	\rightarrow	293
3 Warning lamp	\rightarrow	292
Safety vest	\rightarrow	292
First-aid kit (soft sided)	\rightarrow	292
Vehicles with rear-wheel drive: hydraulic jack and tire-change tool kit	\rightarrow	306

	6 Hazard warning lights	\rightarrow	85
	OR code for accessing the rescue card	\rightarrow	27
	To disconnect the starter battery	\rightarrow	298
	Fuel filler flap with instruction labels for tire pressure, fuel type and QR code for access- ing the rescue card	\rightarrow	133
	Flat tire	\rightarrow	294



Spare wheel (example)

332

Calling up the Digital Operating Instructions


Multimedia system:





The Digital Operating Instructions describes the function and operation of:

- · The vehicle
- The multimedia system
- Select one of the following menu items in the Digital Operating Instructions:
- Search: here you can use keywords to quickly locate answers to questions concerning vehicle operation.
- Quick start: the first steps towards setting up your driver's seat can be found here.
- Tips: provides you with information on specific everyday situations for your vehicle.
- Bookmarks: you can access your saved personal bookmarks here.
- Language: you can set the language for the Digital Operating Instructions here.



- Back
- Add bookmarks
- Picture
- Content area
- Menu

Some sections of the Digital Operating Instructions, e.g. warnings, can be expanded and collapsed.

Additional options for calling up the Digital Operating Instructions

Deep link: pressing and holding down an entry in the tab bar of the multimedia system opens the corresponding content in the Digital Operating Instructions.



Voice Control System: calling up via the voice control system

The Digital Operating Instructions are deactivated for safety reasons while driving.

Environmental protection



ENVIRONMENTAL NOTE Environmental damage due to operating conditions and personal driving style

The pollutant emission of the vehicle is directly related to the vehicle's operation.

Operate your vehicle in an environmentally responsible manner to help protect the environment. Please observe the following recommendations on operating conditions and personal driving style.

Operating conditions:

- Make sure that the tire pressures are always correct.
- Do not transport any unnecessary weight (e.g. a roof rack which is no longer required).
- Observe the service intervals. A regularly serviced vehicle will contribute to environmental protection.
- Always have maintenance work carried out at a qualified specialist workshop.

Personal driving style:

- Do not depress the accelerator pedal when starting the engine.
- Do not warm up the engine while stationary.
- Drive carefully and maintain a sufficient distance to other vehicles.
- Avoid frequent, sudden acceleration and braking.
- Shift gears in good time and use each gear only up to ¾ of its maximum engine speed.
- Switch off the engine when in stationary traffic for a prolonged time.
- Drive in a fuel-efficient manner. Pay attention to the ECO display for a fuelefficient driving style.

Environmental issues and recommendations

It is recommended to re-use and recycle substances instead of immediately disposing of them.

The relevant environmental guidelines and regulations serve to protect the environment and should be followed carefully.

Mercedes-Benz Genuine Parts



ENVIRONMENTAL NOTE Environmental damage caused by not using recycled reconditioned components

Mercedes-Benz AG offers recycled reconditioned components and parts with the same quality as new parts. The same entitlement from the Limited Warranty is valid as for new parts.

- Recycled reconditioned components and parts from Mercedes-Benz AG.
- I NOTE The effectiveness of the restraint systems can be impaired by installing accessory parts, performing repairs or welding operations

Airbags, Emergency Tensioning Devices as well as control units and sensors for the restraint systems can be installed in the following areas of the vehicle:

- · Door frames
- Roof frames
- Doors
- Door pillars
- Door sills
- Seats
- Cockpit
- Instrument cluster
- · Center console
- Do not install any accessories such as audio systems in these areas.
- Do not perform repairs or welding operations.
- Have accessory parts installed at a qualified specialist workshop.

If you use parts, tires, wheels or safety-relevant accessories which have not been approved by Mercedes-Benz, the operating safety of the vehicle may be jeopardized. Safety-relevant systems, e.g. the brake system, may malfunction. Only use Mercedes-Benz Genuine Parts or parts of equal quality. Use only tires, wheels and accessories that are approved for your vehicle model.

Mercedes-Benz tests genuine parts, conversion parts and accessory parts that have been approved for your vehicle model for reliability, safety and suitability. Despite ongoing market research, we are unable to assess other parts. We therefore accept no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been officially approved or independently approved by a testing center.

In some other countries, certain parts are only officially approved for installation or modification if they comply with legal requirements. All Mercedes-Benz Genuine Parts satisfy these requirements. Make sure that all parts are suitable for your vehicle.

Always specify the vehicle identification number (VIN) and the engine number when ordering Mercedes-Benz Genuine Parts (→ page 338).

Notes about attachments, add-on equipment, installations and conversions

For safety reasons, have add-on equipment produced and installed in accordance with the valid Mercedes-Benz body/equipment mounting directives. These body/equipment mounting directives ensure that the chassis and add-on equipment form one unit and that the greatest possible level of operational and driving safety is achieved.

Both vehicle manufacturers and body manufacturers must always ensure that the products they manufacture come into circulation only in a safe state and do not pose any risks to people. Otherwise, there may be consequences under civil, criminal or public law. All manufacturers are responsible for the products that they have manufactured. Manufacturers of attachments, add-on equipment, installations and conversions must guarantee compliance with Directive 2001/95/EC on general product safety.

Mercedes-Benz recommends the following procedure for safety reasons:

- · Do not make any other changes to the vehi-
- Obtain approval from the dealer named on the inside title page in the event of deviations from the approved body/equipment mounting directives.

Acceptance tests performed by public test bodies or official approvals do not rule out safety risks.

Observe the information about Mercedes-Benz Genuine Parts (\rightarrow page 21).

(i) You can obtain further information at a qualified specialist workshop.

WARNING Risk of accident and injury in the event of incorrect conversions or changes to the vehicle

Conversions or changes to the vehicle can impair the function of systems or components.

As a result, they may no longer function as intended and/or endanger the operating safety of the vehicle.

Always have conversions or changes to the vehicle made at a qualified workshop.

If you intend to make changes to your vehicle, Mercedes-Benz urgently recommends contacting the dealer, who will give you all the information you need. There may be a charge for this service.

If body manufacturers and dealers make modifications that affect the final inspection of the engine, vehicle or equipment, they must accept sole responsibility for the vehicle. This also applies to marking and documenting the vehicle parts affected by the changes that they make.

You are responsible for certifying and providing evidence that the following conditions are met:

- The vehicle complies with all relevant standards and regulations that are affected by the modification.
- The modified vehicle still meets the vehicle safety standards and emission regulations.
- The modification does not impair the safety of the vehicle.

Mercedes-Benz is not responsible for the final inspection, product liability or warranty claims resulting from modification. This applies for the following points:

- · the modified components or systems
- the resultant violation of emission regulations or vehicle safety standards
- all consequences resulting from the modified, less safe or even faulty vehicle

Mercedes-Benz accepts no responsibility as final manufacturer or for the resultant product liability.

Even seemingly minor changes to the vehicle, such as attaching a radiator grill in winter, are not permitted. Do not cover the radiator. Do not use any thermal mats, insect protection covers etc.

Otherwise, the values of the vehicle's diagnostic system will be distorted. Some of these values

are prescribed by law and must be correct at all times.

The factory equips the vehicle with a wooden or plastic cargo compartment floor; this is an integral part of the vehicle structure. If you have the cargo compartment floor removed, the vehicle body may be damaged. Load securing will then be impaired and the maximum loading capacity of the tie-down points will no longer be guaranteed. Therefore, do not have the cargo compartment floor removed

Notes on the partition

Without a partition, vehicles that are approved as commercial vehicles (N1, N2) do not fulfill ISO 27956, which describes the equipment for properly securing a load in delivery vehicles. If the vehicle is used to transport goods, retrofitting the partition is strongly recommended, as properly securing the load in vehicles without a partition will always be a complex operation.

Operating Instructions

These Operating Instructions describe all models, as well as standard and optional equipment of your vehicle that was available at the time of going to press. Country-specific differences are possible. Note that your vehicle may not be equipped with all functions described. This is also the case for systems and functions relevant to safety. Therefore, the equipment on your vehicle may differ from that in the descriptions and illustrations.

The original purchase agreement documentation for your vehicle contains a list of all the systems in your vehicle.

Should you have any questions concerning equipment and operation, consult an authorized Mercedes-Benz Center.

The Operating Instructions and Maintenance Booklet are important documents and should be kept in the vehicle.

Note on vehicles which are equipped by body manufacturers

Always observe the body manufacturer's Operating Instructions. You could otherwise fail to recognize dangers.

Service and vehicle operation

Warranty

The Limited Warranty for your vehicle is in accordance with the warranty terms and conditions in the Service and Warranty Information booklet.

Your authorized Mercedes-Benz Center will replace and repair all factory-installed parts in accordance with the terms of the following warranty terms and conditions:

- New Vehicle Limited Warranty
- Exhaust System Warranty
- Emission Systems Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control System Warranty
- State Warranty Enforcement Laws ("Lemon Laws")

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories Warranties.

These are available at any authorized Mercedes-Benz Center.

i Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. The new Service and Warranty Information booklet will be posted to you.

Vehicle operation outside the USA or Canada

When you are traveling abroad with your vehicle, observe the following points:

- service points or replacement parts may not be available immediately.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel can cause damage to the catalytic converter.
- the fuel may have a considerably lower octane number. Unsuitable fuel can cause engine damage.

Certain Mercedes-Benz models are available in Europe through the European Delivery Program.

For more information, please consult an authorized Mercedes-Benz Center, or write to one of the following addresses:

In the USA:

Daimler VANS USA, LLC European Delivery Department One Mercedes-Benz Drive Sandy Springs, GA 30328

In Canada:

Mercedes-Benz Canada, Inc. European Delivery Department 98 Vanderhoof Avenue Toronto. Ontario M4G 4C9

Maintenance information

Your customer service advisor will record every service for you in the Service and Warranty Information booklet

Information on Roadside Assistance

Roadside Assistance offers technical help in the event of a breakdown. Your calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-877-762-8267 (USA)

1-800-387-0100 (Canada)

You can find further information in the Roadside Assistance brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in the vehicle document wallet.

Information on changing address or owner

In the event of a change of address, please send us the "Notification of Address Change" in the Service and Warranty Information booklet or simply call the Customer Assistance Center (USA) at the hotline number 1-877-762-8267 or Customer Service (Canada) at 1-800-387-0100. This way, if necessary, we can reach you in a timely fashion.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner. If you have purchased a used vehicle, please send us the "Notification of Purchase of Used Car" in the Service and Warranty Information booklet or call the Customer Assistance Center (USA) at the hotline number 1-877-762-8267 or Customer Service (Canada) at 1-800-387-0100.

Possible danger due to substances hazardous to health

In compliance with Proposition 65 ("Prop65"), the following detachable label has been added to each vehicle sold in California:



WARNING



Operating, servicing and maintaining a passenger vehicle, pickup nuck, van or off-road motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-verifilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Wanings.ca, gov/passenger-vehicle.

Operating safety



WARNING Risk of accident due to malfunctions or system failures

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this could result in malfunctions or system failures.

 Always have the prescribed service/ maintenance work as well any required repairs carried out at a qualified specialist workshop.



WARNING Risk of accident and injury as a result of incorrect modifications to electronic component parts

Modification to electronic components, their software or wiring could impair their function and/or the function of other networked component parts. In particular, systems relevant to safety could also be affected.

As a result, they may no longer function as intended and/or endanger the operating safety of the vehicle.

- Never tamper with the wiring and electronic component parts or their software.
- You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

Observe the "Vehicle electronics" section in the "Technical data".

WARNING Risk of fire due to flammable materials on hot parts of the exhaust system

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system.

- When driving on unpaved roads or offroad, regularly check the vehicle underside
- Remove trapped plants or other flammable material.
- If there is damage, consult a qualified specialist workshop immediately.

I NOTE Damage to the vehicle

In the following situations, in particular, there is a risk of damage to the vehicle:

- The vehicle becomes grounded, e.g. on a high curb or an unpaved road
- The vehicle is driven too fast over an obstacle, e.g. a curb, speed bump or pothole
- A heavy object strikes the underbody or chassis components

In situations such as this, the body, the underbody, chassis components, wheels or tires could be damaged without the damage being visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, may not absorb the loads that arise as intended.

If the underbody paneling is damaged, flammable materials such as leaves, grass or twigs can collect between the underbody and the underbody paneling. These materials may ignite if they come into contact with hot parts on the exhaust system.

Have the vehicle checked and repaired immediately at a qualified specialist workshop.

or

If driving safety is impaired while continuing your journey, pull over and stop the vehicle immediately in accordance with the traffic conditions, and contact a qualified specialist workshop.

Diagnostics connection

The diagnostics connection is only intended for the connection of diagnostic devices at a qualified specialist workshop.

A

WARNING Risk of accident due to connecting devices to the diagnostics connection

If you connect equipment to a diagnostics connection in the vehicle, it may affect the operation of vehicle systems.

As a result, the operating safety of the vehicle could be affected.

Only connect the vehicle diagnostics connection to devices which have been tested with regard to their use and are considered safe.

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always install the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.

NOTE Battery discharging from using devices connected to the diagnostics connection

Using devices at the diagnostics connection drains the battery.

- Check the charge level of the battery.
- If the charge level is low, charge the battery, e.g. by driving a considerable distance.

Connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions inspection during the main inspection.

Notes on changes to the engine output

Output increases can:

- · change the emission values.
- · lead to malfunctions.
- result in consequential damage.

The operating safety of the engine is not guaranteed in all situations.

Any tampering with the engine management in order to increase the engine output will lead to the loss of the New Vehicle Limited Warranty and other warranty entitlements.

If you sell the vehicle, inform the buyer of any alterations to the vehicle's engine output. This may constitute a punishable offense under national legislation.

Qualified specialist workshop

A qualified specialist workshop has the necessary special skills, tools and qualifications to correctly carry out any necessary work on your vehicle. This particularly applies to safety-relevant works.

Always have the following work on the vehicle carried out at a qualified specialist workshop:

- · safety-relevant works
- service and maintenance work
- · repair work
- modifications as well as installations and conversions
- work on electronic components

Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose.

Vehicle registration

Mercedes-Benz may ask its service centers to carry out technical inspections on certain vehicles. The quality or safety of the vehicle is improved as a result of the inspection.

Mercedes-Benz can only inform you about vehicle checks if it Mercedes-Benz has your registration data.

In the following cases your vehicle may not be registered to you yet:

- You did not purchase your vehicle at an authorized specialist dealer.
- Your vehicle has not yet been inspected at an authorized Mercedes-Benz Center.

It is advisable to register your vehicle with an authorized Mercedes-Benz Center.

Inform Mercedes-Benz as soon as possible about any change in address or vehicle ownership.

You can do this, for example, at an authorized Mercedes-Benz Center.

Correct use of the vehicle

If you remove warning stickers, others may fail to recognize the dangers. Leave warning stickers in position.

Observe the following information in particular when operating the vehicle:

- Safety notes in these Operating Instructions
- · Technical data for the vehicle
- · Traffic rules and regulations
- Laws pertaining to motor vehicles and safety standards

Multi Purpose Vehicle

A

WARNING Risk of accident due to a high center of gravity

As a result of the high center of gravity the vehicle can skid or rollover in the event of abrupt steering movements and/or inappropriate speed.

Adapt the speed and the driving style to the driving characteristics of the vehicle as well as the prevailing road and weather conditions.

Utility vehicles have a significantly higher rollover rate than other types of vehicles.

If this vehicle is not operated in a safe manner it could result in an accident, rollover as well as to severe or fatal injuries.

In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.

You and all vehicle occupants should always wear a seat belt.

Information on problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified.

If the problem is not resolved to your satisfaction, please contact an authorized Mercedes-Benz Center again or write to one of the following addresses.

In the USA:

Daimler VANS USA, LLC Customer Assistance Center One Mercedes-Benz Drive Sandy Springs, GA 30328

In Canada:

Mercedes-Benz Canada, Inc. Customer Relations Department 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Reporting safety defects

USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Daimler VANS USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Daimler VANS USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to https://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590, USA.

You can find more information on vehicle safety at: https://www.safercar.gov

Canada only:

The following text is published as required of manufacturers under subsection 18.4 (4) of the Motor Vehicle Safety Regulations.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Transport Canada in addition to notifying Mercedes-Benz Canada Inc.

If Transport Canada received similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer or Mercedes-Benz Canada Inc.

To contact Transport Canada, you may call the Defect Investigations and Recalls Division toll-free in Canada at 1-800-333-0510 or 819-994-3328in the Gatineau-Ottawa area or internationally; you may also go to the following websites for more information:

- English: https://www.tc.gc.ca/recalls
- French: https://www.tc.gc.ca/rappels

Limited Warranty

NOTE Damage to the vehicle arising from violation of these operating instructions.

Damage to the vehicle can arise from violation of these operating instructions.

Such damage is not covered by either the Limited Warranty or the new or used-vehicle warranty.

Observe the instructions in these operating instructions on proper operation of your vehicle as well as regarding possible vehicle damage.

QR codes for rescue card

The QR code stickers are affixed to the B-pillar on the driver's and co-driver's side. In the event of an accident, emergency services can use the QR code to quickly determine the corresponding rescue card for your vehicle. The current rescue card contains, in compact form, the most important

information about your vehicle e.g. the routing of electric cables.

Further information can be obtained at https://www.mercedes-benz.de/gr-code.

Data storage

Electronic control units

Electronic control units are installed in your vehicle. Some of them are necessary for your vehicle to function safely, some provide support when driving (driver assistance systems). In addition, your vehicle offers comfort or entertainment functions which are also made possible with electronic control units.

Electronic control units contain data memories which can permanently or temporarily store technical information on the vehicle's operating state, component stress, service requirements as well as technical events and malfunctions.

This information generally documents the state of a component part, a module, a system or of the environment such as:

- operating statuses of system components (e.g. fluid levels, battery status, tire pressure)
- status messages concerning the vehicle and its individual components (e.g. number of wheel revolutions/speed, deceleration, lateral acceleration, display of the fastened seat belts)
- malfunctions or defects in important system components (e.g. lights, brakes)
- information on events in which the vehicle is damaged
- system reactions in special driving situations (e.g. airbag deployment, intervention of stability control systems)
- ambient conditions (e.g. temperature, rain sensor)

In addition to the provision of control unit functions, this data serves to recognize and rectify malfunctions as well as to optimize vehicle functions by the manufacturer. Most of this data is volatile and is only processed in the vehicle itself. Only a small proportion of the data is stored in event or fault memories.

When you use services, the technical data from the vehicle can be read out by service network employees (e.g. workshops, manufacturers) or third parties (e.g. breakdown services). Services include repair services, maintenance processes, warranty events and quality assurance measures, for example. The data is read out via the connection for the diagnostics connection in the vehicle, which is required by law. The respective service network locations or third parties collect, process and use the data. The data documents technical states of the vehicle, helps in finding errors and in improving quality and is transferred to the manufacturer if necessary. In addition, the manufacturer is subject to product liability. For this purpose, the manufacturer requires technical data from vehicles.

Fault memories in the vehicle can be reset by a service outlet during repairs or maintenance work

Depending on the equipment selected, you can enter data in comfort and infotainment functions of the vehicle.

This includes, for example:

- multimedia data, such as music, films or photos for playback in an integrated multimedia system
- address book data for use in an integrated hands-free system or an integrated navigation system
- · navigation destinations entered
- · data on the use of Internet services

This data can be saved locally in the vehicle or located on a device that you have connected to the vehicle (e.g. smartphone, USB memory stick or MP3 player). If this data is saved in the vehicle, you can delete it at any time. Transfer of this data to third parties only occurs on your request, especially as part of online services according to the settings you selected.

You can save convenience settings/customizations in the vehicle and change them at any time.

Depending on the equipment, this includes, for example:

- settings of the seat and steering wheel positions
- suspension and climate control settings
- · customizations such as interior lighting

If your vehicle is equipped appropriately, you can connect your smartphone or another mobile end device to the vehicle. You can operate these devices via the control elements integrated in the vehicle. The smartphone's picture and sound can be output via the multimedia system. Simultane-

ously, specific items of information are transferred to your smartphone.

Depending on the type of integration, this can include:

- · general vehicle data
- position data

This enables the use of selected smartphone apps, e.g. navigation or music playback. There is no additional interaction between the smartphone and the vehicle, particularly active access to vehicle data. Which type of further data processing occurs is determined by the provider of the specific app used. Which settings you can make, if any, depends on the specific app and the operating system of your smartphone.

Online services

Wireless network connection

If your vehicle has a wireless network connection, data can be exchanged between your vehicle and other systems. The wireless network connection is enabled via the vehicle's transmission and reception unit or via connected mobile end devices (e.g. smartphones). Online functions can be used via this wireless network connection. These include online services and applications/apps, which are provided by the manufacturer or by other providers.

Manufacturer's own services

In the case of the manufacturer's online services, the manufacturer describes the functions in a suitable place (e.g. operating instructions, manufacturer's website) and provides the associated information subject to data protection legislation. Personal identification data may be used to provide online services. The data exchange for this takes place via a secure connection, e.g. with the manufacturer's IT systems intended for the purpose. The collecting, processing, and use of personal identification data beyond the provision of services occurs exclusively on the basis of a legal permit or after due consent.

Generally, you can activate or deactivate the services and functions (partly subject to a fee). In some cases, this also applies to the whole data connection of the vehicle. Excluded from this are special legally prescribed functions and services.

Services of third parties

If it is possible to use online services from other providers, these services are subject to the data protection and terms of use of the responsible

provider. The manufacturer has no influence on the contents exchanged whilst using these services.

Please ask the respective service provider for details on the type, extent and purpose of the collection and use of personal data in the context of third party services.

Event Data Recorders

USA only:

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- · How fast the vehicle was traveling.

This data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and crash location) are recorded. However, other parties such as law enforcement could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

Access to the vehicle and/or the EDR is needed to read data that is recorded by an EDR, and special equipment is required. In addition to the vehicle manufacturer, other parties that have the special equipment, such as law enforcement, can read the information by accessing the vehicle or the EDR.

EDR data may be used in civil and criminal matters as a tool in accident reconstruction, accident claims and vehicle safety. Since the Crash Data Retrieval CDR tool that is used to extract data from the EDR is commercially available, Daimler Vans USA, LLC ("DVUSA") expressly disclaims any and all liability arising from the extraction of this information by unauthorized Mercedes-Benz personnel.

DVUSA will not share EDR data with others without the consent of the vehicle owners or, if the vehicle is leased, without the consent of the lessee. Exceptions to this representation include responses to subpoenas by law enforcement; by federal, state or local government; in connection with or arising out of litigation involving DVUSA or its subsidiaries and affiliates; or, as required by law.

Warning: The EDR is a component of the Restraint System Module. Tampering with, altering, modifying or removing the EDR component may result in a malfunction of the Restraint System Module and other systems.

State laws or regulations regarding EDRs that conflict with federal regulation are pre-empted. This means that in the event of such conflict, the federal regulation governs. As of December 2016, 17 states have enacted laws relating to EDRs.

Copyright

Information on free and open-source software

Information on license for free and open-source software used in your vehicle can be found on the data storage medium in your vehicle document wallet and with updates on the following website: https://www.mercedes-benz.com/opensource.

Information on registered trademarks

- Bluetooth[®] is a registered trademark of Bluetooth SIG Inc.
- DTS™ is a registered trademark of DTS, Inc.
- Dolby[®] and MLP[™] are registered trademarks of DOLBY Laboratories.
- BabySmart[™], ESP[®] and PRE-SAFE[®] are registered trademarks of Mercedes-Benz AG.
- HomeLink[®] is a registered trademark of Gentex Corporation.
- iPod[®] and iTunes[®] are registered trademarks of Apple Inc.
- Burmester® is a registered trademark of Burmester Audiosysteme GmbH.
- Microsoft[®] and Windows Media[®] are registered trademarks of Microsoft Corporation.

- SIRIUS[®] is a registered trademark of Sirius XM Radio Inc.
- HD Radio™ is a registered trademark of iBiquity Digital Corporation.
- Gracenote[®] is a registered trademark of Gracenote. Inc.
- ZAGATSurvey® and related brands are registered trademarks of ZagatSurvey, LLC.

Restraint system

Protection provided by the restraint system

The restraint system includes the following components:

- Seat belt system
- Airbags
- · Child restraint system
- Child seat securing systems

The restraint system can help prevent the vehicle occupants from coming into contact with parts of the vehicle interior in the event of an accident. In the event of an accident, the restraint system can also reduce the forces to which the vehicle occupants are subjected.

Only a seat belt which is worn correctly can provide the intended level of protection. Depending on the detected accident situation, Emergency Tensioning Devices and/or airbags supplement the protection offered by a correctly worn seat belt. Emergency Tensioning Devices and/or airbags are not deployed in every accident.

Vehicles with a co-driver bench seat: the Emergency Tensioning Device on the co-driver seat is triggered whether or not the seat belt tongue is engaged in the seat belt buckle.

In order for the restraint system to provide the intended level of protection, each vehicle occupant must observe the following information:

- · Fasten seat belts correctly.
- Sit in an almost upright seat position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.
- Always secure persons under 5 ft (1.50 m) tall in an additional restraint system suitable for this vehicle.

However, no system available today can completely eliminate injuries and fatalities in every accident situation. In particular, the seat belt and airbag generally do not protect against objects penetrating the vehicle from the outside. It is also not possible to completely rule out the risk of injury caused by the airbag deploying.

Limited protection from the restraint system

A

WARNING Risk of injury or death from modifications to the restraint system

The restraint system can no longer function correctly after alterations have been made.

The restraint system may then not protect the vehicle occupants as intended by failing in an accident or triggering unexpectedly, for example

- Never alter the parts of the restraint system.
- Never tamper with the wiring or any electronic component parts or their software

If it is necessary to adjust the vehicle to accommodate a person with disabilities, contact an authorized Mercedes-Benz Center for details.

USA only: contact our Customer Assistance Center at 1-877-762-8267.

Restraint system functionality

When the ignition is switched on, a self-test is performed, during which the prestraint system warning lamp lights up. It goes out no later than a few seconds after the vehicle is started. The components of the restraint system are then functional.

Restraint system malfunction


A malfunction has occurred in the restraint system in the following cases:

- The prestraint system warning lamp does not light up when the ignition is switched on.
- The prestraint system warning lamp lights up continuously or repeatedly during a journey.



WARNING Risk of injury due to malfunctions in the restraint system

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or may not deploy as intended during an accident. This may affect the Emergency Tensioning Devices or airbags, for example.



Function of the restraint system in an accident

How the restraint system works is determined by the severity of the impact detected and the type of accident anticipated:

- · Frontal impact
- · Rear impact
- Side impact
- Rollover

The activation thresholds for the components of the restraint system are determined based on the evaluation of the sensor values measured at various points in the vehicle. This process is preemptive in nature. The triggering/deployment of the components of the restraint system should take place in good time at the start of the collision.

Factors which can only be seen and measured after a collision has occurred cannot play a decisive role in airbag deployment. Nor do they provide an indication of airbag deployment.

The vehicle may be deformed significantly without an airbag being deployed. This is the case if only parts which are relatively easily deformed are affected and the rate of vehicle deceleration is not high. Conversely, an airbag may be deployed even though the vehicle suffers only minor deformation. If very rigid vehicle parts such as longitudinal members are hit, for example, this may result in sufficiently high levels of vehicle deceleration.

Depending on the detected deployment situation, the components of the restraint system can be activated or deployed independently of each other:

- Emergency Tensioning Device: frontal impact, rear impact, side impact¹⁾, rollover
- Driver's airbag, co-driver airbag: frontal impact
- Side airbag: side impact
- Window curtain airbag: side impact, rollover, frontal impact

A

WARNING Risk of burns from hot air bag components

The air bag parts are hot after an air bag has been deployed.

- Do not touch the air bag parts.
- Have a deployed air bag replaced at a qualified specialist workshop as soon as possible.

For your safety and that of your passengers, it is recommended that you have the vehicle towed to a qualified specialist workshop after an accident. Take this into account, particularly if an Emergency Tensioning Device has been triggered or an airbag has been deployed.

If the Emergency Tensioning Devices are triggered or an airbag is deployed, you will hear a bang, and a small amount of powder may also be released:

- The bang will not generally affect your hearing.
- In general, the powder released is not hazardous to health but may cause short-term breathing difficulties to persons suffering from asthma or other pulmonary conditions.

Provided it is safe to do so, leave the vehicle immediately or open the window in order to prevent breathing difficulties.

Airbags and pyrotechnic Emergency Tensioning Devices contain perchlorate material, which may require special handling or environmental protection measures. National guidelines must be observed during disposal. In California, see https://www.dtsc.ca.gov/HazardousWaste/Perchlorate/index.cfm.

Seat belts

Protection provided by the seat belt

Always fasten your seat belt correctly before starting a journey. Only a seat belt which is worn correctly can provide the intended level of protection.



WARNING Risk of injury or death due to incorrectly fastened seat belt

If the seat belt is not worn correctly, it cannot perform its intended protective function.

¹⁾ Only when the vehicle is equipped with a side airbag or window curtain airbag.

In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly.

Always observe the instructions about the correct driver's seat position and adjusting the seat $(\rightarrow page 64)$.

In order for the correctly worn seat belt to provide the intended level of protection, each vehicle occupant must observe the following information:

- . The seat belt must not be twisted and must fit tightly and snugly across the body.
- The seat belt must be routed across the center of the shoulder and as low down across. the hips as possible.
- The shoulder section of the seat belt should not touch your neck nor be routed under your arm or behind your back.
- Avoid wearing bulky clothing, e.g. a winter coat.
- Push the lap belt down as far as possible across your hips and pull tight with the shoulder section of the belt. Never route the lap belt across your abdomen.
 - Pregnant women must also take particular care with this.
- · Never route the seat belt across sharp, pointed, abrasive or fragile objects.
- Only one person should use each seat belt at any one time. Infants and children must never travel sitting on the lap of a vehicle occupant.
- Never secure objects with a seat belt if the seat belt is being used by one of the vehicle's occupants. Always observe the instructions for loading the vehicle when securing objects, luggage or loads (\rightarrow page 271).

Also ensure that no objects, e.g. a cushion, are ever placed between a person and the seat.

The seat belts on the following seats are equipped with a special seatbelt retractor:

- · Co-driver seat
- Rear seats

Activate or deactivate the special seatbelt retractor of the seat belt (\rightarrow page 40).

If children are traveling in the vehicle, always observe the instructions and safety notes on "Children in the vehicle" (\rightarrow page 37).

Limitations of the protection provided by the seat belt

WARNING Risk of injury or death due to incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In this case, you could slide underneath the seat belt and sustain abdominal or neck injuries. for example, particularly in the event of sudden braking or an accident.

- Adjust the seat properly before commencing your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.

WARNING Risk of injury or death when additional restraint systems are not used for persons with a smaller build

Persons under 5 ft (1.50 m) tall cannot wear the seat belt correctly without a suitable additional restraint system.

If the seat belt is not worn correctly, it cannot perform its intended protective function. In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

Always secure persons under 5 ft (1.50 m) tall in a suitable restraint system.

WARNING Risk of injury or death due to damaged or modified seat belts

Seat belts cannot provide protection in the following situations:

- The seat belt is damaged, has been modified, is extremely dirty, bleached or dyed
- · The seat belt buckle is damaged or extremely dirty
- · Modifications have been made to the Emergency Tensioning Device, seat belt anchorage or seat belt retractor

Seat belts may sustain non-visible damage in an accident, e.g. due to glass splinters.

Modified or damaged seat belts could tear or fail in the event of an accident, for example.

Modified Emergency Tensioning Devices may be deployed unintentionally or not function as intended.

- Never modify the seat belts, Emergency Tensioning Devices, seat belt anchorages or seat belt retractors.
- Make sure that the seat belts are not damaged, are not worn and are clean.
- Always have the seat belts checked immediately after an accident at a qualified specialist workshop.

Only use seat belts which have been approved for your vehicle by the sales organization named on the inside front cover.

WARNING Risk of injury or death from deployed pyrotechnic Emergency Tensioning Devices

Pyrotechnic Emergency Tensioning Devices that have been deployed are no longer operational and are unable to perform their intended protective function.

Therefore, have deployed pyrotechnic Emergency Tensioning Devices immediately replaced at a qualified specialist workshop.

For your safety and that of your passengers, it is recommended that you have the vehicle towed to a qualified specialist workshop after an accident.


NOTE Damage caused by trapping the seat belt

If an unused seat belt is not fully retracted, it may become trapped in the door or in the seat mechanism.

Always ensure that an unused seat belt is fully retracted.

Fastening and adjusting seat belts

If the seat belt is pulled quickly or sharply, the seat belt retractor locks. The seat belt strap cannot be pulled out any further.



- Always engage seat belt tongue 2 of the seat belt into seat belt buckle (1) of the corresponding seat.
- Press and hold the seat belt outlet release and slide seat belt outlet (3) into the desired
- Let go of the seat belt outlet release and ensure that seat belt outlet 3 locks into position.

Vehicles with single co-driver seat:

NOTE Deployment of the Emergency Tensioning Device when the front-passenger seat is unoccupied

If the seat belt tongue is engaged in the seat belt buckle of the unoccupied front-passenger seat, the Emergency Tensioning Device may also deploy in the event of an accident along with other systems.

Only one person should use each seat belt at any one time.

Releasing the seat belt

Press the release button in the seat belt buckle and guide the seat belt back with the seat belt tongue.

Function of the seat belt warning system for driver and co-driver

The 🚡 seat belt warning lamp in the Instrument Display reminds you that all vehicle occupants must fasten their seat belts correctly.

The seat belt warning lamp lights up for six seconds every time after switching on the ignition.

A warning tone may also sound.


After the vehicle is started, the seat belt warning goes out as soon as the driver's and the co-driver seat belts are fastened.

While driving, the seat belt warning lights up in the following cases:

- If the vehicle's speed is higher than 15 mph (25 km/h) and the driver's or co-driver's seat belt is not fastened
- If the driver or co-driver unfasten their seat belt during the journey

Airbags

Overview of airbags



- Oriver's airbag
- Window curtain airbag
- 3 Co-driver airbag
- Side airbag

An airbag's installation location is identified by the label AIRBAG.

When activated, an airbag can increase protection for the respective vehicle occupant.

Potential protection of each airbag:

	o o
AIRBAG	Possible protection for:
Driver's airbag, co-driver airbag:	Head and chest
Window curtain airbag	Head
Side airbag	Chest and pelvis

Protection by the airbags

Depending on the accident situation, an airbag may supplement the protection offered by a correctly fastened seat belt.

WARNING Risk of injury or death due to incorrect seat position

If you deviate from the correct seat position, the airbag cannot perform its intended protective function and deployment may even cause further injuries.

In order to avoid risks, each vehicle occupant must always make sure of the following:

- Fasten seat belts correctly. Pregnant women must take particular care to ensure that the lap belt never lies across the abdomen.
- Adopt the correct seat position and keep as far away as possible from the airbags.
- Observe the following information.
- Always make sure that there are no objects between the airbag and vehicle occupant.

To avoid the risks resulting from the deployment of an airbag, each vehicle occupant must observe the following information in particular:

- Before starting your journey, adjust your seat correctly, both the driver's and co-driver seat should be moved as far back as possible.
 - When doing so, always observe the information on the correct driver's seat position $(\rightarrow page 64)$.
- Only hold the steering wheel by the steering wheel rim. This allows the airbag to be fully deployed.
- Always lean against the seat backrest when the vehicle is in motion. Do not lean forwards or against the door or side window. You may

otherwise be in the deployment area of the airbags.

- · Always keep your feet on the floor. Do not put your feet on the cockpit, for example, Your feet may otherwise be in the deployment area of the airbag.
- If children are traveling in the vehicle, observe the additional notes (\rightarrow page 37).
- · Always stow and secure objects correctly.

Objects in the vehicle interior may prevent an airbag from functioning correctly. Each vehicle occupant must always make sure of the following in particular:

- There are no people, animals or objects between the vehicle occupants and an airbag.
- There are no objects between the seat, door and door pillar (B-pillar).
- There are no hard objects, e.g. coat hangers, hanging on the grab handles or coat hooks.
- There are no accessory parts, such as mobile navigation devices, mobile phones or cup holders, attached to the vehicle within the deployment area of an airbag, e.g. on the cockpit, on the door, on the side window or on the side wall trim.

In addition, no connecting cables, tensioning straps or retaining straps must be routed or attached to the vehicle within the deployment area of an airbag. Always comply with the accessory manufacturer's installation instructions and, in particular, the notes on suitable places for installation.

 There are no heavy, sharp-edged or fragile objects in the pockets of your clothing. Store such objects in a suitable place.

Limited protection provided by airbags

WARNING Risk of injury due to modifications to the airbag cover

If you modify the cover of an airbag or affix objects such as stickers to it, the airbag may no longer function correctly.

Never modify the cover of an airbag and do not affix objects to it.

An airbag's installation location is identified by the label AIRBAG (\rightarrow page 35).

WARNING Risk of injury or death due to the use of unsuitable seat covers

Unsuitable seat covers can obstruct or prevent the deployment of the airbags integrated into the seats.

Consequently, the airbags cannot protect vehicle occupants as they are designed to do.

Only use seat covers that have been approved for your vehicle by the sales organization named on the inside front cover.



WARNING Risk of injury due to malfunctions of the sensors in the door paneling

Sensors to control the airbags are located in the doors. Modifications or work not performed correctly to the doors or door paneling, as well as damaged doors, can lead to the function of the sensors being impaired. The airbags might therefore not function properly any more.

Consequently, the airbags cannot protect vehicle occupants as they are designed to do.

- Never modify the doors or parts of the doors.
- Always have work on the doors or door paneling carried out at a qualified specialist workshop.



WARNING Risk of injury due to deployed airbag

A deployed airbag no longer has a protective function and cannot protect as intended in the event of an accident.

Have the vehicle towed to a qualified specialist workshop in order to have the deployed airbag replaced.

Have deployed airbags replaced immediately.

Safely transporting children in the vehicle Always observe when children are traveling in the vehicle

(i) Always observe the safety notes relevant to the situation. In doing so, you will be able to identify possible risks and avoid dangers when children are traveling in the vehicle $(\rightarrow page 37)$.

Be consistent

Bear in mind that negligence when securing the child in the child restraint system may have serious consequences. Always be consistent and secure a child carefully before each journey.

To improve protection for children younger than 12 years old or under 5 ft (1.50 m) in height, Mercedes-Benz recommends you always observe the following notes:

- Always secure the child in a child restraint system suitable for your Mercedes-Benz vehicle.
- The child restraint system must be appropriate to the age, weight and size of the child.
- The vehicle seat must be suitable for the child restraint system to be installed.

Always install a child restraint system on a suitable rear seat. Accident statistics show that children secured on the rear seats are safer than children secured on the co-driver seat.

Accident statistics show that children secured on the rear seats are generally safer than children secured on the front seats. For this reason, Mercedes-Benz strongly advises that you install a child restraint system on a rear seat.

The generic term child restraint system

The generic term child restraint system is used in these Operating Instructions. A child restraint system is, for example:

- · A baby car seat
- · A rearward-facing child seat
- · A forward-facing child seat
- A child booster seat with a backrest and seat belt guides

The child restraint system must be appropriate to the age, weight and size of the child.

Observing laws and regulations

Always observe the legal requirements for using a child restraint system in the vehicle.

Observing the standards for child restraint systems

All child restraint systems must meet the following standards:

- U.S. Federal Motor Vehicle Safety Standards 213 and 225
- Canadian Motor Vehicle Safety Standards 213 and 210.2

Confirmation that the child restraint system corresponds to the standards can be found on an instruction label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system.

Detecting risks, avoiding danger

Securing systems for child restraint systems in the vehicle

Only use the following securing systems for child restraint systems:

- The LATCH-type (ISOFIX) securing rings
- The seat belt system of the vehicle
- The Top Tether anchorages

Installing a LATCH-type (ISOFIX) child restraint system is preferred.

Simply attaching to the securing rings on the vehicle can reduce the risk of installing the child restraint system incorrectly.

When securing a child with the integrated seat belt of the LATCH-type (ISOFIX) child restraint system, always comply with the permissible gross weight for the child and child restraint system (\rightarrow page 41).

A booster seat may be necessary to achieve proper seat belt positioning for children over 40 lbs (18 kg) until they reach a height where a three-point seat belt fits properly without a booster seat.

Mercedes-Benz recommends a child booster seat with a backrest and seat belt guides.

Advantage of a rearward-facing child restraint system

It is preferable to transport a baby or a small child in a suitable rearward-facing child restraint system. In this case, the child sits in the opposite direction to the direction of travel and faces backwards.

Babies and small children have comparatively weak neck muscles in relation to the size and weight of their head. The risk of injury to the cervical spine during an accident can be reduced in a rearward-facing child restraint system.

Always secure a child restraint system correctly

▲ WARNING Risk of injury or death caused by incorrect installation of the child restraint system

If the child restraint system is incorrectly installed on a suitable seating position, it cannot perform its intended protective function.

In particular, the child cannot be restrained in the event of an accident, heavy braking or a sudden change of direction.

- Always comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- Make sure that the entire base of the child restraint system always rests on the sitting surface of the seat.
- Never place objects, e.g. cushions, under or behind the child restraint sys-
- Always use child restraint systems with the original cover designed for them.
- Always replace damaged covers with genuine covers.

WARNING Risk of injury or death due to unsecured child restraint systems in the vehicle

If the child restraint system is not correctly installed or secured, it could release, in particular, in the event of an accident, sudden braking or a sudden change in direction.

The child restraint system could be flung around and hit vehicle occupants.

- Always install child restraint systems correctly, even when not in use.
- Always comply with the child restraint system manufacturer's installation instructions.
- Always observe the child restraint system manufacturer's installation and operating

instructions as well as the vehicle-specific information:

- Install the LATCH-type (ISOFIX) child restraint system on the rear seat (\rightarrow) page 41).
- Secure the child restraint system with the seat belt on the rear seat (\rightarrow page 42).
- Secure the child restraint system with the seat belt on the co-driver seat (→ page 43). Observe the specific instructions for the rearward-facing and forward-facing child restraint systems $(\rightarrow page 43)$.
- Observe the warning labels in the vehicle interior and on the child restraint system.
- Also secure Top Tether if present.

Do not modify the child restraint system

WARNING Risk of injury due to modifications to the child restraint system

The child restraint system may no longer function as it is supposed to if you make modifications or attach objects to it, e.g. toys or unsuitable accessories. This poses an increased risk of injury!

Never modify the child restraint system. Only attach accessories which the manufacturer of the child restraint system has authorized especially for this child restraint system.

Only use child restraint systems which are in proper working condition

WARNING Risk of injury or death caused by the use of damaged child restraint systems

Child restraint systems or their retaining systems that have been subjected to a load in an accident may then not be able to perform their intended protective function.

In particular, the child cannot be restrained in the event of an accident, heavy braking or a sudden change of direction.

- Always replace child restraint systems immediately that have been damaged or involved in an accident.
- ► Have the securing systems for the child restraint systems checked at a qualified specialist workshop before installing a child restraint system again.

Avoid direct sunlight

WARNING Risk of burns when the child seat is exposed to direct sunlight

If the child restraint system is exposed to direct sunlight or heat, parts could heat up. Children could suffer burns from these parts, particularly on metallic parts of the child restraint system.

- Always make sure that the child restraint system is not exposed to direct sunlight.
- Protect it with a blanket, for example.
- If the child restraint system has been exposed to direct sunlight, allow it to cool before securing a child into it.
- Never leave children unattended in the vehicle.

Observe when stopping or parking

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traffic.
- · Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- ► When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If people - particularly children - are exposed to extreme temperatures over an extended period of time, there is a risk of serious or even fatal injury.

- Never leave anyone particularly children - unattended in the vehicle.
- Never leave animals in the vehicle unattended.

Overview of suitable seats in the vehicle for installing a child restraint system

Securing systems for child restraint systems

Vehicle seat		
Left/right rear seat	Preferred securing system: LATCH-type (ISOFIX) child seat securing system (→ page 41) If available, also secure with Top Tether (→ page 42)	Alternative securing system: • Seat belt on vehicle seat
Co-driver seat	Securing system: • Seat belt on vehicle seat	
Center rear seat	Securing system: • Seat belt on vehicle seat If available, also secure with Top Tether (→ page 42)	

Activating/deactivating the special seatbelt retractor of the seat belt



MARNING Risk of injury or death if a seat belt is unfastened while the vehicle is in motion

If the seat belt is released while the vehicle is in motion, the child restraint system is no longer correctly secured. The child seat safety feature is deactivated and the seat belt is drawn in a bit by the inertia reel.

It is therefore not possible to engage the seat belt again.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- Activate the child seat safety feature again and correctly secure the child restraint system.

Requirements

When enabled, the special seatbelt retractor ensures that the seat belts on the co-driver seat and the rear seats do not slacken once the child restraint system is secured.

The seat belts on the following seats are equipped with a special seatbelt retractor:

- Co-driver seat
- Rear seats

Installing a child restraint system

- When installing a child restraint system, always observe the manufacturer's installation and operating instructions for the child restraint system used as well as the notes in these Operating Instructions.
- Pull the seat belt smoothly from the seat belt outlet.
- Engage the seat belt tongue in the seat belt buckle.

Activating the special seatbelt retractor

- Extend the seat belt fully and then allow the inertia reel to retract the belt. When the special seatbelt retractor is activated, you should hear a ratcheting sound.
- Push the child restraint system down until the seat belt is tight.

Deactivating the special seatbelt retractor

- Press the release button of the seat belt buckle.
- Hold the seat belt tongue and guide back to the seat belt outlet.

Attaching the child restraint system with LATCH-type (ISOFIX) to the rear seat

Installing a LATCH-type (ISOFIX) child restraint system on the rear seat

A

WARNING Risk of injury or death if the permissible gross mass of the child and child restraint system is exceeded

For LATCH-type (ISOFIX) child restraint systems in which the child is secured using the integrated seat belt in the child restraint system, the permissible gross mass of the child and child restraint system is 73 lb (33 kg).

If the child and the child restraint system together weigh more than 73 lb (33 kg), the LATCH-type (ISOFIX) child restraint system with integrated seat belt does not offer sufficient protection. An excessive load may be placed on the LATCH-type (ISOFIX) child seat attachments and the child may not be restrained in the event of an accident, for example.

- If the child and the child restraint system together weigh more than 73 lb (33 kg), use only a LATCH-type (ISOFIX) child restraint system that secures the child with the vehicle seat belt.
- Also secure the child restraint system with the Top Tether belt, if available.

Always comply with the information about the mass of the child restraint system:


- In the manufacturer's installation and operating instructions for the child restraint system used
- On a label on the child restraint system, if available

Check regularly that the permissible gross mass of the child plus the child restraint system is not exceeded.

When installing a child restraint system, observe the following:

- Always observe the correct use and suitability of the seats for attaching a child restraint system.
- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.

- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.
- When installing a LATCH-type (ISOFIX) child restraint system, also observe the following:
- When using a category 0/0+ baby car seat and a category I rearward-facing child restraint system on a rear seat: the rear seat must be installed in the direction of travel. Adjust the rear seat and/or front seat so that the front seat does not touch the child restraint system.
- When using a category I forward-facing child restraint system: the backrest of the child restraint system must, as far as possible, lie flat against the backrest of the vehicle seat.
- For certain child restraint systems of weight category II or III, there may be limitations for the maximum size setting, e.g. due to possible contact with the roof.
- The child restraint system must not be trapped between the roof and the seat and/or twisted when installed.
- The child restraint system must not be put under strain by the head restraints. Adjust the head restraints as appropriate.



LATCH-type (ISOFIX) mounting brackets

Before every journey, make sure that the LATCHtype (ISOFIX) child restraint system is engaged correctly in both mounting brackets in the vehicle.

- NOTE Be careful not to damage the seat belt for the center seat when installing the child restraint system
- Make sure that the seat belt is not trapped.
- Attach the LATCH-type (ISOFIX) child restraint system to both mounting brackets in the vehicle.

Securing Top Tether


WARNING Risk of injury due to incorrect attachment of the Top Tether belt

If you attach the Top Tether belt incorrectly, e.g. on an eyelet in the cargo compartment, the child restraint system will not have been secured correctly.

In an accident, it will therefore be unable to provide the intended level of protection.

- Only ever attach the Top Tether hook to the designated Top Tether anchorage.
- If the child restraint system is equipped with a Top Tether belt:

The risk of injury can be reduced by Top Tether. The Top Tether belt enables an additional connection between the child restraint system attached with LATCH-type (ISOFIX) and the vehicle.





- If necessary, move the head restraint upwards (→ page 75).
- Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Comply with the child restraint system manufacturer's installation instructions when doing so.
- Guide Top Tether belt (3) under the head restraint between the two head restraint bars.
- ► Hook Top Tether hook ② into Top Tether anchorage ① without twisting.
- Tension Top Tether belt ③. Comply with the child restraint system manufacturer's installation instructions when doing so.
- If necessary, slide the head restraint downwards (→ page 75). Make sure that you do not interfere with the correct routing of Top Tether belt ③.

Securing the child restraint system with the seat belt

Securing the child restraint system with the seat belt on the rear seat

When installing a belt-secured child restraint system, observe the following:

- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- When using a category 0/0+ baby car seat and a category I rearward-facing child restraint system on a rear seat: adjust the front seat so that the seat does not touch the child restraint system.
- When using a category I forward-facing child restraint system: remove the head restraint from the respective seat, if possible.

After the child restraint system has been removed, replace the head restraints immediately and adjust them correctly.

- The backrest of the forwards-facing child restraint system must, as far as possible, rest on the backrest of the rear seat.
- For certain child restraint systems of weight category II or III there may be limitations for the maximum size setting, e.g. due to possible contact with the roof.
- ▼ The child restraint system must not be tensioned between the roof and the seat cushion and/or be installed facing the wrong direction. Where possible, adjust the seat cushion inclination accordingly.
- The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.

The seat belts on the following seats are equipped with a special seatbelt retractor:

- · Co-driver seat
- Rear seats

When enabled, the special seatbelt retractor ensures that the seat belts on the co-driver seat and the rear seats do not slacken once the child restraint system is secured. (\rightarrow page 40).

- Install the child restraint system. The base of the child restraint system must lie fully on the seat cushion of the rear seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.

The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.

Notes on rearward-facing child restraint systems

The co-driver front airbag cannot be disabled. Always install a rearward-facing child restraint system on a suitable rear seat, but never on the co-driver seat. Observe the manufacturer's installation and operating instructions for the child restraint system used.

Notes on a child restraint system on the codriver seat

Accident statistics show that children secured on the rear seats are safer than children secured on the front seats. For this reason, Mercedes-Benz strongly advises that you install a child restraint system on a rear seat.

Securing the child restraint system with the seat belt on the co-driver seat

When installing a belt-secured child restraint system on the co-driver seat, always observe the following:

- Observe the manufacturer's installation and operating instructions for the child restraint system used.
- ▼ The backrest of a forward-facing child restraint system must, as far as possible, lie flat against the backrest of the co-driver seat.
- For certain child restraint systems of weight category II or III there may be limitations for the maximum size setting, e.g. due to possible contact with the roof.
- The child restraint system must not be tensioned between the roof and the seat cushion and/or be installed facing the wrong direction.
- The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- Never place objects under or behind the child restraint system, e.g. cushions.

The seat belt on the co-driver side is equipped with a special seatbelt retractor.

When enabled, the special seatbelt retractor ensures that the seat belt does not slacken once the child restraint system is secured $(\rightarrow page 40)$.

- Set the co-driver seat as far back as possible and move the seat into the highest position possible.
- Fully retract the seat cushion depth adjustment.
- Set the seat cushion angle in such a way that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.
- Set the seat backrest to the most vertical position possible.
- Install the child restraint system. The base of the child restraint system must lie fully on the co-driver seat cushion.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of

the vehicle to the shoulder belt guide on the child restraint system.

The shoulder belt strap must be routed forwards and downwards from the seat belt outlet

If necessary, adjust the seat belt outlet and the co-driver seat as appropriate.

Child safety locks

Activating/deactivating child safety locks for the doors

▲ WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- Get out and be struck by oncoming traffic.
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.

▲ WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If people – particularly children – are exposed to extreme temperatures over an extended period of time, there is a risk of serious or even fatal injury.

- Never leave anyone particularly children unattended in the vehicle.
- Never leave animals in the vehicle unattended.

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are traveling in the vehicle, they could, in particular:


- Open doors, thereby endangering other persons or road users
- Get out and be struck by oncoming traffic
- Operate vehicle equipment and become trapped, for example
- Always activate the child safety locks installed if children are traveling in the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

The following doors have child safety locks:

Sliding doors

The child safety locks on the doors secure each door separately. The doors can no longer be opened from the inside (exception: electric sliding door). When the vehicle is unlocked, the door can be opened from the outside.

If the electric sliding door is secured, only the sliding door controls in the rear compartment are deactivated. The electric sliding door can be opened at any time using the switch in the center console



Example: sliding door child safety lock

Slide child safety lock bolt 1 to position 2 (activate) or 3 (deactivate).

Make sure that the child safety locks are working properly.

Notes on pets in the vehicle

A

WARNING Risk of accident and injury due to animals left unsecured or unattended in the vehicle

If you leave animals in the vehicle unattended or unsecured, they could possibly press down buttons or switches.

Thereby an animal may:

- activate vehicle equipment and become trapped, for example
- switch systems on or off and endanger other road users

Unsecured animals may be thrown around in the vehicle in the event of an accident or sudden steering and braking maneuver and injure vehicle occupants in the process.

- Never leave animals in the vehicle unattended.
- Always correctly secure animals while driving, for example using a suitable animal carrier.

SmartKey

Notes on radio connections of the key

DANGER Risk of fatal injury to persons with medical devices from the electromagnetic radiation of the start/stop but-


Persons with medical devices, e.g. pacemakers or defibrillators:

When you operate the start/stop button, a radio connection is established between the key and the vehicle.

The electromagnetic radiation can affect the functionality of a medical device.

Before operating the vehicle, consult your doctor or the manufacturer of the medical device about any possible effects of emissions from such systems.

Detection range of antenna of KEYLESS-START function



Overview of key functions

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traf-
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle
- ► When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.
- NOTE Damage to the key caused by mag-
- Keep the key away from strong magnetic fields.



- To lock
- Battery check lamp
- To unlock
- 4 To unlock cargo compartment (sliding doors and rear-end doors)/to unlock and open/ close electric sliding doors
- 6 Emergency key

The key's factory setting enables you to centrally lock and unlock the following components:

- the driver's door and the co-driver's door
- the sliding doors
- the rear-end doors
- (i) If you do not open the vehicle within approximately 40 seconds of unlocking, the vehicle will lock again and anti-theft protection will be armed again.

Do not keep the key together with electronic devices or metallic objects. This can affect the key's functionality.

i If the battery check lamp does not light up when you press the o button, the battery is discharged.

Replace the key battery (\rightarrow page 47).

Activating/deactivating the acoustic locking verification signal

Multimedia system:

→ 😭 >> Settings >> Vehicle

Activate or deactivate Acoustic Lock.

Changing the unlocking settings

The key has the following adjustable unlocking functions:

- Unlock centrally
- Unlock the driver's door (vehicles without partition or with cab)
- Unlock the driver's door and co-driver's door (vehicles with partition)
- ➤ To switch between the settings: press and hold the and buttons at the same time for approximately six seconds until the battery check lamp flashes twice.

When the unlocking function is selected for the driver's door or the driver's and co-driver door:

Pressing the button a second time unlocks the vehicle centrally


Reducing the energy consumption of the SmartKey

If you do not use the vehicle or a SmartKey for an extended period, you may deactivate the KEY-LESS START function of the SmartKey.

- To deactivate: press the button on the SmartKey twice in quick succession. The battery check lamp on the SmartKey lights up twice quickly and once for longer.
- ► To activate: press any button on the Smart-Key.

When starting the vehicle with the SmartKey in the slot in the shift console, the SmartKey functions are activated automatically.

Removing and inserting the mechanical key



- ► To remove: press release button ②.

 Mechanical key ① is pushed slightly out.
- Pull mechanical key 1 out completely.
- To insert: press release button 2.
- ➤ Slide mechanical key ① in completely until it engages.

Replacing the key battery

DANGER Serious damage to health caused by swallowing batteries

Batteries contain toxic and corrosive substances. Swallowing batteries may cause serious damage to health.

There is a risk of fatal injury.

- Keep batteries out of the reach of children.
- If batteries are swallowed, seek medical attention immediately.

ENVIRONMENTAL NOTE Environmental damage caused by improper disposal of batteries

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.

Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

Requirements:

• A CR 2032 3 V cell battery

Mercedes-Benz recommends that you have the battery replaced by a qualified specialist workshop.

 \triangleright Remove the emergency key (\rightarrow page 47).



Example image


- Press release button ② down fully and slide cover ① forward.
- Remove battery compartment ③ and remove the discharged battery.
- Insert the new battery into battery compartment (a). Observe the positive pole marking in the battery compartment and on the battery.
- Insert battery compartment 3.
- Replace cover ① so that it engages.
- Slide the emergency key in completely until it engages (→ page 47).

Problems with the key

Problem	Possible causes/consequences and ▶ Solutions
You cannot lock or unlock the vehicle any more.	Possible causes: • the key battery is weak or discharged • there is interference from a powerful source of radio waves • the key is defective Check the battery using the battery check lamp and replace if necessary (→ page 47). Use the emergency key to unlock and lock the vehicle (→ page 47). Have the key checked at a qualified specialist workshop.
You have lost a key.	Have the key deactivated at a qualified specialist workshop.If necessary, have the mechanical locks replaced.


Doors

Unlocking and opening the door from inside



- To unlock and open the front door: pull door handle ②.

 Locking pin ① pops up when the door is unlocked.
- Open the door.



The symbol indicates that the rear door is unlocked.

➤ To unlock and open the rear door: pull opening lever ① and open the rear door. When the door unlocks, latch ② moves forward.

The symbol is visible.

- **To close:** pull the rear door closed by the door handle.
- To lock: slide latch ② down.
 The 📦 symbol is visible.

Locking the door centrally from inside

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- Get out and be struck by oncoming traffic.
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · Releasing the parking brake.
- Changing the transmission position.
- · Starting the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.
- ★ WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle


If people – particularly children – are exposed to extreme temperatures over an extended period of time, there is a risk of serious or even fatal injury.

- Never leave anyone particularly children unattended in the vehicle.
- Never leave animals in the vehicle unattended.

Locking and unlocking manually

You can use the central locking buttons to centrally lock and unlock the entire vehicle from the inside.

The central locking buttons are located in the driver's and co-driver's doors.




Example: central locking buttons in the driver's door

➤ To lock/unlock the entire vehicle: press button () (unlock) or () (lock) when the doors are closed.

Switching the automatic locking feature on/off

When the ignition is switched on and the vehicle is driving at a speed above 9 mph (15 km/h), the vehicle locks automatically.



Example: central locking buttons in the driver's door


There is a danger of being locked out when the function is activated in the following situations:

- . When tow-starting or pushing the vehicle
- · On the roller dynamometer
- When the doors are closed, switch on the power supply or ignition.

- To switch on: press and hold button ② for approximately five seconds. An acoustic signal sounds.
- To switch off: press and hold button for approximately five seconds. An acoustic signal sounds.

Unlocking/locking the driver's door with the emergency key

(i) If you want to lock the vehicle completely with the emergency key, press the button for the locking mechanism from inside first with the driver's door open. Then lock the driver's door with the emergency key.




- To unlock: turn the emergency key counterclockwise to position 1.
- To lock: turn the emergency key clockwise to position 1.
- i Right-hand drive vehicles: turn the emergency key in the opposite direction in each case.


Using the grab handles when getting into and out of the vehicle

The entrances on buses are equipped with grab handles and steps.

- (i) To avoid risks:
 - When getting into and out of the vehicle, only use the grab handles and steps. Only they are designed for such a load.
 - Keep steps and entry sills free from dirt,
 e.g. mud, clay, snow and ice.



Getting into and out of the vehicle (example: front door)



Getting into and out of the vehicle (example: sliding door)

When getting into and out of the vehicle, use grab handles and steps.

Sliding door


Opening/closing the sliding door from outside

WARNING Risk of entrapment by open sliding door which is not engaged

If the open sliding door is not engaged, it could move on its own if the vehicle is on a slope.

This could trap you or other persons.

Always make sure that the open sliding door is engaged. Open the sliding door as far as it will go.




- (i) Your vehicle may be equipped with a long sliding door with an intermediate detent. You can also lock the sliding door in place around halfway when opening and closing. If you do this, the door does not have to be opened fully when getting into or out of the vehicle. The sliding door is not fully engaged when in the intermediate detent.
- To open: pull door handle ①. The sliding door opens.
- Push back the sliding door using door handle until it engages.
- Check the sliding door detent.
- ➤ To close: pull the sliding door by handle ① and firmly slide it forwards until it closes.

Opening/closing the sliding door from inside

WARNING Risk of entrapment by open sliding door which is not engaged

When you open the sliding door, the sliding door could hit other people as it moves backwards.

Only open the sliding door when traffic conditions permit.



- (i) Your vehicle may be equipped with a long sliding door with an intermediate detent. You can also lock the sliding door in place around halfway when opening and closing. If you do this, the door does not have to be opened fully when getting into or out of the vehicle. The sliding door is not fully engaged when in the intermediate detent.
- To unlock: pull locking pin (a) upwards manually or use the central locking button to unlock the sliding door (→ page 49).
- ► To open: press button ①.
- Slide the sliding door by handle ② back to the stop.
- Check the sliding door detent. The sliding door must be engaged.
- To close: press button 1.
- Slide the sliding door firmly forwards by handle until it closes.
- To lock: push locking pin ③ downwards manually or use the central locking button to lock the sliding door (→ page 49).

Notes on electrical closing assist

If your vehicle is equipped with an electrical closing assist, you will require less force to close the sliding door.

Electric sliding door

Function of the electric sliding door

Your vehicle can be equipped with an electric sliding door on the left and/or right-hand side.

You can operate the electric sliding door in the following ways:

- by pressing the sliding door buttons on the center console
- by pressing the sliding door button on the door sill (B-pillar)
- using the door handle (inside or outside)
- using the key

If the electric sliding door is obstructed while opening, it moves a few centimeters in the opposite direction and stops.

If the sliding door is obstructed during the closing procedure, it opens fully again.

If the electric motor of the sliding door is in danger of overheating, e.g. due to frequent opening and closing within a short period, the sliding door opens fully. The sliding door is then locked in place. The sliding door is operational again after approximately 30 seconds.

If there has been a malfunction or if the battery has been disconnected, you can use the release catch to disconnect the sliding door from the electric motor. Then you can open or close the door manually (\rightarrow page 54).

Opening/closing the electric sliding door with the button

WARNING Risk of entrapment by open sliding door which is not engaged

When you open the sliding door, the sliding door could hit other people as it moves backwards.

Only open the sliding door when traffic conditions permit.

WARNING Risk of injury despite obstacle detection

Obstacle detection does not react to soft, light and thin objects, such as fingers. These or other parts of the body could be pressed against the door frame, for instance. Obstacle detection cannot prevent entrapment in these instances.


When opening and closing the electric sliding door, make sure that nobody is within the operating range of the sliding door.



If someone becomes trapped, press the button again to stop the sliding door.

Object recognition:

If an object obstructs the closing of the sliding door, the sliding door is stopped. The object recognition is only an aid. It cannot replace your awareness of the situation.




Sliding door button on the center console

Opens and closes the sliding door on the right side of the vehicle



Sliding door button on the door sill (B-pillar)
On vehicles with a partition, button (3) is located on the partition next to the doorway at the level of the inside door handle.



When the sliding door is locked, it can only be opened from the inside by manually unlocking locking pin (a).

- To unlock: pull locking pin upwards manually or use the central locking button to unlock the sliding door (→ page 49).
- To open: briefly press button (1), (2) or button (3).

The sliding door opens automatically.

When you open the door using button ① or ②, you will additionally hear two warning signals.

The indicator lamp at the top of button ① or ② will flash and button ③ will flash.

When the sliding door is completely open, the indicator lamp at the top of button (1) or (2) will light up.

To close: briefly press button (1), (2) or button (3).

The sliding door closes automatically.

When you close the door using button ① or ②, you will additionally hear two warning signals.

The indicator lamp at the top of button ① or ② will flash and button ③ will flash.

When the sliding door is completely closed, the indicator lamp at the top of button ① or ② will go out.

➤ To stop automatic operation: briefly press button (1) or (2).

The sliding door stops moving.

To lock: push locking pin (3) downwards manually or use the central locking button to lock the sliding door (→ page 49).

- i When you stop automatic operation upon opening the door, the door closes when you press the button again.
- i In unfavorable operating conditions, e.g. frost, ice or heavy soiling, you can press and hold the corresponding button. The electric sliding door moves with increased force.

 Observe that, in such circumstances, the object recognition is less sensitive. To stop the movement, release the button.


Opening/closing the electric sliding door with the key


- To unlock: briefly press the or button on the key.
- ➤ To open: press and hold the press and hold the press and hold the press of the button on the key for longer than 0.5 seconds.

You will hear two acoustic signals and the sliding door will open automatically.

- To close: press and hold the or button on the key for longer than 0.5 seconds.
 - You will hear two acoustic signals and the sliding door will close automatically.
- ➤ To interrupt automatic operation: briefly press the ☐ or ☐ button on the key. The sliding door stops moving.
- i When you stop automatic operation upon opening the door, the door closes when you press the button again.

Opening/closing the electric sliding door with the door handle






- To unlock: pull locking pin ② upwards manually or use the central locking button to unlock the sliding door (→ page 49).
- Press button (1) or pull outside handle (3). The sliding door opens or closes.
- Press button **(1)** again or pull outside handle **(3)**.

The sliding door stops moving.

Unlocking the electric sliding door manually



If there has been a malfunction or if the battery has been disconnected, you can use release catch ② to disconnect the sliding door from the electric motor. Then, you can open or close the door manually.

Vehicles with complete sliding door trim: remove the cover from release catch 2. Service operation is accessible.

➤ To disconnect the sliding door from the electric motor: turn release catch ② 180° clockwise.

The "MAN" position is set.

- To unlock: pull locking pin (a) upwards manually or use the central locking button to unlock the sliding door (→ page 49).
- Press button ①.
- Open or close the sliding door with the outside/inside door handle.
- ➤ To connect the sliding door to the electric motor: turn release catch ② 180° counterclockwise.

The "AUTO" position is set.

- Adjust the sliding door (→ page 55).
- If it is not possible to rectify the malfunction, visit a qualified specialist workshop.

Resetting the electric sliding door



Sliding door button on the center console Sliding door button on the center console

Opens and closes the sliding door on the right side of the vehicle



Sliding door button on the door sill (B-pillar)

You must reset the sliding door if there has been a malfunction or a voltage supply interruption.

If the sliding door is open: press button (1) on the center console or sliding door button (3) on the door sill (B-pillar) and hold until the door is closed.

or

- Close the sliding door with the door handle (→ page 54).
- Then briefly press button on the center console or sliding door button on the door sill (B-pillar) once, or pull the door handle (→ page 54) to completely open the sliding door.

The sliding door is operational.

Rear-end doors

Opening and closing the rear-end doors from outside

★ WARNING Risk of accident and injury when opening the rear-end door in poor traffic conditions


When you open a rear-end door, the following is possible:

- Other people or road users may be endangered
- You may be caught by oncoming traffic

This is particularly the case if you open the rear-end door more than 90°.


- Only open the rear-end doors when traffic conditions permit.
- Always make sure that the rear-end doors are properly locked.

Opening the right rear-end door



- Pull handle ①.
- Swing the rear-end door to the side until it engages.

Opening the left rear-end door



- Make sure that the right rear-end door is open and engaged.
- ► Pull release handle in the direction of the
- Swing the rear-end door to the side until it engages.


Opening the rear-end doors fully

- Open the relevant rear-end door out past the first detent (90°).
- Open the rear-end door fully. The rear-end door will stay in the stop position.

Closing the rear-end doors from outside

- Close the left rear-end door firmly from outside.
- Close the right rear-end door firmly from outside.

Opening/closing the rear-end doors from the inside



The symbol indicates that the rear-end door is unlocked.

- To unlock: slide latch 2 to the left. The symbol is visible.
- To open: pull opening lever up and open the rear-end door.
- Swing the rear-end door to the side until it engages.
- To close: make sure that the left rear-end door is closed.
- Pull the right rear-end door firmly closed by the door handle.
- To lock: slide latch 2 to the right The symbol is visible.

Partition sliding door


Opening and closing the partition sliding door from the driver's compartment

WARNING Risk of becoming trapped due to non-engaged partition sliding door

If the open partition sliding door is not engaged, it can move on its own while the vehicle is in motion.


This can cause you or other people to become trapped.

 Before driving, always close the partition sliding door and ensure that it is engaged.



- To open: turn the key counter-clockwise (3). The sliding door is unlocked.
- Slide the sliding door to the right ② as far as it will go.
- To close: slide the sliding door to the left until it engages.
 You can lock the sliding door with the key.

Opening and closing the partition sliding door from the cargo compartment




- ➤ **To open:** push the lever to the right ③. The sliding door is unlocked.
- Slide the sliding door to the left as far as it will go.

- To close: slide the sliding door to the right
 - 2 until it engages.

Electrical step

Function of the electrical step



Your vehicle's sliding door may be equipped with an electrical step.

Electrical step ① automatically extends when the sliding door opens, and retracts after the sliding door closes. Electrical step ① is equipped with obstacle detection at the front. If the step meets an obstacle while extending, it stops. Once you have removed the obstacle, you must first close the sliding door then re-open it so that the step extends completely.

If the electrical step prevents loading, you can block it via obstacle detection when the sliding door opens. The electrical step then remains retracted and a fork-lift truck or other lifting vehicle can move closer to the cargo compartment.

The display shows the Step Not Extended See Operator's Manual message or the step not extended malfunction message.


When the ignition is switched off, a warning tone will sound if obstacle detection is blocked. The tone lasts for two minutes.


When the ignition is switched on, the warning tone will sound continuously.

If electrical step (a) is malfunctioning, the step may not extend or retract, or do so only partially.

After a malfunction occurs, you must retract and lock the electrical step \bigcirc manually in order to continue your journey (\rightarrow page 58). Before passengers exit the vehicle, inform them that electrical step \bigcirc may be missing.


Releasing the electrical step in an emergency (manual retraction)






If the electrical step does not automatically retract, you must manually retract the step and lock it in order to continue driving.

- On the underside of step ② on both bars ① remove the spring cotters ③ from the pin.
- Remove the washers (4) and detach both bars.



- Fold bars 1 into the step's housing.
- Slide the step into its housing.
- (i) When securing the step for the first time, you must puncture a foil with the spring cotters.



On both sides, insert spring cotters through the housing's holes and into the step as far as they will go.
The step has been secured in its housing.

Side window

Opening and closing the side windows

WARNING Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

When opening, make sure that nobody is touching the side window.


- If someone is trapped, release the button immediately or pull it in order to close the side window again.
- **WARNING** Risk of becoming trapped when closing a side window

When closing a side window, body parts could be trapped in the closing area in the process.

- When closing, make sure that no body parts are in the closing area.
- If someone is trapped, release the button immediately or press the button in order to reopen the side window.
- **WARNING** Risk of becoming trapped when children operate the side windows

Children could become trapped if they operate the side windows, particularly when unattended.

- Activate the child safety lock for the rear side windows.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle.



- Window lifter, left
- Window lifter, right
- To open manually: press and hold button or ...
- To close manually: pull and hold button or ②.

The windows in the front doors can also be operated automatically.

- ➤ To open completely: briefly press button or obeyond the point of resistance. Automatic operation will start.
- ➤ To close completely: briefly pull button
 or ② beyond the point of resistance.

 Automatic operation will start.
- ➤ To interrupt automatic operation: briefly press or pull button ① or ② again.
- i If an object blocks a side window during the automatic closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.
- i If automatic operation of the side windows does not work, there is no anti-entrapment function.

Automatic reversing function of the side windows

If an object blocks a side window during the closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

During the closing process, make sure that no body parts are in the closing area.

WARNING Risk of becoming trapped despite there being reverse protection on the side window

The reverse function does not react:

- To soft, light and thin objects, e.g. fingers
- Over the last 1/6 in (4 mm) of the closing path
- · During resetting
- When the side window is closed again manually immediately after automatic reversing

This means that the reverse function cannot prevent someone from becoming trapped in these situations.

- During the closing process, make sure that no body parts are in the closing area.
- If someone becomes trapped, press the

 button to open the side window again.

Ventilating the vehicle before starting a journey (convenience opening)

★ WARNING Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- Release the button immediately if somebody becomes trapped.

You can ventilate the vehicle before you start driving.

To do this, the key is used to carry out the following functions simultaneously:

- · unlock the vehicle
- open the side windows

The "convenience opening" function can only be operated using the key. The key must be in close proximity to the driver's or front-passenger door.

- Press and hold the button on the key.
 - The following functions are performed:
 - · the vehicle is unlocked
 - the side windows are opened
- To interrupt convenience opening: release the button.

Closing side windows from the outside (convenience closing)



WARNING Risk of entrapment caused by inadvertent convenience closing

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side windows.

- Observe the complete closing procedure when using convenience closing.
- When closing, make sure that no body parts are in the closing area.
- Press and hold the button on the key. The following functions are performed:
 - The vehicle is locked
 - The side windows are closed

To interrupt convenience closing: release the button.

Resetting the side windows

The side windows must be reset after a malfunction or a voltage supply interruption.

- Switch on the ignition (\rightarrow page 109).
- Push both window lifter buttons and hold for approximately one second after the side window has closed.

Problems with the side windows

Problem

Possible causes / consequences and ▶ Solutions

A side window cannot be closed and the cause is not obvious.

Check to see if there are any objects in the window guide.

WARNING Risk of becoming trapped or fatally injured if reversing protection is not activated

If you close a side window again immediately after it has been blocked, the side window will close with increased or maximum force. The reversing feature will then not be active.

Parts of the body could become trapped in the closing area in the process.

- Make sure that no parts of the body are in the closing area.
- To stop the closing process, release the button or press the button again to re-open the side window.

If a side window is obstructed during closing, and reopens again slightly, vou can proceed as follows:

Immediately after the window is obstructed, pull the corresponding button again until the side window has closed, and hold the button for an additional second.

The side window is closed with increased force

If the side window is obstructed again and reopens slightly, you can proceed as follows:

- Repeat the previous step.
 - The side window is closed without the automatic reversing function.

The side windows cannot be opened or closed using the convenience opening feature.

The SmartKey battery is weak or discharged.

Check the battery with the battery check lamp and replace if necessary (\rightarrow page 47).

Anti-theft protection

Function of the immobilizer

The immobilizer prevents your vehicle from being started without the correct key.

The immobilizer is automatically activated when the ignition is switched off, and deactivated when the ignition is switched on.

When leaving the vehicle, always take the key with you and lock the vehicle. If the key is left inside the vehicle, anyone can start the engine.

(i) In the event the engine does not start despite the vehicle's starter battery having sufficient charge, the immobilizer is defective. Contact a qualified specialist workshop or call 1-800-367-6372 (in the USA) or 1-800-387-0100 (in Canada).

ATA (Anti-Theft Alarm system)


Function of ATA (Anti-theft Alarm system)

If the ATA system is armed, a visual and audible alarm is triggered in the following situations:

- a side door is opened
- · the rear-end door is opened
- the hood is opened
- · the interior motion sensor is triggered $(\rightarrow page 63)$
- · the tow-away alarm is triggered $(\rightarrow page 62)$

ATA is automatically armed after approximately five seconds in the following situation:

 after the vehicle has been locked with the SmartKey



When the ATA system is armed, indicator lamp

(1) flashes in the overhead control panel.

ATA is automatically deactivated in the following situations:


- After unlocking the vehicle with the Smart-Key.
- After pressing the start/stop button with the SmartKey inside the vehicle.

Arming/disarming ATA (Anti-theft Alarm system)

If the alarm system is armed, a visual and audible alarm is triggered in the following situations:


- A door is opened
- · The hood is opened
- (i) The alarm is not deactivated, even if you immediately close the open door that has triggered it, for example.

Arming



- Close all the doors.
- Lock the vehicle with the SmartKey. Indicator lamp (i) in the overhead control panel flashes.

Disarming



- Unlock the vehicle with the SmartKey. Indicator lamp in the overhead control panel goes out.
- (i) The vehicle locks again automatically if you do not open a door within 40 seconds after unlocking the vehicle.

Stopping the alarm

Press the or button on the Smart-Key.

or

Press the start/stop button with the Smart-Key inside the vehicle. The alarm stops.

Function of the tow-away alarm

Function of the tow-away alarm

A visual and audible alarm is triggered if the inclination of the vehicle changes when the tow-away alarm is activated. This can be the case if the vehicle is raised on one side, for example.

Arming/disarming the tow-away alarm


Arming/disarming

- Lock the vehicle with the key. The tow-away alarm is automatically armed after about 40 seconds:
- Open the vehicle with the key.
 The tow-away alarm is deactivated.

The tow-away alarm is only armed when the following components are closed:

- the driver's door and the front-passenger door
- the side doors
- the rear-end doors

Deactivating



- Switch off the power supply (\rightarrow page 109).
- Press button (1).
 When the button is released, indicator lamp
 (2) in the button lights up for approximately five seconds.
- Lock the vehicle with the key. The tow-away alarm is deactivated.

The tow-away alarm remains deactivated until you lock the vehicle again.

Deactivate the tow-away alarm when locking your vehicle in the following situations:

- when loading and/or transporting the vehicle on a ferry or car transporter, for example
- when parking the vehicle on a movable surface, such as a split-level garage

This will prevent false alarms.

Interior motion sensor

Function

If the activated the interior motion sensor detects motion in the vehicle interior, a visual and acoustic alarm is triggered. This can happen if someone reaches into the vehicle interior, for example.

Activating/deactivating the interior motion sensor

Activating

- Close the side windows.
- Make sure that nothing (such as mascots or coat hangers) is hanging on the inside rear-

- view mirror or on the grab handles on the headliner. This will prevent false alarms.
- Lock the vehicle with the key.
 The interior motion sensor is activated after approximately 30 seconds.


The interior motion sensor is only activated when the following components are closed:

- the driver's door and the co-driver door
- · the side doors
- · the rear-end doors

Deactivating

Unlock the vehicle with the key. The interior motion sensor automatically switches off.

Deactivating



- Switch off the power supply (\rightarrow page 109).
- Press button ①.
 When the button is released, indicator lamp
 ② in the button lights up for about five seconds.
- Lock the vehicle with the key.

 The interior motion sensor is deactivated.

The interior motion sensor remains deactivated until you lock the vehicle again.

Deactivate the interior motion sensor when locking your vehicle in the following situations:

- if there are people or animals remaining inside
- if the side windows remain open
- when transporting the vehicle on a ferry or car transporter, for example

This will prevent false alarms.

Correct driver's seat position

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten vour seat belt.



Comply with the following when adjusting steering wheel 3, safety belt 2 and driver's seat 1:

- Sit as far away as possible from the driver's airbag.
- Sit in an upright position.
- Your thighs are slightly supported by the seat cushion.
- Your legs are not fully extended and you can easily fully press on the pedals.
- The back of your head is supported at eye level by the middle part of the head restraint.
- · You can reach the steering wheel with your arms in a slightly bent position.
- · You can move your legs freely.
- · You can easily see all displays on the instrument display.

- You have a good overview of the traffic situation.
- Your safety belt fits securely around your body and runs across the middle of your shoulder, your pelvic area and groin.

Seats

Adjusting the front seats manually (without Seat Comfort Package)



WARNING Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle



WARNING Risk of becoming trapped when adjusting the seats

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".



WARNING Risk of accident due to the driver's seat not being engaged

If the driver's seat is not engaged, it could move unexpectedly while the vehicle is in motion.

This could cause you to lose control of the vehicle.

Always make sure that the driver's seat is engaged before starting the vehicle.

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

- While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.
- ▲ WARNING Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.

There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to set the height and inclination of the head restraints to the correct position.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of the head as possible.

WARNING Risk of injury or death due to incorrect seat position


The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdominal or neck injuries, for example.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.
- NOTE Damage to the seats when moving the seats back

The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.



- Seat fore-and-aft position
- Seat height
- Seat backrest inclination
- (i) Depending on the seat model, certain adjustment options may not be available.

- ➤ To set the seat fore-and-aft adjustment: raise lever and slide the seat into the required position.
- Ensure that the seat is engaged.
- To set the seat height: keep on pressing or pulling lever ② until the required seat height has been reached.
- To set the seat backrest inclination: rotate handwheel (a) forwards and backwards until the required position has been reached.

Adjusting the front seats mechanically (with Seat Comfort Package)

WARNING Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle.

WARNING Risk of becoming trapped when adjusting the seats

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".

WARNING Risk of accident due to the driver's seat not being engaged

If the driver's seat is not engaged, it could move unexpectedly while the vehicle is in motion.

This could cause you to lose control of the vehicle.

Always make sure that the driver's seat is engaged before starting the vehicle.

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

▲ WARNING Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.

There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to set the height and inclination of the head restraints to the correct position.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of the head as possible.

WARNING Risk of injury or death due to incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdominal or neck injuries, for example.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.
- ! NOTE Damage to the seats when moving the seats back

The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.



Sample image of comfort suspension seat

- Seat cushion length
- Seat backrest inclination
- Seat height
- Seat cushion inclination
- Seat fore-and-aft position

- Seat suspension
- Vibration limiting
- i Depending on the seat model, certain adjustment options may not be available.
- ➤ To adjust the seat cushion length: raise lever

 and slide the front part of the seat cushion forwards or backwards.
- ➤ To set the seat backrest inclination: rotate handwheel ② forwards and backwards until the required position has been reached.
- To set the seat height: pull or push lever
 until the required position has been reached.
- ➤ To set the seat cushion inclination: rotate handwheel ⓐ forwards and backwards until the required position has been reached.
- ➤ To set the seat fore-and-aft adjustment: raise lever ⑤ and slide the seat into the required position.
- ► Ensure that the seat is engaged.
- ➤ To set the seat suspension: take the weight off the seat.
- ➤ On handwheel ②, set the body weight (88 lb (40 kg) to 264 lb (120 kg)) so that the seat suspension works optimally. If you set a higher weight, the seat suspension will become firmer. The seat will then not vibrate as much. If the seat vibrates often and significantly, you can engage it in the lower area.
- To engage vibration limiting: turn lever upwards.

The next time the seat vibrates, it will engage.

➤ To release vibration limiting: turn lever ②
to the right.
The seat can vibrate.

Adjusting the front seat electrically

WARNING Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle.

The seats can be adjusted while the ignition is off.

WARNING Risk of becoming trapped when adjusting the seats

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".

WARNING Risk of accident due to the driver's seat not being engaged

If the driver's seat is not engaged, it could move unexpectedly while the vehicle is in motion.

This could cause you to lose control of the vehicle.

Always make sure that the driver's seat is engaged before starting the vehicle.

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

WARNING Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.

There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to set the height and inclination of the head restraints to the correct position.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of the head as possible.

A

WARNING Risk of injury or death due to incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.


When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdominal or neck injuries, for example.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.

NOTE Damage to the seats when moving the seats back


The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.



- Seat backrest inclination
- Seat height
- Seat cushion inclination
- Seat fore-and-aft position
- Save the settings with the memory function (→ page 69).

Setting 4-way lumbar support



- Higher
- Weaker
- 3 Lower
- Stronger
- Use buttons 1 to 2 to adjust the backrest curvature individually to your spine.

Operating the memory function

A

WARNING Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made.

- Only use the memory function on the driver's side when the vehicle is stationary.
- **WARNING** Risk of entrapment when setting the seat with the memory function

When the memory function adjusts the seat, you and other vehicle occupants – particularly children – could become trapped.

- During the adjustment process of the memory function, make sure that no one has any body parts in the sweep of the seat.
- If somebody becomes trapped, immediately release the memory function position button.

The adjustment process is stopped.

WARNING Risk of entrapment if the memory function is activated by children


Children could become trapped if they activate the memory function, particularly when unattended.

- Never leave children unattended in the vehicle.
- ► When leaving the vehicle, always take the key with you and lock the vehicle.

The memory function can be used when the ignition is switched off.

Storing seat settings

Seat settings for up to three people can be stored and called up using the memory function. You can adjust the seat and the backrest.



- Adjust the seat into the desired position.
- Press memory button M together with one of the preset position buttons 1, 2 or 3. An acoustic signal sounds. The settings are stored.
- ➤ **To call up:** press and hold the relevant preset position button 1, 2 or 3 until the front seat is in the stored position.

Rotating the front seats

WARNING Risk of injury or death if the driver's seat and front-passenger seat are not engaged

If the driver's and front-passenger seats are not engaged in the direction of travel during the trip, the restraint systems cannot offer protection as intended.

- Engage the driver's and front-passenger seat in the direction of travel before the engine is started.
- **WARNING** Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the

steering wheel or the mirror and fasten your seat belt.



You can rotate the driver's and front passenger seat 50° and 180°. The seats engage both in and opposite to the direction of travel as well as at 50° to the exit.


- Ensure that the parking brake is applied and the brake lever is folded downwards as far as it will go (→ page 141).
- Adjust the steering wheel in such a way that there is sufficient free space to rotate and adjust the driver's seat (→ page 76).
- Slide the front passenger seat forward before rotating it (→ page 64).
- ➤ To rotate the seat: push lever (1) towards the door and rotate the seat slightly inwards. The rotation device is unlocked.
- ► Release lever **(1)** again.
- Rotate the seat by around 50° outwards or inwards into the required position.

Folding the co-driver bench seat cushion forwards and backwards



- To fold the seat cushion forwards: lift the seat cushion out of front anchorage 1.
- Pull the seat cushion out of rear anchorage
 and move it slightly forwards.
- Fold the rear edge of the seat cushion upwards.
- (i) You can stow individual objects in the stowage space beneath the co-driver bench seat.
- ➤ To fold the seat cushion backwards: fold the rear edge of the seat cushion downwards.
- Slide the seat cushion under the seat backrest into rear anchorage ②.
- Push the front seat cushion downwards until it engages in front anchorage (1).

Adjusting armrests



Example image

- ➤ To set the armrest inclination: fold the armrest more than 45° upwards ②.


 The armrest will be unlocked.
- Fold the armrest forwards (3) as far as it will go.
- Slowly fold the armrest upwards into the required position.
- To fold the armrest upwards: if necessary, fold the armrest more than 90° upwards ①.

Folding the folding seat up or down

WARNING Risk of injury when using the folding seat due to inserted key

When the key is in the lock of the partition sliding door, it can come into contact with the person on the folding seat.

Always remove the key from the partition sliding door before a person sits on the folding seat.



- Remove key from the partition sliding door.
- Press the push button on catch ② and fold seat cushion ③ up or down.
- Release push button on catch ② when seat cushion ③ reaches its end position.
- Move seat cushion (3) until it has locked. The push button on catch (2) must be completely flush with the seat frame.

Installing and removing the rear bench seat

A

WARNING Risk of injury if rear bench seat is installed incorrectly

If you do not install the rear bench seat as described, or install an unsuitable rear bench seat, the seat belts may not provide the intended protection.

- Install the rear bench seat as described and only in the direction of travel.
- Installing the rear bench seat in the opposite direction is not permitted.
- Use only rear bench seats approved for your vehicle by Mercedes-Benz.

WARNING Risk of injury if the rear bench seat is not locked in place

If the locking mechanisms on the rear bench seat legs are not correctly engaged, the rear bench seat will not be held firmly and could roll over during travel.

- Ensure that the rear bench seat is engaged before setting off. There must be no red indicator tabs visible on the release handle.
- If red indicator tabs are visible on the release handle, re-engage the rear bench seat into place.

WARNING Risk of injury when installing and removing the rear bench seat

When you install or remove the rear bench seat, body parts such as feet may become trapped when the rear bench seat is tipped.

- When installing and removing the rear bench seat, ensure that there are no body parts between the rear bench seat and the floor.
- ! NOTE Damage to rear bench seat rollers caused by incorrect use

The rear bench seat rollers can be damaged if the rear bench seat is used improperly or is removed incorrectly.

As long as the rear bench seat is in the mounting shells, do not pull these in the direction of the rear-end doors. Roll the rear bench seat only beside the mounting shells. Do not roll the rear bench seat when it has been removed or use it as a means of transport.




Warning on rear bench seat with correctly installed rear bench seat shown.

Installation position of three-person and fourperson rear bench seat with strut

The three-person rear bench seat is available with or without a strut. The four-person rear bench seat is available only with a strut.

The strut is located on the rear side of the rear bench seat.


The three-person rear bench seat with strut must be installed only on the third row of seats (above the rear axle). The four-person rear bench seat must be installed only on the last row of seats.



Vehicles with four rows of seats

- First row of seats
- Second row of seats
- Third row of seats: three-person rear bench seat with strut
- Fourth row of seats: four-person rear bench seat with strut


- Install the three-person rear bench seat on third row of seats (3).
- Install the four-person rear bench seat on fourth row of seats 4.



Vehicles with three rows of seats


- First row of seats
- Second row of seats
- Third row of seats: four-person rear bench seat with strut
- Install the four-person rear bench seat on third row of seats 3.

Removing the rear bench seat




Perform these tasks carefully with the assistance of a second person.

To remove the covers of the mounting shells: push clip (1) in the direction of the arrow and detach cover (2) by pushing to the top rear at an angle.



- Push release handle ② for the bench seat all the way down and hold it there while tilting the bench seat backwards slightly at the same time using the release handle and pull it slightly backwards.
- Let go of the release handle.
 The locks on the bench seat legs will be unlocked and red indicator tabs (a) on the housing of release handle (a) will be visible.
- Hold the unlocked bench seat by grab handles and pull backwards slightly.




- Tilt bench seat 1 backwards and pull it out of the mounting shells.
- (i) If the bench seat cannot be pulled out of the mounting shells, the bench seat may be wedged in the seat anchorage. This can happen if the bench seat is tilted too far backwards.

If the bench seat cannot be pulled out of the mounting shells, you can rectify this situation as follows:

- Tilt the bench seat forwards without engaging it.
- Pull the bench seat backwards again using release handle 2.
- Tilt the bench seat backwards slightly and pull it out of the mounting shells.
- To remove or store the bench seat, place it next to the mounting shells and roll it towards the rear-end doors.

or

- Lift the bench seat out from the side to store it
- i It may be necessary for the bench seats in front or behind to be removed.



- To attach the covers of the mounting shells: hold cover (a) such that retaining lug (a) is pointing towards rear seat anchorage (b).
- Insert cover (a) into rear seat anchorage (a) by pushing it downwards at an angle and then clip it to the mounting shell.
- After removing the rear bench seat, ensure that the rear bench seat can stand firmly and not tip over when in storage.


Please note that the metallic seat support in the vehicle floor will heat up during a journey if the rear seating has been removed.

Installing the rear bench seat

Secure engagement of the rear bench seat is guaranteed only if you keep the seat anchorages clean and free of objects.

 In vehicles registered as passenger vehicles, observe the maximum permitted number of seats.

- Remove the covers of the mounting shells as described under "Removing the rear bench seat".
- Ensure that there are no objects in the seat anchorages and mounting shells.
- Position the bench seat behind the installation position.
- Hold the bench seat by the grab handles and tilt it backwards.
- Roll the bench seat forwards on the level plastic carriers.
- Ensure that the rear legs of the bench seat are engaged.




- ➤ Tilt the bench seat forwards firmly until the locks on the front legs of the bench seat engage audibly.
 - The locks on the front legs of the bench seat will now be locked and the red indicator tabs on the housing of release handle (1) should no longer be visible.
- (i) If the red indicator tabs on the release handle housing are visible, the bench seat is not correctly engaged.

If the bench seat is not correctly engaged, you can rectify this situation as follows:

- Unlock the bench seat again and tilt it forwards firmly until the locks on the bench seat front legs engage audibly.
- Attach the covers of the mounting shells as described under "Removing the rear bench seat".

Adjusting the seat backrest of the rear bench seat



- (i) If a partition is installed: the rear bench seat must not come into contact with the partition at any time.
- Move the seat backrest to the desired position.

Head restraints

Adjusting the head restraints manually

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.
- **WARNING** Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.

There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to set the height and inclination of the head restraints to the correct position.

Using the head restraint fore-and-aft adjustment, adjust the head restraint so that it is as close to the back of the head as possible.



Head restraint (example of comfort head restraint on the driver's seat)

- To raise: pull the head restraint upwards into the required position and ensure that the head restraint is engaged.
 Only use the head restraint in the engaged state.
- ➤ To lower: push release button and slide the head restraint downwards into the required position and ensure that the head restraint is engaged. Only use the head restraint in the engaged state.
- To move forwards: push release button and pull the head restraint forwards until it engages in the required position.
- ➤ To move backwards: push release button ② and slide the head restraint backwards into the required position.

(i) Depending on the head restraint model, individual adjustment options may be omitted.

Switching the seat heating on and off

WARNING Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

The health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it is switched on repeatedly.


NOTE Damage to the seats caused by objects or documents when the seat heating is switched on

When the seat heating is switched on, overheating may occur due to objects or documents placed on the seats, e.g. seat cushions or child seats. This could cause damage to the seat surface.

Make sure that no objects or documents are on the seats when the seat heating is switched on.

Requirements:

• The power supply has been switched on.



- To switch on: press button ①. All indicator lamps on the button light up.
- To lower the level: press button
 until the required heating level is reached. Depending on the heating level, one to three indicator lamps light up.
- To switch off: press button 1 until all indicator lamps are off.
- (i) The seat heating automatically switches back out of the three heating levels after 8, 10 and 20 minutes until the seat heating switches off.


Adjusting the steering wheel



WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.



Children could injure themselves if they adjust the steering wheel.

- Never leave children unattended in the
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.




- Lever
- Steering column height
- 3 Steering column fore-and-aft adjustment
- To adjust the steering wheel: swing lever down as far as it will go. The steering wheel is unlocked.
- Move the steering wheel to the desired position.
- Pull lever 1 up as far as it will go. The steering wheel is locked.

Stowage areas


Overview of the front stowage compartments

Overview of the front stowage compartments Observe the notes on loading the vehicle (→ page 271).



- Lockable compartment above windshield (→ page 78)
- Windshield stowage compartment with two cup holders/ashtray stowage space Stowage compartment with cover, depending on specification (→ page 77)
- © Center console stowage compartment with USB port, charging interface, NFC interface and 12 V socket
- Stowage compartment above windshield (subject to a maximum load of 5 lb (2.5 kg))
- Front passenger side stowage compartment (subject to a maximum load of 11 lb (5 kg))
- Cup holders
- Stowage compartment in the doors

Opening and closing the center console/ windshield stowage compartment



Stowage compartment cover (example: center console)


- ➤ To open: press button ② on stowage compartment ⑥.

 The cover folds upwards.
 - To close: fold the cover downwards.
- i The windshield stowage compartments have a cover, depending on the specification.

Opening and closing the lockable compartment above the windshield

You can lock and unlock the stowage compartment with the emergency key (\rightarrow page 47).

Opening




- To unlock: turn the emergency key clockwise to position 3.
- Slide handle ① upwards in the direction of the arrow.
- Swivel the cover upwards.
- i The weight in the compartment must not exceed 4 lbs (2 kg).

Closing

- Fold the cover downwards and slide handle


 on downwards in the direction of the arrow.
- To lock: turn the emergency key counterclockwise to position 2.

Opening the eyeglasses compartment



Press button ①.

Bottle holder



 Bottle holder in the front doors (example: codriver's door)


Cup holder

Opening the cup holder in the rear passenger compartment

WARNING Risk of injury when getting out, due to extended cup holder

If the cup holder in the rear passenger compartment is extended when you are getting out, you may bump into it.

Before getting out, slide the cup holder back under the rear bench seat.



- To open: press cup holder 1 or 2.
- Fold out the cup holder.
- ➤ To close: slide cup holder ① or ② back in until it engages.

Ashtray and cigarette lighter

Using ashtrays

While driving

- Place the closed ashtray in a cup holder in the windshield stowage compartments while driving.
- Check that the ashtray is seated securely.
- i Do not place the ashtray in the center console cup holders. It cannot sit securely here.

Opening



Fold cover 1 upwards.

Using the cigarette lighter in the center console

WARNING - Risk of fire and injury from hot cigarette lighter


You can burn yourself if you touch the hot heating element or the socket of the cigarette lighter.

In addition, flammable materials may ignite if:

- you drop the hot cigarette lighter
- a child holds the hot cigarette lighter to objects, for example
- Always hold the cigarette lighter by the knob.
- Always make sure that the cigarette lighter is out of reach of children.
- Never leave children unattended in the vehicle.

Requirements:

• The ignition is switched on



Press in cigarette lighter ①.
The cigarette lighter will pop out when the heating element is red-hot.


Sockets

Using 12 V sockets in the center console

Requirements:


 Only devices with a maximum power consumption of 180 W (15 A) may be connected.

12 V socket in stowage compartment




- Open the lid of the stowage compartment in the center console (→ page 77).
- Fold up cover ① of the socket.
- Insert the plug of the device.

12 V socket in lower control panel



- Lift up cover 1 of the socket.
- Insert the plug of the device.

Using 12 V socket on the driver's seat



- Fold up cover ① of the socket.
- Insert the plug of the device.

Using the 115 V socket in the lower control panel

DANGER Risk of fatal injury due to damaged connecting cables or sockets

If a suitable device is connected, the 115 V socket will be carrying a high voltage. If the connecting cable or the 115 V socket is pulled out of the trim or is damaged or wet, you could receive an electric shock.

- Only use dry and damage-free connecting cables.
- When the ignition is switched off, ensure that the 115 V socket is dry.
- ► If the 115 V socket is damaged or gets pulled out of the paneling, immediately have the socket checked or replaced at a qualified specialized workshop.
- Never plug the connecting cable into a 115 V socket that is damaged or has been pulled out of the trim.
- **DANGER** Risk of fatal injury due to incorrect handling of the socket

You could receive an electric shock:

- if you reach into the socket.
- if you insert unsuitable devices or objects into the socket.
- Do not reach into the socket.



Only connect suitable devices to the socket.

Requirements:

- The devices must be equipped with a suitable plug which conforms to the standards specific to the country you are in.
- Only devices up to a maximum of 150 watts are permitted.
- Do not use multiple socket outlets.




- Open flap 3.
- Insert the plug of the device into 115 V socket
 When the on-board electrical system voltage is sufficient, indicator lamp
 Iights up.

If you will not be using the 115 V power socket, keep the flap closed.

Using sockets in the cargo compartment


Requirements:

• Only devices with a maximum power consumption of 180 W (15 A) may be connected.



- Fold up cover 1 of the socket.
- Insert the plug of the device.

Charging a mobile phone using the USB socket in the rear



Place the mobile phone in stowage compartment ① and connect it to USB port ② to charge.

Wirelessly charging the mobile phone and coupling with the exterior antenna

Notes on wireless charging of the mobile phone

WARNING Risk of injury due to objects being stowed incorrectly

If you do not adequately stow objects in the vehicle interior, they could slip or be tossed around and thereby strike vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always restrain the objects they contain in the event of an accident.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be tossed about in these or similar situations.
- Always make sure that objects do not project from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the cargo compartment.

Comply with the instructions for loading the vehicle.

WARNING Risk of fire from placing objects in the mobile phone stowage compartment

There is a risk of fire, in particular, if you place more than one mobile phone in the mobile phone stowage compartment.

- Apart from a mobile phone, do not place any other objects in the mobile phone stowage compartment, especially those made of metal.
- NOTE Damage to objects caused by placing them in the mobile phone stowage compartment

If objects are placed in the mobile phone stowage compartment, they may be damaged by electromagnetic fields.

- Do not place credit cards, storage media or other objects sensitive to electromagnetic fields in the mobile phone stowage compartment.
- I NOTE Damage to the mobile phone stowage compartment caused by liquids

If liquids enter the mobile phone stowage compartment, the compartment may be damaged.

Ensure that no liquids enter the mobile phone stowage compartment.

Observe the following notes on wireless charging:


- The charging function is only available when the drive system has been started.
- In some cases, it may not be possible to charge small mobile phones at every position of the mobile phone receptacle.
- It may not be possible to charge large mobile phones that do not rest in the mobile phone receptacle.
- The mobile phone can warm up during the charging process. This depends on the applications (apps) currently running.
- For more efficient charging, the protective case should be removed from the mobile phone. Protective cases designed for wireless charging are an exception.
- When charging, the mat should be used if possible.

Charging the mobile phone in the front wirelessly

Requirements:

 The mobile phone must be suitable for wireless charging. A list of compatible mobile phones can be found at:

http://www.mercedes-benz.com/connect



- Open the flap of stowage compartment above the media display.
- ▶ Place the mobile phone as centrally as possible with the display facing upwards on the marked surface of mat ②.

When the charging symbol is shown in the multimedia system, the mobile phone is being charged.

Malfunctions during charging are shown in the multimedia system display.

(i) The mat can be removed for cleaning, e.g. with clean, lukewarm water.


Installing or removing the floor mats

▲ WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always install the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.



- To install: press pushbuttons (1) onto holders (2).
- To remove: pull the floor mats off holders



Exterior lighting

Notes on changing the lights when driving abroad


Vehicles with halogen or static LED headlamps: Changing the headlamps is not necessary. The legal requirements will also be fulfilled in countries with left and right-hand traffic.

Information about lighting systems and your responsibility

The vehicle's various lighting systems are only aids. The vehicle driver is responsible for adjusting the vehicle's lighting to the prevailing light, visibility, statutory conditions and traffic conditions.

Light switch

Operating the light switch



- 1 ∑0€ Activates or deactivates parking lights and license plate and instrument lighting
- 2 Auro Activates or deactivates automatic driving lights/daytime running lights (preferred light switch position).
- ▶ 3 Ø Activates or deactivates low beam/ high beam.
- Activates or deactivates fog light.
- ⑤ ① Activates or deactivates rear fog light.
- Applies or releases the electric parking brake(→ page 143)
- i If you hear a warning tone when exiting the vehicle, the light may still be on.

- The turn signal light, the high beam and the high-beam flasher are operated with the combination switch (→ page 85).
- Leaving the standing lights on for several hours drains the battery.

 If the battery charge is very low, the standing lights will switch off automatically to enable the next vehicle start.

Automatic driving lights function

A

WARNING Risk of accident when the low beam is switched off in poor visibility

When the light switch is set to Auto, the low beam may not be switched on automatically if there is fog, snow or other causes of poor visibility such as spray.

In such cases, turn the light switch to

The automatic driving lights are only an aid. Responsibility for vehicle lighting rests with you. Turn the light switch from Auto to D immediately in the event of fog, snow or spray. Otherwise, the driving light is temporarily interrupted.

To switch the automatic driving lights on:

• Turn the light switch to the AUTO position. Switch the power supply on: the parking lamps will automatically switch on or off depending on the brightness of the ambient light.

The daytime running lamps are switched on when the engine is running. The parking lamps and the low beam also switch on or off depending on the brightness of the ambient light.


When the low beam is switched on, the principle indicator lamp on the instrument cluster will also switch on

Switching fog light and rear fog light on or off Requirements:

- The light switch is in the or auto position
- The power supply or the engine has been switched on.
- To switch the fog light on or off: press button .
- ➤ To switch the rear fog light on or off: press button ⑥.

Comply with the country-specific regulations for using the rear fog lamp.

Operating the combination light switch




- High beam
- Right turn signal light
- 3 Headlamp flashing
- Left turn signal light
- ➤ To indicate: push the combination switch in the required direction ② or ③ until it engages. In the case of larger steering movements, the combination switch will automatically switch back.
- To indicate briefly: tap the combination switch briefly in the required direction ② or
 The corresponding turn signal lamp will flash three times.
- ➤ To switch on the high beam: switch on the low beam (→ page 84).
- ➤ Push the combination switch forwards ①.

 The ② indicator lamp on the instrument cluster will light up. The combination switch will return to its starting position.
- (i) The high beam switches to the AUTO position only in darkness and when the engine is running.
- ➤ To switch off the high beam: push the combination switch forwards or briefly pull it in the direction of arrow (the action for headlamp flashing switches the high beam off).

The **D** indicator lamp on the instrument cluster will go out. The combination switch will return to its starting position.

- (i) Vehicles with Highbeam Assist: when Highbeam Assist is active, it controls the activation and deactivation of the high beam (→ page 86).
- To activate headlamp flashing: switch on the power supply or ignition.
- Briefly pull the combination switch in the direction of arrow <a>3.

Switching hazard warning lights on or off



To switch on and off: press button 1.

If you operate a turn signal indicator while the hazard warning lights are switched on, only the turn signal lamps on the relevant side of the vehicle will light up.

i The hazard warning lights will work even when the vehicle has been switched off.

Cornering light function



The cornering light improves the illumination of the roadway over a wide angle in the turning direction, e.g. enabling better visibility in tight bends. The function is active under the following conditions:

- The speed is less than 37 mph (60 km/h) and the indicator has been switched on or the steering wheel is turned.
- The speed is between 37 mph (60 km/h) and 50 mph (80 km/h) and the steering wheel is turned.

The cornering light may still light up for a short time but is switched off automatically after a maximum of three minutes.

i) When reverse gear is engaged, the lighting switches to the opposite side.

Highbeam Assist

Adaptive Highbeam Assist function

WARNING Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not recognize the following road users:

- Road users without lights, e.g. pedestrians
- Road users with poor lighting, e.g. cyclists
- Road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognize other road users with their own lighting, or may recognize them too late.

In these or similar situations, the automatic high beam is not deactivated or is activated despite the presence of other road users.

Always observe the traffic carefully and switch off the high beam in good time.

The Adaptive Highbeam Assist automatically switches between the following settings:

- · Low beam
- · High beam

The system detects that vehicle lights are approaching in the opposite direction or driving ahead of the vehicle.

At speeds greater than 19 mph (30 km/h), a change is made to the following setting:

• If no other road users are detected, the high beam switches on automatically.

At speeds less than 16 mph (25 km/h) or if there is sufficient road lighting, a change is made to the following setting:

• The high beam automatically switches off.

System limitations

Adaptive Highbeam Assist cannot take the road, weather or traffic conditions into consideration.

The detection of obstacles can be restricted if:

- Visibility is impaired, e.g. in fog, heavy rain or snow
- · The sensors are dirty or covered

Adaptive Highbeam Assist is only an aid. You are responsible for ensuring correct vehicle lighting in accordance with the prevailing light, visibility and traffic conditions.

The system's optical sensor is located behind the windshield near the overhead control panel.

Switching Highbeam Assist on or off

- To switch on: turn the light switch to the AUTO position.
- Switch the highbeam on using the combination switch.

If the highbeam is automatically switched on in darkness, the bindicator lamp on the multifunction display lights up.

To switch off: switch off the highbeam using the combination switch.

Setting the exterior lighting switch-off delay time

Requirements:

• The light switch is in the **AUTO** position.

Multimedia system:

→ ☐ → Settings → Light
→ Exterior Lighting Delay

Set a switch-off delay time.

When the vehicle engine is switched off, the exterior lighting will be activated for the set time.

Activating and deactivating the surround lighting

Multimedia system:


→ 🔝 ➤ Settings ➤ Light

>> Locator Lighting

Activate or deactivate the function.

The exterior lighting remains on for 40 seconds after the vehicle is unlocked. When you start the vehicle, the surround lighting will be deactivated and the automatic driving lights activated.


Adjusting the interior lighting Adjusting the front interior lighting



Variant 1


- Switches the front left reading lamp on/off
- ▶ ② To switch off the automatic interior lighting control: press the □□□ button.

 The interior lighting will switch on automatically if you:
 - · Unlock the vehicle or
 - · Open a door
- Switches the front interior lighting on/off
- Switches the rear passenger compartment/cargo compartment lamp on/off
- ▶ ⑥ 潘 Switches the front right reading lamp on/off



Variant 2


- Switches the front left reading lamp on/off
- ▶ ② To switch off the automatic interior lighting control: press the ☐ button. The interior lighting will switch on automatically if you:
 - · Unlock the vehicle or
 - Open a door
- Switches the front interior lighting on/off
- Switches the rear passenger compartment/cargo compartment lamp on/off
- ► ⑤ ☎ Switches the front right reading lamp on/off



Variant 3

② To switch off the automatic interior lighting control: press the button. The interior lighting will switch on automatically if you:


- · Unlock the vehicle or
- Open a door
- Switches the front interior lighting on/off
- Switches the rear passenger compartment/cargo compartment lamp on/off



Variant 4

▶ ① ៑ Switches the interior lighting on/off

Adjusting interior lighting on bus equipment



- Activates / deactivates bus function
- ② Switches the front left reading lamp on/off
- Activates/deactivates automatic interior lighting control
- Switches the front interior lighting on/off
- Switches passenger compartment lighting on/off

- Switches reading lights in the passenger compartment on/off
- To activate the bus function: press button

The LED lights up.

The bus function is in one of the following modes:

Stop mode

If the vehicle comes to a halt at a bus stop, for example, and the passenger door opens, the passenger compartment will be illuminated and undimmed.

· Driving mode

If all doors are closed and the vehicle is traveling faster than walking pace, the passenger compartment will be illuminated but dimmed.

Automatic off mode

If automatic interior lighting control (3) is deactivated, and thereby automatic off mode is active, the passenger compartment will be continuously illuminated (dimmed).

When the bus function is activated, the passenger compartment lighting on/off modes can be selected using button ③. Passenger compartment lighting is then deactivated completely. When button ⑤ is pressed again to switch passenger compartment lighting on/off, the bus function is again in one of the modes.

- If automatic off mode was not previously activated, either driving or stop mode is active.
- (i) The bus function can be used to switch passenger compartment lighting on/off without using button (§). The passenger compartment lighting must not be switched on beforehand
- To deactivate the bus function: press button (i).

The LED does not light up.

To switch the front left reading lamp on or off: press button ②.

To deactivate the automatic interior lighting: press button 3.

The interior lighting control will switch on automatically, for example, if you:


- · Unlock the vehicle
- Open a door
- To switch front interior lighting on or off: press button (a).
- To switch passenger compartment lighting on or off: press button (3).
- To switch the front right reading lamp on or off: press button (6).
- ➤ To switch reading lights on in the passenger compartment: press button ⑦. The LED lights up.

Passengers can switch the reading lamps on and off.

➤ To switch reading lights off in the passenger compartment: press button ⑦. The LED does not light up.


Passengers can no longer operate the reading lamps.

Switching the reading lamp above the passenger seat on and off (bus equipment)



To switch the reading lamp on and off: press button .

Rear interior lighting



Switches rear compartment/cargo compartment lamp on or off

Motion detector


WARNING Risk of injury by laser beam from motion detector

The motion detector transmits invisible radiation from LEDs (light-emitting diodes).

These LEDs are classified under the 1M laser class and can cause retina damage in the following situations:

- If you look directly into the unfiltered laser beam from the motion detector for an extended period
- If you look directly into the laser beam of the motion detector with optical instruments such as eyeglasses or a magnifying glass.
- Never look directly into the laser beam.

The motion detector is located in the cargo compartment behind the partition, in the middle of the roof.



Position of motion detector

If the vehicle is equipped with a motion detector, the cargo compartment lighting is also activated via the motion detector.

If the motion detector detects movement in the cargo compartment while the vehicle is stationary, the cargo compartment lighting will switch on for approximately two minutes.

The cargo compartment lighting can be switched on via the motion detector if:

- The vehicle is stationary, the parking brake is applied and you are not depressing the brake pedal.
- Vehicles with automatic transmission: the selector lever is in position P and you are not depressing the brake pedal.
- The vehicle has not been locked from the outside using the key.

If no change to the vehicle, such as a door opening, is detected over several hours, the motion detector will automatically switch off. This prevents the battery from discharging.

Switching the interior lighting switch-off delay time on/off

Multimedia system:



Switch the switch-off delay time on or off. If the function is active, the interior lighting will remain lit up for a short time when the seat belt buckle is released.

Changing bulbs

Instructions for changing bulbs



WARNING Risk of burns from hot component parts whilst replacing a bulb

Bulbs, lamps and plug connectors can become very hot during operation.

When replacing a bulb, you could burn yourself on these component parts.



Allow the component parts to cool down before replacing the bulbs.

When you are replacing the bulb, observe the following:

- Do not use any bulb that has been dropped or has scratches on its glass surface. Otherwise, the bulb may explode.
- The bulb may explode if it is hot or if you touch, drop or scratch it.
- Stains on the glass surface reduce the service life of the bulb. Do not touch the glass surface with your bare hands. If necessary, clean the glass surface with alcohol or spirits in a cold state and wipe it down with a lintfree cloth.
- Protect bulbs from humidity and do not bring them into contact with liquids.

Always ensure the bulbs are firmly secured.

If your vehicle is equipped with LED lamps, you can check this as follows: the light cone will move from top to bottom and back again when the vehicle starts. For this to work, the low beam needs to have been switched on before the vehicle is started.

Bulbs and lamps are a major part of vehicle safety. Therefore, ensure that they are always working. Have the headlamp setting checked regularly.


- Before changing the bulbs, switch off the vehicle's lighting system. This will prevent a short circuit.
- Use bulbs only in closed lights that have been designed for them.
- Use only spare bulbs of the same type and with the correct voltage.

If the new bulb also does not light up, consult a qualified specialist workshop.

Replacing front light bulbs (vehicles with halogen headlamps)

Overview of front light source types

You can replace the following light sources.



Halogen headlamps

- High beam/daytime running lights: H15 55 W/15 W
- 2 Low beam/perimeter lights: H7 55 W/W 5 W
- 3 Turn signal lights: 3457 NAK 28 W

Replacing halogen headlamps Requirements:


- Low beam: bulb type H7 55 W
- High beam/daytime running lamps: bulb type H15 55 W/15 W
- Perimeter lights: bulb type W 5 W
- Turn signal lights: bulb type 3457 NAK 28 W



- Low beam/perimeter light housing cover
- High beam/daytime running lamps housing cover
- Turn signal light socket
- Switch off the lighting system.
- Low beam/perimeter light: remove housing cover 1 towards the rear.
- Pull out the socket towards the rear.
- Remove the bulb from the socket.
- Insert the new bulb into the socket such that the base of the bulb rests fully against the base of the socket.
- Align and insert the socket.
- Attach housing cover ①.
- ► High beam/daytime running lamps: remove housing cover ② towards the rear.
- Turn the socket counter-clockwise and pull it out.
- Remove the bulb from the socket.
- Insert the new bulb into the socket such that the base of the bulb rests fully against the base of the socket.
- Insert the socket and turn it clockwise.
- Attach housing cover 2.
- ► Turn signal light:
- Turn socket (3) counter-clockwise and remove it.
- Gently turn the bulb counter-clockwise and take it out of the socket.
- Insert the new bulb into the socket and turn it clockwise.
- Insert socket (3) and turn it clockwise.

Additional turn signal light Requirements:

 Additional turn signal light (all-wheel drive vehicles): bulb type P 21 W




- Switching off the lighting system.
- Unscrew screws 1 and remove lens 2.
- Gently turn the bulb counter-clockwise and take it out of the socket.
- Insert the new bulb into the socket and turn it clockwise.
- Place lens in position and tighten the screws.

Replacing rear light bulbs (Cargo Van and Passenger Van)

Overview of rear light source types (Cargo Van and Passenger Van)


You can change the following light sources.



Vehicles with standard tail lamps

- Brake lights/tail lamps/perimeter lights:
 P 21 W
- Backing up light: P 21 W
- 3 License plate lamp: W 5 W
- Rear fog light: P 21 W

You can change the following light sources.



Vehicles with partial LED tail lamps

- Backing up light: P 21 W
- 2 License plate lamp: W 5 W
- Rear fog light: P 21 W


Changing the tail lamps (Cargo Van and Passenger Van)


Requirements:

- Brake lights/tail lights/perimeter lights: bulb type P 21 W
- Backing up lights: bulb type P 21 W
- Rear fog lights: bulb type P 21 W



- Brake light/tail light/perimeter light
- Backing up light
- Rear fog light
- Switch off the lighting system.
- Open the rear-end door.





- To remove: loosen screws and pull out the tail lamp in the direction of the arrow.
- Remove the plug from bulb mount 3.
- Loosen screws ② and remove bulb mount
 ③ from the tail lamp.
- Gently turn the bulb counter-clockwise and take it out of the socket.
- Insert the new bulb into the socket and turn it clockwise.
- To install: set bulb mount (3) on the tail lamp and screw in screws (2).
- Press the plug into bulb mount 3.
- Insert the tail lamp and screw in screws ①.

License plate lamp Requirements:


• License plate lamp: light bulb type W 5 W



- Switch off the lighting system.
- Place a screwdriver, for example, at opening
 between lamp (a) and panel (a) and carefully pry off lamp (a).
- Remove lamp 3 from panel 1.
- Rotate the bulb holder by around 45° and detach it from the lamp.
- Remove the light bulb.
- Insert the new bulb into the bulb holder.
- Insert the bulb holder into the lamp and rotate it by around 45°.
- Insert the lamp into the panel opening until it engages.

Replacing rear light bulbs (chassis)

Overview of rear light source types (chassis) You can replace the following light sources.




Vehicles with standard tail lamps

- Clearance lamp: R 5 W
- 2 Tail light: R 5 W
- Brake light: P 21 W
- Turn signal lights: PY 21 W
- Backing up light: P 21 W
- Rear fog light (driver's side): P 21 W
- License plate lamp: R 5 W

Replacing the tail lamps on the chassis Requirements:

- Rear fog lights: bulb type P 21 W
- License plate lighting: bulb type R 5 W
- Backing up lights: bulb type P 21 W
- Turn signal lights: bulb type PY 21 W
- Clearance lamps: bulb type R 5 W
- Brake lights: bulb type P 21 W
- Tail lights: bulb type R 5 W




- 1 Light lens
- Screws

- Rear fog light
- 4 License plate lamp
- Backing up light
- Turn signal light
- Clearance lamp
- Brake light
- Tail light
- Switch off the lighting system.
- Unscrew screws ② and remove light lens
- Remove the plug from the bulb mount.
- Gently turn the bulb counter-clockwise and take it out of the socket.
- Insert the new bulb into the socket and turn it clockwise.
- Position light lens (1) and tighten screws (2).

Replacing interior light bulbs

Replacing rear interior lamps Requirements:

(i) For the standard bulb failure indicator function to work correctly, only lights bulbs must be used that are the same type and power as those installed during production.




- Switch off the interior lighting.
- Press in catch spring of lens (1) with a suitable object e.g. a screwdriver, and then lever off the lens with the lamp housing.
- To pull back lens from the lamp housing: press the lugs of lens ② inwards.
- Remove light bulb (3) from the lamp housing.
- Insert the new light bulb.

- Insert the lens in the lamp housing until it engages.
- Place the lens with the lamp housing in position and engage it.

Windshield wipers

Switching the front windshield wipers on and off



- ① Single wipe/wiping with washer fluid
- 1 0 Windshield wipers off
- Vehicles with rain sensors: automatic wiping, normal
- Intermittent wiping, frequent
 Vehicles with rain sensors: automatic wiping, frequent
- Continuous wiping, slow
- 5 Continuous wiping, fast
- Turn the combination switch to the corresponding position 1 5.
- Single wipe/washing: press the button on the combination switch in the direction of arrow .
 - Single wipe
 - Wipes with washer fluid

Switching the rear window wiper on/off



- 1 Single wipe/wash
- Intermittent wiping
- Single wipe: press button (1) to the point of resistance.
- Wiping with washer fluid: press button beyond the point of resistance.
- To switch intermittent wiping on or off: press button (a).

 If the rear window wiper is switched on, the symbol will appear on the Instrument Display.

Replacing the windshield wiper blades

WARNING Risk of becoming trapped if the windshield wipers are switched on while wiper blades are being replaced


If the windshield wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the ignition before changing the wiper blades.

▲ WARNING Risk of injury from using the windshield wipers while the engine hood is open

When the engine hood is open and the windshield wipers are set in motion, you can be trapped by the wiper linkage.

Always switch off the windshield wipers and ignition before opening the engine hood. i If the wiper blades are worn out, they will not wipe the windshield properly. Replace the wiper blades twice a year, preferably in spring and fall.



- Fold wiper arm (3) away from the windshield.
- ► Hold wiper arm ③ and turn the wiper blade away from wiper arm ③ in the direction of the arrow as far as it will go.
- Slide catch @ upwards in the direction of the arrow until it engages.
- Fold back the wiper blade onto the wiper arm.
- Remove wiper blade from wiper arm.
- Insert new washer blade
 in the holder on wiper arm
 in .

When doing so, take into account the different lengths of the wiper blades:

- Driver's side: long wiper blade
- Front-passenger side: short wiper blade
- Slide catch ② downwards until it engages.
- Fold wiper arm (3) back onto the windshield.

Replacing the windshield wiper blades (WET WIPER SYSTEM)


WARNING Risk of becoming trapped if the windshield wipers are switched on while wiper blades are being replaced

If the windshield wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the ignition before changing the wiper blades. ▲ WARNING Risk of injury from using the windshield wipers while the engine hood is open

When the engine hood is open and the windshield wipers are set in motion, you can be trapped by the wiper linkage.

- Always switch off the windshield wipers and ignition before opening the engine hood.
- i If the wiper blades are worn out, they will not wipe the windshield properly. Replace the wiper blades twice a year, preferably in spring and fall.




- Fold wiper arm (3) away from the windshield.
- ► Hold wiper arm ③ and turn the wiper blade away from wiper arm ③ in the direction of the arrow as far as it will go.
- Slide catch ② upwards in the direction of the arrow until it engages.
- Remove wiper blade from the wiper arm in the direction of arrow 4.
- Carefully remove hose (5) from the wiper blade.
- Attach hose (5) to the new wiper blade.
- Insert new washer blade 1 in the holder on wiper arm 3.

When doing so, take into account the different lengths of the wiper blades:

- · Driver's side: long wiper blade
- front-passenger side: short wiper blade
- Slide catch ② downwards until it engages.
- Fold back the wiper blade onto the wiper arm.

Fold wiper arm 3 back onto the windshield.

Replacing the rear window wiper blade



- Fold wiper arm (3) away from the rear window
- Press both retaining clips ② in the direction of the arrow and swivel the wiper blade away from the wiper arm.
- Pull wiper blade upwards out of the holder on wiper arm .
- Insert new washer blade 1 in the holder on wiper arm 3.
- Push new wiper blade onto wiper arm until the retaining clips engage.
- Fold wiper arm (a) back onto the rear window.

Mirrors

Operating the outside mirrors

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the

steering wheel or the mirror and fasten your seat belt.

▲ WARNING Risk of accident due to misjudgment of distances when using the passenger mirror

The outside mirror on the front-passenger side reflects objects on a smaller scale. The objects in view are in fact closer than they appear.


As a result, you may misjudge the distance between you and the road user driving behind you, for example, when changing lanes.

Therefore, always look over your shoulder in order to ensure that you are aware of the actual distance between you and the road users driving behind you.

Adjusting the outside mirrors manually

- Adjust the outside mirrors to the correct position manually.
- To engage an outside mirror that has been pushed out of position: push the outside mirror into position manually.

Adjusting the outside mirrors electrically



Example image

! NOTE Damage to the electric outside mirrors

If you fold the electric outside mirrors in or out manually, you may damage the outside mirrors and they will not lock in place properly. If the outside mirrors are not folded in when washing the vehicle in a car wash, the washer brushes may fold them in forcibly and damage them.


- ► The outside mirrors must only be folded in and out electrically.
- Fold the outside mirrors in before washing the vehicle in a car wash.
- Before driving off, switch on the power supply or the ignition.
- To fold in or out: briefly press button 2.
- To adjust: use button (1) or (3) to select the outside mirror to be adjusted.
- Set the position of the mirror glass by pressing button 4.
- To engage an outside mirror that has been pushed out of position: press and hold button 2.

You will hear a click and the mirror will audibly engage in position. The outside mirror is set in the correct position.

Heating the outside mirrors


- Vehicles without a rear window heater: at low temperatures, the mirror heater will switch on automatically after the engine is started.
- Vehicles with a rear window heater: at low temperatures, the mirror heater will switch on automatically after the engine is started. The mirror heater can also be switched on together with the rear window heater using the rear window heater button.

Dimming the inside rearview mirror



To dim the inside rearview mirror: move anti-glare lever
in the direction of the arrow.

Using sun visors




- Glare from front: fold sun visor (1) down-
- Glare from the side: swivel sun visor 1 to the side.

Overview of climate control systems

Heating system overview



- Sets the temperature
- REAR Switches the rear-compartment heating on/off
- Switches the rear window heater on/off (→ page 104)
- Switches footwell air distribution on/off
- Switches windshield defrosting on/off
 (→ page 103)
- Vehicles with stationary heater or heater booster: switches the stationary heater or heater booster on/off (→ page 106)
- Sets the airflow
- i The indicator lamps on the buttons signal that the function in question has been activated.




- ② Display
- 3 Sets the airflow

- Vehicles with a rear window heater:
 switches the rear window heater on/off
 (→ page 104)
- Switches air-recirculation mode on/off
 (→ page 104)
- Adjusts the air distribution(→ page 103)

- i The indicator lamps on the buttons signal that the function in question has been activated.

Overview of 3-zone automatic climate control



- **▼** ▲ Sets the temperature
- ② Display
- Sets the airflow
- 4 Vehicles with a windshield heater: switches the windshield heater on /off $(\rightarrow page 104)$
- Output
 Selection
 Output
 Description
 Des booster: switches the stationary heater or heater booster on $/ off(\rightarrow page 106)$
- O Vehicles with a rear window heater: WEEAR switches the rear window heater on off $(\rightarrow page 104)$
- Switches air-recirculation mode on/off $(\rightarrow page 104)$
- Switches windshield defrosting on / off $(\rightarrow page 103)$
- Adjusts the air distribution نزع المناققة $(\rightarrow page 103)$
- Switches the A/C function on/off $(\rightarrow page 102)$
- Automatically controls the climate control, front (→ page 102) and rear compartment (\rightarrow page 103)
- SYNC Switches synchronization on / off $(\rightarrow page 103)$

13 REAR

Vehicles with dual-zone climate control systems: adjusts the rear-compartment climate control/heating (indicator lamp flashes) (\rightarrow page 102)

(i) The indicator lamps on the buttons signal that the function in question has been activated.

Operating climate control systems

Switching the climate control system on or off

- To switch on: set the airflow to 1 or higher on the front-compartment menu.
- To switch off: set the airflow to 0 or OFF on the front-compartment menu. OFF will appear on the climate control system display.
- (i) When the climate control system is switched off, the windows may fog up more quickly. Switch the climate control system off only briefly.
- (i) If the front-compartment system has already been switched on and the rear-compartment system has been switched off, you can switch it on by turning up the blower on the rear-compartment menu. If the front-compartment system is switched on, the rearcompartment system will automatically switch on as well.

Adjusting the rear-compartment climate control

Requirements:

 The climate control system has been switched on (→ page 101).

Setting the temperature and airflow with dual-zone and 3-zone automatic climate control:

Press the REAR button.

The indicator lamp on the button and

the symbol on the climate control system display will flash.

The display will switch to the temperature and the blower on the rear menu.

- ► Use the rocker switches ▼▲ and ⑤ to set the required temperature and airflow on the rear-compartment menu.
- i If there are significant differences between the temperature settings of the front and rear systems, these cannot be regulated accurately.
- i) If the rear-compartment climate control has been switched off, you can switch it on automatically by pressing the SYNC button.

Depending on the vehicle equipment, climate control will switch on the roof-mounted air conditioning system or rear-compartment heating as required:

- Vehicles with a roof-mounted air conditioning system: the rear compartment can only be cooled.
- Vehicles with rear-compartment heating: the rear compartment can only be heated.

Switching off rear-compartment climate control via dual-zone and 3-zone automatic climate control:

Press the REAR button.

If the indicator lamp on the button

the symbol on the climate control sys-

- tem display flash, set the airflow to 0 on the rear-compartment menu.
- i Indicator lamp on: rear-compartment climate control has been switched on.
 Indicator lamp off: rear-compartment climate control has been switched off.
 Indicator lamp flashes: the setting mode of the rear-compartment climate control is active.

Switching the A/C function on and off

Requirements:

 The climate control system has been switched on (→ page 101).

The A/C function controls the climate and dries the air inside the vehicle.

- ▶ Press the A/c button.
- i Switch off the A/C function only briefly. Otherwise, the windows could fog up faster.
- (i) Condensation may leak from the underside of the vehicle in cooling mode. This is not a sign of a defect.

Automatically regulating climate control

Requirements:

 The climate control system has been switched on (→ page 101).

Switching on automatic climate control

In automatic mode, the temperature, airflow and air distribution are regulated and kept constant.

Press the AUTO button.

The display will show the temperature. The airflow and air distribution will disappear from the display.

If the rear-compartment climate control has been switched on, the setting will be carried over for the rear compartment.

Switching off automatic climate control

 Use the ⊕ rocker switch to change the airflow setting and air distribution (→ page 103).

The other setting remains unaffected by the change.

Automatically controlling the climate control in the rear compartment

Requirements:

Rear-compartment climate control has been switched on $(\rightarrow page 102)$.

In automatic mode, the temperature, airflow and air distribution are regulated and kept constant.



REAR

button.

- Press the AUTO button.
- (i) Even if the front-compartment system is in automatic mode, the rear-compartment system can exit automatic mode if you adjust the blower on the rear-compartment menu.
- i If the air is cooled and the driver's, front passenger or sliding door is opened, the rear compartment air conditioning system blower will be turned down after around 15 minutes. When all doors have been closed again, the blower will be reset to the previous setting after around one minute.

Information on the air distribution settings

The symbols on the display indicate the vents through which the air is being directed.

Dual-zone automatic climate control

- Defroster and center vents
- الخبّ All vents
- Center vents
- Center and footwell vents

3-zone automatic climate control

- Defroster vents
- Defroster and center vents
- الزيُّ All vents
- Defroster and footwell vents
- Center vents
- Center and footwell vents
- المرا Footwell vents

Setting the air distribution

Requirements:

- The climate control system is switched on.
- Press the انزيّ button repeatedly until the desired air distribution appears in the air conditioning system display.

Switching the synchronization function on and off

Requirements:

• The climate control system has been switched on $(\rightarrow page 101)$.

The synchronization function controls the climate control function centrally. The settings for the temperature and airflow in the front zone are automatically adopted for the rear zone.

- Press the **SYNC** button.
- i) If the rear-compartment climate control has been switched off, you can switch it on automatically by pressing the **SYNC** button.

Clearing condensation from the windows

Misting on the inside of windows

- Press the www button. When the windshield defroster is switched on, the temperature and airflow cannot be adjus-
- In vehicles with a heating system and a manual air-conditioning system, also close the side and center air vent (\rightarrow page 104) as well as the air vents for the rear compartment $(\rightarrow page 105)$.
- Vehicles with dual-zone or 3-zone automatic climate control: press the A/C button and, if necessary, use the button to direct the air onto the windshield آنيا.
- Increase the airflow as necessary and close all air vents (\rightarrow page 104).
- If the windows remain fogged up: press the wax button.

When the windshield defroster is switched on, the temperature and airflow cannot be adjusted.

or no symbol will appear on the climate control system display.

Vehicles with a windshield heater: press the 🔞 button.

Close the center air vent (→ page 104) and air vents for the headroom (→ page 105) and rear compartment (→ page 105).

Misting on the outside of windows

Switch on the windshield wiper (\rightarrow page 95).

Switching air-recirculation mode on or off

Press the Dutton.
The interior air is recirculated.

The air-recirculation mode switches off automatically.

(i) When air-recirculation mode is switched on, the windows may fog up more quickly. Switch on air-recirculation mode only briefly.

Air-recirculation mode will automatically switch on in the following cases:

- At high outside temperatures
- While the vehicle is driving through a tunnel (vehicles with 3-zone automatic climate control and navigation only)
- When the windshield wipers are switched on (→ page 95)

The indicator lamp on the Dutton will not light up in this case. After a maximum of 30 minutes, outside air is automatically introduced again.

Switching the windshield heater on and off

- in the event of high outside temperatures, the windshield heater may not switch on.
- ➤ Press the <a> Description Press the <a> Description button.

 If the indicator lamp on the button lights up, the windshield heater has switched on.
- i The windshield heater switches off automatically after a few minutes.
- i If the battery voltage is too low, it may not be possible to switch the windshield heater on. If the battery voltage becomes too low while the windshield heater is in operation, the windshield heater will switch off automatically.

Switching the rear window heater on or off

Press the when button.
If the indicator lamp lights up, the rear window heater is switched on.

Operating air vents

Adjusting the front-compartment air vents


A

WARNING - Danger of burns or frostbite due to being too close to the air vents


Very hot or very cold air can flow from the air vents.

This could result in burns or frostbite in the immediate vicinity of the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance to the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.



- ➤ To open or close: hold center ② of air vent ③ and turn it to the left or right as far as it will go.
- ➤ To set the air direction: hold center ② of air vent ③ and swivel it upwards, downwards, to the left or to the right.



- To open or close: turn the adjustment wheels
 on the high-power air vents to the left or right as far as they will go.
- (i) Cooled air will flow out of the high-power air vents. Heating will not be possible. Open the high-power air vents only in summer during cooling mode and keep them closed in winter.

Adjusting air vents in the roof air duct



In vehicles with a rear compartment air conditioning system, adjustable air vents have been integrated in the roof air duct.

- To adjust the airflow: if necessary, open or close the air flaps in air vents 1.
- To adjust the air distribution: turn air vents 1 to the required position.


Information about air vents in the rear compartment

WARNING - Danger of burns or frostbite due to being too close to the air vents

Very hot or very cold air can flow from the air vents.

This could result in burns or frostbite in the immediate vicinity of the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance to the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.



Depending on the vehicle equipment, there will be an air duct or a heater with additional air vents in the rear compartment footwell on the left-hand side 1. No objects may be placed there. Occupants must maintain a sufficient distance due to the warm air flow and air intake

Auxiliary heating

Notes about auxiliary heating

DANGER Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case in enclosed spaces or if the vehicle gets stuck in snow, for example.

- Always switch the stationary heater off in enclosed spaces without an air extraction systems, e.g. in garages.
- Keep the tailpipe and the area around the vehicle free from snow when the engine or the stationary heater are run-
- Open a window on the windward side of the vehicle to ensure an adequate supply of fresh air.
- WARNING Risk of fire due to hot stationary heater components

When the stationary heater is switched on, parts of the vehicle can become very hot, e.g. the stationary heater exhaust system.

Flammable materials such as leaves, grass or twigs may ignite if they come into contact with:

- hot parts of the stationary heater exhaust system
- · the exhaust gas itself

There is a risk of fire.

- When the stationary heater is switched on, make sure that:
 - Hot vehicle parts do not come into contact with flammable materials.
 - The exhaust gas can flow out of the stationary heater exhaust pipe unhindered.
 - The exhaust gas does not come into contact with flammable materials.
- **NOTE** Damage to the auxiliary heating

If the auxiliary heating is not used for an extended period of time, it can be damaged.

- Switch the auxiliary heating on for around ten minutes at least once a month.
- ! NOTE Damage to the auxiliary heating due to overheating

If the hot air flow is blocked, the auxiliary heating can overheat and switch off.

- Do not block the hot air flow.
- (i) Vehicles with modified fuel displays: if an externally operated consumer is connected via the cable for the auxiliary heater, this is not taken into consideration on the "range remaining" display of the on-board computer. In this case, observe the fuel display. The fuel display provides the current level.

If you are transporting hazardous materials, comply with the relevant safety regulations. Always place objects at a sufficient distance from the outlet opening of the auxiliary heating.

Auxiliary heating works independently of the engine and complements the climate control system in the vehicle. Auxiliary heating heats the air inside the vehicle to the set temperature.

Hot-water auxiliary heater

Function of the hot-water auxiliary heater

The hot-water auxiliary heater complements your vehicle's climate control system, and has a heater booster, auxiliary heating and auxiliary ventilation function. In addition, the auxiliary heating system heats the engine coolant to protect the engine and save fuel during the warmingup phase. The auxiliary heating heats the air inside the vehicle to the set temperature. It is not dependent on the heat output of the running engine. The auxiliary heating is operated directly using the vehicle's fuel. For this reason, the fuel tank must have been filled above the reserve fuel. level so that the auxiliary heating can work. The auxiliary heating automatically adapts its operating mode to the outside temperature and weather. It is therefore possible that the auxiliary heating may switch from ventilation to heating mode or from heating to ventilation mode. When the engine is running, auxiliary ventilation is not active. Auxiliary heating automatically switches itself off after a maximum of 50 minutes. You cannot use the "auxiliary ventilation" operating mode to cool the air inside the vehicle to below the outside temperature. Auxiliary heating helps to heat up the vehicle while the engine is running and at low outside temperatures.

Operating the hot-water auxiliary heater draws power from the vehicle battery. Therefore, drive a reasonably long distance after heating or ventilating the vehicle twice in succession at most.

Auxiliary heating can be activated only at temperatures below 40 °F (4.5 °C).

Switching the hot-water auxiliary heater on and off with the button Requirements:

• The fuel tank is filled above the reserve level.

Switching auxiliary heating on and off

- ► To switch on: press the state button.
- ► To switch off: press the 👑 button.

Activating the specified temperature

- Switch on the ignition.
- ► To switch on: press the 🖼 button.
- ► To switch off: press the button.
- Set the temperature using the ▼▲ button.
- Press the button.
 The red or blue indicator lamp on the button goes on or off.

Colors of the indicator lamp:

- Blue: stationary ventilation has been switched on.
- Red: the stationary heater has been switched
- Yellow: the departure time has been preselected.

The stationary heater or ventilation switches off after a maximum of 50 minutes.

Switching heater booster mode on and off

- Switch on the ignition.
- To switch on: press the 域 button.
- To switch off: press the switch button. Heater booster mode will be switched on at an outside temperature of less than 32 °F (0 °C) when necessary.
- (i) Heater booster mode is available only for vehicles with hot-water auxiliary heaters.

Adjusting the hot-water auxiliary heater with the on-board computer Requirements:

- The fuel tank is filled above the reserve fuel level.
- · The ignition is switched on.

On-board computer:

→ Settings → Heating

Setting the switch-on time

- Select Settings.
- Select the desired departure time.

Activating the departure time

- Activate the departure time by ticking the box.
- (i) Ensure that A, B and C each correspond to a programmed departure time.
- (i) The programmed time remains set only until the next time the engine is started.


Selecting programmed time

- Set the required programmed time A, B or C.
- (i) The required programmed time A, B or C will appear only if the box to activate the departure time is ticked.
- Select the required programmed time by swiping left or right, e.g. A, B or C.

Problems with hot water auxiliary heating

Problem	Possible causes/consequences and ▶ Solutions	
FAIL ^{((*†))}	Signal transmission between transmitter and vehicle is malfunctioning. Change your position in relation to the vehicle, moving closer if necessary.	
FAIL	The starter battery is not sufficiently charged. Charge the starter battery.	
	The fuel tank is not filled up to the reserve level. Refuel at the nearest gas station.	
FAIL	Auxiliary heating is malfunctioning. Have the auxiliary heating checked at a qualified specialist workshop.	

Operating cargo compartment ventilation



If your vehicle is equipped with a roof ventilator, you can admit fresh air to the cargo compartment, or extract air from it as well.

- Switch on the ignition.
- ➤ To switch on and extract: press switch
 at the top.

 The roof ventilator removes used air from the cargo compartment.
- ➤ To switch on and admit fresh air: press switch ② at the bottom. The roof ventilator feeds fresh air into the cargo compartment.
- ➤ To switch off: set the switch to the center position.

Driving

Switching on power supply or ignition with the start/stop button

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle. they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traf-
- · Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- ► When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.

DANGER Risk of death caused by exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and leads to poisoning.


- Never leave the engine or, if present, the auxiliary heating running in an enclosed space without sufficient ventilation.
- WARNING Risk of fire due to flammable material in the engine compartment or the exhaust system

Flammable materials brought in by either animals or environmental influences may ignite if they come into contact with hot parts of the engine or exhaust system.

Therefore, check regularly that there are no flammable materials in the engine compartment or on the exhaust system.

Requirements:

 The key is in detection range of the antenna (→ page 46) and the key battery is not discharged.



To switch on the power supply: press button
once.

You can now activate the windshield wipers, for example.

The power supply is switched off again when one of the following conditions is met:

- The driver's door is open.
- You press button 1 twice.
- To switch on the ignition: press button (1) twice.

The indicator lamps appear in the instrument cluster.

The ignition is switched off again when one of the following conditions is met:

- · You do not start the vehicle within 15 minutes.
- You press button ① once.

Starting the engine

Starting the vehicle with the start/stop but-

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle. they could:


- · open doors, thereby endangering other persons or road users.
- get out of the vehicle and be hit by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, children could also set the vehicle in motion, for example, by:

- releasing the parking brake.
- shifting the automatic transmission out of park position P.
- starting the engine
- Never leave children and animals unattended in the vehicle.
- ▶ When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

Requirements:

• The key is in detection range of the antenna (→ page 46) and the key battery is not discharged.



- Vehicles with automatic transmission: shift the transmission to position \boxed{P} or \boxed{N} .
- Depress the brake pedal and press button (1) once.
- If the vehicle does not start: switch off unnecessary consumers and press button 1 once.
- If the vehicle still does not start and the Place the Key in the Marked Space See Operator's Manual display message appears in the multifunction display: start the vehicle in emergency operation mode.

Starting the vehicle in emergency operation mode

WARNING Risk of accident and injury due to children left unattended in the vehicle


If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traf-
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.

If the vehicle does not start and the Place Key in Marked Space See Operator's Manual display message appears in the multifunction display, you can start the vehicle in emergency operation mode.



- Remove key ① from your key ring.
- Insert key 1 into the slot.

 The vehicle is started after a brief time.
- Leave the key inserted during the entire journey.
- If you pull key ① out of the slot, the engine continues to run.
- Have key the checked at a qualified specialist workshop.

If the vehicle does not start:

- Leave key (1) in the slot.
- Depress the brake pedal.
- Start the vehicle with the start/stop button.
- (i) You can also switch on the power supply or the ignition with the start/stop button.

Breaking-in notes

Protect the engine during the first 1,000 miles (1,500 km) by:

- Driving at varying road and engine speeds.
- Shifting to the next gear up when or before the tachometer needle is ²/₃ of the way to the red area.
- Avoiding stress on the vehicle such as driving at full throttle.
- Not shifting manually to a lower gear to brake.
- After 1,000 miles (1,500 km), gradually increasing the engine speed and accelerate the vehicle up to full speed.
- Vehicles with automatic transmission: not depressing the accelerator pedal beyond the pressure point (kickdown).

This also applies if the engine or parts of the driverrain have been replaced.

Also observe the following breaking-in notes:

- The sensors of the ESP® driving safety system adjust automatically while a certain distance is being driven after the vehicle has been delivered or after repairs. Full system effectiveness is not reached until the end of this teach-in process.
- New or exchanged brakepads, brake discs and tires only provide optimal braking and bonding after several hundred kilometers. Until then, compensate for the reduced braking effect by applying greater pressure to the brake pedal.

Driving tips

Notes on driving

▲ WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Ensure floor mats and carpets cannot slip and provide sufficient room for the pedals.
- Do not lay multiple floor mats or carpets on top of one another.

WARNING Risk of accident due to unsuitable footwear

Operation of the pedals may be restricted due to unsuitable footwear such as:

- Shoes with platform soles
- Shoes with high heels
- Slippers
- When driving always wear suitable shoes in order to be able to operate the pedals safely.

WARNING Risk of accident when switching off the ignition when driving

If you switch off the ignition while driving, safety functions are restricted or no longer available. This may affect the power steering system and the brake force boosting, for example.

You will then need to use considerably more force to steer and brake.

Do not switch off the ignition while driving.

DANGER Risk of death caused by exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and leads to poisoning.

Never leave the engine or, if present, the auxiliary heating running in an enclosed space without sufficient ventilation.

DANGER Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case when the vehicle becomes stuck in snow, for example.

- Keep the tailpipe and the area around the vehicle free from snow when the engine or the stationary heater are running.
- Open a window on the side of the vehicle facing away from the wind to ensure an adequate supply of fresh air.

WARNING Risk of accident and injury due to being under the influence of alcohol and drugs while driving

Driving when under the influence of alcohol and/or drugs is an extremely dangerous combination. Even small quantities of alcohol or drugs may affect your reflexes, perception and judgment.

The probability of a serious or even fatal accident greatly increases if you drive when under the influence of alcohol or drugs.

Do not drink alcohol or take drugs while driving, and do not allow anyone to drive who has been drinking alcohol or taking drugs.

WARNING Risk of accident and injury from operating mobile communications equipment

If you operate mobile communication equipment when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

The probability of a serious or even fatal accident increases greatly if you operate mobile communication equipment when driving.

Only operate mobile communication equipment when the vehicle is stationary.

For your own safety, always observe the following points when operating mobile communications equipment:

- · Observe the legal requirements for the country in which you are driving.
- · While driving, only operate mobile communications equipment when the traffic conditions permit it. You may otherwise be distracted from the traffic conditions and cause an accident, injuring yourself and others.

WARNING Risk of accident due to overheated brake system

If you rest your foot on the brake pedal during while driving, the brake system may overheat.

This increases the braking distance and the brake system may even fail.

- Never use the brake pedal as a footrest.
- Do not press the brake pedal and accelerator pedal simultaneously while driv-

On long and steep downhill gradients, you should change down to a lower gear in good time. Take particular note of this when driving a laden vehicle. By doing so, you will make use of the engine's braking effect. This will take some of the strain off the brake system and prevent the brakes from overheating and wearing too quickly.

- **NOTE** Wearing out the brake linings by continuously depressing the brake pedal
- Do not depress the brake pedal continuously whilst driving.
- To use the braking effect of the engine, shift to a lower gear in good time.
- **NOTE** Damage to the drivetrain and engine when pulling away
- Do not warm up the engine while the vehicle is stationary. Pull away immediately.
- Avoid high engine speeds and driving at full throttle until the engine has reached its operating temperature.
- **NOTE** Damage to the catalytic converter due to non-combusted fuel

The engine is not running smoothly and is misfiring.

Non-combusted fuel may get into the catalytic converter.

- Only depress the accelerator pedal slightly.
- Have the cause rectified immediately at a qualified specialist workshop.

Exhaust emission monitoring

Specific engine systems are designed to keep poisonous components of exhaust emissions within legal limits.

These systems only work optimally if they are maintained exactly according to manufacturer's specifications. It is for this reason that all work on the engine should only be performed by qualified and authorized Mercedes-Benz Center technicians.

Under no circumstances should engine settings be changed. In addition, all specific maintenance work must be performed at regular intervals and in compliance with the service regulations of the dealer named in the imprint. Refer to the Maintenance Booklet for details.

Notes on short-distance trips

If the vehicle is predominantly used for short-distance driving, fuel may accumulate in the engine oil and cause engine damage.

If you mainly drive short distances, you should drive on a freeway or go for a country drive for 20 minutes every 480 km (300 miles). This facilitates the regeneration of the diesel particulate filter

Notes on the speed limit

WARNING Risk of injury through exceeding the specified tire load rating or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.

As the driver, you must find out about the maximum permissible speed for the tires (tire and tire pressure). In particular, observe the legal requirements for tires for the country you are in. You can permanently limit the speed of your vehi-

Mercedes-Benz recommends a qualified specialist workshop for programming the speed limit.

Note that you cannot exceed a programmed limit speed when overtaking.

On downhill gradients, the speed limit may be exceeded. Apply the brakes if necessary.

Display messages indicate that you are approaching the limit speed.

(i) For buses, the speed is limited at the factory to 100 km/h. When overtaking, bear in mind that the limit speed cannot be exceeded.

Information about driving abroad

Service

An extensive Mercedes-Benz service is also available abroad. Nevertheless, please remember that services facilities or spare parts may not be available immediately. The relevant workshop directories are available from an authorized Mercedes-Benz Center.

Fuel

In some countries, only fuels with an increased sulfur content are available.

Mercedes-Benz recommends installing a fuel filter with a water separator for countries with an increased water content in diesel.

Unsuitable fuel can cause engine damage. Information about fuel can be found in the "Fuel" section (\rightarrow page 341).

Information about transport by rail

Transporting your vehicle by rail may be subject to certain restrictions or require special measures to be taken in some countries due to varying tunnel heights and loading standards.

You can obtain information about this from any authorized Mercedes-Benz Center.

Notes on brakes

WARNING Risk of skidding and of an accident due to shifting down on slippery road surfaces

If you shift down on slippery road surfaces to increase the engine braking effect, the drive wheels may lose traction.

Do not shift down on slippery road surfaces to increase the engine braking effect.



▲ WARNING Risk of accident due to the brake system overheating

If you leave your foot on the brake pedal when driving, the brake system may overheat.

This increases the braking distance and the brake system may even fail.

- Never use the brake pedal as a footrest.
- Do not depress the brake pedal and the accelerator pedal at the same time while driving.

Downhill gradients

On long and steep downhill gradients you should observe the following instructions:

- In vehicles with an automatic transmission, shift down to shift ranges 2 or 1 in good time so that the engine is running at a medium to high engine speed (\rightarrow page 124).
- (i) Change the shift range in good time when cruise control is activated. Observe the driving tips (\rightarrow page 111).

You thereby make use of the braking effect of the engine and do not have to brake as often to maintain the speed. This relieves the load on the service brake and prevents the brakes from overheating and wearing too quickly.

Heavy and light loads

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately. Drive on for a short while. The brakes cool down more quickly in the airflow.

If the brakes have been used only moderately, you should occasionally test their effectiveness. To do this, brake more firmly from a higher speed while paying attention to the traffic conditions. The brakes will grip better as a result.

Wet road surfaces

If you have been driving for a long time in heavy rain without braking, there may be a delayed response when you first apply the brakes. This may also occur after driving through a car wash or deep water. You must depress the brake pedal more firmly. Maintain a greater distance to the vehicle in front.

While paying attention to the traffic conditions. you should brake the vehicle firmly after driving on a wet road surface or through a car wash. This heats the brake discs so that they dry more quickly, which protects them against corrosion.

Limited braking effect on salt-treated roads:

- · A layer of salt on the brake discs or brakepads can increase braking distances considerably, or braking may happen on only one side
- Maintain an especially large safe distance to the vehicle in front

To remove the layer of salt:

- Apply the brakes from time to time, paying attention to traffic conditions
- Carefully depress the brake pedal at the end of a journey and after the start of a new journey

Checking the brakepad thickness

In addition to monitoring using the brakepad wear sensor, regularly monitor and check all of the brakepads by performing a visual inspection to look for pad material wear.

If you are unable to check the brakepad wear on the inside of the wheels, remove the wheels if you possess the required skills, or visit a qualified specialist workshop.

If the brakepad material thickness is less than 0.12 in (3 mm), have the brakepads checked and replaced at a qualified specialist workshop, if necessary.

Do not solely rely on the brakepad wear sensor.

It is also strongly recommended that you have the brakepads checked at a qualified specialist workshop, not only at every service displayed by the maintenance interval display, but also prior to long journeys and whenever the wheels are removed

New brake discs and brakepads

New brakepads and brake discs only reach their optimal braking effect after approximately 100 miles (100 kilometers).

Until then, compensate for the reduced braking effect by applying greater pressure to the brake pedal. For safety reasons, Mercedes-Benz recommends that you only have brakepads and brake discs which are approved by Mercedes-Benz installed on your vehicle.

Other brake discs or brakepads may compromise the safety of your vehicle.

Always replace all brake discs and brakepads on an axle at the same time. Always install new brakepads when replacing brake discs.

Parking brake



WARNING Risk of skidding or an accident by braking with the parking brake

If you have to brake your vehicle with the parking brake, the braking distance is considerably longer and the wheels may lock. There is an increased risk of skidding and/or accident.

- Only brake the vehicle with the parking brake if the service brake has failed.
- In this case, do not apply the parking brake with too much force.
- If the wheels lock, immediately release the parking brake as much as required for the wheels to turn again.

Vehicles with a manual parking brake

When driving on wet roads or dirt-covered surfaces, road salt or dirt may get into the parking brake. This causes corrosion and a reduction of braking force.

In order to prevent this, drive with the parking brake lightly applied from time to time.

When doing so, drive for a distance of approximately 300 ft at a maximum speed of 13 mph (20 km/h).

The brake lights do not light up when you brake the vehicle with the parking brake.

Information about driving on wet roads Hydroplaning



▲ WARNING Risk of aquaplaning because tire tread is too low

Depending on the depth of the water on the roadway, aquaplaning can occur despite sufficient tire tread depth and low speed.

Avoid tire ruts and brake carefully.

Therefore, in heavy rain or other conditions in which hydroplaning can occur, drive as follows:

- Reduce your speed
- Avoid tire ruts
- Brake carefully

Driving on flooded roads

Bear in mind that vehicles traveling in front or in the opposite direction create waves. This may cause the maximum permissible depth of water to be exceeded. These notes must be observed. under all circumstances. Otherwise, you can damage the engine, electrics and transmission.

If you have to drive on stretches of road on which water has collected, please bear in mind the following:

- The water level of standing water may not be above the lower edge of the front bumper.
- You may drive no faster than walking pace.

Observe the notes on fording while off-road for all-wheel drive vehicles (\rightarrow page 116).

Information about driving in winter



DANGER Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case when the vehicle becomes stuck in snow, for example.

- Keep the tailpipe and the area around the vehicle free from snow when the engine or the stationary heater are run-
- Open a window on the side of the vehicle facing away from the wind to ensure an adequate supply of fresh air.

A

WARNING Risk of skidding and of an accident due to shifting down on slippery road surfaces

If you shift down on slippery road surfaces to increase the engine braking effect, the drive wheels may lose traction.

 Do not shift down on slippery road surfaces to increase the engine braking effect.

Vehicles with automatic transmissions may roll in neutral position N for only a short time. Allowing the wheels to roll for longer, e.g. when towing, causes transmission damage.

If the vehicle threatens to skid, or cannot be stopped when traveling at a low speed, you can stabilize the vehicle using the following measures:

- Shift the automatic transmission to neutral position N.
- Try to maintain control of the vehicle using corrective steering.

Drive particularly carefully on slippery roads. Avoid sudden acceleration, steering and braking maneuvers.

Have your vehicle winterized at a qualified specialist workshop in good time at the onset of winter

Observe the notes on snow chains $(\rightarrow page 309)$.

Regularly check the vehicle and remove snow or ice when traveling in wintry conditions.

An accumulation of snow and ice, particularly when frozen, in the area around the air intake, moving parts, the axles and the wheel housing, may cause the following problems:

- · Obstruction of the air intake
- · Damage to vehicle parts
- Malfunctions due to restriction of mobility intended by the design (e.g. reduced steering movement)

If there is any damage, inform a qualified specialist workshop.

Information about driving off-road

A

WARNING Risk of accident if you do not keep to line of fall on inclines

If you drive at an angle or turn on an incline, the vehicle could slip sideways, tip and rollover.

Always drive on inclines in the line of fall (straight up or down) and do not turn.

WARNING Risk of injury due to accelerating force during off-road driving

When driving off-road on uneven surfaces, the force of the vehicle's acceleration affects your body from all directions.

You could, for example, be thrown from your seat.

Always wear a seat belt when driving off-road.

WARNING Risk of injury to the hands when driving over obstacles

If you drive over obstacles or in tire ruts, the steering wheel may fold back and cause injuries to the hands.

- Steering wheel must always be held securely with both hands.
- When driving over obstacles, expect increased steering forces at short notice.

★ WARNING Risk of fire due to flammable materials on hot parts of the exhaust system

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system.

- When driving on unpaved roads or offroad, regularly check the vehicle underside.
- Remove trapped plants or other flammable material.
- If there is damage, consult a qualified specialist workshop immediately.

NOTE Damage to the vehicle after driving off-road

When driving off-road or on unpaved surfaces, foreign bodies such as stones and branches could become trapped on the vehicle underside, on wheels and tires, causing damage to the vehicle.

Foreign bodies could cause the following

- Damage the suspension, the fuel tank or the brake system.
- Disturb the balance and cause vibrations.
- Regularly remove any trapped foreign bodies, e.g. stones and branches.
- After driving off-road, check carefully whether there is any damage to the vehicle.
- If there is damage, have the vehicle checked at a qualified specialist workshop.

When driving off-road or on unpaved surfaces, check the vehicle underside, wheels and tires regularly at regular intervals. In particular, remove any trapped foreign bodies, such as stones and branches.

Observe the following notes regarding foreign bodies of this kind:

- They may damage the suspension, the fuel tank or the brake system.
- They may disturb the balance and cause vibrations.
- They may be flung out from the vehicle when you continue driving.

If there is any damage, inform a qualified specialist workshop.

When driving off-road on steep inclines, you must make sure that the DEF tank is sufficiently filled. Therefore, ensure a level of at least ten liters before off-road driving.

When driving off-road and on construction sites. sand, mud and water, also mixed with oil, can get into the brakes. This may lead to a reduction in braking effect or total brake failure, also as a result of increased wear. The braking characteristics will vary depending on the material that has got into the system. Clean the brakes after driving off-road. If you then notice a reduced braking effect or hear scraping noises, have the brake

system checked immediately at a qualified specialist workshop. Adjust your driving style to the changed braking characteristics.

Driving off-road or on construction sites increases the possibility of vehicle damage which may in turn lead to the failure of certain major assemblies and systems. Adapt your driving style to the off-road driving conditions. Drive carefully. Have any vehicle damage rectified at a qualified specialist workshop as soon as possible.

When driving on rough cross-country terrain, do not shift the transmission to neutral and do not disengage the clutch. You could lose control when attempting to brake the vehicle with the service brake. If your vehicle cannot manage an uphill incline, drive back down in reverse gear.

When loading your vehicle for off-road driving or on a construction site, keep the vehicle's center of gravity as low as possible.

Checklist before off-road driving

- Check the fuel and DEF levels (→ page 175) and refill if necessary (\rightarrow page 133).
- Engine: check the oil level and add oil if necessary (-> page 281). Before driving up or down extreme inclines or slopes, fill the oil to the maximum level.
- i If you drive up or down extreme inclines or slopes, the symbol may appear in the multifunction display. The engine operating safety is not put at risk if you have filled the engine oil to the maximum level before the journey.
- · Vehicle tool kit: check that the jack is working (\rightarrow page 327).
- Make sure that a lug wrench (→ page 327), a wooden underlay for the jack, a robust tow rope, a folding spade and a wheel chock (depending on equipment) are carried in the vehicle.
- Tires and wheels: check the tire tread depth $(\rightarrow$ page 308) and the tire pressure $(\rightarrow page 316)$.

Rules for off-road driving

Always be aware of the ground clearance of the vehicle and avoid obstacles such as deep tire ruts.

Obstacles can damage the following parts of the vehicle, for example:

- Suspension
- Drivetrain
- Fuel and supply tanks

Therefore, always drive slowly when off-road. If you must drive over obstacles, have the co-driver instruct vou.

- (i) Mercedes-Benz recommends that you additionally carry a shovel and a recovery rope with a shackle in the vehicle.
- · Make sure that loads and items of luggage are securely stored or lashed down $(\rightarrow page 271)$.
- · Before driving off-road, stop the vehicle and engage a low gear.
- Vehicles with DSR: activate DSR when you are driving downhill (\rightarrow page 127).
- . All-wheel drive vehicles: activate the allwheel drive (\rightarrow page 125) and, if necessary, activate the LOW RANGE transmission ratio $(\rightarrow page 126)$.
- If the surface requires, temporarily deactivate ESP® when pulling away (\rightarrow page 148).
- Only drive off-road with the engine running and a gear engaged.
- Drive slowly and smoothly. Walking pace is necessary in many situations.
- · Avoid spinning the driven wheels.
- Always ensure that the wheels remain in contact with the ground.
- Exercise the utmost caution when driving across unfamiliar, unpredictable terrain. As a precaution, get out of the vehicle to take a look at the route to be taken first.
- Look out for obstacles (e.g. rocks, holes, tree stumps and tire ruts).
- · Avoid edges where the surface could crumble or break away.

Rules for fording off-road (all-wheel drive vehicles)

- Observe the safety notes and general notes on driving off-road.
- Check the depth and characteristics of the body of water before fording. The water must not be deeper than 23.6 in (60 cm).
- The climate control system is switched off $(\rightarrow page 101)$.

- The auxiliary heating is switched off $(\rightarrow page 106)$.
- Activate all-wheel drive (→ page 125) and activate it on vehicles with the LOW RANGE transmission ratio (\rightarrow page 126).
- Restrict the shift range to 1 or 2.
- · Avoid high engine speeds.
- Drive slowly and smoothly at no more than a walking pace.
- Ensure that no bow wave forms while driving.
- After fording, dry the brakes.

After driving through a body of water deeper than 19.7 in (50 cm), make sure to check all vehicle fluids for any signs of penetration by water.

Checklist after driving off-road

Driving over rough terrain places greater demands on your vehicle than normal road operation. Check your vehicle after driving on rough terrain. This allows you to detect damage promptly and reduce the risk of an accident for vourself and other road users. Clean your vehicle thoroughly before driving on public roads.

If you find damage to the vehicle after off-road driving, have the vehicle checked at a qualified specialist workshop immediately.

Observe the following points after driving offroad, on construction sites and before driving on public roads:

- Vehicles with DSR: deactivate DSR $(\rightarrow page 127).$
- . All-wheel drive vehicles: deactivate the allwheel drive (\rightarrow page 125).
- Activate ESP[®] (→ page 148).
- Clean the exterior lighting, particularly the headlamps and tail lamps, and check them for damage.
- Clean the front and rear license plates.
- Clean the windshield, windows and outside mirrors.
- Clean the steps, entrances and grab handles. This increases the safety of your footing.
- · Clean the wheels and tires, wheel wells and the underbody of the vehicle with a water iet. This increases road adhesion, especially on wet roadways.
- Check the wheels and tires and wheel wells for trapped foreign objects and remove them. Trapped foreign objects can damage the

wheels and tires or may be flung out from the vehicle when continuing the journey.

- Check the underbody for trapped branches or other parts of plants and remove them.
- Clean the brake discs, brakepads and axle joints, particularly after operation in sand, mud, grit and gravel, water or similarly dirty conditions.
- Check the entire floor assembly, the tires. wheels, bodywork structure, brakes, steering, suspension and exhaust system for any damage.
- Check the service brake for operating safety, e.g. carry out a brake test.
- · If you notice strong vibrations after driving off-road, check the wheels and drivetrain for foreign objects again. Remove any foreign objects which can lead to imbalances and thus cause vibrations. In the event of damage to the wheels and the drive train, visit a qualified specialist workshop immediately.

Function of the ECO display

The ECO display sums up your driving characteristics from the start to the end of the trip and supports a consumption-optimized driving style.

You can influence consumption as follows:

- Anticipate road and traffic conditions.
- Observe the gearshift recommendation.



Instrument Display with color display

The segment's lettering lights up brightly, the outer edge lights up and the segment is filled when the vehicle is driven with the following characteristics:


- ACCELERATION: moderate acceleration
- CONSTANT: consistent speed
- 3 COASTING: gentle deceleration and rolling

The segment's lettering is gray, the outer edge is dark and the segment is emptied when the vehicle is driven with the following characteristics:

- ACCELERATION: sporty acceleration
- CONSTANT: speed fluctuations
- COASTING: heavy braking

You have driven in a consumption-optimized manner when:

- The three segments have been completely filled simultaneously.
- The edge of all three segments lights up.



Instrument Display with black and white displav

The bars will fill up when the vehicle is driven with the following characteristics:

- Moderate acceleration
- Consistent speed
- Gentle deceleration and rolling

The bars will empty when the vehicle is driven with the following characteristics:

- Sporty acceleration
- Speed fluctuations
- 3 Heavy braking

The display will also show the additional range Bonus XXX mi Fr. Start or XXX mi From Start) that you have achieved with your driving style compared with a driver with a very sporty driving style. This range does not correspond to any fixed consumption saving.

Diesel particulate filter

Notes on regeneration

DANGER Risk of death caused by exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and leads to poisoning.

Never leave the engine or, if present, the auxiliary heating running in an enclosed space without sufficient ventilation.

A WARNING Risk of fire caused by hot exhaust system parts

Flammable materials such as leaves, grass or twigs may ignite.

- Park the vehicle so that no flammable material can come into contact with hot vehicle components.
- In particular, do not park on dry grassland or harvested grain fields.

Regeneration without interruption takes approx. 15 minutes.

If the vehicle is predominantly used for short distance driving or extended non-operational times, this could lead to a malfunction in the automatic cleaning function for the diesel particulate filter. As a result, permanent blocking of the diesel particulate filter may occur, and fuel may also accumulate in the engine oil and cause engine failure.

If you mainly drive short distances, you should drive on a freeway or go for a country drive for 20 minutes every 500 km (300 miles). This facilitates the diesel particulate filter's burn-off process.

!

NOTE Damage due to hot exhaust gases

During regeneration, extremely hot exhaust gases escape from the tailpipe.


During regeneration, maintain a minimum distance of 7 ft (2 m) from other objects, e.g. parked vehicles.

Displaying load

On-board computer:

→ Service → Consumption Info

The load of the diesel particulate filter is displayed.



Load display at 75% load

To exit the display: press the back button on the left-hand side of the steering wheel.

Bear in mind the following related topic:

Operating the on-board computer $(\rightarrow page 120)$

Battery main switch

Notes on the battery main switch

NOTE Damage to the electrical system

If you remove the battery main switch, it could lead to the electrical system becoming damaged.

Make sure that the ignition is switched off and that at least 15 minutes have passed before removing the battery main switch. Otherwise, electrical system components could be damaged.

You can use the battery main switch to disconnect the current to all your vehicle's consumers. This will prevent uncontrolled battery discharge caused by quiescent current consumers.


If your vehicle is equipped with an auxiliary battery in the engine compartment or in the base of the co-driver's seat, you must disconnect both batteries. Only then is the electrical system fully disconnected from the power supply.

- (i) Only disconnect the vehicle from the power supply using the battery main switch in the following situations:
 - The vehicle is stationary for a long time
 - It is absolutely necessary to disconnect the vehicle from the power supply

After switching on the power supply, you will need to reset the side windows (\rightarrow page 58) and the electric sliding door (\rightarrow page 55).

Switching the power supply on/off

Switching off the power supply



Battery main switch


NOTE Damage to the auxiliary battery in vehicles with a rear wheel drive and automatic transmission

If the battery main switch is removed, the auxiliary battery could be damaged by heavy discharging.

- Do not remove the battery main switch.
- Consult a qualified specialist workshop to put the vehicle out of use.
- (i) Note the remaining time before the next service due date and oil change. The time recording is also disrupted if the power supply is disconnected.
- Switch off the ignition and wait at least 15 minutes.
- Remove cover ①. To do this, take hold of the cover at the upper edge, move it outwards in the direction of the driver's door and lift it off.
- Press and hold button 3.

- Pull plug 2 out of the ground pin.
- Push plug 2 as far as possible in the direction of the arrow so that it cannot make contact with the ground pin. All starter battery consumers are disconnected from the power supply.

Switching on the power supply



Battery main switch

- Press plug 2 onto the ground pin until you feel it engage and plug 2 is in full contact with the ground pin. All starter battery consumers are reconnected to the power supply.
- Fasten cover ①. To do this, place the cover on from above.
- Press the cover into the neighboring switching console on the right hand side.

Automatic transmission

DIRECT SELECT lever

Function of the DIRECT SELECT lever

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- open doors, thereby endangering other persons or road users.
- get out of the vehicle and be hit by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, children could also set the vehicle in motion, for example, by:


- · releasing the parking brake.
- shifting the automatic transmission out of park position P.
- starting the engine
- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

WARNING Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position \boxed{D} or \boxed{R} , the vehicle may accelerate sharply.


If you engage the transmission position
D or R always depress the brake pedal firmly and do not accelerate at the same time.

You use the DIRECT SELECT lever to switch the transmission position. The current transmission position appears in the multifunction display.



- P Park position
- R Reverse gear
- N Neutral
- **D** Drive position

Engaging reverse gear R



Transmission position display **R** is shown in the multifunction display.


Selecting neutral N

WARNING Risk of accident and injury when neutral position is engaged

If you park the vehicle with the transmission in neutral position $\boxed{\mathbf{N}}$ and the parking brake is not engaged, the vehicle may roll away.

There is a risk of accident and injury.

Before parking the vehicle, apply the parking brake.




Press the brake pedal and the DIRECT SELECT lever upwards or downwards to the first point of resistance. Transmission position display N is shown in the multifunction display.

Releasing the brake pedal will allow you to move the vehicle freely, e.g. to push it or tow it.

If the automatic transmission should also stay in neutral N when the ignition is switched off, carry out the following:

- Start the vehicle.
- Depress the brake pedal and shift to neutral N.
- Release the brake pedal.
- Switch off the ignition.
- (i) If you then leave the vehicle and the Smart-Key is still in the vehicle, the automatic transmission will stay in neutral N from then on.

Engaging park position P




Press button 1. Transmission position display P is shown in the multifunction display.

Park position **P** is engaged automatically when one of the following conditions is met:

- You switch off the engine in transmission position D or R.
- You open the driver's door when the vehicle is stationary or when driving at a very low speed and in transmission position $\boxed{\mathbf{D}}$ or $\boxed{\mathbf{R}}$.

Engaging drive position D



Depress the brake pedal and push the DIRECT SELECT lever downwards past the first point of resistance. Transmission position display **D** is shown in the multifunction display.


The automatic transmission shifts through the individual gears automatically when it is in transmission position D. This is determined by the following factors:

- Position of the accelerator pedal
- Driving speed

Restricting the shift range

Requirements:

• Transmission position D is engaged $(\rightarrow page 123)$.



To restrict the shift range: briefly pull steering wheel paddle shifter 1.

The automatic transmission shifts to the next gear down, depending on the gear currently engaged. The shift range is also restricted.

The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

Pull and hold steering wheel paddle shifter

The automatic transmission will change to a shift range which allows easy acceleration and deceleration. To do this, the automatic transmission shifts down one or more gears and restricts the shift range.

The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

- (i) The automatic transmission does not shift down if you pull steering wheel paddle shifter whilst traveling at too high a speed. If the shift range is restricted and the maximum engine speed for the restricted shift range is reached, the automatic transmission will not shift up.
- To derestrict the shift range: briefly pull steering wheel paddle shifter 2. The automatic transmission shifts to the next gear up, depending on the gear currently engaged. This derestricts the shift range at the same time.

The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

To derestrict the shift range: pull and hold steering wheel paddle shifter 2.

or

Engage transmission position **D** again $(\rightarrow page 123)$.

The automatic transmission shifts up one or more gears depending on the gear currently engaged. Simultaneously, the shift range restriction is deactivated and the transmission position appears in the multifunction display D.

Adapt the shift range to the driving situation:

- 3 Use the engine's braking effect.
- Use the engine's braking effect on downhill gradients and when driving on steep roads, in mountainous areas as well as under arduous operating conditions.
- Use the engine's braking effect on extremely steep downhill gradients and on long downhill stretches.

Using kickdown

- For maximum acceleration: depress the accelerator pedal beyond the pressure point.
- Ease off the accelerator pedal once the desired speed is reached.

All-wheel drive

Notes on all-wheel drive

All-wheel drive ensures permanent drive for all four wheels, and together with ESP® it improves the traction of the vehicle.

The traction control of the all-wheel drive also takes place via the brake system. Therefore, the brake system can overheat during extreme offroad use. In this case, ease off the accelerator pedal or stop to allow the brake system to cool down.

If a driven wheel spins due to insufficient traction, observe the following notes:

- When pulling away, make use of the traction control integrated in ESP®. Depress the accelerator pedal as far as necessary.
- Take your foot off the accelerator pedal, slowly, while the vehicle is in motion.

In wintry driving conditions, always use winter tires (M+S tires) and, if necessary, snow chains (→ page 309). Only in this way can the maximum effect of all-wheel drive be achieved.

Use DSR (Downhill Speed Regulation) when driving downhill off-road (\rightarrow page 126).

If you fail to adapt your driving style or if you are inattentive, the all-wheel drive system can neither reduce the risk of an accident nor override the laws of physics. The all-wheel drive system cannot take road, weather and traffic conditions into account. The all-wheel drive system is only an aid. You are responsible for maintaining a safe distance from the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

NOTE Risk of damage to the drivetrain and the brake system

If you operate vehicles with all-wheel drive on a one-axle test stand, you may damage the drivetrain or the brake system.

- A function or performance test should only be carried out on a two-axle test stand
- If you wish to operate the vehicle on such a test stand, please consult a qualified specialist workshop in advance.
- **NOTE** Risk of damage to the transfer

If you tow the vehicle with a raised axle, the transfer case can get damaged. Such damage is not covered by Mercedes-Benz Limited Warranty.

- Never tow the vehicle with a raised axle.
- Only tow the vehicle with all wheels on the ground or fully raised.
- Note the instructions on towing the vehicle with full contact with the ground for all wheels.

Engaging all-wheel drive

Conditions for engaging/disengaging

You can engage and deactivate the all-wheel drive when stationary or while driving slowly.

When stationary, the following must be observed:

- The engine is running.
- The steering wheel in the straight-ahead posi-

If the all-wheel drive cannot be engaged when stationary:

Vehicles with automatic transmission: shift the selector lever from N to D from D to N from N to R and back to N. Engaging and disengaging the all-wheel drive can be made easier in this way.

Observe the following when driving slowly:

- · The engine is running.
- The vehicle is not traveling faster than 6.2 mph (10 km/h).
- The vehicle is not being driven around a bend.

If it is not possible to engage all-wheel drive when the vehicle is rolling:


Vehicles with automatic transmission: briefly move the selector lever to \mathbb{N} .

Engaging/disengaging all-wheel drive

NOTE Risk of damage to the transfer case

If you step on the accelerator pedal while the all-wheel drive is engaged or disengaged, the transfer case may be damaged.

Do not step on the accelerator pedal when the indicator lamp in the switch for the all-wheel drive is flashing.



To engage/disengage: press the upper section of switch .

The indicator lamp in switch flashes while the all-wheel drive is engaged or disengaged.

The and warning lamps light up in the instrument display. ESP® and ASR are deactivated for the duration of the shift operation. If the shift operation is successful, the and warning lamps in the instrument display go out and ESP® and ASR are reactivated.

As long as the indicator lamp in switch (1) is flashing, you can cancel the shift operation by pressing switch (1) again. If the shift operation fails, the indicator lamp in switch (1) briefly flashes three times. One of the shift conditions was not met.

If the indicator lamp in switch ① lights up, all-wheel drive is engaged. A relevant message appears in the display of the on-board computer.

(i) If the LOW RANGE gear reduction is engaged, the all-wheel drive cannot be disengaged.

Function of the LOW RANGE gear reduction


The LOW RANGE gear reduction enables very slow driving in the respective gears. If you engage LOW RANGE, the engine's performance characteristics and the automatic transmission's shifting characteristics are adjusted accordingly. The transmission ratio from the engine to the wheels is around 40% lower than in the road position. The drive torque is increased correspondingly.

Conditions for engaging/disengaging

The following shifting conditions must be met in order to engage or disengage LOW RANGE:

- All-wheel drive is engaged (→ page 125).
- · The engine is running.
- The vehicle is stationary.
- You depress the brake pedal.
- Vehicles with automatic transmission: the selector lever is in position P or N.

Engaging and disengaging LOW range



- Engaging and disengaging LOW range
- (i) On vehicles with DSR (Downhill Speed Regulation), switch (ii) is replaced with the switch for DSR.
- To engage and disengage: press the upper section of switch .

The RANCE indicator lamp flashes in the instrument display for the duration of the shift operation.

- When the shift operation takes place and LOW RANGE is engaged, the RANGE indicator lamp lights up.
- When the shift operation takes place and LOW RANGE is disengaged, the RANGE indicator lamp goes out.

As long as the indicator lamp RANGE is flashing, you can cancel the shift operation by pressing button again. If the shift operation fails, the indicator lamp RANGE briefly flashes three times. One of the shift conditions was not met.

DSR (Downhill Speed Regulation)

Notes on DSR

If you fail to adapt your driving style or you are inattentive, DSR can neither reduce the risk of accident nor override the laws of physics. DSR cannot take road, weather and traffic conditions into account. DSR is only an aid. You are responsible for a safe distance to the vehicle in front, for vehicle speed and for braking in good time.

DSR supports you when driving downhill. DSR maintains a set speed for you on downhill gradients by applying the brakes as required. Main-

taining the speed is dependent on the road surface conditions and the downhill gradient and cannot therefore be guaranteed in all situations.


You can set the speed depending on the gear range to between 2 mph (4 km/h) and 11 mph (18 km/h) using the brake and accelerator pedals or the rocker switch on the steering wheel.

DSR automatically controls in the following situations:

- If the vehicle is stationary, or its speed is less than 2 mph (4 km/h), the speed is set to 2 mph (4 km/h) or it is set to the minimum speed for the respective gear range.
- If you drive faster than 11 mph (18 km/h) offroad, DSR switches to standby mode. DSR remains activated, but does not brake automatically.
- If you drive downhill slower than 11 mph (18 km/h), DSR sets the speed to the previously set speed.
- If you drive faster than 28 mph (45 km/h), DSR switches off automatically.

Activating/deactivating DSR

Activating DSR



You can activate DSR when the vehicle is stationary or moving.

- Press the upper section of switch ①.
- Brake or accelerate the vehicle to the desired speed between 2 mph (4 km/h) and 11 mph (18 km/h).
- Release the brake or accelerator pedal. The current speed is stored. When stationary, 2 mph (4 km/h) or the minimum possible speed for each gear range is stored. DSR

maintains the stored speed on the downhill gradient and brakes automatically.

When DSR is activated and the vehicle pulls away, accelerates or brakes on an incline, the speed set corresponds to the speed at which the accelerator or brake pedal is released or the rocker switch is pressed during DSR regulation. This is only the case if you are not driving faster than 11 mph (18 km/h).

DSR status display in the on-board computer

DSR is activated:

DSR and the set speed appear in the status area of the on-board computer.

DSR is activated, but is not intervening:

- You are driving between 11 mph (18 km/h) and 28 mph (45 km/h).
- DSR and the speed 11 mph (18 km/h) appear in the status area of the on-board computer.


DSR is in standby mode.

DSR is inactive:

- You are exceeding a speed of 28 mph (45 km/h).
- DSR appears in the status area of the onboard computer. In addition, the DSR Off message appears.
- DSR --- appears in the status area of the on-board computer.

Setting the speed while driving downhill

You can set the speed to between 2 mph (4 km/h) and, depending on the gear range, up to 11 mph (18 km/h) using the brake and accelerator pedals or the rocker switch on the steering wheel.



Release the brake or accelerator pedal. The current speed is stored.


or

- Press rocker switch up or down during a DSR regulation.
 - The last saved speed is increased or reduced.
- Release rocker switch ①.
 The current speed is stored.

or

- Press rocker switch up or down until desired speed is reached.
- Release rocker switch ①.
 The current speed is stored.
- i It may be a moment before the vehicle starts to brake to the set speed. Take this delay into account when setting the speed with rocker switch ...

Deactivating DSR



Press the upper section of switch ①.

or

Accelerate and drive faster than 28 mph (45 km/h).

DSR deactivates automatically in the following situations:

- You drive faster than 28 mph (45 km/h).
- There is a malfunction in the ESP® or ABS system.

Electronic level control

Function of ENR (electronic level control)



WARNING Risk of entrapment from vehicle lowering

When lowering the vehicle, people could become trapped if their limbs are between the vehicle body and the tires or underneath the vehicle.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.

WARNING Risk of injury from jack tipping

If you park a vehicle with air suspension, the air suspension may remain activated for up to one hour, even when the ignition is switched off. If you then raise the vehicle with the jack, the air suspension will attempt to adjust the vehicle level.

The jack may tip.

Press the Service button on the air suspension remote control before raising the vehicle.

This prevents automatic readjustment of the vehicle level and prevents it from being raised or lowered manually.

WARNING Risk of accident due to lowered or raised chassis

Driving with a lowered or raised chassis may greatly impair braking and handling characteristics. You may also exceed the permissible vehicle height when the chassis is raised.

Set the driving level before pulling away.

WARNING Risk of accident from malfunction of electronic level control

If electronic level control is malfunctioning, the vehicle level may be asymmetrical, too high or too low.

The driving and steering characteristics of the vehicle may be noticeably different.

Adapt your driving style accordingly and drive carefully.

- Stop, paying attention to road and traffic conditions.
- Consult a qualified specialist workshop.
- NOTE Risk of damage to the chassis from lowered vehicle level

If electronic level control is malfunctioning or readjusts while you are driving, the vehicle level may be lowered.

- Pay attention to the road conditions and ensure there is sufficient ground clearance.
- Drive carefully.

The level of the vehicle depends on vehicle load and the load distribution. Electronic level control adjusts the level of the rear axle automatically on vehicles with an air-sprung rear axle. The vehicle level is thereby always maintained at the driving level, regardless of vehicle load. Driving dynamics remain unaffected. The height difference between the sides of the vehicle may be up to 0.4 in (1 cm).

Electronic level control is not engine-dependent and is only operational when the ignition is switched on. The electronic level control compressor works audibly.

(i) If the compressor works constantly or starts up several times per minute, electronic level control is malfunctioning.

Depending on the vehicle equipment, electronic level control switches between manual and automatic mode depending on either the vehicle speed or the position of the parking brake.

If electronic level control switches depending on vehicle speed, manual operation is automatically activated when the vehicle is stationary. You may raise or lower the vehicle level. If you subsequently drive faster than 6 mph (10 km/h), manual mode is automatically deactivated and automatic mode sets the vehicle level.

If electronic level control switches depending on the parking brake position, manual mode is automatically activated when the parking brake is applied. You may raise or lower the vehicle level to load and unload. If you release the parking brake, manual mode is automatically deactivated and automatic mode sets the driving level.

When working on the vehicle or changing a wheel, you can deactivate electronic level control $(\rightarrow page 129).$

If electronic level control is malfunctioning or the vehicle level is too high or too low, an audible signal sounds

The driving and steering characteristics of the vehicle will be noticeably different. Electronic level control adjusts the vehicle level to the normal level as soon as possible. Continue driving carefully until the audible signal stops. Only then is the vehicle at normal level.

Automatic mode and electronic level control automatically switch on again to restore the vehicle level, depending on the option selected:

- when the parking brake is released
- from speeds of approximately 6 mph (10 km/h)

If the electronic level control compressor threatens to overheat, e.g. due to repeated raising or lowering within a short period, electronic level control is deactivated. You can raise or lower the vehicle level again after approximately one minute.


Raising and lowering the vehicle level

Certain special equipment enables other operation options:

- Ambulance: raising the vehicle level above the driving level (center position) is not possible. Only the lowest position and the driving level can be set.
- Speed signal: in order to operate electronic level control, the parking brake must not be applied. Electronic level control can be operated manually up to 6.2 mph (10 km/h). If this speed is exceeded, driving level will be set automatically.
- · Caster module, 30 min: electronic level control can be operated up to 30 min after switching off the ignition.

Using the remote control

The remote control is located in a holder on the B-pillar on the driver's side. Remove the remote control from the holder before use.



Electronic level control starts automatically if the ignition is switched on. Operation is only possible after the parking brake has been applied.

Electronic level control performs a self-check regularly when it is activated and while in use. Indicator lamp on the remote control lights up for about one second when you switch on the ignition.

There is a malfunction if indicator lamp (2) behaves in the following ways:

- The indicator lamp does not light up when you switch on the ignition.
- The indicator lamp then lights up again or flashes.

In addition, a warning tone is emitted from the remote control for approximately 30 seconds. The fault that has been detected can be shown using the indicator lamps (signaling of fault codes).

- Park the vehicle, leaving the ignition switched on.
- Apply the parking brake.
- To raise or lower the vehicle level: press and hold button 4 or 5 until the vehicle level reaches the required height. The indicator lamp in button 4 or 5 flashes as long as the vehicle level is being changed. When the vehicle level has been set, the indicator lamp in button 4 or 5 lights up.
- To lower automatically: briefly press button

Electronic level control automatically lowers the vehicle to the next lower position:

- · From the highest position to driving level
- From driving level to the lowest position

The indicator lamp in button (5) flashes as long as the vehicle level is being changed.

- When the vehicle level has been set, the indicator lamp in button (5) lights up.
- (i) By pressing button (4) during the movement, the original position will be reset.
- To raise automatically: briefly press button

Electronic level control automatically raises the vehicle to the next higher position:

- From the lowest position to driving level
- From driving level to the highest position

The indicator lamp in button 4 flashes as long as the vehicle level is being changed. When the vehicle level has been set, the indicator lamp in button (4) lights up.

- (i) By pressing button (5) during the movement, the original position will be reset.
- To raise or lower automatically to driving level (center position): press and hold but-

Electronic level control automatically raises or lowers the vehicle to driving level.

- To save the set vehicle level: set the required vehicle level.
- Press and hold button (1) or (2) until you hear

The vehicle level set has been saved on corresponding button (1) or (2).

To call up the saved vehicle level: briefly press button (1) or (2).

Electronic level control automatically raises or lowers the vehicle to the saved driving level.

The indicator lamp in button
or
flashes as long as the vehicle level is being changed. When the vehicle level has been set, the indicator lamp in button (1) or (2) lights up.


- (i) Service mode may only be activated or deactivated at a qualified specialist workshop by trained personnel. In service mode, the air suspension system is deactivated for maintenance or fault detection.
- To activate service mode: press button 3. Service mode is active and the indicator lamp in button (3) lights up continuously.
- To deactivate service mode: press button

Service mode is deactivated and the indicator lamp in button (3) goes out.

To switch on automatically: drive at over 6.2 mph (10 km/h) or release the parking brake.

Electronic level control controls the vehicle level automatically.

Using the button in the control panel



- Park the vehicle, leaving the ignition switched on.
- Apply the parking brake.
- To raise or lower the vehicle level: press and hold button or until the vehicle level reaches the required height.
- To lower automatically: briefly press the lower section of switch 2.

Electronic level control automatically lowers the vehicle to the next lower position:


- From the highest position to driving level
- From driving level to the lowest position
- (i) By pressing button (1) during the movement, the original position will be reset.
- To raise automatically: briefly press the lower section of switch 1.

Electronic level control automatically raises the vehicle to the next higher position:

- From the lowest position to driving level
- From driving level to the highest position
- (i) By pressing button (2) during the movement, the original position will be reset.
- To switch on automatically: drive at over 6.2 mph (10 km/h) or release the parking

Electronic level control controls the vehicle level automatically.

Using the button in the rear compartment



- Park the vehicle, leaving the ignition switched
- Apply the parking brake.
- To raise or lower the vehicle level: press and hold button or until the vehicle level reaches the required height.
- To lower automatically: briefly press the lower section of switch 2.

Electronic level control automatically lowers the vehicle to the next lower position:

- From the highest position to driving level
- From driving level to the lowest position
- (i) By pressing button (1) during the movement, the original position will be reset.
- To raise automatically: briefly press the lower section of switch 1.

Electronic level control automatically raises the vehicle to the next higher position:

- From the lowest position to driving level
- From driving level to the highest position
- (i) By pressing button (2) during the movement, the original position will be reset.
- To switch on automatically: drive at over 6.2 mph (10 km/h) or release the parking brake.

Electronic level control controls the vehicle level automatically.


Using electronic level control for charging with air in an emergency

NOTE Damage due to pressure being too high

If the pressure in the air suspension bellows is too high, the compressed-air lines or the air suspension bellows may be damaged.

Ensure you observe the maximum permissible operating pressure of 900 kPa (9 bar/130 psi).

Only for vehicles with valves for electronic level control emergency charging. If electronic level control is malfunctioning and the vehicle is leaning, you can raise or lower the vehicle by connecting an external compressed-air source to one of the emergency valves (similarly as with tire valve). If electronic level control is not operational, you can drive on carefully to the nearest qualified specialist workshop and have the malfunction remedied.



- Apply the parking brake.
- **Vehicles with automatic transmission:** shift the transmission to position [P].
- Switch off the engine.
- Turn the valve cap of the corresponding valve (1) L = left, 2) R = right).
- Connect the external compressed-air source.
- Raise or lower the vehicle level by charging or releasing compressed air until the driving level has been reached and the vehicle is in a horizontal position. While doing so, ensure you observe the maximum permissible operating pressure of 900 kPa (9 bar/130 psi).

- Disconnect the external compressed-air source.
- Tighten the valve cap on the valve (1) L = left. 2 R = right).
- Drive on carefully to the nearest qualified specialist workshop.

Problems with the electronic level control

Problem

Possible causes / consequences and ▶ Solutions

You cannot raise or lower the vehicle level when stationary.

The compressor is in danger of overheating. After repeatedly raising and lowering the vehicle, electronic level control (play protection) is deactivated.

Try to set the vehicle level manually again after approximately one minute.

Electric level control has been deactivated due to undervoltage. The battery may not be charging.

Handling and ride comfort may suffer.

- Start the engine.
- Consult a qualified specialist workshop as soon as possible.

Refueling

Refueling the vehicle

WARNING Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, open flames, smoking and creation of sparks must be avoided.
- Switch off the ignition and, if available, the stationary heater, before and while refueling the vehicle.

WARNING Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eves or clothing.
- Do not inhale fuel vapor.
- Keep children away from fuel.
- Keep doors and windows closed during the refueling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical attention immediately.

- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- Change immediately out of clothing that has come into contact with fuel.

WARNING Risk of fire and explosion due to electrostatic charge

Electrostatic charge can create sparks and thereby ignite fuel vapors.

- Before you open the fuel filler cap or take hold of the pump nozzle, touch the metallic vehicle body. This discharges any electrostatic charge
- Do not get into the vehicle again during the refueling process. Otherwise, electrostatic charge can build up again.

WARNING Risk of fire from fuel mixture

Vehicles with a diesel engine:

that may have built up.

If you mix diesel fuel with gasoline, the flash point of the fuel mixture is lower than that of pure diesel fuel.

While the engine is running, component parts in the exhaust system may overheat without warning.

- Never refuel using gasoline.
- Never mix gasoline with diesel fuel.

NOTE Do not use diesel to refuel vehicles with a gasoline engine

If you have accidentally refueled with the wrong fuel:

- Do not switch the ignition on. Otherwise fuel can enter the engine.
 - Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high.
- Consult a qualified specialist workshop.
- ► Have the fuel tank and fuel lines drained completely.
- NOTE Do not use gasoline to refuel vehicles with a diesel engine

If you have accidentally refueled with the wrong fuel:

- Do not switch the ignition on. Otherwise, fuel can enter the fuel system.
 - Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high.
- Consult a qualified specialist workshop.
- Have the fuel tank and fuel lines drained completely.
- NOTE Damage to the fuel system caused 1 by overfilled fuel tanks
- Only fill the fuel tank until the pump nozzle switches off.
- NOTE Fuel may spray out when you ! remove the fuel pump nozzle
- Only fill the fuel tank until the pump nozzle switches off.
- **NOTE** Damage to painted surfaces due to 1 fuel
- Do not spill any fuel on painted surfaces.
- **ENVIRONMENTAL NOTE** Environmental damage due to improper handling of fuel


If fuels are handled improperly, they pose a danger to persons and the environment.

Do not allow fuels to run into the sewage system, the surface waters, the ground water or into the ground.

Requirements:

- · The vehicle is unlocked.
- The auxiliary heating is deactivated.
- The ignition is switched off.
- The front left-hand door is open.
- (i) Do not get back into the vehicle during the refueling process. Otherwise, electrostatic charge could build up again.

Observe the notes on operating fluids $(\rightarrow page 340)$.



- Fuel filler flap
- Fuel filler cap
- The fuel filler flap is beside the front left-hand door when viewed in the direction of travel. The position of the fuel filler cap [4] is also shown in the Instrument Display. The arrow on the filling pump specifies the side of the vehicle.
- Open fuel filler flap 1.
- Turn fuel filler cap 2 counter-clockwise and remove it.
- Close all vehicle doors to prevent fuel vapors from entering the vehicle interior.
- Completely slide the filler neck of the pump nozzle into the tank, hook in place and refuel.
- Fill the fuel tank only until the pump nozzle switches off.

- Replace fuel filler cap 2 and turn it clockwise. You will hear a click when the fuel filler cap is
 - closed fully.
- Open the front left-hand door.
- Close fuel filler flap ①.
- (i) Vehicles with a diesel engine and incorrect fueling protector against refueling with gasoline: the filler neck is designed for refueling at diesel filling pumps for passenger vehicles.
- (i) Vehicles with a diesel engine without an incorrect fueling protector: refueling preferred at diesel filling pumps for passenger vehicles. However, you can also refuel at a diesel filling pump for trucks.
- (i) If the fuel tank has been run completely dry, add at least 1.3 gal (5 l) of fuel.

Problems with the fuel and fuel tank

Problem	Possible causes/consequences and ▶ Solutions
Fuel is leaking from the vehicle.	 The fuel line or the fuel tank is defective. Apply the parking brake. Switch off the engine. Remove the key from the ignition lock. Or, on vehicles with KEYLESS-GO: Open the driver's door. The on-board electronics are in position o. This corresponds to the "key removed". Do not restart the engine under any circumstances. Consult a qualified specialist workshop.
The engine does not start.	 The fuel tank has been run completely dry. Refuel the vehicle with at least 1.3 gal (5 l) of fuel. Switch the ignition on for approximately ten seconds. Start the engine continuously for a maximum of ten seconds until it runs smoothly. If the engine does not start: Switch the ignition on for approximately ten seconds. Start the engine continuously for a maximum of ten seconds until it runs smoothly. If the engine does not start after three attempts: Consult a qualified specialist workshop.

DEF

Notes on DEF

- NOTE When you open the DEF tank, small amounts of ammonia vapor may escape.
- Only fill the DEF tank in well-ventilated areas.
- Do not let DEF come into contact with skin, eyes or clothes.
- Keep DEF away from children.
- **NOTE** Do not ingest DEF.

If DEF is swallowed:

- Immediately rinse out your mouth thoroughly.
- Drink plenty of water.
- Seek medical attention immediately.
- NOTE Damage caused by additives in DEF or by diluting DEF

The DEF exhaust gas aftertreatment system could be destroyed by the following:

- · Additives in DEF
- Diluting DEF
- Only use DEF in accordance with ISO 22241.
- Do not mix additives.
- Do not dilute DEF.
- NOTE Damage and malfunctions caused by impurities in DEF

Impurities in DEF result in the following:

- · Higher emission values
- Damage to the catalytic converter
- Engine damage
- Malfunctions in the DEF exhaust gas aftertreatment system
- Avoid impurities in DEF.

- NOTE DEF residue crystallizes after some time. Remove DEF residue.
- Immediately rinse surfaces that come in contact with DEF when filling with water.
- ▶ DEF can also be removed with a damp cloth and cold water.
- If DEF has already crystallized, clean using a sponge and cold water.

DEF is a liquid urea solution used for exhaust gas aftertreatment of diesel engines. In order for the exhaust gas aftertreatment to function properly, only use DEF in accordance with ISO 22241.

DEF has the following properties:

- non-toxic
- · colorless and odorless
- non-flammable

DEF availability:

- you can have DEF added by fast service at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.
- DEF is available at numerous gas stations via DEF filling pumps.
- alternatively, DEF is available at qualified specialist workshops, e.g. an authorized Mercedes-Benz Center, and at numerous gas stations as a DEF refill canister or DEF refill bottle.
- (i) DEF freezes at a temperature of approximately 12.2 °F (-11 °C). The vehicle is equipped with a DEF preheating system at the factory. This means that winter operation is also ensured for temperatures below 12.2 °F (-11 °C). If you add DEF at temperatures below 12.2 °F (-11 °C), the DEF level in the instrument cluster may not be displayed correctly. If the DEF is frozen, drive for at least 20 minutes and then park the vehicle for a minimum of 30 seconds, so that the level is correctly displayed. In extreme winter conditions, the time needed to detect the top-up amount may be considerably longer. Park the vehicle in a warm garage to speed up this process.
- i Ensure the connection between the refill container and vehicle filler neck does not drip.

Calling up the DEF level gauge

On-board computer:

- → Service
- Select DEF and confirm.
 - The DEF level and the DEF range appear.



Instrument Display with color display

DEF level



Instrument Display with black and white display

DFF level

Refilling DEF

- NOTE Engine damage due to DEF being
- DEF must not be used to fill the fuel tank.
- Only use DEF to fill the DEF tank.
- Do not overfill the DFF tank.
- NOTE Contamination of the vehicle interior due to DEF leakage
- After adding, carefully close the DEF refill container.
- Avoid carrying DEF refill containers permanently in the vehicle.

Requirements:

· The ignition is switched off.

The following messages that appear in succession in the multifunction display indicate that you need to refill the DEF tank:

Refill Additive See Operator's Manual

The DEF tank has fallen below the first warning threshold.

• Refill Additive Starts until Emerg. Op.: XXX See Operator's Manual

The DEF supply has fallen below the reserve mark.

After the message appears for the first time, the remaining DEF supply will last for approximately 1,200 mi (1,900 km) and you can start the engine a further 16 times. The number of remaining engine starts XX (16 to 1) is shown in the message every time the engine is started.

 Refill Additive Emergency Op.: XXX mph See Operator's Manual


You can only drive the vehicle at a maximum speed of 5 mph (8 km/h).

Refill quantity:

With a prompt in the display	at least 2 l
Without a prompt in the display	at least 8 l

You can also have the DEF level displayed $(\rightarrow page 137)$.


Opening the DEF filler cap on filler caps that are not lockable




Open the hood.

➤ Turn DEF filler cap **(1)** counter-clockwise and remove it.

Opening the DEF filler cap on lockable filler caps





- Open the hood.
- Take tool (a) for unlocking DEF filler cap (1) from the vehicle tool kit.
- Pull cover (3) on DEF filler cap (1) up, turn 90° and release.
- Insert tool (4) in holes (2) of DEF filler cap (1).
- ➤ Turn DEF filler cap **(1)** counter-clockwise and remove it.

Preparing the DEF refill canister




Variant 1




Variant 2

- Unscrew the cap on DEF refill canister ①.
- Screw disposable hose ② onto the opening of DEF refill canister ① until hand-tight.

Refilling DEF



Variant 1



Variant 2


- Screw disposable hose 2 onto the filler neck of the vehicle until hand-tight.
- Lift up and tip DEF refill canister ①. The filling process stops when the DEF tank is completely full.
 - DEF refill canister (1) can be removed when it has been only partially emptied.
- Unscrew disposable hose 2 and close DEF and refill canister 1 in reverse order.
- Switch on the ignition for at least 60 seconds.
- Start the vehicle.
- (i) Avoid storing DEF containers permanently in the vehicle.

DEF refill bottle

Only screw the DEF refill bottle hand-tight onto the filler opening in the engine compartment. It may otherwise be damaged.



DEF refill bottles (1) can be obtained at many gas stations or at a qualified specialist workshop. Refill bottles without a threaded cap offer no overfill protection. DEF may leak out as a result of overfilling. Mercedes-Benz offers special refill bottles with a threaded cap. You can obtain this from an authorized Mercedes-Benz Center.




- Unscrew the protective cap from DEF refill bottle 1.
- Place DEF refill bottle (1) as shown on filler opening 2 and screw it on clockwise until hand-tight.
- Press DEF refill bottle 1 towards filler opening 2.
 - The DEF tank is filled. This could take up to one minute.
- (i) When the DEF refill bottle is no longer pressed down, filling stops. The bottle can be removed when it has been only partially emptied.
- Let go of DEF refill bottle 1.

- Turn DEF refill bottle (1) counter-clockwise and remove it.
- Screw the protective cap onto DEF refill bottle again.

Filling procedure with the pump nozzle of an DEF filling pump


Insert the pump nozzle into the filler neck and add DEF. When doing so, do not overfill the DEF tank. You can also use an DEF filling pump for trucks.


Closing the DEF filler cap on filler caps that are not lockable



- After filling the DEF tank, place DEF filler cap
 on the filler neck and tighten it clockwise.
- Turn the DEF filler cap until the lettering is legible and horizontal. The filler neck is only locked correctly when this is the case.
- Close the hood.

Closing the DEF filler cap on lockable filler caps





- After filling the DEF tank, place DEF filler cap
 on the filler neck and tighten it clockwise.
- ► Remove tool **(a)** from DEF filler cap **(b)** and store it in the vehicle tool kit.
- Pull cover (a) on DEF filler cap (b) up over holes (a) of DEF filler cap (b), turn and release.
- ➤ Turn DEF filler cap ①.

 If DEF filler cap ① turns freely, the DEF tank is closed.

Parking

Parking the vehicle

WARNING Risk of fire caused by hot exhaust system parts

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system or exhaust gas flow.

Park the vehicle so that no flammable material can come into contact with hot vehicle components.

- In particular, do not park on dry grassland or harvested grain fields.
- WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle. they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traf-
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.
- **NOTE** Damage to the vehicle or the drivetrain due to rolling away
- Always park your vehicle safely and according to legal requirements.
- Always properly secure the vehicle against rolling away.
- WARNING Risk of accident and injury if parking brake is not applied

If you park the vehicle with the transmission in park position P and the parking brake is not engaged, the vehicle may roll away.

Engaging park position P is not a fully adequate replacement for the parking brake.

There is a risk of accident and injury.

Secure the vehicle against rolling away as described below.

Observe the following points to ensure that the vehicle is properly secured against rolling away unintentionally:

- always apply the parking brake.
- Vehicles with automatic transmission: engage transmission position P.
- On uphill or downhill inclines: turn the front wheels towards the curb.
- On uphill or downhill inclines: secure the rear axle with a chock or an object without sharp edges.
- (i) You can operate the side windows for five minutes after you have switched off the vehicle.

Manual parking brake

Applying/releasing the handbrake lever

WARNING Risk of skidding or an accident by braking with the parking brake


If you have to brake your vehicle with the parking brake, the braking distance is considerably longer and the wheels may lock. There is an increased risk of skidding and/or accident.

- Only brake the vehicle with the parking brake if the service brake has failed.
- In this case, do not apply the parking brake with too much force.
- If the wheels lock, immediately release the parking brake as much as required for the wheels to turn again.
- WARNING Risk of fire and an accident if the parking brake is not released

If the parking brake is not fully released when driving, the following situations can occur:

- The parking brake can overheat and cause a fire
- The parking brake can lose its holding function
- Completely release the parking brake before driving off.

The brake lights do not light up when you brake the vehicle with the parking brake.



Generally, you may only apply the parking brake when the vehicle is stationary.


- To apply the parking brake: pull handbrake lever 1 up as far as the last possible detent. When the engine is running, the PARK and ((USA) or ((Canada) indicator lamps in the Instrument Display light up. If the vehicle is in motion, a warning tone sounds.
- in vehicles with a folding handbrake lever. you can then press handbrake lever 1 down as far as it will go.
- To release the parking brake: on vehicles with a folding handbrake lever, first pull handbrake lever 1 up as far as it will go.
- Guide handbrake lever (1) down to as far as it will go.

The PARK and (P) (USA) or (P) (Canada) indicator lamps in the instrument display go

Folding the handbrake lever up or down (only in vehicles with a folding handbrake lever) Requirements:

- The handbrake lever is applied.
- To fold down the handbrake lever: push the handbrake lever down as far as it will go.
- To raise the handbrake lever: pull the handbrake lever up as far as it will go.

Performing emergency braking with the handbrake lever



If, in exceptional cases, the service brake fails, you may use the parking brake to perform emergency braking.

Emergency braking: press and hold release button 2 and carefully pull brake lever 1.

Electric parking brake

Information on the electric parking brake

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- Open doors, thereby endangering other persons or road users.
- · Get out and be struck by oncoming traf-
- Operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion, for example by:

- · Releasing the parking brake.
- Changing the transmission position.
- Starting the vehicle.
- Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- Keep the vehicle key out of reach of children.

For the automatic functions to work correctly, the driver must be seated in the correct seat position $(\rightarrow page 64)$.

The function of the electric parking brake is dependent on the on-board electrical system voltage. If the on-board electrical system voltage is low or there is a malfunction in the system, it may not be possible to apply the electric parking brake and the yellow (P) indicator lamp lights up.

In this case, park the vehicle in the following way:

- · Park the vehicle on level ground and secure it to prevent it from rolling away.
- · Vehicles with automatic transmission: shift the transmission to position **P**.
- (i) The electric parking brake is only actually applied when the red PARK and (USA) or (Canada) indicator lamps light up continuously.

It may not be possible to release a parking brake if the on-board electrical system voltage is low or if there is a malfunction in the system. Inform a qualified specialist workshop.


When the engine is switched off, the electric parking brake carries out a function test at regular intervals. Noises are normal in this process.

Automatically applying the electric parking brake

Vehicles with automatic transmission:

The electric parking brake is automatically applied when the transmission is in position \mathbf{P} . In addition, at least one of the following conditions must be fulfilled:

- The engine is switched off
- The driver is not sitting in the driver's seat
- The belt buckle is undone



To prevent the electric parking brake from applying automatically, pull switch 1.

The electric parking brake is also automatically applied if Active Distance Assist DISTRONIC has brought the vehicle to a standstill.

In addition, at least one of the following conditions must be fulfilled:

- · The engine is switched off
- The driver is not sitting in the driver's seat
- The belt buckle is undone
- There is a system malfunction
- The power supply is insufficient
- The vehicle is stationary for a long time

The red PARK and (P) (USA) or (P) (Canada) indicator lamp in the instrument display lights up. The electric parking brake is only actually applied when the red PARK and (P) (USA) or (P) (Canada) indicator lamps light up continuously.

Releasing the electric parking brake automatically

Vehicles with automatic transmission:

The electric parking brake of your vehicle is released when all of the following conditions are fulfilled:

- The driver is sitting in the driver's seat.
- The driver is belted.
- The engine is running.
- The transmission is in position D or R and you depress the accelerator.

or

You switch from transmission position P to position **D** or **R**. You must also depress the accelerator if traveling on steep uphill gradients.

If the transmission is in position R, the rearend doors must be closed.

Applying/releasing the electric parking brake manually


WARNING Risk of accident and injury due to children and animals left unattended in the vehicle

If you leave children and animals unattended in the vehicle, they may be able to set the vehicle in motion, for example by:

- · Releasing the parking brake.
- Shifting the automatic transmission out of park position P.
- Starting the engine.

In addition, they may operate vehicle equipment and become trapped.

- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.



To apply: press switch ①.

When the electric parking brake is applied, the red PARK and (P) (USA) or (Canada) indicator lamps light up in the instrument display. The electric parking brake is only actually applied when the red PARK and (N) (USA) or (Canada) indicator lamps light up continuously.


It is also possible to apply the electric parking brake when the ignition is switched off.

► To release: pull switch ①.

The red PARK and ((S) (USA) or ((Canada) indicator lamps in the instrument display go out.

You may only release the electric parking brake if the ignition is switched on with the start/stop button.

Emergency braking



In the event of an emergency, you can brake the vehicle while it is in motion with the electric parking brake.

While driving, press switch **(1)** of the electric parking brake.

The vehicle is braked as long as you keep switch ① of the electric parking brake depressed.

The longer electric parking brake switch ① is depressed, the greater the braking force.

During the braking procedure, you will receive the following feedback from the vehicle:

- · a warning tone sounds
- the "Release parking brake" display message appears
- the red PARK and ((USA) or ((Canada) indicator lamps in the instrument display flash

When the vehicle has been braked to a standstill, the electric parking brake is applied.

Parking the vehicle for an extended period

Parking the vehicle for longer than 4 weeks

Method 1: connect the starter battery to a trickle charger via the jump-start connection.

- Method 2: interrupt the power supply by activating standby mode (\rightarrow page 145).
- Method 3: disconnect all batteries. In this case, please contact a qualified specialist workshop.
- (i) Charge the starter battery every 6 months, even if it has been disconnected or in standby mode.

The charge level of the starter battery must be checked every four weeks if no measures are taken to maintain the battery charge.

- Voltage of the starter battery below 12.2 V: charge the starter battery to prevent deep discharge damage.
- (i) You can obtain further information at a qualified specialist workshop.

Standby mode

Activating/deactivating standby mode Requirements:

· The engine is switched off.

When you activate standby mode, the energy loss is minimized if the vehicle is parked for an extended period.

Standby mode has the following characteristics:

- The starter battery is protected.
- The maximum non-operational time is shown in the media display.
- The connection to online services is interrupted.
- The ATA (anti-theft alarm system) is not avail-
- The interior motion sensor and tow-away alarm functions are not available.

If the following conditions are met, standby mode can be activated or deactivated using the multimedia system:

- The engine is switched off.
- The ignition is switched on.

If the displayed non-operational time of the vehicle is exceeded, there could be a loss of comfort and the starter battery can no longer be guaranteed to reliably start the engine.

The starter battery must first be charged in the following situations:

- The non-operational time of the vehicle is to he extended
- The message that the battery charge is not sufficient for standby mode appears in the media display.
- (i) Standby mode is automatically deactivated when the ignition is switched on.

On-board computer:


- ¬→ Settings → Vehicle
- >> Ruhezustand (Standby)
- ➤ To activate/deactivate: select Yes or No.
- (i) If the options are graved out, then the battery charge is not sufficient for standby mode.

Driving and driving safety systems

Note on driving systems and your responsibility

Your vehicle is equipped with driving systems which assist you in driving, parking and maneuvering the vehicle. The driving systems are aids and do not relieve you of your responsibility. Always pay attention to the traffic and intervene if necessary. Be aware of the limitations regarding the safe use of these systems.

Information about sensors



Certain driving and driving safety systems use sensors 1 to monitor the area in front of, behind or next to the vehicle (depending on the vehicle's equipment).

Function of driving systems and driving safety systems

In this section, you will find information about the following driving systems and driving safety systems:

- ABS (Anti-lock braking system)
 (→ page 146)
- ASR (acceleration skid control) (→ page 147)
- BAS (Brake Assist System) (→ page 146)
- ESP[®] (Electronic Stability Program)
 (→ page 147)
- EBD (Electronic Brakeforce Distribution)
 (→ page 148)
- Active Brake Assist (→ page 149)
- Cruise control (→ page 151)
- Active Distance Assist DISTRONIC
 (→ page 152)
- Hill start assist (→ page 155)
- HOLD function (→ page 155)
- Parking Assist PARKTRONIC (→ page 156)
- Rear view camera (→ page 157)
- Surround view camera (→ page 159)
- ATTENTION ASSIST (→ page 162)
- Traffic Sign Assist (→ page 163)
- Blind Spot Assist (→ page 164)
- Active Lane Keeping Assist (→ page 167)

Functions of ABS (Anti-lock Braking System)

Observe the important safety guidelines for the driving safety system.

ABS controls the brake pressure in critical situations:

- The wheels are prevented from locking when braking, e.g. during maximum full-stop braking or when there is insufficient tire traction
- The steerability of the vehicle in terms of physical possibilities is ensured when braking
- ABS is active from speeds of approx. 3 mph (5 km/h). On a slippery road surface, ABS intervenes even if you only brake gently.

System limits

If there is a malfunction and the yellow [ABS warning lamp lights up continuously in the instrument display after starting the engine, ABS may be impaired or inoperative.

If ABS intervenes, you will feel a pulsing in the brake pedal. The pulsating brake pedal may be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

If ABS intervenes: keep the brake pedal firmly depressed until the braking situation has passed.

To carry out maximum full-stop braking: depress the brake pedal with full force.

Function of BAS (Brake Assist System)

A

WARNING Risk of an accident caused by a malfunction in BAS (Brake Assist System)

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased.

 Depress the brake pedal with full force in emergency braking situations. ABS prevents the wheels from locking.

BAS supports you with additional braking force in an emergency braking situation.

If you depress the brake pedal quickly, BAS is activated:

- BAS automatically boosts the braking force of the brakes
- BAS can shorten the braking distance
- · ABS prevents the wheels from locking

When you release the brake pedal, the brakes function as usual again. BAS is deactivated.

Functions of ASR (Acceleration Skid Control)

ASR can neither reduce the risk of an accident nor override the laws of physics if the driver does not pay attention when pulling away or accelerating. ASR is only an aid. Always adapt your driving style to suit the prevailing road and weather conditions.

If you activate or deactivate the all-wheel drive in a vehicle with this option, ASR will be deactivated for the duration of the activation/deactivation process.

Vehicles without steering wheel buttons: if ASR is malfunctioning, the 👩 indicator lamp lights up while the engine is running and the engine output may be reduced (\rightarrow page 26).

ASR improves traction, i.e. the transfer of power from the tires to the road surface, for a sustained period and thereby, also improves the driving stability of the vehicle. If the drive wheels start to spin. ASR brakes individual drive wheels and limits the engine torque. ASR thus significantly assists you when pulling away and accelerating, especially on wet or slippery roads.

If traction on the road surface is not sufficient. even ASR will not allow you to pull away without difficulty. The type of tires and total weight of the vehicle as well as the gradient of the road also play a crucial role.

If ASR intervenes, the warning lamp in the Instrument Display flashes.

Functions of ESP® (Electronic Stability Program)

WARNING Risk of skidding if ESP® is malfunctioning

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have ESP® checked at a qualified specialist workshop.

WARNING Risk of skidding if ESP® is deactivated

If you deactivate ESP®, ESP® cannot carry out vehicle stabilization.

ESP® should only be deactivated in the following situations.

If the surface requires, temporarily deactivate ESP^{\otimes} when pulling away (\rightarrow page 148).

Do not operate the vehicle on a roller dynamometer (e.g. for a performance test). If you have to operate the vehicle on a roller dynamometer, consult a qualified specialist workshop beforehand.

If you activate or deactivate the all-wheel drive in a vehicle with this option. ESP® will be deactivated for the duration of the activation / deactivation process.

If ESP® is malfunctioning or deactivated, the warning lamp lights up while the engine is running and the engine output may be reduced $(\rightarrow page 26)$.

(i) Only use wheels with the recommended tire sizes. Only then will ESP® function properly.

ESP® can, within physical limits, monitor and improve driving stability and traction in the following situations:

- When pulling away on wet or slippery road surfaces
- When braking
- If you are driving faster than 49.7 mph (80 km/h) in strong crosswinds

If the vehicle is deviating from the direction desired by the driver. ESP® can stabilize the vehicle by performing the following actions:

- One or more wheels are braked
- The drive system performance is adapted depending on the situation

If ESP® is deactivated <a>[, the <a>[warning lamp lights up constantly in the Instrument Display:

- Vehicle stabilization may be delayed
- · Crosswind Assist is still active
- The drive wheels may start to spin
- · ASR traction control is no longer active

If ESP® is deactivated, ESP® will still support you when braking.

If the marning lamp in the Instrument Display flashes, one or more wheels have reached their tire traction limit:

- · Adapt your driving style to suit the prevailing road and weather conditions
- Do not deactivate ESP® under any circumstances

Activating/deactivating ESP® (Electronic Stability Program)

Multimedia system:



- (i) ESP® can only be activated and deactivated via quick access when at least one other function is available in quick access. Otherwise, you can find ESP® in the Assistance menu.
- Select ESP. A prompt appears.
- ➤ Select On or 👼 Off.

If the F ESP® OFF warning lamp lights up constantly in the instrument cluster, ESP® is deactivated.

Observe the information on warning lamps and display messages which may appear in the instrument cluster.

Functions of ESP® Crosswind Assist

Crosswind Assist does not react under the following conditions:

- The vehicle is subjected to severe jolts and vibrations, e.g. as a result of uneven surfaces or potholes.
- The vehicle loses traction, e.g. on snow or ice or when hydroplaning.
- The driver is performing sudden and large steering movements.

Crosswind Assist is operational again as soon as the driving conditions return to normal.

Crosswind Assist detects strong crosswind gusts that can impair ability of your vehicle to drive straight ahead. Crosswind Assist intervenes depending on the direction and strength of the crosswind.

A stabilizing brake application helps you to keep the vehicle on track.

Information is shown in the instrument cluster in the event of a clearly discernible intervention by Crosswind Assist.

Crosswind Assist is active above a vehicle speed of 50 mph (80 km/h) when driving straight or slightly cornering.

Function of ESP® trailer stabilization



WARNING Risk of accident in poor road and weather conditions

In poor road and weather conditions, the trailer stabilization cannot prevent lurching of the vehicle/trailer combination. Trailers with a high center of gravity may tip over before ESP® detects this.

Always adapt your driving style to suit the current road and weather conditions.

ESP® trailer stabilization counteracts critical driving situations in good time and thereby provides considerable assistance when driving with a trailer. Trailer stabilization is part of ESP®.

If the sensor system and evaluation logic detect trailer swinging movements. ESP® trailer stabilization initially brakes individual vehicle wheels in a targeted manner. It thus counteracts swinging movements. If the swinging movements do not stop, the vehicle is braked until the vehicle/ trailer combination is stabilized. If necessary, the vehicle's engine output is limited.

If your vehicle with trailer (vehicle/trailer combination) starts to swerve, you are able to stabilize the vehicle/trailer combination only by braking. ESP® trailer stabilization helps you to stabilize the vehicle/trailer combination in this situation.

ESP® trailer stabilization is active at speeds above approximately 40 mph (65 km/h).

If ESP® is deactivated because of a malfunction. trailer stabilization will not function.

Function of EBD (electronic brake force distribution)

EBD has the following characteristics:

- · monitoring and controlling the braking force on the rear wheels
- improving driving stabilization when braking, especially on bends

Function of Active Brake Assist

Active Brake Assist consists of the following functions:

- Distance warning function
- Autonomous braking function
- Situation-dependent braking assistance

Active Brake Assist can help you to minimize the risk of a collision with vehicles or pedestrians or to reduce the effects of such a collision.

If Active Brake Assist has detected a risk of collision, you will be warned visually and acoustically.

If you do not react to the visual or acoustic warning, autonomous braking can be initiated in critical situations.

If there are pedestrians and cyclists crossing: in especially critical situations, Active Brake Assist can initiate autonomous braking directly. In this case, the visual and acoustic warning occurs simultaneously with the braking application.

If you apply the brake yourself in a critical situation, or apply the brakes during autonomous braking, situation-dependent braking assistance occurs. The brake pressure increases up to maximum full-stop braking if necessary. Situationdependent braking assistance only intervenes when the brakes are applied firmly; otherwise, it remains within the autonomous braking process.



WARNING Risk of accident caused by limited detection performance of Active **Brake Assist**

Active Brake Assist cannot always clearly identify objects and complex traffic situations.

Due to the nature of the system, complex driving conditions may also cause Brake Assist to intervene or not intervene without reason. In such cases, and in the event of Active Brake Assist malfunctioning, the brake system will continue to be available with full brake boost and BAS.

- Always pay careful attention to the traffic situation; do not rely on Active Brake Assist alone. Active Brake Assist is only an aid. The driver of the vehicle is responsible for keeping a sufficiently safe distance to the vehicle in front, for vehicle speed and for braking in good time.
- Be prepared to brake or swerve if necessary.

Also observe the system limits of Active Brake Assist.

The individual subfunctions are available in the following speed ranges: Distance warning function

The distance warning function warns you at speeds greater than approximately 4 mph (7 km/h), if your vehicle is critically close to a vehicle or pedestrian.

An intermittent warning tone sounds and the distance warning lamp lights up in the instrument cluster.

Brake immediately or take evasive action, provided it is safe to do so and the traffic situation allows this.

The distance warning function can aid you in the following situations with an intermittent warning tone and a warning lamp:

Vehicles travel-	Stationary vehi-	Crossing vehi-	Crossing pedes-	Stationary pedestrians
ing in front	cles	cles	trians/cyclists	
Up to approx. 155 mph (250 km/h)	Up to approx. 124 mph (200 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Autonomous braking function

The autonomous braking function may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

Vehicles travel-	Stationary vehi-	Crossing vehi-	Crossing pedes-	Stationary pedestrians
ing in front	cles	cles	trians/cyclists	
Up to approx. 155 mph (250 km/h)	Up to approx. 124 mph (200 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Situation-dependent braking assistance

Situation-dependent braking assistance may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

Vehicles travel-	Stationary vehi-	Crossing vehi-	Crossing pedes-	Stationary pedestrians
ing in front	cles	cles	trians/cyclists	
Up to approx. 155 mph (250 km/h)	Up to approx. 50 mph (80 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction

Canceling a brake application of Active Brake Assist

You can cancel a brake application of Active Brake Assist at any time by:

- Fully depressing the accelerator pedal or with kickdown.
- Fully releasing the brake pedal (only during situation-dependent braking assistance).

Active Brake Assist may cancel the brake application when one of the following conditions is fulfilled:

- You maneuver to avoid the obstacle.
- There is no longer a risk of collision.
- An obstacle is no longer detected in front of your vehicle.

System limits

The system may be impaired or may not function in the following situations:

- The sensors are affected by snow, rain, fog or heavy spray.
- The sensors are dirty, fogged up, damaged or covered
- The sensors are affected by interference from other radar sources, e.g. strong radar reflections in parking garages.

- If a loss of tire pressure or a faulty tire has been detected and displayed.
- Full system performance is not available for a few seconds after switching on the ignition or after driving off.

The system may not react correctly in the following situations:

- In complex traffic situations, objects may not always be clearly detected.
- Pedestrians or vehicles move quickly into the detection range of the sensors.
- Pedestrians are obscured by other objects.
- · In bends with a narrow radius.

Setting Active Brake Assist

Requirements:

· The ignition is switched on.

Multimedia system:

The following settings are available:

- Early
- Medium
- Late
- Off

- (i) It is recommended that Active Brake Assist is always left activated.
- Select a setting.

The last active setting is selected automatically every time the engine is started.

Exception: if the last setting was Off, the Medium setting will be automatically activated the next time the engine is started.

Deactivating Active Brake Assist

- i It is recommended that Active Brake Assist is always left activated.
- Select Off. The distance warning function and autonomous braking function are deactivated.

The next time the engine is started, the Medium setting will be automatically activated.

(i) When Active Brake Assist is deactivated, the ক্ট্রাল্ল symbol appears in the status area of the multifunction display.

Cruise control

Function of cruise control

Cruise control accelerates and brakes the vehicle automatically in order to maintain a previously stored speed.

If you accelerate to overtake, for example, the stored speed is not deleted. If you remove your foot from the accelerator pedal after overtaking, cruise control will resume speed regulation back to the stored speed.

Cruise control is operated using the corresponding steering wheel buttons. You can store any road speed above 15 mph (20 km/h).

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Cruise control is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, braking in good time and for staying in your lane.

Displays in the multifunction display

The status of cruise control and the stored speed are shown in the multifunction display.



Display in the Instrument Display (color display)

- Cruise control is selected
- Set speed gray: speed is stored, cruise control is deactivated
- 3 Set speed green: speed is stored, cruise control is activated

System limitations

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out.

On long and steep downhill gradients, you should change down to a lower gear in good time. Take particular note of this when driving a laden vehicle. By doing so, you will make use of the engine's braking effect. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Do not use cruise control in the following situations:

- In traffic situations where frequent speed changes are required, e.g. in heavy traffic or on winding roads.
- On slippery roads. Accelerating can cause the drive wheels to lose traction and the vehicle could then skid.
- If you are driving when visibility is poor.

Operating cruise control

WARNING Risk of accident due to stored speed

If you call up the stored speed and this is lower than your current speed, the vehicle decelerates.

Take into account the traffic situation before calling up the stored speed.

Requirements:

- ESP® is activated, but may not intervene.
- The driving speed is at least 15 mph (20 km/h).

- To activate cruise control: push rocker switch up.
- Remove your foot from the accelerator pedal. The current speed is then saved and maintained by the vehicle.
- Push rocker switch ① up.
- To increase/reduce speed: push rocker switch ② up or down.

The stored speed is increased or reduced by 1 mph (1 km/h).

or

Press rocker switch ② up or down and hold. The stored speed is increased or reduced in 1 mph (1 km/h) increments.

or

Push rocker switch beyond the pressure point.
The stored speed is increased or reduced by

The stored speed is increased or reduced 5 mph (10 km/h).

or

Push rocker switch ② beyond the pressure point and hold.
The stored speed is increased or reduced in

The stored speed is increased or reduced in 5 mph (10 km/h) increments.

or

- Accelerate the vehicle to the desired speed.
- Push rocker switch ② up.

tains this speed.

If cruise control is activated and Traffic Sign Assist has detected a speed restriction sign with a maximum permissible speed and this appears in the instrument display:

 To adopt the detected speed: push rocker switch up.
 The maximum permissible speed shown by

To adopt the detected speed: push rocker

the traffic sign is stored and the vehicle main-

To deactivate cruise control: push rocker switch (3) (CNCL) down.

If cruise control is deactivated, it can be reactivated as follows:

- rocker switch (2) (SET+) or (SET-) stores the current speed and the vehicle maintains this speed
- rocker switch (3) (RES) calls up the last speed stored and the vehicle maintains this speed
- i If you brake, deactivate ESP® or if ESP® intervenes, cruise control is deactivated. When you switch off the vehicle, the last speed stored is cleared.

Active Distance Assist DISTRONIC

Function of Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC maintains the set speed on free-flowing roads. If vehicles ahead are detected, the set distance is maintained, if necessary until the vehicle comes to a halt. The vehicle accelerates or brakes depending on the distance to the vehicle in front and the set speed. Speed and distance are set and stored on the steering wheel. The speed can be set in the range between 15 mph (20 km/h) and 99 mph (160 km/h) or between 15 mph (20 km/h) and the vehicle's maximum speed.

Other features of Active Distance Assist DISTRONIC:

- Depending on the preselected distance, DISTRONIC intervenes either dynamically (short distance) or to save fuel (long distance).
- Depending on the vehicle mass detected, the dynamics of the DISTRONIC intervention are reduced.
- Rapid acceleration to the stored speed is initiated if the turn signal indicator is switched on to change to the overtaking lane.

Active Distance Assist DISTRONIC is only an aid. The driver is responsible for the distance to the vehicle in front, for vehicle speed and for braking in good time.

System limitations

The system may be impaired or may not function in the following instances:

- The radar sensors are affected by snow, rain. fog, heavy spray, glare, direct sunlight or greatly varying ambient light.
- The radar sensors may malfunction in parking garages or on roads with steep uphill or downhill gradients.
- If the radar sensors are dirty or covered.
- On icy or slippery roads, braking or accelerating can cause the drive wheels to lose traction and the vehicle could then skid.
- · Stationary objects are not detected if these were not previously detected as moving.
- On bends, target vehicles may be lost or not recognized correctly. As a result, a target vehicle is not used to regulate the speed which may lead to unwanted acceleration.

Do not use Active Distance Assist DISTRONIC in these situations

WARNING Risk of accident from acceleration or braking by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC may accelerate or brake in the following cases, for example:

- If the vehicle pulls away using Active Distance Assist DISTRONIC.
- If the stored speed is called up and is considerably faster or slower than the currently driven speed.
- If Active Distance Assist DISTRONIC no longer detects a vehicle in front or does not react to relevant objects.
- Always carefully observe the traffic conditions and be ready to brake at all times
- Take into account the traffic situation before calling up the stored speed.

WARNING Risk of accident due to insufficient deceleration by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC brakes your vehicle with up to 50% of the maximum possible deceleration. If this deceleration is

not sufficient. Active Distance Assist DISTRONIC alerts you with a visual and acoustic warning.

- In these cases, adjust your speed and keep a sufficient distance.
- Brake the vehicle vourself and/or take evasive action.

WARNING Risk of accident if detection function of Active Distance Assist DISTRONIC is impaired

Active Distance Assist DISTRONIC does not react or has a limited reaction:

- when driving on a different lane or when changing lanes
- · to pedestrians, animals, bicycles or stationary vehicles, or unexpected obstacles
- to complex traffic conditions
- to oncoming vehicles and crossing traffic

As a result, Active Distance Assist DISTRONIC may neither give warnings nor intervene in such situations.


Always observe the traffic conditions carefully and react accordingly.

Active Distance Assist DISTRONIC may not detect narrow vehicles driving in front, e.g. motorcycles and vehicles driving on a different line.

Operating Active Distance Assist DISTRONIC Requirements:

- The vehicle has been started.
- The parking brake has been released.
- ESP® is activated and is not intervening.
- The transmission is in position **D**.
- The driver's and the front-passenger door are closed.
- The seat occupancy recognition on the driver's seat has detected that the driver has fastened the seat belt.
- The check of the radar sensor system has been successfully completed.

Activating Active Distance Assist DISTRONIC



- Press button ①.
- To activate without a stored speed: press rocker switch (3) up (SET+) or down (SET-). The current speed is then saved and maintained by the vehicle.

or

- To activate with a stored speed: press rocker switch 4 up (RES).
- If rocker switch (a) is pressed up twice, Active Distance Assist DISTRONIC is activated with the speed restriction displayed in the instrument cluster.

Accepting the displayed speed limit when Distance Assist DISTRONIC is activated

Press rocker switch (a) up (RES).
The speed limit displayed in the instrument cluster is adopted as the stored speed. The vehicle adapts its speed to that of the vehicle in front, but only up to the stored speed.

Pulling away again with Active Distance Assist DISTRONIC

- Remove your foot from the brake pedal.
- Press rocker switch 4 up (RES).

or

 Depress the accelerator pedal briefly with force.

The functions of Active Distance Assist DISTRONIC continue to be carried out.

Deactivating Active Distance Assist DISTRONIC

A

WARNING Risk of accident due to Active Distance Assist DISTRONIC still being activated when you leave the driver's seat

If you leave the driver's seat while the vehicle is being braked by Active Distance Assist DISTRONIC only, the vehicle can roll away.

- Always deactivate Active Distance Assist DISTRONIC and secure the vehicle to prevent it from rolling away before you leave the driver's seat.
- Press rocker switch @ down (CNCL).
- Depress the brake pedal.

Increasing or reducing the speed

Push rocker switch (3) up (SET+) or down (SET-). The stored speed is increased or reduced by 1 mph (1 km/h).

or

Press and hold rocker switch (a) up (SET+)/down (SET-).
The stored speed is increased or reduced in 1 mph (1 km/h) increments.

or

Push rocker switch (3) beyond the pressure point.

The stored speed is increased or reduced by 5 mph (10 km/h).

or

 Push rocker switch (3) beyond the pressure point and hold.
 The stored speed is increased or reduced in 5 mph (10 km/h) increments.

Increasing or reducing the specified distance from the vehicle in front

- ➤ To increase the specified distance: press rocker switch ② down (☒).
- To reduce the specified distance: press rocker switch (2) up ().

Driving and parking 155

Information on Hill Start Assist

Hill Start Assist holds the vehicle for a short time when pulling away on a hill under the following conditions:

- · Vehicles with automatic transmission: the transmission is in position **D** or **R**.
- The parking brake has been released.

This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll.

WARNING Risk of accident and injury due to the vehicle rolling away

After a short time, Hill Start Assist no longer holds the vehicle and it can roll away.

► Therefore, swiftly move your foot from the brake pedal to the accelerator pedal. Never attempt to leave the vehicle if it is being held by Hill Start Assist.

HOLD function

HOLD function

Requirements:

• The seat occupancy recognition on the driver's seat has detected that the driver has fastened the seat belt.

The HOLD function holds the vehicle at a standstill without requiring you to depress the brake pedal, e.g. when pulling away on steep slopes or when waiting in traffic. When you depress the accelerator pedal to pull away, the braking effect is canceled and the HOLD function is deactivated.

The HOLD function is only an aid. The responsibility for the vehicle safely standing still remains with the driver.

System limits

The HOLD function is only intended to provide assistance when driving and is not a sufficient means of safeguarding the vehicle against rolling away when stationary.

• The incline must not be greater than 30%.

Activating/deactivating the HOLD function Requirements:

- The vehicle is stationary.
- The engine is running or it has been automatically switched off by the ECO start/stop function.
- The driver is seated and belted.
- The electric parking brake is released.
- Vehicles with automatic transmission: the selector lever is in position D, R or N.
- Active Distance Assist DISTRONIC is deactivated.

Activating the HOLD function

WARNING Risk of an accident due to the HOLD function being activated when you leave the vehicle

If you leave the vehicle while only the HOLD function is braking the vehicle, the vehicle can roll away in the following situations:

- If there is a malfunction in the system or in the power supply.
- If the HOLD function is deactivated by depressing the accelerator pedal or brake pedal, e.g. by a vehicle occupant.
- Always deactivate the HOLD function and secure the vehicle against rolling away before leaving the vehicle.

NOTE Damage from automatic braking

When Active Brake Assist, Active Distance Assist DISTRONIC or the HOLD function are activated, the vehicle brakes autonomously in certain situations.

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- During towing
- In a car wash
- Make sure that the activation conditions are
- Depress the brake pedal until the HOLD display appears in the multifunction display. The HOLD function is activated. You can release the brake pedal.
- (i) If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

Deactivating the HOLD function

The HOLD function is deactivated in the following situations:

- Vehicles with automatic transmission: depress the accelerator pedal when the automatic transmission is in position $\boxed{\mathbf{D}}$ or $\boxed{\mathbf{R}}$.
- Depress the brake pedal again with sufficient pressure until the HOLD display in the multifunction display goes out.
- Activate Active Distance Assist DISTRONIC.
- (i) Vehicles with automatic transmission: the automatic transmission of your vehicle shifts to P after some time. This relieves the load on the service brake.

When the HOLD function is activated, the automatic transmission automatically shifts to P in the following situations:

- The driver leaves the driver's seat.
- The driver's door is opened.
- The engine is switched off without the ECO start/stop function.

Parking Assist PARKTRONIC

Function of Parking Assist PARKTRONIC

Parking Assist PARKTRONIC is an electronic parking assistance system with ultrasound. It monitors the area around your vehicle using six sensors on the front bumper and six sensors on the rear bumper. Parking Assist PARKTRONIC indicates visually and audibly the distance between your vehicle and an object.

Parking Assist PARKTRONIC is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects in the maneuvering area while maneuvering and parking in/exiting parking spaces.

In the standard setting, an intermittent warning tone sounds from a distance of approximately 1.3 ft (0.4 m) to an obstacle. A continuous tone sounds from a distance of approximately 1.0 ft (0.3 m). You can set the warning tone in the multimedia system so that it will sound earlier at a greater distance of approximately 3.3 ft (1 m) $(\rightarrow page 156)$.

Parking Assist PARKTRONIC display in the multimedia system

If the Parking Assist PARKTRONIC display in the multimedia system is not active and an obstacle is detected in the path of the vehicle, a pop-up window for Parking Assist PARKTRONIC appears in the multimedia system at speeds up to approximately 6 mph (10 km/h).

System limitations

Parking Assist PARKTRONIC does not necessarily take into account the following obstacles:

- · Obstacles below the detection range, e.g. persons, animals or objects.
- Obstacles above the detection range, e.g. overhanging loads, overhangs or loading ramps of trucks.

The sensors must be free of dirt, ice and slush. Otherwise, they may not function correctly. Clean the sensors regularly, taking care not to scratch or damage them.

Vehicles with trailer hitch: Parking Assist PARKTRONIC is deactivated for the rear zone when you establish an electrical connection between your vehicle and a trailer.

Deactivating/activating Parking Assist PARKTRONIC

NOTE Risk of an accident from objects at close range

Parking Assist PARKTRONIC may not detect certain objects at close range.

When parking or maneuvering the vehicle, pay particular attention to any objects which are above or below the sensors, e.g. flower pots or drawbars. The vehicle or other objects could otherwise be damaged.

Multimedia system:

- Select PARKTRONIC On. The function is activated or deactivated depending on the previous setting.
- (i) Parking Assist PARKTRONIC is automatically activated when starting the vehicle.

Setting the warning tones of Parking Assist PARKTRONIC

Multimedia system:

- ¬→ Settings → Assistance
- >> Camera & Parking >> Set Warning Tones

Adjusting the volume of the warning tones

Select Warning Tone Volume.

Adjust the value.

Adjusting the pitch of the warning tones

Select Warning Tone Pitch. Adjust the value.

Specifying the starting point for the warning tones

You can specify whether the Parking Assist PARKTRONIC warning tones should commence when the vehicle is further away from an obstacle.

- Select Warn Early All Around.
- Activate or deactivate the function.


Activating or deactivating audio fadeout

You can specify whether the volume of a media source in the multimedia system is to be reduced when Parking Assist PARKTRONIC gives a warning tone.

- Select Audio Fadeout During Warning Tones.
- Activate or deactivate the function.

Rear view camera

Function of the rear view camera



If you have activated the function in the multimedia system, the image from rear view camera 1 appears in the multimedia system when reverse gear is selected. Dynamic guide lines show the path the vehicle will take with the steering wheel in its current position. This helps you to orient yourself and to avoid obstacles when backing up. The image from rear view camera (1) appears in the multimedia system when the following conditions are fulfilled:

- · The ignition is switched on.
- Reverse gear has not been engaged.
- The rear-end doors are opened.

This means that the area behind the vehicle can be monitored.

When the rear-end doors are closed, the image from the rear view camera is switched off after approximately ten seconds.

The rear view camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects etc., in the maneuvering area while maneuvering and parking.

The rear view camera may show a distorted view of obstacles, show them incorrectly or not at all. The rear view camera cannot display all objects which are very near to or under the rear bumper. It will not warn you of a collision, people or objects.

You can select from the following views:

- Normal view
- Wide-angle view
- Trailer view

The area behind the vehicle is displayed as a mirror image, as in the inside rearview mirror.

System limitations

The rear view camera will not function or will only partially function in the following situations:

- · There is heavy rain, snow or fog.
- The ambient light is poor, e.g. at night.
- The area is lit by fluorescent light (the display may flicker).
- If there is a sudden change in temperature, e.g. when driving into a heated garage in win-
- The ambient temperature is very high.
- · The camera lens is obstructed, dirty or fogged up. Observe the notes on cleaning the rear view camera (→ page 288).
- The camera or rear of your vehicle is damaged. In this event, have the camera, its position and its setting checked at a qualified specialist workshop.

The field of vision and other functions of the rear view camera may be restricted due to additional accessories on the rear of the vehicle (e.g. a loading tailgate).

- (i) The display contrast may be impaired due to incident sunlight or other light sources. In this case, pay particular attention.
- (i) Have the display repaired or replaced if, for example, pixel errors considerably restrict its use.
- (i) Objects that are not at ground level appear further away than they actually are. This includes, for example:
 - The bumper of a vehicle parked behind.
 - The drawbar of a trailer.
 - · The ball neck of a trailer coupling.
 - The rear end of a truck.
 - Slanted posts.

Only use the guide lines of the camera image for orientation. Do not travel further than the lowest horizontal guide line when approaching objects. You may otherwise damage your vehicle and/or the object.

Vehicles without Parking Assist PARKTRONIC

The following camera views are available in the multimedia system:




Normal view

- Yellow lane marking the course the tires will take at the current steering wheel angle (dynamic)
- Yellow guide line, vehicle width (driven surface) depending on the current steering wheel angle (dynamic)
- Marking at a distance of approximately 3.3 ft (1.0 m) (the rear-end doors can still be opened completely)

- Red guide line at a distance of approximately 1.0 in (0.3 m) from the rear area
- 6 Red guide line at a distance of approximately 8 in (0.2 m) from the rear area, vehicle width with outside mirror



Wide-angle view




View of trailer (if trailer hitch is installed)

- Yellow guide line, locating aid
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the ball head of the trailer hitch
- Ball head of the trailer hitch.

Vehicles with Parking Assist PARKTRONIC

The following camera views are available in the multimedia system:



Normal view

Yellow lane marking the course the tires will take at the current steering wheel angle (dynamic)

- Yellow guide line, vehicle width (driven surface) depending on the current steering wheel angle (dynamic)
- Marking at a distance of approximately 3.3 ft (1.0 m) (the rear-end doors can still be opened completely)
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the rear area
- 6 Red guide line at a distance of approximately 8 in (0.2 m) from the rear area, vehicle width with outside mirror
- Orange warning display of Parking Assist PARKTRONIC: obstacles are a medium distance away (between approximately 1.3 ft (0.4 m) and 2.0 ft (0.6 m))
- Yellow warning display of Parking Assist PARKTRONIC: obstacles are at a distance of between approximately 2.0 ft (0.6 m) and 3.3 ft (1.0 m)
- (i) If the distance to the obstacle is less than approx. 1.3 ft (0.4 m), the warning display of Parking Assist PARKTRONIC will be red.
- (i) If the entire system fails, the inner segments of the warning display are shown in red.

If the system fails at the rear, the display of the segments changes as follows:

- The rear segments are shown in red when backing up.
- · The rear segments are hidden when driving forwards.

If Parking Assist PARKTRONIC is deactivated, the warning display fades out.



Wide-angle view



View of trailer (if trailer hitch is installed)

- Yellow guide line, locating aid
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the ball head of the trailer hitch
- Ball head of the trailer hitch

360° Camera

Function of the 360° Camera

The 360° Camera is a system that consists of four cameras. The cameras cover the immediate vehicle surroundings. The system assists you, e.g. when parking or at exits with reduced visibil-


The 360° Camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects etc., in the maneuvering area while maneuvering and parking.

The system evaluates images from the following cameras:

- Rear view camera
- Front camera
- Two side cameras in the outside mirrors

Views of the 360° Camera

You can select from different views:



- Yellow lane marking the course the tires will take at the current steering wheel angle (dynamic)
- Yellow guide line, vehicle width (driven surface) depending on the current steering wheel angle (dynamic)
- Marking at a distance of approximately 3.3 ft (1.0 m) (the rear-end doors can still be opened completely)
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the rear area
- Red guide line at a distance of approximately 8 in (0.2 m) from the rear area, vehicle width with outside mirror
- Red warning display of Parking Assist PARKTRONIC: obstacles at a distance of approximately 1.3 ft (0.4 m) or less

When Parking Assist PARKTRONIC is operational and no object is detected, the segments of the warning display are shown in gray.

i If the entire system fails, the segments of the warning display are shown in red.

If the system fails at the rear, the display of the segments changes as follows:

- The rear segments are shown in red when backing up.
- The rear segments are hidden when driving forwards.


If Parking Assist PARKTRONIC is deactivated, the warning display fades out.

Guide lines

(i) The guide lines in the multimedia system display show the distances to your vehicle. The distances only apply to road level.

In trailer mode, the guide lines are shown at the level of the trailer hitch.

View of trailer (if trailer hitch is installed)



View of trailer (if trailer hitch is installed)

- 1 Yellow guide line, locating aid
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the ball head of the trailer hitch
- 3 Ball head of the trailer hitch

Side view of the mirror cameras

The sides of the vehicle can be seen in this view.



- Lane indicating the route the vehicle will take with the steering wheel in its current position
- Yellow warning display of Parking Assist PARKTRONIC: obstacles at a distance of approximately 3.3 ft (1.0 m) or less
- Your vehicle from above
- Marker of the wheel contact points
- Guide line of external vehicle dimensions with outside mirrors folded out

If the distance to the object lessens, the color of warning display ② changes.

System failure

If there is no operational readiness, the following message appears in the multimedia system:



System limitations

The 360° Camera will not function or will only partially function in the following situations:

- The front doors are open.
- The side mirrors are folded in.
- There is heavy rain, snow or fog.
- The ambient light is poor, e.g. at night.
- The area is lit by fluorescent light (the display may flicker).
- If there is a sudden change in temperature, e.g. when driving into a heated garage in winter.
- · The ambient temperature is very high.
- · The camera lens is obstructed, dirty or fogged up.
- Cameras, or vehicle components in which the cameras are installed, are damaged. In this event, have the cameras, their positions and their setting checked at a qualified specialist workshop.

Do not use the 360° Camera under such circumstances. You could otherwise injure others or collide with objects when parking the vehicle.

On vehicles with height-adjustable suspension or if the vehicle is carrying a heavy load, leaving the standard height can result in inaccuracies in the guide lines and in the display of the generated images, depending on technical conditions.

The field of vision and other functions of the camera system may be restricted due to additional attachments on the vehicle (e.g. loading tailgate).

- (i) The contrast of the display may be impaired by abrupt direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.
- i Have the display repaired or replaced if, for example, pixel errors considerably restrict its use.

The image from the 360° Camera appears automatically in the multimedia system when the following conditions are fulfilled:

- · The ignition is switched on.
- The rear-end doors are opened.

This means that the area behind the vehicle can be monitored.

When the rear-end doors are closed, the image from the rear view camera is switched off after approximately ten seconds.

See the notes on cleaning the 360° Camera $(\rightarrow page 288)$.

Selecting a view for the 360° Camera Requirements:

- The Auto, Rear View Cam, is activated in the multimedia system (\rightarrow page 161).
- Engage reverse gear.
- Select the desired view in the multimedia system.

Activating/deactivating automatic operation of the rear view camera

The rear view camera is only an aid. It is not a substitute for you paying attention to the surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. Make sure that no persons, animals or objects etc. are in the path of your vehicle. Pay attention to your surroundings and be ready to brake at all times.

Multimedia system:

→ Settings → Assistance >> Camera & Parking

Switch Auto. Rear View Cam. on or off.

Activating/deactivating maneuvering assistance

Multimedia system:

→ Settings → Assistance >> Camera & Parking

- Switch Maneuvering Assistance on or off.
- (i) When maneuvering assistance is activated, the following functions are active:
 - Drive Away Assist (→ page 165)
 - Rear Cross Traffic Alert (→ page 166)

ATTENTION ASSIST

Function of ATTENTION ASSIST

ATTENTION ASSIST can assist you on long, monotonous journeys, e.g. on highways and trunk roads. If ATTENTION ASSIST detects indicators of fatigue or increased lapses in concentration on the part of the driver, it suggests taking a break.

ATTENTION ASSIST is only an aid. It cannot always detect drowsiness or increased lapses in concentration in good time. The system is not a substitute for a well-rested and attentive driver. On long journeys, take regular and timely breaks that allow you to rest properly.

You can choose between two settings:

- Standard: normal system sensitivity
- Sensitive: higher system sensitivity. The driver is warned earlier and the attention level detected by the system (Attention Level) is adapted accordingly.

If fatigue or increased lapses in concentration are detected, the ATTENTION ASSIST: Take a Break! warning appears in the Instrument Display. You can acknowledge the message and take a break if necessary. If you do not take a break and ATTEN-TION ASSIST continues to detect increased lapses in concentration, you will be warned again after a minimum of 15 minutes.



Instrument Display (color display)

You can have the following status information for ATTENTION ASSIST displayed in the Assistance menu of the on-board computer:

- The journey length since the last break
- The attention level determined by ATTENTION ASSIST:
 - The fuller the circle is, the higher the detected attention level is
 - The circle in the center of the display empties from the outside inwards as attentiveness decreases



Instrument Display (black and white display)

You can have the following status information for ATTENTION ASSIST displayed in the Assistance menu of the on-board computer:

- The journey length since the last break
- The attention level determined by ATTENTION ASSIST:
 - The fuller the bar is, the higher the detected attention level is
 - The bar empties as attentiveness decreases

If ATTENTION ASSIST cannot calculate the attention level and cannot issue a warning, the Attention Level message appears.

If a warning is displayed in the Instrument Display, the multimedia system offers to search for a rest area. You can select a rest area and start navigation to this rest area. This function can be activated and deactivated in the multimedia system.

If ATTENTION ASSIST is deactivated, the Tope symbol appears in the assistance graphic in the Instrument Display when the engine is running. ATTENTION ASSIST is activated automatically when the engine is re-started. The last selected sensitivity level remains stored.

System limits

ATTENTION ASSIST is active in the 37 mph (60 km/h) to 124 mph (200 km/h) speed range.

The functionality of ATTENTION ASSIST is restricted, and warnings may be delayed or not occur at all, in the following situations:

- The journey lasts less than approximately 30 minutes
- The road condition is poor (uneven road surface or potholes)
- The vehicle is subjected to a strong crosswind
- You have a sporty driving style (high cornering speeds or high rates of acceleration)

- The time is set incorrectly
- You change lanes and vary your speed frequently in active driving situations

The ATTENTION ASSIST drowsiness or alertness. assessment is deleted and restarted when continuing the journey in the following situations:

- · If you switch off the engine
- You unfasten your seat belt and open the driver's door (e.g. change drivers or take a break)

Setting ATTENTION ASSIST

Multimedia system:

→ Settings → Assistance > Attention Assist

Setting options

Select Standard, Sensitive or Off.

Suggesting a rest area

- Select Suggest Rest Area.
- Activate or deactivate the function. If ATTENTION ASSIST detects fatigue or an increasing lack of attention, it suggests a nearby rest area.
- Select a suggested rest area. You are guided to the selected rest area.

Traffic Sign Assist

Function of Traffic Sign Assist



Traffic Sign Assist detects traffic signs with multifunction camera 🕦. It assists you by displaying detected speed limits and overtaking restrictions in the instrument cluster.

Since Traffic Sign Assist also uses the data stored in the navigation system, it can also update the display without detecting traffic signs:

- when the vehicle changes roads, e.g. freeway entry or exit road
- when a village or city boundary stored in the digital map is passed

The camera also detects traffic signs with a restriction indicated by an additional sign (e.g. in wet conditions).

Warning when the maximum permissible speed is exceeded

The system can warn you if you unintentionally exceed the maximum permissible speed. To do this, you can specify in the multimedia system by how much the maximum permissible speed can be exceeded before a warning is issued. You can specify whether the warning is to be just a visual warning or an audible one as well.

Display in the Instrument Display



Instrument Display (color display)

- Permissible speed
- Permissible speed when there is a restriction
- Additional sign with a restriction
- (i) Only one of traffic signs (1) or (2) is displayed at any one time in the Instrument Display, if necessary with additional sign 3. If two valid traffic signs are detected at the same time, a plus sign appears next to the traffic sign in the Instrument Display as an indication that both traffic signs are displayed in the navigation system.

Since Traffic Sign Assist also uses the data stored in the navigation system, it can also update the display without detecting traffic signs:

- when the vehicle changes roads, e.g. freeway entry or exit road
- when a village or city boundary stored in the digital map is passed



Traffic Sign Assist is not available in all countries. If it is unavailable, display (1) is shown in the speedometer.

System limitations

The system may be impaired or may not function in the following situations:

- The system is affected by poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, or due to rain, snow, fog or heavy spray
- The system is impaired by glare, e.g. from oncoming traffic, direct sunlight or reflections
- · The system is affected by dirt on the windshield in the area of the multifunction camera, or because the camera is fogged up. damaged or covered
- The traffic signs are hard to detect, e.g. due to dirt, because they are covered, due to snow or insufficient lighting
- The information in the navigation system's digital map is incorrect or out-of-date
- The system is affected by ambiguous signs. e.g. traffic signs on construction sites or in adjacent lanes

Setting Traffic Sign Assist

Multimedia system:

→ Settings → Assistance >> Traffic Sign Assist

Displaying detected traffic signs in the media display

- Select Display in Central Display.
- Activate or deactivate the function.

Setting the type of warning

Select Visual & Audible, Visual or None.

Setting the warning threshold

This value determines at which point the warning is given once a speed limit is exceeded.

- Select Warning Threshold.
- Set a speed.

Blind Spot Assist

Function of Blind Spot Assist with exit warn-

Blind Spot Assist uses two lateral, rear-facing radar sensors to monitor the area directly next to and on the side behind the vehicle.

(i) USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter or use in any non-approved way. Any unauthorized modification to this device could void the user's authority to operate the equipment.

WARNING Risk of accident despite Blind Spot Assist

Blind Spot Assist reacts neither to stationary objects nor to vehicles approaching and overtaking you at a greatly different speed.

As a result, Blind Spot Assist cannot warn drivers in these situations.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle

Blind Spot Assist is only an aid. It may fail to detect some vehicles and is no substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.

If a vehicle is detected above speeds of approximately 7.5 mph (12 km/h) and this vehicle subsequently enters the monitoring range directly next to your vehicle, the warning lamp in the outside mirror lights up red.

(i) When a trailer is connected, the radar sensor's field of vision may be impaired, thereby making limited monitoring possible. Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

If a vehicle is detected close to your vehicle in the lateral monitoring range and you switch on the turn signal indicator in the corresponding direction, a warning tone sounds. The red warning

lamp in the outside mirror flashes. If the turn signal indicator remains switched on, all other detected vehicles are indicated only by the flashing of the red warning lamp.

If you overtake a vehicle quickly, no warning is given.

Exit warning

The exit warning is an additional function of Blind Spot Assist and warns vehicle occupants when leaving the vehicle about any approaching vehicles.

WARNING Risk of accident despite exit warning

The exit warning reacts neither to stationary objects nor to vehicles approaching you at a greatly different speed.

As a result, the exit warning cannot warn drivers in these situations.

- Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.
- (i) An exit warning is not issued for sliding doors and rear-end doors.

Overview

When the vehicle is stationary, an object is detected from behind in the monitoring range.	Display in outside mirror
When the vehicle is stationary, a door on the relevant side of the vehicle is opened. An object which is close to your vehicle is detected in the monitoring range.	Visual and audible warning

(i) This additional function is only available when Blind Spot Assist is activated and up to a maximum of three minutes after the drive system has been switched off. The end of the availability of the exit warning function is indicated by a series of flashes in the outside mirror.

The exit warning function is only an aid and is no substitute for the attentiveness of the vehicle occupants. Responsibility always lies with the

vehicle occupants when opening doors and leaving the vehicle.

System limits

Blind Spot Assist and the exit warning function may be limited in the following situations:

- If there is dirt on the sensors or the sensors are obscured
- If there is poor visibility, e.g. due to fog, heavy rain, snow or spray
- If narrow vehicles are within the monitoring range, e.g. bicycles
- On very wide lanes
- · If vehicles are not driving in the middle of their lane
- (i) Stationary or slowly moving objects are not displayed.

Warnings may be issued in error when driving close to crash barriers or similar solid lane borders. Warnings may be interrupted when driving alongside long vehicles, for example trucks, for a prolonged time.

Blind Spot Assist is not operational when reverse gear is engaged.

The exit warning function may be limited in the following situations:

- · When the sensor is blocked by adjacent vehicles in narrow parking spaces
- When people are approaching

Activating/deactivating Blind Spot Assist Multimedia system:

→ Settings → Assistance

Activate or deactivate Blind Spot Assist.

Drive Away Assist

Function of Drive Away Assist

i Drive Away Assist is only available for vehicles with automatic transmission.

Drive Away Assist can reduce the severity of an impact when pulling away. If an obstacle is detected in the direction of travel, the vehicle's speed is briefly reduced to approximately 1 mph (2 km/h). If a critical situation is detected, a symbol appears on the camera image of the multimedia system.

WARNING Risk of accident caused by limited detection performance of Drive Away Assist

Drive Away Assist cannot always clearly identify objects and traffic situations.

In such cases, Drive Away Assist might:

- Warn you without reason and limit the vehicle speed.
- Not warn you or not limit the vehicle speed.
- Always pay careful attention to the traffic situation; do not rely on Drive Away Assist alone
- ▶ Be prepared to brake or swerve as necessary, provided the traffic situation permits and that it is safe to take evasive action.

Drive Away Assist is only an aid. It is not a substitute for your attention to the surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. Make sure that no persons, animals or objects etc. are in the path of your vehicle.

A risk of a collision may arise in the following situations, for example:

- If the driver mixes up the accelerator and brake pedals.
- If the wrong gear is selected.

The Drive Away Assist function is active under the following conditions:

- If Parking Assist PARKTRONIC is activated.
- Every time the gear is changed to R or D when the vehicle is at a standstill.
- If the detected obstacle is less than approximately 3.3 ft (1.0 m) away.
- If the maneuvering assistance function is activated in the multimedia system.

System limits

Drive Away Assist is unavailable on inclines and when driving with a trailer.

Rear Cross Traffic Alert

Function of Rear Cross Traffic Alert

The radar sensors in the bumper are used for the system. This way the area adjacent to the vehicle is continually monitored. If the radar sensors are

obscured by vehicles or other objects, detection is not possible.

(i) Also read the notes on Blind Spot Assist $(\rightarrow page 164)$.

Vehicles with Blind Spot Assist: drivers can also be warned of any crossing traffic when backing up out of a parking space. If a vehicle is detected, the warning lamp in the outside mirror on the corresponding side lights up red. If it detects a critical situation, a warning tone also sounds.

Vehicles with Blind Spot Assist and Parking Assist PARKTRONIC: drivers can also be warned of any crossing traffic when backing up out of a parking space. If a critical situation is detected, a warning symbol appears on the camera image of the multimedia system. If the driver does not respond to the warning, the vehicle's brakes can be applied automatically. In this case, a warning tone sounds.


The Rear Cross Traffic Alert function is active under the following conditions:

- Blind Spot Assist is activated.
- Reverse gear is engaged or the vehicle is backing up at walking pace.
- If the maneuvering assistance function is activated in the multimedia system.

The Rear Cross Traffic Alert function is unavailable when driving with a trailer.

Lane Keeping Assist and Active Lane Keeping Assist

Functions of Lane Keeping Assist



Lane Keeping Assist monitors the area in front of your vehicle with multifunction camera 1. It

serves to protect you against unintentionally leaving your lane. You may also be warned by a vibrating message from the steering wheel and by the status symbol flashing in the Instrument Displav.

The warning is issued when the following conditions are met at the same time:

- · Lane Keeping Assist detects lane markings.
- A front wheel drives over a lane marking.

You can activate and deactivate the Lane Keeping Assist warning.


If you fail to adapt your driving style, Lane Keeping Assist can neither reduce the risk of accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Lane Keeping Assist is only an aid and is not intended to keep the vehicle in the lane without the driver's cooperation. You are responsible for the safe distance to the vehicle in front, for vehicle speed, braking in good time and for staying in your lane.

System limits

The system may be impaired or may not function in the following situations:

- There is poor visibility, e.g. due to insufficient illumination of the road, if there are highly variable shade conditions or in rain, snow, fog or spray.
- · Glare from oncoming traffic, direct sunlight or reflections.
- There is dirt on the windshield in the vicinity of the multifunction camera or the camera is fogged up, damaged or obscured.
- · No or several unclear lane markings are present for one lane, e.g. in a construction area.
- The lane markings are worn, dark or covered.
- The distance to the vehicle driving in front is too short and thus the lane markings cannot be detected.
- The lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- The road is very narrow and winding.

Functions of Active Lane Keeping Assist



Active Lane Keeping Assist monitors the area in front of your vehicle by means of multifunction camera 1. It serves to protect you against unintentionally leaving your lane. You may also be warned by a vibrating message from the steering wheel and by the status symbol flashing in the instrument display. In addition, you may be guided back into your lane by a lane-correcting brake application. A relevant message appears in the instrument display.

The warning is issued when the following conditions are met at the same time:

- The driving system detects lane markings.
- A front wheel passes over the lane markings.

A lane-correcting brake application occurs when the following conditions are met:

- Active Lane Keeping Assist detects lane markings on both sides of the vehicle.
- · A front wheel drives over a solid lane marking.

A relevant message appears in the instrument display.

The brake application is available in the speed range between approximately 40 mph (60 km/h) and 100 mph (160 km/h).

You can either deactivate the Active Lane Keeping Assist warning or switch off the system completely.

If you fail to adapt your driving style, Active Lane Keeping Assist can neither reduce the risk of an accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. The driving system is an aid for when you unintentionally leave or cross the lane and

not a system for automatically keeping to the lane. You are responsible for the distance to the vehicle in front, for vehicle speed, braking in good time and for staying in your lane.



If a lane-correcting brake application from Active Lane Keeping Assist occurs, display
appears in the multifunction display.

System limits

No lane-correcting brake application from Active Lane Keeping Assist occurs in the following situations:

- You clearly and actively steer, brake or accelerate
- · You switch on the turn signal.
- A driving safety system intervenes, such as ESP[®] or Active Brake Assist.
- You have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- · ESP® has been switched off.
- When driving with a trailer, the electrical connection to the trailer has been correctly established
- If a loss of tire pressure or a faulty tire has been detected and displayed.

The system may be impaired or may not function in the following situations:

- There is poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, or due to rain, snow, fog or heavy spray.
- Glare from oncoming traffic, direct sunlight or reflections.
- There is dirt on the windshield in the vicinity of the multifunction camera or the camera is fogged up, damaged or obscured.
- No or several unclear lane markings are present for one lane, e.g. in a construction area.
- The lane markings are worn, dark or covered.

- The distance to the vehicle in front is too small, and therefore the lane markings cannot be detected.
- The lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- The roadway is very narrow and winding.

Activating/deactivating Lane Keeping Assist or Active Lane Keeping Assist

Multimedia system:

- → 🔝 >> Settings >> Assistance
- Select Lane Keeping Assist or Act. Lane Keep Asst. On.

Activating or deactivating the warning

- Select Lane Keeping Assist or Act. Lane Keep Asst. On.
- Select Warning.

Work mode


ADR (working speed control)

Function of ADR (working speed control)

When activated, ADR automatically increases the engine speed to a preset speed or a speed you have set.

- (i) After a cold start, the idle speed of the engine is increased automatically. If the preset working speed is lower than the increased idle speed, the working speed is only reached once the engine has completed the warm-up phase.
 - It is only possible to activate ADR with the vehicle stationary and the parking brake applied.
 - On vehicles with automatic transmission, the selector lever must be in position $\boxed{\mathbf{P}}$.

Activating/deactivating ADR




- To activate: while the engine is running, press switch 1. The Working Speed Governor Active message appears in the multifunction display.
- To deactivate: while the engine is running, press switch 2.

ADR goes out automatically in the following situations:

- · You release the parking brake.
- You depress the brake pedal.
- The vehicle moves.
- The control unit detects a malfunction.

Adjusting ADR



- Engage power take-off or activate ADR.
- To increase: press switch ①.
- To reduce: press switch 2.

Trailer operation

Notes on trailer operation

WARNING Risk of accident- and injury if the load is exceeded

If you exceed the permitted load when using the rack, the rack system may disconnect from the vehicle and endanger other road users.

- Always comply with the permitted load when using the rack.
- WARNING Swerving of the vehicle/ trailer combination due to increased speed

If the vehicle/trailer combination swerves, you can lose control of it.

The vehicle/trailer combination can even tip

- Under no circumstances should you try to increase the speed to straighten the vehicle/trailer combination.
- Reduce speed and do not counter-steer.
- If necessary, apply the brakes.

WARNING Risk of accident due to the brake system overheating

If you leave your foot on the brake pedal when driving, the brake system may overheat.

This increases the braking distance and the brake system may even fail.

- Never use the brake pedal as a footrest.
- ▶ Do not depress the brake pedal and the accelerator pedal at the same time while driving.

WARNING Danger of accident due to unsuitable ball coupling

If you install an unsuitable ball coupling, overloading of the trailer hitch and rear axle will be the result. This is particularly the case if the ball coupling is relatively long or angled differently.

The handling characteristics may be heavily impaired and the trailer can become detached. There is a risk of fatal injury.

Only install a ball coupling that meets the permitted dimensions and has been

- designed for the trailer operation requirements.
- Do not modify the ball coupling or the trailer hitch.
- **WARNING** Risk of accident and injury due to an incorrectly installed ball coupling

If the ball coupling is not installed and engaged correctly, it may become detached during travel and endanger other road users. There is a risk of fatal injury.

- Install and secure the ball coupling as described in the ball coupling manufacturer's installation instructions.
- ▶ When the ball coupling has been installed, ensure that it is correctly secured before every trip.
- ▲ WARNING Risk of accident due to an incorrectly installed and secured ball coupling

If the ball coupling has not been correctly installed and secured, the trailer can become detached.

- Install and secure the ball coupling as described in the ball coupling manufacturer's installation instructions.
- When the ball coupling has been installed, ensure that it is correctly secured before every trip.
- ! **NOTE** Wearing out the brake linings by continuously depressing the brake pedal
- Do not depress the brake pedal continuously whilst driving.
- To use the braking effect of the engine, shift to a lower gear in good time.

Always comply with the operating instructions of the manufacturer of the trailer coupling and the ball neck.

Place your vehicle/trailer combination on surfaces that are as even as possible and secure it against rolling away (\rightarrow page 140). Couple and uncouple the trailer carefully.

When backing up the towing vehicle, ensure that there is no-one between the vehicle and the trailer.

If you do not couple the trailer to the towing vehicle correctly, the trailer may become detached. Once it has been coupled and is roadworthy, the trailer must be in a horizontal position behind the towing vehicle.

Note the following regarding the tongue weight:

- Make full use of the maximum tongue weight, where possible.
- Never fall below a legally prescribed minimum tongue weight; the tongue weight must always be positive.
- Do not exceed or fall below the permissible tongue weights - this must be observed during loading and unloading of the trailer.

Do not exceed the following values:

- Permitted braked or unbraked towing capa-
 - The maximum permissible towing capacity for unbraked trailers is 1,653 lbs (750 kg).
- Permissible rear axle load of the towing vehi-
- Permissible gross mass of the towing vehicle
- Permissible gross mass of the trailer
- Permissible gross combination mass
- Maximum permissible speed of the trailer

The relevant permitted values, which must not be exceeded, can be found in the following places:

- In your vehicle documents
- On the identification plate of the trailer hitch
- On the trailer's identification plate
- On the vehicle identification plate

If there are discrepancies between the values, the lowest one shall apply.

Before driving off, ensure the following:

- The tire pressure on the rear axle of the towing vehicle has been set for the maximum load.
- The headlamps have been set correctly.

Values approved by the manufacturer can be found on the identification plates and in the section for the towing vehicle (\rightarrow page 311).

Your vehicle will behave differently with a trailer relative to without a trailer:

- The vehicle/trailer combination will be heav-
- The vehicle/trailer combination will be restricted in its acceleration and climbing ability.
- The vehicle/trailer combination will have an increased braking distance.
- The vehicle/trailer combination will be more susceptible to crosswind gusts.
- The vehicle/trailer combination will require more sensitive steering.
- The vehicle/trailer combination will have a larger turning circle.

This may impair the vehicle's driving characteristics.

When driving with a vehicle/trailer combination, always adapt your speed to the current road and weather conditions. Drive carefully, Keep a sufficient safe distance.

Comply with the maximum speed of 49 mph (80 km/h) or 62 mph (100 km/h), even in countries in which higher speeds are permitted for vehicle/trailer combinations.

Comply with the legally prescribed maximum speed for vehicle/trailer combinations in force in the country, state or Canadian province in guestion. Before setting off, consult the trailer's vehicle documents to see the maximum permissible speed for your trailer.

Attach only an approved trailer hitch to your vehicle. Use only a ball neck that has been approved for your vehicle. Further information about availability and installation of the trailer electrics is available from any qualified specialist workshop.

The trailer hitch is one of the most important vehicle parts for road safety. Comply with the instructions on operating, maintaining and servicing in the manufacturer's operating instructions.

(i) Your vehicle's bumpers are not suitable for installing detachable trailer tow hitches.

Do not attach any rented trailer tow hitches or any other detachable trailer tow hitches to the bumpers.

- (i) When using a trailer, remember that PARKTRONIC is available only to a limited extent, if at all.
- (i) The height of the ball head will change depending on the vehicle's load. In this case,

use a trailer with a height-adjustable drawhar.

Driving notes

The maximum permissible speed for vehicle/ trailer combinations depends on the type of trailer. Before setting off, consult the trailer's vehicle documents to see the maximum permissible speed for your trailer.

Your vehicle will behave differently with a trailer relative to without a trailer, and will consume more fuel. In the case of a long and steep descent, you must select shift range 3, 2 or 1 in good time.

(i) This also applies if the cruise control is switched on.

You will thereby make use of the engine's braking effect and will not have to brake as often to control the speed. This will take some of the strain off the brake system and prevent the brakes from overheating and wearing too quickly. If you need additional braking, depress the brake pedal intermittently rather than continuously.

Driving tips

If the trailer sways, remember the following points:

- Do not accelerate under any circumstances.
- Do not countersteer.
- If necessary, apply the brakes.
- (i) You can prevent the trailer from swaying and rocking by retrofitting stabilizer bar or trailer stability programs. You can obtain further information from an authorized Mercedes-Benz Center.

When you are driving with a trailer, comply with the following points:

- · Maintain a greater distance than when driving without a trailer.
- · Avoid braking abruptly. If possible, brake gently first of all so that the trailer closes up behind your vehicle. Then, increase the braking force rapidly.
- The values given for start-off gradeability refer to sea level. When driving in mountainous areas, note that engine output, and therefore start-off gradeability, will decrease with increasing altitude.

Coupling/uncoupling a trailer

Coupling a trailer

NOTE Damage to the vehicle battery due to full discharge

Charging the trailer battery using the power supply of the trailer can damage the vehicle battery.

- ▶ Do not use the vehicle's power supply to charge the trailer batterv.
- Shift the selector lever to position **P**.
- Apply the vehicle's parking brake.
- Close all the doors.
- Position the trailer on a level surface behind the vehicle.
- (i) The ball head height changes depending on the vehicle's load. In this case, use a trailer with a height-adjustable trailer drawbar.
- Couple up the trailer.
- Establish all electrical and other connections to the trailer.
- Remove objects or devices which prevent the trailer from rolling, e.g. wheel chocks.
- Release the trailer's parking brake.
- The vehicle harness has a cable connection to the brake light indicator lamp.

Observe the maximum permissible trailer dimensions (width and length).

Most US states and all Canadian provinces prescribe the following points, and you are urgently recommended to comply with these:

- · Safety chains between the towing vehicle and the trailer. The chains should be routed in a criss-cross pattern under the trailer drawbar. They must be connected to the trailer tow hitch and not to the bumper or to the vehicle axle.
 - Leave sufficient slack in the chains. This allows for even sharp cornering.
- A separate brake system is required for certain trailers.
- A safety feature is required for braked trailers. Determine the specific requirements according to the relevant laws.

If the trailer becomes detached from the towing vehicle, the safety feature triggers the trailer brakes and can thus reduce the danger.

Uncoupling a trailer

WARNING Risk of being crushed and becoming trapped when uncoupling a trailer

When uncoupling a trailer with an engaged inertia-activated brake, your hand may become trapped between the vehicle and the trailer drawbar.



Do not uncouple trailers with an engaged overrun brake.

Do not uncouple a trailer with an overrun brake in a state of overrun. Otherwise, the rebound of the overrun brake can damage your vehicle.

- Shift the selector lever to position **P**.
- Apply the vehicle's parking brake.
- Close all the doors.
- Apply the trailer's parking brake.
- Secure the trailer against rolling away with a wheel chock or similar object.
- Remove the trailer cables and safety chains.
- Uncouple the trailer.

Information about towing a trailer

Operating a trailer is subject to many statutory regulations such as speed restrictions.

Many states also require an auxiliary separate functional braking system when towing a weight that exceeds a certain limit. For your safety, it is recommended to use a separate functional braking system on any towed vehicle.

Make sure that your trailer combination meets local regulations. This not only applies to your place of residence, but also to your destination. Information on this can be obtained from the police and local authorities.

Comply with the following when driving with a trailer:

 Practice cornering, stopping and backing up in a traffic-free location. In this way, you will gain driving experience and become accustomed to the new handling characteristics.

- Before driving, check the following:
 - that the trailer tow hitch and ball coupling are secure
 - that the safety switch for braked trailers is functioning correctly
 - that the safety chains are secure and undamaged
 - that the electrical connections are secure
 - that the lights are functioning correctly
 - the wheels for damage and correct tire pressure (\rightarrow page 308)
- Adjust the outside mirrors so that you have a clear view of the rear section of the trailer.
- If the trailer is equipped with an individual braking system, check before each journey whether the brakes are functioning correctly.
- If the trailer has electronically controlled brakes, pull away carefully with the vehicle/ trailer combination. Brake manually using the brake controller and check whether the brakes are functioning correctly.
- Secure the load on the trailer in line with the requirements and rules for load-securing methods.
- When driving with a trailer, check at regular intervals that the load is secure and that the lights and brakes are functioning correctly.
- Bear in mind that the handling characteristics are more unstable when towing a trailer than when driving without a trailer. Avoid sudden steering movements.
- The vehicle/trailer combination is heavier, accelerates more slowly, has a reduced climbing ability and an increased braking distance. It is more susceptible to side winds and requires careful steering.
- If possible, do not brake suddenly, but rather moderately at first so that the trailer can activate its brakes. Then increase the pressure on the brake pedal.
- If the automatic transmission shifts between gears on uphill or downhill gradients, restrict the shift range. Select shift range 4, 3, 2 or 1. A lower gear and reduced speed decrease the risk of engine damage.
- When driving on a downhill gradient, shift to a lower gear to use the engine's braking effect.

- Avoid constant braking, as this could cause the vehicle brakes and possibly also the trailer brakes to overheat
- If the coolant temperature increases significantly when the air-conditioning system is switched on, switch the air-conditioning system off.
 - Coolant heat can also be dissipated by switching the airflow and the temperature of the heater or air conditioning to the maximum level. Open the windows if necessary.
- When overtaking, pay particular attention to the increased overtaking distance of your vehicle/trailer combination.

Due to the length of your vehicle/trailer combination you will require a longer stretch of road before switching back to the original lane.

Permissible trailer loads and trailer drawbar noseweights

Weight information

WARNING Risk of accident due to unbraked trailer with excessively high gross weight

If you tow a trailer without a separate functional braking system and a gross trailer weight (GTW) of more than 1635 lbs (750 kg), then the vehicle brake system may overheat.

This increases the braking distance and the brake system may even fail.

Always use a trailer with a separate functional braking system when towing a trailer with a gross trailer weight (GTW) of more than 1635 lbs (750 kg).

NOTE Damage to the drive train, transmission or trailer tow hitch due to excess gross combination weight

The permissible gross combination weight is exceeded.

The drive train, the transmission or the trailer tow hitch may be damaged.

Comply with the permissible gross combination weight.

For vehicles with a permissible gross vehicle weight of 11030 lbs (5003 kg), the permissible gross combination weight is less than the sum of the permissible gross vehicle weight plus the permissible trailer load. If either the vehicle or the trailer is fully laden, the permitted gross vehicle weight or the permitted trailer load values are reduced accordingly. In this case, you may only partially load the trailer or the vehicle.

The gross trailer weight (GTW) is calculated by adding the weight of the trailer to the weight of the load and equipment. If the trailer is equipped with a separate braking system, then the maximum gross trailer weight is 5000 lbs (2268 kg) or 7500 lbs (3402 kg).

The maximum permissible trailer drawbar nose-weight on the ball head is 500 lbs (227 kg) or 750 lbs (340 kg). However, the actual trailer drawbar noseweight must not exceed the value given on the trailer tow hitch or trailer identification plates. Where the values differ, the lowest value always applies.

The permissible gross weight for vehicle-trailer combinations (GCWR) is calculated by adding the gross weight of the trailer to the gross vehicle weight including a driver's weight of approximately 150 lbs (68 kg). The maximum permissible gross combination weight is vehicle-specific and equipment-dependent. When driving with a trailer, you should not exceed the maximum permitted permissible gross weight for vehicle-trailer combinations (GCWR).

The permissible values, which must not be exceeded, can be found in your vehicle documents and on the identification plates of the trailer tow hitch, the trailer and the vehicle. The values approved by the manufacturer can also be found in the "Technical data" section. Where the values differ, the lowest value always applies.

Loading the trailer

Use a drawbar noseweight that is as close as possible to the maximum permissible noseweight. Do not undershoot the minimum permissible noseweight. Otherwise, the trailer may become detached.

- Distribute the load over the vehicle and the trailer so as not to exceed either the maximum permissible values for the gross vehicle weight rating (GVWR) and gross trailer weight (GTW), the permissible gross weight for vehicle-trailer combinations (GCWR), nor the maximum permissible gross axle weight rating (GAWR) and trailer drawbar noseweight (TWR) of your vehicle.
- Add the rear axle load to the trailer drawbar noseweight of the trailer drawbar on the ball

- head (TWR). This will ensure that you do not exceed the permissible gross axle weight rating (GAWR).
- Add the vehicle load to the trailer drawbar noseweight of the trailer drawbar on the ball head (TWR). This will ensure that you do not exceed the permissible gross vehicle weight rating (GVWR).

Checking the vehicle and trailer weight

- Make sure that the weights of the towing vehicle and the trailer comply with the maximum permissible values. Have the car/trailer combination weighed on a calibrated weighing machine. The car/trailer combination comprises the towing vehicle including driver, passengers and load as well as the laden trailer.
- Check the maximum permissible gross axle weight rating of the front and rear axles (GAWR), the gross trailer weight (GTW), the permissible gross weight for vehicle-trailer combinations (GCWR) and the trailer drawbar noseweight rating (TWR).

Trailer power supply

Incorrect cabling of the connector plug may interfere with other electronic systems in the vehicle. Mercedes-Benz therefore recommends that you have the cabling of the connector plug carried out at a qualified specialist workshop.

You can connect accessories up to a maximum of 240 W to the permanent power supply. Do not charge a trailer battery using the power supply.

Your vehicle may be equipped with a range of electrical equipment for trailer operation. Depending on your trailer, you may need an adapter for the electrical connection between the trailer and your vehicle.

The trailer socket of your vehicle is equipped with a permanent power supply at the factory.

The permanent power supply is supplied via trailer socket pin 4.

Note that the trailer's permanent power supply is not switched off when the vehicle's on-board electrical system voltage is low. This could completely discharge your vehicle's starter battery.

Further information on the electrical equipment currently installed on your vehicle and on installing the trailer electrics can be obtained at a qualified specialist workshop.

Overview of Instrument Display

WARNING Risk of accident due to an instrument display malfunction

If the Instrument Display has failed or malfunctioned, you may not recognize function restrictions applying to safety relevant systems.

The operating safety of your vehicle may be impaired.

- Drive on carefully.
- Have the vehicle checked immediately at a qualified specialist workshop.

If you are uncertain regarding the operational safety of your vehicle, park the vehicle safely as soon as possible. Inform a qualified specialist workshop.


Instrument Display



Example: Instrument Display with color display


- Speedometer
- Multifunction display
- Tachometer
- Coolant temperature display
- Fuel level and fuel filler flap location indicator

In normal driving mode, coolant temperature display (4) is permitted to rise to the red marking.



Example: Instrument Display with black and white display

- Speedometer
- Indicator lamps display
- Tachometer
- Multifunction display



The engine will be damaged if you drive with the engine in the overrevving range.

Do not drive with the engine in the overrevving range.


When the red marking in tachometer (3) is reached (overspeed range), the fuel supply will be interrupted in order to protect the engine.

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

Overview of the buttons on the steering wheel




Variant 1

- Back button, left (on-board computer)
- Touch Control, left (on-board computer)
- 3 Button group for cruise control or Active Distance Assist DISTRONIC
- Button group:

sound

- ₩ Voice-operated control
- ☐ Displays favorites (multimedia system) VOL: using the ☒ control, increases/ reduces the volume or switches off the
- Makes/accepts a call
- Rejects/ends a call
- Main menu button (multimedia system)
- Touch Control, right (multimedia system)
- 🕖 🔚 Back button, right (multimedia system)



Variant 2

- Back button, left (on-board computer)
- Touch Control, left (on-board computer)
- Main menu button (on-board computer)
- Button group for cruise control or Active Distance Assist DISTRONIC
- 6 Button group:
 - \(\text{\\circ}\exitingt{\\circ}\exitingth\\exitin\ex
 - ☐ Displays favorites (multimedia system)

VOL: using the \ control, increases/ reduces the volume or switches off the sound

- Makes/accepts a call
- Rejects/ends a call
- Main menu button (multimedia system)
- Touch Control, right (multimedia system)
- Back button, right (multimedia system)

Operating the on-board computer

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.


- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paving attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the on-board computer.

Operating the on-board computer (vehicles with steering wheel buttons)

(i) The displays of the on-board computer appear on the multifunction display $(\rightarrow page 177)$.

When the function is switched on, different signal tones will provide feedback while the on-board computer is being operated. These include a signal tone when the end of a list is reached or when a list is being scrolled through.



The on-board computer is operated via left-hand Touch Control 2 and back button on the left 1.



The on-board computer is operated using the following buttons:

- Back button on the left
- Left-hand Touch Control (2)
- Main menu button on the left (3)

The following menus are available depending on the equipment:

- Service
- Assistance
- Trip
- Navigation
- Radio
- Media
- Phone
- Settings

- To call up the main menu: press back button on the left (1) repeatedly, or press and hold it.
- (i) Vehicles without Active Distance Assist **DISTRONIC:** you can call up the main menu of the on-board computer with the hut-
- To browse through the menu bar: swipe to the left or right on left-hand Touch Control 2.
- To call up a menu or confirm a selection: press left-hand Touch Control 2.
- To browse through displays or lists in the menu: swipe upwards or downwards on lefthand Touch Control 2.
- To call up a submenu or confirm a selection: press left-hand Touch Control 2.
- To exit a submenu: press back button on the left 1.

If you are in a submenu and press and hold back button on the left (1), the main menu will appear.

Overview of the displays on the multifunction display



Instrument Display with color display

- Outside temperature
- Transmission position
- Time
- Display section



Instrument Display with black and white display

- Outside temperature
- 2 Display section
- Time
- Transmission position

Further displays on the multifunction display:

Gearshift recommendation •

P///■ Parking Assist PARKTRONIC switched

(6) Cruise control (\rightarrow page 151)

=83 Active Distance Assist DISTRONIC $(\rightarrow page 152)$

DSR DSR (\rightarrow page 126)

HOLD HOLD function (→ page 155)

■ Adaptive Highbeam Assist $(\rightarrow page 86)$

₹20cc ATTENTION ASSIST switched off

1 A door is not fully closed.

Rear window wiper switched on

 $(\rightarrow page 95)$

LOW RANGE LOW RANGE active (\rightarrow page 126)

SOS Emergency call system not active NOT

READY


₽off Active Lane Keeping Assist switched off (\rightarrow page 167)

≥!€-Active Brake Assist switched off $(\rightarrow page 149)$

OFF Blind Spot Assist switched off $(\rightarrow page 164)$

Vehicles with Traffic Sign Assist: detected traffic signs and messages (\rightarrow page 163).

Setting the instrument lighting



Turn brightness control knob (1) upwards or downwards.

The lighting on the Instrument Display and the control elements in the vehicle interior is

in vehicles without brightness control knob 1, the instrument lighting can be set via the on-board computer (\rightarrow page 183).

Menus and submenus

Calling up functions on the service menu

On-board computer:

→ Service

Select and confirm the required function.

The following functions are available on the service menu:


- Announcements: message memory $(\rightarrow page 355)$
- DEF: display the DEF fill level (→ page 137)
- Tires:
 - Check the tire pressure with the tire pressure monitor (\rightarrow page 316)
 - Restart the tire pressure monitor $(\rightarrow page 316)$
- ASSYST PLUS: call up the service due date $(\rightarrow page 278)$
- Engine Oil Level: measure the engine oil level

Calling up the Assistance graphic display

On-board computer:

→ Assistance

Select the desired display and confirm.



Instrument Display with color display

The following displays are available on the assistant display:

- Assistant display
- Attention level (→ page 162)
- Switch between the displays and confirm the selected display.

The following status displays are available on the assistant display:

- ATTENTION ASSIST switched off
- Specified minimum distance of Active Distance Assist DISTRONIC (\rightarrow page 152)




Instrument Display with black and white display

The following status displays are available on the assistant display:

- Lane markings dotted: Lane Keeping Assist switched off
- Lane markings solid and thin: Lane Keeping Assist switched on, not ready to issue warnings
- Lane markings solid and thick: Lane Keeping Assist ready to issue warnings
- ATTENTION ASSIST switched off
- Changing Blind Spot Assist status dis-

Status displays for Blind Spot Assist



- On and ready to issue warnings
- On and not ready to issue warnings
- Off

Calling up displays on the trip menu

On-board computer:

¬→ Trip

Select the desired display and confirm.

The following displays are available on the trip menu:

- Standard display
- Range and current fuel consumption With certain engines a recuperation display is also shown. If only a small amount of fuel is left in the fuel tank, a vehicle being refueled appears instead of the approximate range.
- ECO display (→ page 119)
- Trip computer:
 - From Start
 - From Reset
- Digital speedometer



Instrument Display with color display Standard display (example)

- Trip distance
- Total distance



Instrument Display with black and white display Standard display (example)

- Trip distance
- Total distance



Instrument Display with color display Trip computer (example)

- Distance covered (from start / from reset)
- ② Driving time (from start/from reset)
- Average speed (from start/from reset)
- Average fuel consumption (from start/from reset)



Instrument Display with black and white display Trip computer (example)

- Distance covered (from start/from reset)
- ② Driving time (from start/from reset)
- 3 Average speed (from start/from reset)
- 4 Average fuel consumption (from start/from reset)

Resetting values on the on-board computer trip menu

On-board computer:

- ¬→ Trip
- (i) The spelling of the displayed main menu may differ. Therefore, pay attention to the menu overview for the instrument display $(\rightarrow page 176)$.

You can reset the values of the following functions:

- Trip Odometer:
 - Reset Trip Odometer?
- Trip computer:
 - From Start
 - From Reset
- ECO display
- Select the function that is to be reset and confirm this selection.
- Confirm the Reset Values? prompt with Yes.

Calling up navigation instructions on the onboard computer


On-board computer:

¬→ Navigation



No change of direction announced (example)

- Distance to the next destination
- Estimated arrival time
- 3 Distance to the next change of direction
- Name of current road



Change of direction announced (example)

- Street into which the change of direction leads
- Destination route of the change of direction
- ② Distance to the change of direction
- Change of direction symbol
- Recommended lane and the new lane that appears during the change of direction (white)
- 6 Possible lane
- Unrecommended lane (dark gray)

Further possible displays are available on the Navigation menu:

- Direction of Travel: The direction of travel and the road currently being traveled are displayed.
- New Route... or Calculating Route...: A new route is being calculated.
- Road Not Mapped: The road is not known, e.g. it has only recently been constructed.

- No Route: The route to the selected destination cannot be calculated.
- Off Map: The map for the current position is not available.
- Area of Destination Reached: You have reached the target area.
- 🏻 : You have reached the destination or an intermediate destination.
- Exit the menu or select and confirm a destination.
 - If a destination is entered and confirmed, route guidance starts.
- If route guidance was previously active, a query appears whether the current route guidance is to be terminated.
- Confirm the prompt.
 Route guidance is started.

Selecting a radio station

On-board computer:

¬→ Trip



- Frequency range
- Station
- Name of the track
- Artist's name

The following displays are available:

- Frequency range
- Station list
- Select the radio station's frequency or a radio station from the station list.
- Confirm the selection.

When you select a station in the station memory, the storage location appears beside the station name. When you select a saved station in the frequency range, a star appears beside the station name.

Operating media playback with the on-board computer

On-board computer:

T→ Media



- Media source
- Current track and track number
- Artist's name
- Name of the album

The following displays are available on the media menu:

- Media source selection list
- Current playback
- Select and confirm the media source.
- Select and confirm the required playback.
- (i) This is how to select a station when TV is the media source.

Dialing a telephone number using the onboard computer

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

When using the phone, you must observe the legal requirements for the country in which you are currently driving.

Requirements:

 The mobile phone is connected to the multimedia system.

On-board computer:

→ Phone

Select one of the following options:

- Previous calls
- Phone book
- Call status

Vehicles with MBUX multimedia system: the most recent telephone calls (dialed numbers, accepted and missed calls) are displayed on the Phone menu.

- Select and confirm a telephone number. If only one telephone number has been saved for the entry: the telephone number is dialed.
- If several telephone numbers have been saved for the entry: select and confirm a telephone number. The telephone number is dialed.

Instead of the selected telephone numbers, the following displays may appear:

- Please Wait: The application is currently starting. If no Bluetooth® connection to the mobile phone is established, the menu for authorizing and connecting a mobile phone will be displayed in the multimedia system $(\rightarrow page 243)$.
- · Updating Data...: The call list is being upda-
- Importing Contacts: The mobile phone's contacts, or a memory medium's contacts are being imported.

Accepting/rejecting a call

When you are called, the Incoming Call message appears on the display.

Press ot to accept the call or to reject it.

You can also accept or reject the call using the or buttons on the steering wheel.

Calling up settings on the on-board computer

On-board computer:

¬→ Settings

The following entries can be set on the Settings menu:

- Light
 - Setting Instrument lighting
- Vehicle
 - Switching Regensensor (Rain sensor) on and off
- Setting Heating
- Display and Operation
 - Switching permanent Display DEV Level on and off
- Select an entry and confirm the selection.
- Make the necessary changes.

Notes on operating safety

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.
- ▲ WARNING Risk of an accident from operating mobile communication equipment while the vehicle is in motion

Mobile communications devices distract the driver from the traffic situation. This could also cause the driver to lose control of the vehicle.

- As the driver, only operate mobile communications devices when the vehicle is stationary.
- As a vehicle occupant, only use mobile communications devices in the areas intended for this purpose, e.g. in the rear passenger compartment.


For your own safety, always observe the following points when operating mobile communications equipment and especially your voice control system:

- · Observe the legal requirements for the country in which you are driving.
- · While driving, only operate mobile communications equipment and your voice control system when the traffic conditions permit it. You may otherwise be distracted from the traffic conditions and cause an accident, injuring vourself and others.
- If you use the voice control system in an emergency your voice can change and your telephone call, e.g. an emergency call, can thereby be unnecessarily delayed.
- · Familiarize yourself with the voice control system functions before starting the journey.

Operation

Multifunction steering wheel operation overview

The Voice Control System is operational approximately thirty seconds after the ignition is switched on.



- 1 Press the rocker switch up: [] starts the
- 2 Press the control knob: 🗖 switches the sound off or on (ends the dialog) Turn the control knob up/down: increases/ decreases the volume
- Oress the rocker switch down: rejects/ ends a call (ends the dialog)

Conducting a dialog with the Voice Control System

For the dialog with the Voice Control System, you can use complete sentences of colloquial language as voice commands, such as, for example, "Please show me the list of the last calls" or "How warm is it outside?". It is also not necessary to first change to the relevant application such as "Telephone" or "Vehicle function".

To activate or continue dialog by using a **keyword:** say "Hello Mercedes" to activate the Voice Control System. Voice activation must be switched on in the multimedia system (→ page 185). For this, it is not necessary to press up the well rocker switch on the multifunction steering wheel. Voice activation can also be directly combined with a voice command, e.g. "Hello Mercedes, how fast can I drive?".

- Press the rocker switch up on the multifunction steering wheel.
 - You can say a voice command after an acous-
- To correct an entry: say the "Correction" voice command.
- To select an entry from the selection list: say the line number or the contents.
- To browse the selection list: say the "Next" or "Back" voice command.
- To interrupt the dialog: say the "Pause" voice command.

The dialog can be continued with the "Hello" Mercedes" voice command or by pressing up the rocker switch on the multifunction steering wheel.

- To jump to the preceding dialog: say the "Back" voice command.
- To jump back to the top dialog level: say the "Home" voice command.
- To cancel the dialog: say the "Close" voice command or press the 🐧 or 🥿 button on the multifunction steering wheel.
- To interrupt a voice output: speak in the middle of a voice dialog when the system is still answering.

The voice output is shortened and the conclusion is reached more quickly.

The corresponding option must be switched on in the multimedia system.

Operable functions

You can use the Voice Control System to operate the following functions depending on the equipment:

- Telephone
- · Text messages
- Navigation
- Address book
- Radio
- Media
- Vehicle functions
- Weather

Full functionality is only available with online voice control active (\rightarrow page 185).

Overview of types of voice commands

A distinction is made between the following voice commands:

- Global voice commands can be said at any time and regardless of the current application, e.g. the voice commands "Navigate to", "Call" or "Text message to".
- · Application-specific voice commands are only available for the active application.

On the display next to the active application. examples of global voice commands and the corresponding application-specific voice commands are displayed on a teleprompter. The lists can be scrolled or operated by voice.

Number entry functions

- The numbers allowed are zero to nine.
- Telephone numbers can be entered as single digits.

Notes on the language setting

You can change the language of the Voice Control System via the system language settings. If the set system language is not supported by the Voice Control System, English will be selected.

The Voice Control System is available in English. French, Portuguese and Spanish.

Setting the Voice Control System (multimedia system)

Requirements

For online voice control:

- Your vehicle is connected with your Mercedes PRO user account (\rightarrow page 195).
- There is an Internet connection. $(\rightarrow page 254)$.

For activation of contacts for online use:

· Online voice control is activated.

Multimedia system:

Switching voice activation for the Voice Control System on/off

Select Voice Activation "Hey Mercedes". The function is activated or deactivated depending on the previous status. When the function is active, the "Hi Mercedes" voice command can activate the dialog.

Activating voice interruption

Select Speak During Voice Output. When the function is active, you can speak a command during voice output from the system.

Switching online voice control on/off

- Activate Online Voice Control.
- (i) Online voice control is activated at the factory.
- Select Online Voice Control Subscr.. You will be forwarded to the Mercedes PRO portal.
- Activate online voice control in the Mercedes PRO portal.

Activating contacts for online use

Select Contacts for Online Use. When active the function allows contacts to be found more easily using voice input. Also, the quality of the pronunciation of contact names through the system is enhanced.

Using the Voice Control System effectively Help functions

You receive information and help for:

- For optimal operation: say the "Voice control tutorial" voice command or call up the Digital Operator's Manual with "I want to read the Operator's Manual for the Voice Control System", for example. The full extent of the Digital Operator's Manual is available when the vehicle is stationary.
- Current application: on the multifunction steering wheel, press the rocker switch

- up and say the "Help" voice command. You will receive suggestions and information about operation of the Voice Control System for the current application.
- Continued dialog: say the "Help" voice command during a voice dialog. You receive aligned information for each step of the dialog.
- Specific function: say the voice command for the desired function, e.g. with "Hi Mercedes, I would like to have help with my radio" or, after pressing the http://ocker switch on the multifunction steering wheel up, say the "Help for phone" voice command, for example.

Notes on how to improve speech quality

If the Voice Control System does not understand vou:

- Activate online services. Recognition is improved.
- Only operate the Voice Control System from the driver's seat.
- Say the voice commands coherently and clearly, but do not exaggerate the words.
- Avoid loud noises that cause interference while making a voice command entry, e.g. the entertainment in the rear-passenger compartment
- Say the voice tag with the same intonation when creating voice tags.
- · For telephone or address book entries:
 - Only create sensible address book entries in the system/mobile phone, e.g. enter surname and first name in the correct field.
 - Do not use any abbreviations, unnecessary spaces or special characters.
- For radio station names: say the "Read out station list" voice command and say the desired station name in the way the voice output reads aloud to you.

Information on the online services

The online services enable improved recognition and provide better and additional results based on the external information, e.g. about weather or news. For this reason, we recommend you activate the online services.

To do this, you need a user account in the Mercedes PRO portal. If you do not yet have a user account, this must be created.

For more information consult an authorized Mercedes-Benz Center or visit the Mercedes PRO portal: http://www.mercedes.pro

Basic voice commands

Notes on the voice commands

Aside from the exact voice commands (see the "Voice command" column in the following tables) to call up specific functions, in most cases the Voice Control System also understands a great many paraphrases from daily usage. Examples of these are listed in the "Colloquial examples" column. For some languages however these examples are only available to a limited extent.

Overview of switch voice commands

Switch voice commands can be used to open certain applications.

Switch voice commands

Voice command	Colloquial example	Function
Switch to navigation	I would like to go to navigation	Switches to navigation
Switch to address book	I would like to switch to the address book	Switches to the address book
Switch to telephone	I would like to switch to the phone	Switches to the telephone
Switch to messages	Can you switch to messages please?	Switches to the messages application
Switch to radio	I would like to switch to the radio	Switches to radio
Switch to media	I would like to switch to the media applica- tion	Switches to media
Switch to comfort	I would like to go to the comfort application	Switches to the comfort settings
Switch to vehicle info	I would like to go to the vehicle application	Switches to vehicle information
Switch to settings	I would like to go to the settings menu	Switches to the menu with the setting options

Overview of navigation voice commands

Using navigation voice commands, you can enter POIs or conventional addresses as well as directly change important navigation settings.

The following list offers just a small selection of the possible navigation commands. You will receive additional suggestions if you say "Help for navigation".

Navigation voice commands

Voice command	Colloquial example	Function
Navigate to <address></address>	Navigate to address "Baltimore, 34 Anne Street"	Starts navigation to an address in the address book directly
Navigate to <name></name>	Drive/bring me to the private address of John Doe	Destination entry to a contact in the address book
Home	To my home address	Starts navigation to home address
Navigate to <3 word address>	Drive to Takeover Dot Desk Dot Stumps	Starts navigation to a 3 word address, e.g. to the Mercedes-Benz Museum
Work	To my office/busi- ness/my job	Starts navigation to your workspace
Navigate to <poi></poi>	Navigate me to McDo- nald's	Starts navigation to a POI directly
Enter POI	I would like to enter a new POI	Destination entry for a POI, e.g. the POI Brandenburg Gate.
I would like to navigate to <poi></poi>	Find/search in the Internet/web for a <poi></poi>	Conducts a POI search on the Internet only
Enter address in <country></country>	I would like to enter a new address in "Can- ada"	Enters a destination in the desired country
Enter country	Enter a new country	Enters a country
Enter city	I would like to enter a specific address	Enters a city
Search for district	I would like to search for a specific district	Enters a district
Enter intersection	I would like to enter a junction.	Navigates to an intersection
Enter the house number	I would like to enter house number "7"	Enters the house number
Enter ZIP code	Start route guidance to a new ZIP code	Enters a ZIP code
Last destinations	Display the previous destinations	Selects a destination from the list of last entered destinations
Show alternative routes	I would like you to dis- play an alternative route	Switches route guidance to another route
Start route guidance	I would like to start route guidance	Starts route guidance after entering a valid destination

Voice command	Colloquial example	Function
Cancel route guidance	Can you quit route guidance?	Cancels route guidance
Driving recommenda- tions on	Switch on driving rec- ommendations	Switches on voice output for route guidance
Driving recommenda- tions off	Mute the driving instructions	Switches off the voice output for route guidance
Show traffic map	I would like to switch on the traffic informa- tion	Switches on the traffic map
Hide traffic map	Switch off the traffic jam messages	Switches off the traffic map
POI symbols on	Show the symbols on the map	Switches on display of POI symbols on the map
Hide POI icons	I would like to hide all POI symbols	Switches off the POI symbols display on the map

Overview of telephone voice commands

You can use the telephone voice commands to make phone calls or search through the address book. The following list offers just a small selection of the possible telephone commands. You will receive additional suggestions if you say "Help for phone".

Telephone voice commands

Voice command	Colloquial example	Function
Call <telephone number=""></telephone>	I would like you to dial <telephone number=""></telephone>	Makes a telephone call by entering the telephone number directly
Call <contact></contact>	I would like you to call "Doe, John on the O2 number	Makes a telephone call directly by entering a name from the address book
Call name	I would like to call a name	Makes a phone call. All address book names are available.
Search for contact	I would like you to search for a contact	Searches for a contact. All address book names are available.
Latest calls	I would like to see the latest calls	Displays all outgoing, incoming and missed telephone calls.
Missed calls	I would like you to show me a list of missed calls	The list of missed calls is shown
Incoming calls	I would like to see a list of incoming calls, please	The list of incoming calls is shown

Voice command	Colloquial example	Function
Outgoing calls	I would like you to show me a list of all outgoing calls	The list of outgoing calls is shown
Redial number	I'd like to redial	Selects the last phone number dialed
Change phone	Could you please switch to the second phone?	Changes the primary telephones
Call MB emergency	Could you call the Mercedes-Benz emer- gency center?	An emergency call is initiated
Call Mercedes PRO	Call Mercedes-Benz breakdown assistance	Mercedes PRO is called

Overview of the radio voice commands

Radio voice commands can also be used when the radio application runs in the background and another application is visible in the foreground.

The following list offers just a small selection of the possible radio voice commands. You will receive additional suggestions if you say "Help for radio".

Radio voice commands

Voice command	Colloquial example	Function
Station <station name=""></station>	I would like to select station "Cool FM".	To select the station/channel mentioned
Radio station <station name=""></station>	I would like to select station "Cool FM"	To select the radio station mentioned
Frequency <frequency></frequency>	I would like to listen to the radio station "One hundred and seventy ".	To enter a radio frequency, e.g. for the FM area
Next station	I would like you to search for the follow- ing station	To switch to the next station that can be received
Next radio station	I would like you to search for the next station	The next radio station in a list is called up
Previous station	I would like to go back to the previous station	To switch to the previous station
Save station	Store station	To save the current station in the favorites list
Save radio station	Save the radio station, please	To save a station name for a radio station
Show station list	Show me a list of all stations	To show the list of stations that can be received

Voice command	Colloquial example	Function
Read out station list	I would like to listen to the station list, please	To listen to the names of all receivable stations
Read out radio station list	Please read out the radio program	To have the list of available stations for the currently selected radio application read aloud
Traffic announce- ments on	I would like to switch on the traffic announcement	To switch on traffic announcements
Traffic announcements off	I would like to switch off the traffic announcement	To switch off traffic announcements
Radio info on	I want you to turn on additional radio sta- tion text	To switch on information about the current station
Radio info off	I want you to turn off additional radio sta- tion text	To switch off information about the current station

Overview of media player voice commands

Media player voice commands can also be used when the media player application runs in the background and another application is visible in the foreground. The following list offers just a

small selection of the possible media player voice commands. You will receive additional suggestions if you say "Help for media" or "Help for player".

Media player voice commands

Voice command	Colloquial example	Function
Play <track <br="" albums=""/> artists/composers/ music genres>	Play "Hey Jude"	The names of all available tracks, albums, artists, composers or genres are accepted during the search. In the case of a clear search result the track found is played back immediately.
Play track <track/>	Play song "So What"	The available tracks are played back.
Play album <album></album>	Play album "A Night at the Opera"	The available albums are played back.
Play artist <artist></artist>	I want to listen to the artist "Madonna"	The available artists are played back.
Play composer <composer></composer>	I'd like to hear the composer "Ludwig van Beethoven"	The available composers are played back.
Play music genre <music genre=""></music>	I'd like to hear the music genre "Rock"	The available music genres are played back.

Overview of message voice commands

Text messages can be created, edited and listened to using the message voice commands. The following list offers just a small selection of the possible message commands. You will receive additional suggestions if you say "Help for messaging".

Message voice commands

Voice command	Colloquial example	Function
Text message to <name></name>	I would like to write a new text to "John Doe's mobile number"	To create a text message. All address book names are available.
Text message to <name><text></text></name>	I would like you to write a new text to "list entry John Doe"	To write a text message to the person called up. The content of the text can be spoken immediately if online voice control has been activated.
Forward text message	Forward text message to "John Doe"	To forward selected or open text messages.
Read out new text messages	I would like you to read out the new text messages	To read out new text messages.
Read out the last text message from <name></name>	I would like you to read out the last text message from "John Doe"	The last text message from the person mentioned is read.
Reply	I would like to answer this text message	To reply to a message
Reply in <language></language>	Respond to the SMS in German	A reply is made to the message just read in another language.

Overview of vehicle voice commands

You can use the vehicle voice commands to directly call up the corresponding menus for the vehicle settings. The following list offers just a

small selection of the possible vehicle voice commands. You will receive additional suggestions if you say "Help for vehicle settings" or "Help for vehicle functions".

Vehicle voice commands

Voice command	Colloquial example	Function
Current speed limit	Tell me the maximum permitted speed	To call up the current speed limit
Outside temperature	How cold is it outside?/How warm is it?	To call up the outside temperature
Average consumption	Read out the average fuel consumption	To call up average consumption
Vehicle data	Can you please display the vehicle data menu?	To call up vehicle data

Voice command	Colloquial example	Function
Engine data	Can I switch to the motor menu?	To call up engine data
Next service	Tell me my next service appointment	To call up the next service due date
Range	Tell me the current range	To call up range data
Consumption	Open the consumption menu	To call up consumption settings
Display and styles menu	Go to display and styles menu settings	To show display settings
Assistance menu	Show me the driver assistance settings	To display assistance settings
Light menu	Switch to the light set- tings	To display light settings

Information about Mercedes PRO (Mercedes me)

Mercedes-Benz Vans vehicles support the following telematics solutions depending on what is selected:

- Mercedes PRO
- Mercedes me

When you log in with a user account to the Mercedes PRO portal or Mercedes me Portal, then services and offers from Mercedes-Benz Vans will be available to you.

Availability is country-dependent. You can check the availability of Mercedes PRO in your country at the following page: http://www.mercedes.pro You can check the availability of Mercedes me in your country at the following page: http:// www.mercedes.me

For more information on Mercedes PRO or Mercedes me contact an authorized Mercedes-Benz Center or visit the Mercedes PRO Portal or Mercedes me Portal.

Information about Mercedes PRO connect (Mercedes me connect)

Amongst others, Mercedes PRO connect or Mercedes me connect provide the following services:

· Accident and breakdown management (breakdown assistance call button or automatic accident or breakdown detection) as a supplement to the emergency call system Use the breakdown assistance call button in the overhead control panel to make a call to the Mercedes-Benz Customer Center $(\rightarrow page 196)$.

You can also select a menu entry in the multimedia system (\rightarrow page 195).

· Emergency Call System

Use the Sos button (SOS button) in the overhead control panel to make a call to the Mercedes-Benz emergency call center $(\rightarrow page 196)$.

The Mercedes-Benz Customer Center and the Mercedes-Benz emergency call center are available for you around the clock for the use of the services.

Please note that Mercedes PRO connect, or Mercedes me connect, is a Mercedes-Benz

service. In emergencies, always call the national emergency services first using the standard national emergency service phone numbers. In emergencies, you can also use the Emergency Call System (\rightarrow page 292). Observe the legal requirements for the country in which you are staying.

The following conditions must be met to use Mercedes PRO connect or Mercedes me connect services in the vehicle:

- You have access to a GSM network
- The contract partner's GSM network coverage is available in the respective region
- The ignition is switched on, so that vehicle data can be transferred automatically

Calling the Mercedes-Benz Customer Center using the multimedia system

Multimedia system:

→ 🚡 >> Phone >> 👪


Call Mercedes PRO connect or Mercedes me connect

Then, you can select a service and be connected to a specialist at the Mercedes-Benz Customer Center.

You can find information on the following topics:

- Activation of Mercedes PRO connect or Mercedes me connect
- Operating the vehicle
- Nearest authorized Mercedes-Benz Center
- Other products and services from Mercedes-Benz

Making a call via the overhead control panel



- Breakdown assistance call button
- Release catch for the cover on the \(\sigma^{SOS}\) button (SOS button)
- (SOS button)
- To make a breakdown assistance call: press button (i).
- To make an emergency call: press the release catch for the cover on & button briefly to open.
- Press and hold button for at least one second.

An emergency call can still be triggered when a breakdown assistance call is active. This has priority over all other active calls.

Information on the breakdown assistance call via the overhead control panel

A call to the Mercedes-Benz Customer Center using the breakdown assistance button has been initiated via the overhead control panel:

In the event of a breakdown, you will get support:

 A qualified technician carries out repairs on site and/or the vehicle will be towed to the nearest authorized Mercedes-Benz Center
 These services may require payment.

Data is transmitted during the connection to the Mercedes-Benz Customer Center (\rightarrow page 196).

Giving permission for data transfer

Requirements:

 There is an active breakdown assistance call (→ page 196).

The Do you consent to the transfer of your vehicle data and the vehicle's position to the Mercedes-Benz Customer Center in order to improve the processing of your request? message appears.

Select Yes. Relevant identification data is transmitted automatically.

Transferred data during a service call

In certain countries you must confirm the data transfer.

The data transferred when calling depends on the services activated and the type of call made.

- General information about the vehicle
- · Concierge Service
- Accident and breakdown assistance
- · Service appointment arrangement

The following data is transmitted if the data protection query has been confirmed in the multimedia system or in the instrument cluster:

- Vehicle identification number
- Reason for the initiation of the call
- Language set in the multimedia system
- Confirmation of the data protection prompt

If a call is made for a service appointment via the service reminder, the following data may be transmitted:

Current mileage and maintenance data
 Transfer is possible assuming the required data transfer technology is supported by the

mobile service operator and the quality of the mobile connection is sufficient.

If accident and breakdown assistance is called via the voice control system, and the data protection query has been confirmed, the following data can also be called up from the vehicle by the Mercedes-Benz Customer Center:

· Current vehicle location

The following data is transmitted if the data protection query has been declined in the multimedia system or in the instrument cluster:

- Reason for the initiation of the call
- · Rejection of the data protection prompt

Overview and operation


Overview of the MBUX multimedia system

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paving attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system. MBUX stands for Mercedes-Benz User Experience.



- Touch Control and multimedia system control panel
- Media display with touch functionality Opens/closes the center console stowage compartment above the display (→ page 78)
- Operating strip, calls up applications

In the center console stowage compartment you can find the following ports and interfaces:

 Two USB ports or one USB port The USB port with the symbol facilitates the connection of the mobile phone with the multimedia system using a suitable cable.

This will enable you to use the functions of the mobile phone via Apple CarPlay™ or Android Auto

Stowage space with charging interface and NFC interface (if available)

You can operate the multimedia system with the following central control elements:

- Touch Control ① Operation takes place by cursor control.
- Media display (touchscreen) (2)
- Buttons on operating strip (3)
- (i) Alternatively you can conduct a dialog with the Voice Control System (\rightarrow page 184).

Multiple applications are available for you. You can call these up using the home screen or using the buttons on operating strip 3.

You can conveniently call up and add favorites on the steering wheel using the 🔯 rocker switch. Quick-access in the home screen and in the applications serve to select functions more quickly.

If you use the learn function of the multimedia system, you will receive suggestions during operation of the most probable navigation destinations, radio stations and contacts. The configuration of the suggestions takes place in your profile. You can compile your profile from various vehicle settings and settings of the multimedia system.

The Notifications Center collects incoming notifications, e.g. about an available software update. Depending on the type of notification it offers various actions. You can call up the Notifications Center on the home screen and in the menus of the applications.

With the global search in the vehicle you can search on-board across many categories as well as online in the Internet. You can use the global search in the home screen and in the notifications.

Anti-theft protection

This device is equipped with technical provisions to protect it against theft. Further information on protection against theft can be obtained from an authorized Mercedes-Benz Center.


Notes on the media display

Observe the notes on caring for the interior $(\rightarrow page 290)$.

Automatic temperature-controlled switch-off feature: if the temperature is too high, the brightness is initially reduced automatically. The media display may then switch off completely for a while.

(i) If you are wearing polarized sunglasses, it may be difficult to read the media display.


Home screen overview



- On the home screen: displays the first three applications
 - In other displays: calls up the home screen
- Calls up the profile
- Calls up the global search
- SOS NOT READY display only when the emergency call system (eCall) is not available
- Oisplays, for example network display, battery status of the mobile phone connected, signal strength of the mobile phone network, time
- Calls up the Notifications Center The star indicates new notifications.
- O Calls up an application using the symbol
- Name of the application, beneath the current selection or information
- Quick-access (in the example: calls up destination entry and enters the destination address for home)
- Number of applications and currently selected display area
- Calls up SUGGESTIONS and FAVORITES

Touch Control

Operating Touch Control (multimedia system)



- 1 hutton Calls up the home screen
- 2 Touch Control
- Back button Returns to the previous display
- Control panel for multimedia system

Press the ☆ rocker switch down: shows favorites

Turn the control knob: sets the volume
Press the control knob: switches sound off
Press the rocker switch up: makes or
accepts a call

Press the rocker switch down: ends or declines a call

To call up the home screen: press button

o
.

or

- Press and hold button 3.
- To open a menu or list: press Touch Control

 2.
- To close a menu or list: press button 3.
- ► To select a menu item: swipe up, down, left or right on Touch Control ②.
- Press Touch Control 2.
- To move the digital map: swipe in any direction.

Setting the sensitivity for the Touch Control Multimedia system:

- → Settings → System
- **▶** Controls **▶** Touch Control Sensitivity
- Select Fast, Medium or Slow.

Switching acoustic operating feedback for the Touch Control on/off

Multimedia system:

→ Settings → System → Controls

The function is supported by the selection in a list.

Select Acoustic Operating Feedback.

will hear another clicking sound.

Set Normal, Loud or Off. If the function is activated you will hear a clicking sound when scrolling in a list. When the beginning or end of the list is reached you

Touchscreen

Operating the touchscreen

Tapping

To select a menu item or entry: tap on a symbol or an entry.

- To increase the map scale: tap twice quickly with one finger.
- To reduce the map scale: tap with two fingers.
- To enter characters with the keyboard: tap on a button.

Single-finger swipe

- To navigate in menus: swipe up, down, left or right.
- To move the digital map: swipe in any direction.
- To use handwriting to enter characters: write the character with one finger on the touchscreen.

Two-finger swipe

- To zoom in and out of the map: move two fingers together or apart.
- To enlarge or reduce the size of a section of a website: move two fingers together or apart.
- To turn the map: turn counter-clockwise or clockwise using two fingers.

Touching, holding and moving

- To move the map: touch the touchscreen and move your finger in any direction.
- ➤ To set the volume on a scale: touch the touchscreen and move the finger to the left or right.

Touching and holding

- ➤ To save the destination in the map: touch the touchscreen and hold until a message is shown.
- To call up a global menu in the applications: touch the touchscreen and hold until the OPTIONS menu appears.

Setting acoustic operation feedback for the touchscreen

Multimedia system:

→ ি Settings → System

➤ Controls ➤ Touch Control Sensitivity

The function is supported by the selection in a list.


- Select Acoustic Operating Feedback.
- Set Normal, Loud or Off.
 If the function is activated you will hear a clicking sound when scrolling in a list. When

the beginning or end of the list is reached you will hear another clicking sound.

Applications

Calling up applications

Using buttons on the operating strip



- TEL button Calls up the telephone
- Volume rocker switch Adjusts the volume(\rightarrow page 202)
- ③ / fin button Press briefly: returns to the previous display Press and hold: calls up the home screen
- 4 人 button Press briefly: switches sound off Press and hold: activates / deactivates the multimedia system
- Quick-access button for media Calls up the control menu of the last active media source
- Vehicle button Sets vehicle functions
- RADIO MEDIA button Pressing repeatedly calls up the desired audio source
- NAVI button Calls up navigation
- To access stations and music tracks quickly: press button (5). The control menu appears for the audio source that was last selected.
- Swipe to the left or right. Radio: the previous or next station is set. Media source: the previous or the next music track is selected.
- To hide the control menu: press button **5**.

Using the home screen

The home screen is shown in the media display when you start the vehicle.

Select the application by swiping and tapping.

or

In any display: press the hatton on the Touch Control.

or

- Tap on the symbol on the touchscreen. The applications are displayed.
- Select the application by swiping and tapping.

Changing the arrangement of applications on the home screen


- Call up the home screen
- Touch and hold an application on the touchscreen until symbols appear.
- Tap on

 or

 and move the application in the menu.
- Tap on 🕝 .

Switching the sound on/off

On the multifunction steering wheel



To mute: press volume control 1. The symbol appears in the status line of the multimedia system display.

You will also hear traffic announcements and navigation announcements even when the sound is muted.

To switch on: turn volume control (1) or change the media source.

On the multimedia system




- ➤ To switch off: briefly press button ①.

 The ဩ symbol appears in the status line of the multimedia system display.
 - You will also hear traffic announcements and navigation announcements even when the sound is muted.
- **To switch on:** briefly press button ① or change the media source.

Adjusting the volume

On the multifunction steering wheel



Turn volume control ①. The volume of the current radio or media source is set. The volume of other audio sources can be adjusted separately.


Adjust the volume in the following situations:

- · during a traffic announcement
- during a navigation announcement
 The volume of the current media sour

The volume of the current media source changes in accordance with the volume of the navigation announcement.

· during a telephone call

On the multimedia system



- To raise/reduce the volume in steps: briefly press rocker switch (1) up or down.
- ➤ To raise/reduce the volume continuously: press rocker switch (1) up or down until the desired volume is set.

Profile

Overview of profiles

Using the multimedia system up to seven profiles can be created in the vehicle.

Profiles store your personal vehicle settings and settings for the multimedia system.

If the vehicle is used by several drivers, the driver can select their profile before the journey, without changing the settings of other drivers.

You can select the profile:

- when entering (\rightarrow page 203)
- on the home screen (\rightarrow page 199)

The profile settings are activated as soon as a profile is selected.

Profile content

The following settings can be saved in your profile, for example:

- Radio (including station list)
- Last destinations
- · Favorites and suggestions

Creating a new profile

Multimedia system:

- → 🔝 » 👤 Profiles
- Select + Create Profile .
- Select an avatar.
- ► Enter the name and confirm with OK.
- ➤ Select Continue > .
- To save the current settings in a profile: select Current Settings.

Select Save.

or

- To adopt factory settings: select Save save directly.
- (i) Further information on setting a user profile $(\rightarrow page 203)$.
- Activate Bluetooth® and select Connect Phone, to connect a mobile phone with the user profile (\rightarrow page 243).

You can also set up a user profile without registering a mobile phone.

Select Finished

The user profile is saved.

Selecting profile options

Multimedia system:



- Select ••• for a profile.
- To edit a profile: select Edit Profile.
- Select an avatar.
- Change the name, if necessary.
- Select Save.
- To configure suggestions: select Suggestion Settings (\rightarrow page 204).
- To reset favorites: select Reset Favorite to Factory Settings.
- Select Yes.
- To reset a profile: select Reset Profile to Factory Settings.
- Select Yes.
- To delete a profile: select Delete Profile.
- Select Yes.
- (i) The guest profile cannot be deleted.

Selecting a profile

Multimedia system:



- Select a profile.
- Press the OK button to confirm the mes-

The profile is loaded and activated.

(i) Alternatively, the profile can already be selected when the vehicle is entered $(\rightarrow page 203)$.

Showing the profile selection when entering Requirements:

At least one profile has been created.

Multimedia system:

¬→ 🝙 » 👤 Profiles

- Select General Settings.
- Activate Show Profile Selection When Getting

When the vehicle is started, the media display shows the active profile.

Suggestions

Suggestions overview

The vehicle can learn the habits of the driver. Based on the habits that have been learned by the system, the most likely navigation destinations, music tracks, radio stations or contacts are offered under SUGGESTIONS.

Suggestions are shown when the following requirements are fulfilled:

- A profile has been created (→ page 202). No suggestions are available in the Guest pro-
- A profile has been selected.
- You have accepted data recording.
- From the beginning of usage, the multimedia system must analyze the user habits. When sufficient data is collected then the suggestions are available.

If the requirements mentioned are not fulfilled, a preview with a description of the function appears in the SUGGESTIONS menu.

You can configure the data recording (\rightarrow) page 204) or delete unsuitable suggestions $(\rightarrow$ page 204)in order to improve suggestions.

Calling up suggestions Requirements:

- An individual user profile has been created and is selected (\rightarrow page 203).
- (i) The guest profile is active when the multimedia system is first started.
- ► Tap on in the media display. The home screen is shown.
- Swipe up until the SUGGESTIONS menu is shown.
- Select a navigation destination, a music track, a radio station or a contact.

(i) If route guidance is already active, you can start a suggestion as a new route guidance or set an intermediate destination for the existing route.

Configuring suggestions

Multimedia system:

- → 🖟 >> 📘 Profiles
- Select for a profile.
- Select Suggestion Settings.
- ➤ To switch suggestions display on/off: switch Allow Destination Suggestions, Allow Music Suggestions and Allow Contact Suggestions on or off.

If an option is switched on, suggestions for navigation destinations, music tracks, radio stations or contacts are shown.

If the option is switched off, no suggestions are shown.

To deactivate the learn function for one day: activate 24h Learning Deact..

For 24 hours no new actions will be trained and no data recorded for the active profile. Suggestions will continue to be shown. The remaining time is shown next to 24h Learning Deact..

Before the time runs out, a message is shown that the multimedia system will continue the learn function shortly.

Example: if the option is switched on and a route to a new destination has been calculated, this destination would not be taken into account for the learn function.

- ➤ To reset the suggestion history: select Reset Suggestion History.
- i) This process cannot be reversed.
- Select Yes.

Renaming suggestions

Only navigation destinations can be renamed.

- Tap on the symbol in the media display.
 The home screen is shown.
- Swipe up until the SUGGESTIONS menu is shown.
- Highlight a navigation destination and press until the OPTIONS menu is shown.
- Select Rename.
- Enter the name.
- To confirm the entry: select Yes.

Deleting a suggestion

- Tap on in the media display.
 The home screen is shown.
- Swipe up until the SUGGESTIONS menu is shown.
- Highlight a suggestion and press until the OPTIONS menu is shown.
- Select Delete.

Deleting suggestions in the applications

You can delete suggestions in the previous destinations, in the radio station list and in the contacts.

- ▶ Select ▼ for a suggestion.
- Select No Longer Suggest.
- To delete the suggestion from the current list: select Not Now.

The suggestion will be shown again at a later time in the list.

- To delete a suggestion permanently: select Never.
- Select Yes.

The suggestion will not be shown again in future. All suggestions are reset.

To cancel the function: select Cancel.

Favorites

Overview of favorites

Favorites offer you quick access to frequently used applications. It is possible to create 20 favorites in total.

You can select favorites from categories or you add favorites directly from an application.

Calling up favorites

In the media display

Tap on .
The home screen is shown.

Swipe up until FAVORITES is shown.

Using the steering wheel

► Press the ☆ rocker switch on the steering wheel down.

Adding favorites

Selecting favorites from categories

- Tap on in the media display.
 The home screen is shown.
- Swipe up until FAVORITES is shown.

- Select + Create Favorite. The categories are displayed.
- Select the category. The favorites are displayed.
- Select a favorite. The favorite is stored at the next available position.
- All positions in the favorites are taken: confirm the message shown with OK. A list shows all the favorites.
- Select a favorite which should be overwritten.

Adding a favorite from an application

Examples of adding from an application are:

- · Saving a contact.
- · Storing a radio station.
- · Adding a media source.
- · Saving a navigation destination.
- To save a contact as a global favorite: select a contact (\rightarrow page 247). The details are displayed.
- Press on a phone number until the OPTIONS menu is shown.
- Select Save as Favorite. The contact is added as a favorite.
- To store a radio station as a global favorite: set a radio station (\rightarrow page 266).
- Press on the radio station until the OPTIONS menu is shown.
- Select Save as Favorite. The radio station is added as a favorite.

Renaming favorites

- ► Tap on in the media display. The home screen is shown.
- Swipe up until FAVORITES is shown.
- Press on a favorite until the OPTIONS menu is shown.
- Select Rename.
- Enter the name.
- Select OK.

Moving favorites

Moving favorites in the favorites menu

- ► Tap on in the media display. The home screen is shown.
- Swipe up until FAVORITES is shown.

- Press on a favorite until the OPTIONS menu is shown.
- Select Move.
- Move the favorite to the new position.
- Tap on 🕢 .

Moving the favorites menu in the personaliza-

- ► Tap on in the media display. The home screen is shown.
- Swipe up until Set New Order is shown.
- Select Set New Order.
- Move Favorites to the new position.
- Tap on 🕢 .
- To close the menu: select Close.

Deleting favorites

- Tap on 📦 in the media display. The home screen is shown.
- Swipe up until FAVORITES is shown.
- Press on a favorite until the OPTIONS menu is shown.
- Select Delete.
- Select Yes.

Notifications Center

Overview of the Notifications Center

The following communications are collected in the Notifications Center:

- Communications which are generated by the vehicle or from multimedia system.
- · Communications which are received through the use of services.

The following notification types are available for you, for example:

- Navigable destinations and routes
- Messages (text messages)
- · System information, e.g. software update available
- Other notifications, e.g. from additional online services that can be subscribed to

The Notifications Center can be found on the home screen, in menus and at the top right of the navigation map (\rightarrow page 199).

A star in the symbol informs you of new notifications.

Notifications are normally briefly shown as they are received. This occurs for nearly every application that you are currently using. If you take no action, these are stored for future access in the Notifications Center.

The notifications are sorted chronologically. The most recent notifications are at the top.



(i) This message type shown is not available in all countries.

A notification shows the following information, for example:

- Symbol or image (1) for the application
- Title ②, which contains the name, a telephone number or a navigation destination, for example
- The service and additional information (3)
- A time stamp (5)
- If several actions are available, symbol (4) to open or close the notification.

Depending on the type of notification, up to four different actions (a) are available.

Examples of actions include:

- · Read aloud
- Placing a call
- Replying
- · Calling up a web page
- Navigating

Some notifications, e.g. a navigation destination, are stored longer. Therefore, it is not necessary to carry out available actions directly on the receipt of the notifications. A route guidance can be started at a later time.

(i) You can start a global search in the Notifications Center (→ page 207).

Calling up notifications

Multimedia system:



Opening the Notifications Center

On the touchscreen: tap on the symbol for the Notifications Center.

or

- On the Touch Control: mark the symbol for the Notifications Center by swiping.
- Press on the control element.

Selecting a notification

- Swipe up or down.
- Tap or press on the control element.

Calling up old notifications

If notifications have not been called up after four hours, these are stored in the archive.

- Swipe upwards and select Archive.
- Select the notification.

Selecting actions for a notification

The following options are available:

- Select the action directly in an application after a notification is received and shown.
- Select the action later after calling up in the Notifications Center.
- An action is available: select the action.
- Several actions are available: if the notification is not open, select the symbol.
- Select the action.
 The notification is still available.

Editing notifications

Multimedia system:



- Call up the Notifications Center (→ page 206).
- ► To make settings: select 🔘 .
- (i) If no settings can be made, a message appears.
- Activate or deactivate the setting.
- ▶ To delete: select the recycle bin.
- Select Delete or Delete All.
 Delete deletes a single notification.

Delete All deletes all notifications currently shown.

▶ With Finished you will exit delete mode.

Global search

Global search overview

You can use the global search in the home screen and in the notifications.

The global search provides search results for the following categories and their sub-categories:

- Navigation
- Media
- · Telephone, social media
- User interface and Digital Operating Instructions
- Internet

This enables you to search for cities, roads and tourist attractions with the navigation system, for example.

(i) You can also search for three-word addresses $(\rightarrow page 221)$.

When you enter a 3 word address in the global search, separate each of the words with a space or a full stop.

During the entry process the most likely suggestions are shown beneath the search field. When you enter "S", "Stuttgart", "Steak" and "Sandra" are shown, for example. If you select "Stuttgart", you receive the suggestions "Starbucks", "Steak" and "City railway", for example.

The search results in the list are shown, sorted according to category. Next to the category is the number of results. You will be shown the best results from each category. Additional results can be found after selecting the respective category.

If you confirm an entry with OK, all categories and the number of results will be shown in a summary. After selecting a category you can select the search results within the category. When you select a search result the detailed view opens. In the detailed view you can choose whether and which actions you want to carry out with the respective search result. For example, you can start route guidance or place a call to somebody. The actions are named correspondingly.

The search can be carried out with the following input methods:

- Entering characters using the on-screen key-
- · Entering characters with handwriting recogni-
- Dictation function

Using the global search

Multimedia system:

→ 🔝

Select Search.

or

- Call up the notifications (\rightarrow page 206).
- Select Search.
- Enter the search term into the search field Use the character input function During the entry process the three most likely suggestions are offered beneath the search field.

In the list on the right, the top two search results are shown for each category.

- (i) Alternatively, you can use the J dictation function for the search.
- To accept a suggestion: select the sugges-

The three most likely suggestions are offered.

- Continue the search or accept a suggestion.
- To accept the second search result: select the search result. An action starts or a list is shown.
 - Select a search result or an action in the list.
- To show all categories: select OK.
- To show search results for a category: select a category.
- To show details: select a search result.
- To start an action: select an action. After selection of an action, a track is played back or the route to a destination is calculated, for example.

Entering characters

Using the character input function

▲ WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paving attention to road

and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Character entry can be carried out with these control elements:

- Touch Control
- Touchscreen (media display)

Character entry takes place by cursor control when using the Touch Control.

Character input can be started with a control element and resumed with another.

When the keyboard is shown, enter the characters on the control element by swiping and pressing or by tapping (touchscreen).

or

Write the character on the touchscreen.

Examples of character entry:

- · Renaming a favorite
- Entering a destination address in the navigation system
- · Entering a web address

Entering characters on the touchscreen Requirements:

An online connection is required for some functions.

Using the keyboard



- Input line
- Shows suggestions during entry (if available)
- Oeletes an entry
- Deletes

Pressing or pressing briefly deletes the last character entered Pressing and holding deletes the entry

- 6 Accepts an entry
- Switches to handwriting input
- Enters a space
- Changes the keyboard language
- Switches to special characters
- Switches to digits and additional special characters

ABC switches to letters (level 2)

Pressing or pressing briefly switches between upper-case and lower-case letters Pressing and holding switches to upper-case letters permanently


If available, the symbol allows you to change to voice input.

- Call up the character entry to rename a favorites, for example (→ page 205). The keyboard is shown.
- Press briefly on a character key. The character is entered in input line ①. Suggestions are shown in ②.
- To select a suggestion: select one of the entries.

- If available, display additional suggestions with \ or \.
- Resume character input.
- To enter an alternative character: press and hold a character.
- Select the character.

- To end character input: press the button.
- (i) The available editing functions depend on the editing task, the language set and the character level.

Using handwriting input



- Input line
- Shows suggestions during entry
- Oeletes an entry
- Operation in the property of the property o

Pressing or pressing briefly deletes the last character entered

Pressing and holding deletes the entry

- 6 Enters a space
- 6 Switches to input using the keyboard
- Accepts an entry
- Writes characters on the drawing surface If available, the symbol allows you to change to voice input.
- Call up the character entry to rename a favorites, for example (\rightarrow page 205).
- When the keyboard is displayed, select .
- Write the character with one finger on the touchscreen.

The character is entered in input line 1. Suggestions are shown in 2.

- To select a suggestion: select one of the entries.
- If available, display additional suggestions with \(\) or \(\).

- Resume character input. The letters can be written next to each other or above each other.
- To end character input: press the button.

Setting the keyboard for character entry

Multimedia system:

→ Settings → System → Controls

- > Keyboards and Handwriting
- Confirm Select keyboards. Select the keyboard language in the list.

System settings

Display

Configuring display settings

Multimedia system:

→ Settings → System

>> Designs & Display

Styles

Select Classic, Sport or Progressive.

Display brightness

- Select Display Brightness.
- Select a brightness value.

Switching the display off/on

- ▶ Off: select Display Off.
- On: press a button, TEL, for example.

Display design

- ▶ Select Day/Night Design.
- Select Automatic, Day Design or Night Design.

Time and date

Setting the time and date automatically Multimedia system:

- → System → Time and Date
- Deactivate Manual Time Adjustment. The time and date are set automatically for the selected time zone and summer time option.
- i The correct time is required for the following functions:
 - Route guidance with time-dependent traffic guidance.
 - Calculation of expected time of arrival.

Setting the time zone Requirements:

 For setting the time zone manually: the Automatic Time Zone function is activated.

Multimedia system:

Setting the time zone manually

➤ Select Time Zone:.

The list of countries is displayed.

- i If there are several time zones available in a country, these will be shown after the country is selected.
- Select a country and, if required, a time zone. The time zone set is displayed after Time Zone:.

Setting the time zone automatically

Activate Automatic Time Zone.

Setting the time and date format

Multimedia system:

→ ☐ → Settings → System

→ Time and Date → Set Format

Set the date and time format •.

Setting the time and date manually Requirements:

- The Manual Time Adjustment function is switched on.
- For setting the date manually: no GPS is installed in the vehicle.

Multimedia system:

→ Settings → System → Time and Date

Setting the time (without time zone)

- Select Set Time.
- Set a time.

Setting the time (with time zone)

Select Set Time.

If a time zone is set the time is set automatically using the time zone. The time can be adjusted by a maximum of plus or minus 60 minutes.

Adjust the time using the slide control.

Setting the date

- Select Set Date.
- Set a date.
- (i) In vehicles with GPS, a date cannot be set even with active manual time adjustments. The date is then set automatically through the selected time zone.

Bluetooth®

Information about Bluetooth®

Bluetooth® technology is a standard for short-range wireless data transfer up to approximately 32.8 ft (10 m).

You can use Bluetooth® to connect your mobile phone to the multimedia system and use the following functions, for example:

- Hands-free system with access to the following options:
 - Call lists (→ page 249)
- Internet connection (→ page 254)
- Transferring business cards (vCards) into the vehicle

Bluetooth[®] is a registered trademark of Bluetooth Special Interest Group (SIG) Inc.

i Internet connection via Bluetooth® is not available in all countries.

Activating/deactivating Bluetooth®

Multimedia system:

→ 🔝 >> Settings >> System

>> Wi-Fi & Bluetooth

- To switch on Bluetooth®: select Connect via Bluetooth.
- Activate Bluetooth.
- ➤ To switch off Bluetooth®: select Settings.
- Deactivate Bluetooth.

Wi-Fi

Wi-Fi connection overview

You can use Wi-Fi to establish a connection with a Wi-Fi network and to access the Internet or other network devices.

The following connection options are available:

- · Wi-Fi connection
 - The Wi-Fi connection is established to a Wi-Ficapable device, e.g. to the customer's mobile phone or tablet PC.
- Multimedia system as a Wi-Fi hotspot
 Using this function, a tablet PC or notebook
 can be connected, for example.

To establish a connection, you can use the following methods:

WPS PIN

The connection to a secure Wi-Fi network is made via a PIN.

WPS PBC

The connection to a secure Wi-Fi network is made by pressing a button (push button).

· Security key

The connection to a secure Wi-Fi network is made via a security key.

Setting up Wi-Fi Requirements:

 The device to be connected supports one of the three means of connection described.

Multimedia system:

→ Settings → System (System)

→ Wi-Fi & Bluetooth

Switching on Wi-Fi

Select Wi-Fi.

The Wi-Fi is switched on and you can connect the multimedia system with external hotspots.

Switching off Wi-Fi

- Select Settings.
- Deactivate Wi-Fi.

If Wi-Fi is deactivated, communication via Wi-Fi to all devices is interrupted. This also means that a connection to the communication module cannot be established. Then some functions such as dynamic route guidance with Live Traffic Information are not available.

Connecting the multimedia system with a new device via Wi-Fi

This function is available if a communication module is not installed.

The type of connection established must be selected on the multimedia system and on the device to be connected.

- (i) The connection procedure may differ depending on the device. Follow the instructions that are shown in the display. Further information (see the manufacturer's operating instructions).
- Select Internet Settings.
- Select Connect via Wi-Fi.
- Select Add Hotspot.

Connecting using a security key

- Select the options of the desired Wi-Fi network.
- Select Connect Using Security Key.
- Have the security key displayed on the device to be connected (see the manufacturer's operating instructions).

- Enter this security key on the multimedia system.
- Confirm the entry with ok.
- All devices support a security key as a means of connection.

Connecting using a WPS PIN

- Select the options of the desired Wi-Fi network.
- Select Connect via WPS PIN Input.
 The multimedia system generates an eightdigit PIN.
- Enter this PIN on the device to be connected.
- Confirm the entry.

Connecting using a button

- ➤ Select the options of the desired Wi-Fi
- ► Select Connect via WPS PBC.
- Select "Connect via WPS PBC" in the options on the device to be connected (see the manufacturer's operating instructions).
- Press the WPS button on the device to be connected.
- Select Continue in the multimedia system.

Activating automatic connection

- Select Connect via Wi-Fi.
- Select the options of the desired Wi-Fi network.
- Activate Permanent Internet Connection.

Connecting with a known Wi-Fi

- Select Connect via Wi-Fi.
- Select a Wi-Fi network.
 The connection is established again.

Setting up a Wi-Fi hotspot

Multimedia system:

→ Settings → System (System)

Wi-Fi & Bluetooth

Configuring the multimedia system as a Wi-Fi hotspot

The type of connection established depends on the device to be connected. The function must be supported by the multimedia system and by the device to be connected. The type of connection established must be selected on the multimedia system and on the device to be connected.

Select Vehicle Hotspot.

Select Connect Device to Vehicle Hotspot.

Connecting using WPS PIN generation

- ▶ Select Connect via WPS PIN Generation.
- Enter the PIN shown in the media display on the device to be connected and confirm.

Connecting using WPS PIN entry

- Select Connect via WPS PIN Input.
- Enter the PIN that is shown on the external device's display on the multimedia system.

Connecting using a button

- Select Connect via WPS PBC.
- Press the push button on the device to be connected (see the manufacturer's operating instructions).
- Select Continue.

Connecting using a security key

- Select Connect Device to Vehicle Hotspot. A security key is displayed.
- Select the vehicle from the device to be connected. It will be shown with the DIRECT-MB Hotspot 12345 network name.
- Enter the security key which is shown in the media display on the device to be connected.
- Confirm the entry.

Connecting using NFC

- Select Connect via NFC.
- Activate NFC on the mobile device (see the manufacturer's operating instructions).
- Bring the mobile device into the NFC area of the vehicle (→ page 245).
- Select Finished. The mobile device is now connected to the multimedia system hotspot via NFC.

Generating a new security key:

- Select Vehicle Hotspot.
- Select Generate Security Key.
 A connection will be established with the newly created security key.
- To save a security key: select Save. When a new security key is saved, all existing Wi-Fi connections are then disconnected. If the Wi-Fi connections are being re-established, the new security key must be entered.

System language

Notes on the system language

This function allows you to determine the language for the menu displays and the navigation messages. The selected language affects the characters available for entry. The navigation announcements are not available in all languages. If a language is not available, the navigation announcements will be in English.

Setting the system language

Multimedia system:

→ Settings → System

- Language
- Set the language.
- (i) If you are using Arabic map data, the text information can also be shown in Arabic on the navigation map. To do so, select العربية as the language from the language list. Navigation announcements are then also made in Arabic.

Setting the distance unit

Multimedia system:

→ System → Units

- Select km or mi.
- In the multifunction display of the Instrument Display, switch the Additional Speedometer display on.

Data import and data export

Data import/export function

The following functions are possible:

- · Transfer of data from one system or vehicle to another system or vehicle.
- Making a backup copy of your personal data and load it again.
- · Protecting your personal data against unwanted export with PIN protection.
- i Please note that the NTFS file system is not supported. The FAT32 file system is recommended.

Importing/exporting data

NOTE Loss of data due to premature removal

▶ Do not remove the data storage medium when data is being exported.

Mercedes-Benz is not liable for any loss of data.

Requirements:

- The vehicle is stationary.
- · The ignition is switched on.
- A USB device is connected (→ page 262).

Multimedia system:

→ System >> System Backup

Select Import Data or Export Data.

Importing

Select a data storage medium.

A prompt appears asking whether you really wish to overwrite the current data. If data originates from another vehicle, this is recognized during data reading.

The multimedia system is restarted once the data has been imported.

(i) Current vehicle settings can be edited after the import.

Exporting

If PIN protection is activated, your PIN is requested.

- Enter the four-digit PIN.
- Select a data storage medium. The data is exported. The data export may take several minutes.
- (i) After successful export, the data is saved in the "MyMercedesBackup" directory which can be found on the storage medium.

Activating/deactivating PIN protection

Multimedia system:

→ Settings → System >> PIN Protection

Setting the PIN

- Select Set PIN.
- Enter a four-digit PIN.
- Enter the four-digit PIN again. If both PINs match, PIN protection is active.

Changing the PIN

- Select Change Settings.
- Enter the current PIN.
- Select Change PIN.
- Set a new PIN.

Activating PIN protection for data export

- Select Change Settings.
- Confirm with the PIN.
- Select Protect Data Export.
- Activate or deactivate the function.

Unblocking the PIN

Consult an authorized Mercedes-Benz Center and have the PIN protection reset.

Software update

Information on software updates

A software update consists of three steps:

- Downloading or copying of the data required for installation
- Installation of the update
- Activation of the update by restarting the system

The multimedia system provides a message when an update is available.

Depending on the source, you can perform various updates:

Software update

Source of the update	Update type
Internet	Navigation map, system updates, Digital Operator's Manual
External storage medium, e.g. USB flash drive	Navigation maps

Advantages of updating software

Software updates ensure your vehicle's technology is always up-to-date.

In order to constantly improve the quality of our services you will receive future updates for your multimedia system, the Mercedes PRO connect services and your vehicle's communication module. These will conveniently be sent to you via the mobile phone connection in your vehicle and, in

many cases, installed automatically. You can monitor the status of your updates at any time via the Mercedes PRO portal and find information about potential innovations.

Your advantages at a glance:

- Conveniently receive software updates via the mobile phone network
- The long-term quality and availability of Mercedes PRO connect is guaranteed
- Keep your multimedia system and communication module up-to-date

Further information about software updates can be found at https://www.mercedes.pro

Performing a software update Requirements:

- For online updates: an Internet connection is established (→ page 254).
- For automatic online updates: your vehicle has a permanently installed communication module.

Multimedia system:

→ Settings → System → Software Update

Automatically

Activate Automatic Online Update. The updates will be downloaded and installed automatically.

The current status of the updates is displayed.

Manually

- ▶ Deactivate Automatic Online Update.
- Select an update from the list and start the update.

Activating the software update

Restart the system. The modifications from the software update will be active.

Important system updates

Important system updates may be necessary for the security of your multimedia system's data. Please install these updates, or else the security of your multimedia system cannot be ensured.

 If automatic software updates are activated, the system updates will be downloaded automatically (→ page 214). As soon as an update is available for download, a corresponding message appears on the media display.

You have the following selection options:

Download

The update will be downloaded in the background.

Details

Information about the pending system update is displayed.

Later

The update can be downloaded manually at a later time (\rightarrow page 214).

Deep system updates

Deep system updates access vehicle or system settings and can therefore only be carried out when the vehicle is stationary and the ignition is switched off.

If the download of a deep system update is completed and the update is ready for installation, you will be informed of this after the next ignition cycle, for example.

(i) Park the vehicle safely in a suitable location before starting the installation.

Requirements for the installation:

- · The ignition is switched off.
- · Notes and warnings have been read and accepted.
- · The parking brake is applied.

If all requirements are met, the update will be installed. The multimedia system cannot be operated while the update is being installed and vehicle functions are restricted.

If errors should occur during the installation, the multimedia system automatically attempts to restore the previous version. If restoration of the previous version is not possible, a symbol appears on the media display. Please consult a qualified specialist workshop to resolve the problem.

Resetting the multimedia system (reset function)

Multimedia system:

→ Settings → System → Reset

Personal data is deleted, for example:

- Station presets
- · Connected mobile phones
- Individual user profiles
- (i) The guest profile is reset when the settings are restored to the factory settings.

A guery appears again asking if the system should really be reset.

Select Yes.

If PIN protection is activated, a prompt appears asking if you also wish to restore this to the factory settings during a reset.

- Select Yes.
- Enter the current PIN. The PIN is reset.

or

Select No.

The current PIN stays the same after reset-

(i) If you have forgotten your PIN, an authorized Mercedes-Benz Center can deactivate the PIN protection for you.

A prompt appears again asking whether you really wish to reset.

Select Yes.

The multimedia system is reset to the factory settings.

Resetting using a button

Press both the TEL and buttons at the same time until the multimedia system restarts (at least 15 seconds). The multimedia system is restarted. No data is deleted during this process.

Vehicle information

Displaying vehicle data

Multimedia system:

¹→ 🚡 🕪 Info

Select Vehicle.

The vehicle data is displayed.

Multimedia system:



Select Engine.

The engine data is displayed.

(i) The values for engine output and engine torque may deviate from the nominal values.

Items that can influence this are, for example:

- · Engine speed
- Sea level
- Fuel grade
- · Outside temperature

Calling up the fuel consumption indicator

Multimedia system:





Select Consumption.

A display with current and average consumption figures is displayed.

Navigation

Switching navigation on

Multimedia system:

→ Navigation (Navigation)

Alternatively: press the NAVI button. The map appears. The current vehicle position is shown. The navigation menu is shown.

The navigation menu is hidden if route guidance is active.

Showing/hiding the navigation menu



If route guidance is not active the map appears. The navigation menu is shown.

The navigation menu is hidden if route guidance is active.

To show: tap on the touchscreen.

or

- Press the Touch Control.
- To hide: the navigation menu is hidden automatically.

Navigation overview



Example: digital map with navigation menu

- To enter a POI or address and additional destination entry options
- To interrupt route guidance (if route guidance) is active)
- 3 To repeat a navigation announcement and switch navigation announcements on or off
- To call up the ON THE WAY menu
 - To show Route Overview
 - To select Alternative Routes
 - Report Traffic Incident (Car-to-X)
 - To call up the TRAFFIC menu
 - To show Traffic Announcements.
 - To show Area Alerts
 - To show Live Traffic Subscription Info
 - To show Route List
 - To call up the POSITION menu
 - Save Position
 - To show Compass
- Quick-access and settings
 - To show Traffic
 - To show Parking
 - To show Highway Information
 - · Via Advanced options to use View, Announcements and Route
- (i) Some options are not available in all countries.
- (i) You can enter 3 word addresses in the online search (\rightarrow page 221). This option is not available in all countries.

Destination entry

Notes on destination entry

WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Entering a POI or address

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Requirements:

- For the online search: Mercedes PRO connect is available.
- You have a user account for the Mercedes PRO portal.

- The service is available.
- The service has been activated at an authorized Mercedes-Benz Center.

Further information can be found at: https://www.mercedes.pro

Multimedia system:

Navigation (Navigation)

Navigation (Navigation)

Navigation (Navigation)

Using the on-board search function



Destination entry uses the on-board search of the database stored in the multimedia system.

The federal state or province in which the vehicle is located is set ①.

Enter the POI or the address using the keyboard (in the image) or using handwriting recognition (a). The entries can be made in any order.

During destination entry, suggestions are made under ② by the multimedia system. Destination selection takes place in list ③ or with OK.

If the multimedia system is equipped with a small display, calling up list (3) is carried out using a list symbol at the top right.

The following entries can be made, for example:

- · City, street, house number
- Street, city
- ZIP code
- POI name
- POI category, e.g. Tankstelle (gas station)
- · City, POI name
- Telephone number, if this is available for the POI
- · Contact name
- Alternatively, use voice input (3).
- To switch to handwriting recognition: select 6.

- Write the character on the touchscreen. The letters can be written next to each other or above each other (\rightarrow page 208).
- To return to entry using the keyboard: select ::: .
- To delete an entry: select (4). The characters are deleted individually.

- If characters have been entered in 2. select (x) next to the input line. The complete entry is deleted.
- To switch to upper-case or lower-case letters: select .
- To switch to digits, special characters and symbols: select @.

123 changes to ABC.

Display (11) changes to #+=.

- Select and switch to additional special characters.
- To enter a space: select 7.
- To set the language: select ①.
- Select the language.
- (i) This function is useful for countries in which several character sets are supported.
- To change the state: select indicator for federal state or province 1.
- Select the state in 1.
- Enter the country indicator, e.g. CA for Can-

The list is filtered.

- Select the country on list 3. The destination can be entered.
- To change the state or province: select the state or the province in list 3.
- To accept a destination: select the destination in list <a> .
- If the destination is ambiguous, select the destination in the list.
 - The destination address is shown. The route can be calculated.

Using online search

(i) Requirements: the media display shows an Internet connection with a double-arrow symbol in the status line.

Online search is not available in all countries.

Destination entry uses online map services. If the on-board search finds no suitable destinations or

if you change countries, the online search is available.

For the destination you can enter an address, a POI or a three-word address.

- Select country indicator 1.
- Select the provider for the online service from the countries list

or

- If the on-board search delivers no search results, enter the destination in the input line. The entry order is not relevant, e.g. street and city. Use the functions described for the onboard search.
 - The search results are displayed.
- Select the destination in the list. The detailed view for the route is displayed.

Selecting previous destinations Requirements:

- Previous destinations are stored.
- For destination suggestions: you have created a profile (\rightarrow page 202).
- The Allow Destination Suggestions option is switched on (\rightarrow page 204).
- The multimedia system has already gathered sufficient data in order to show destination suggestions.

Multimedia system:

→ 🔝 ➤ Navigation ➤ 🔎 Where to? >> PREV. DESTINATIONS

The following destinations can be selected:

- Destination suggestions (→ page 232)
- Destinations
- Routes
- Select the destination or route. The destination address is shown. The route can be calculated.
- (i) A previous destination or a destination suggestion can be saved as a favorite $(\rightarrow page 232)$. Using the favorites you have quick access to the destinations (\rightarrow page 222).

Selecting a POI Requirements:

- For use of personal POIs: a USB device is connected with the multimedia system.
- Personal POIs with the GPS Exchange format (.gpx) have been saved in the "PersonalPOI" folder on the USB device.

Multimedia system:

Searching using categories (no route guidance)

Select the category.

or

- Select All Categories.
- Select the category and the sub-category (if available).

The search takes place in the vicinity of the vehicle's current position. The search result are sorted by distance in ascending order.

The POIs show the following information:

- direction of the linear distance to the POI (arrow)
- name of POI
- linear distance to the POI
- ➤ To filter according to categories or in search results: enter a search entry in the Search text field.
- Select a POI from the list.
 The destination address is shown. The route can be calculated.

Searching using categories (route guidance active)

 Select the category, for example Tankstelle (gas station).

or

- Select All Categories.
- Select the category and the sub-category (if available).
- To filter according to categories or in search results: enter a search entry in the Search text field.
- Select the search positions In the Vicinity, Near Destination or Along the Route.
- If there are intermediate destinations for the route and Near Destination has been selected, select the POI in the route overview.

Select a POI from the list. The destination address is shown. The route can be calculated.

Searching for personal POIs

- Select Personal POIs.
- Select a category.
- If route guidance is active, select a search position In the Vicinity, Near Destination or Along the Route.
- Select a personal POI. The destination address is shown. The route can be calculated.

٥r

- Enter a search entry into the search field and filter the list.
- Select a personal POI.

Editing personal POI categories

- Select a personal POI category from the list

 .
 A menu opens.
- ▶ To change a name: select Change Name.
- Enter the name.
- ► Select OK .
- To change a symbol: select Change Icon.
- Select a symbol.
- ➤ To delete a personal POI category: select Delete.
- Select Yes.

Configuring categories for quick-access

You can configure the categories for quick-

If you calculate the route, for example, the first three of these categories can be selected as symbols.

- Select All Categories.
- Select the category and the sub-category (if available).
- - removes the category.
- If all available quick-access positions are full, select the category to be replaced.

Selecting a contact for destination entry Requirements:

• A mobile phone is connected to the multimedia system (\rightarrow page 243).

Multimedia system:

→ Navigation → Where to? **>>** CONTACTS

Using the contact list

- Select a contact. The contact details are displayed.
- Select the address.

Using search entry

- Enter a name or telephone number, for example, into the search field.
- ► Select OK .
- Select the contact.
- Select the address. The destination address is shown. The route can be calculated.
- (i) Route guidance to a contact address is reliable in the following cases:
 - The contact address is complete.
 - The contact data matches the map data in the digital map.

Entering geo-coordinates

Multimedia system:

→ 🔝 ➤ Navigation ➤ 🔎 Where to?

- **▶** GFO-COORDINATES
- Select geo-coordinates as latitude and longitude coordinates in degrees, minutes and seconds. To do this swipe up or down respectively.

The map shows the position.

Confirm the entry with OK.

Select Latitude or Longitude.

- To set the destination: select or .
- Calculate the route (\rightarrow page 222).

Entering the destination as a 3 word address Requirements:

- Searching for a destination using 3 word addresses is possible in the online search $(\rightarrow page 217).$
- The media display shows an Internet connection with a double-arrow symbol in the status line.

(i) Searching for a destination using 3 word addresses is not possible in all countries and in all languages.

Multimedia system:

→ 🔝 **>>** Navigation **>>** 🔎 Where to?

- Select the country indicator.
- Select the provider for the online service from the countries list.

or

If the on-board search delivers no search results, enter the destination address as a 3 word address. Separate each of the words with a full stop.

The search results are displayed.

- Select the destination in the list. The destination address is shown. The route can be calculated
- 3 word addresses from what3words are an alternative addressing system for multilingual georeferencing of global locations with a resolution of three meters. Using this grid, locations on the Earth's surface are included which do not have a building address such as street and house number, for example.

The Empire State Building has this language dependent 3 word address:

- · English: parade.help.bleat
- French: commun.verbe.bisquer
- · Spanish: suertes.diga.pesca

3 word addresses are unique, easy to remember and suffice for most routine applications.

You can convert addresses to 3 word addresses and back again:

- At the website http://what3words.com
- In the what3words apps

Selecting a destination on the map

Multimedia system:

→ 🔝 >> Navigation

- Move the map (\rightarrow page 236).
- When the crosshair marks the destination, press and hold on the control element. The destination address is shown.

If several destinations are located around the crosshair, a list shows the available roads and POIs.

Select the destination in the list.

The destination address is shown. The route can be calculated.

Showing POIs in the vicinity of the map

If several destinations are located around the crosshair, the function is available.

- ➤ Select ···..
- Select POIs in the Vicinity. The map appears.
- Swipe left or right on the control element. The previous or next POI is highlighted on the map. The name or the address is shown.
- Select the POI symbol.

or

- To filter the display according to the POI category: scroll on the control element.
- Select the POI category.

Selecting a destination from favorites Requirements:

Destinations are saved as favorites.
 Save a previous destination or a destination suggestion as a favorite (→ page 232).

Multimedia system:

► NavigationNavigation
► NavigationNavigation
► PAVORITES

Select a favorite.

The destination address is shown. The route can be calculated.

The following options are available in the favorites menu:

- · Saving addresses for home and work
- · Creating favorites
- · Deleting favorites
- If no address has been saved for home and work: select Home or Work.
- Confirm the prompt with Yes.
- Enter the favorite as a POI or address (→ page 217).
- To save a favorite: select Add Favorites.
- Enter the favorite as a POI or address (→ page 217).

or

- If all the positions in the favorites are full, first select a favorite which is to be overwritten (→ page 204).
- Follow the instructions provided.

- **To delete a favorite:** select ⊕ for a destination.
- Select Delete.

or

- Press on a favorite until the OPTIONS menu is shown.
- Select Delete.

Route

Calculating a route Requirements:

- · The destination has been entered.
- The destination address is shown.



- No route yet

 A route has been mapped

or

Select . If a route is already mapped, a prompt is shown.

Select Set as Way Point.

The selected destination address is set as the next intermediate destination. Route guidance begins.

If there are already four intermediate destinations, the multimedia system asks whether intermediate destination 4 should be deleted. Confirm the prompt with Yes.

or

Select Start New Route Guidance.

The selected destination address is set as a new destination. The previous destination and the intermediate destinations are deleted. Route guidance to the new destination begins.

Searching for POIs in the vicinity of the destination shown

- (i) The POI symbols to the right of POIs in the Vicinity show the first three categories for quick-access. You can configure these categories (\rightarrow page 219).
- Select a POI symbol. The search results are displayed.
- Select a POL The destination address is shown. The route can be calculated.

٥r

- Select POIs in the Vicinity > .
- Search using categories, enter a search entry or search for a personal POI (\rightarrow page 219).
- Select a POI. The destination address is shown. The route can be calculated.

Other menu functions

- To save the destination: select ☆ .
- Select an option.

The following options are available:

- Save in "Previous Destinations"
- Save as Favorite
- Save as "Home"
- Save as "Work"
- To call the destination: if a telephone number is available, select Call.
- To share the destination using NFC or QR code: select Share via NFC or QR Code.
- Hold the NFC area of the mobile phone (see manufacturer's operating instructions) on the mat or place the mobile phone on it $(\rightarrow page 245)$.

or

- Hold the mobile phone near to the multimedia system and scan the QR code.
- To call up an Internet address: if a web address is available, select www.
- To show on the map: select Show on Map.

Selecting a route type

Multimedia system:

→ 🔝 >> Navigation >> 💍

▶ Advanced ▶ Route

Select the route type. If no route has been created, the next route is calculated on the basis of the new route type. If a route has already been created, the route is calculated on the basis of the new route type.

The following route types are available:

A route with a guick journey time is calculated.

Short

A route with a short driving distance is calculated.

Eco

An economical route is calculated. The journey time may be somewhat longer than for quicker routes.

Trailer

The option is available if a trailer has been coupled with the vehicle.

A prompt is shown in the multimedia system. Confirm the prompt.

The route is optimized for trailer operation with a maximum speed of 50 mph (80 km/h).

Traffic information can be taken into account for the route types:

- Select Dynamic Route Guidance .
- Select Automatic, On Request or Off.

Explanation of the options:

Automatic

The route is calculated with the currently set route type.

Traffic reports via Live Traffic Information are taken into account (\rightarrow page 233).

Live Traffic Information is not available in all countries.

On Request

A prompt appears when a new route is detected with a shorter journey time based on traffic reports. You can continue to use the current route or use the dynamic route instead $(\rightarrow page 235)$.

Off

No traffic reports are taken into account for the route.

Calculating alternative routes

Activate Suggest Alternative Route. The display button is activated. Alternative routes are calculated for every route.

Select an alternative route (→ page 226).

Selecting route options

Multimedia system:

→ 🔝 ➤ Navigation ➤ 💆

➤ Advanced ➤ Route

Avoiding areas

- Select Avoid Options.
- Select Avoid Areas (→ page 238).

Avoiding or using highways, ferries, tunnels, motorail trains, unpaved roads

- Select Avoid Options.
- Activate or deactivate the avoid option. To avoid: the display button is activated. The route avoids highways, for example.

To use: the display button is off. The route takes highways into consideration, for example.

These route options are not available in every country.

The selected route options cannot always be implemented. Therefore, a route may include a ferry, for instance, even though the Avoid Ferries avoid option is enabled. A message appears and you will hear a corresponding message.

Avoiding or using toll roads

- Select Avoid Options.
- Select Toll Roads.
- Activate or deactivate Avoid All.

To avoid: the display button is activated. The route avoids all toll roads.

To use: the display button is off. The route allows for all roads that require the payment of a usage fee (toll).

or

- ➤ To avoid a payment type: select Avoid.

 The route avoids all toll roads with the selected method of payment.
- ➤ To use a payment type: select Use.
 The route allows for all toll roads with the selected method of payment.

These route options are not available in every country.

Using carpool lanes

When using carpool lanes, observe the applicable legal requirements as well as any conditions pertaining to when and where such lanes may be

used. Carpool lanes may only be used if certain conditions are met.

Carpool lanes are not available in all countries.

- Select Avoid Options.
- Select Carpool Lanes.
- Select For Two Occupants or For 3 Occupants or More .

or

➤ Select On Request •.

When this option is selected and a carpool lane is available, a prompt appears. You can continue to use the current route or select a route with the carpool lane.

i If the Avoid option is selected, then no carpool lanes will be used for the route.

Selecting notifications Requirements:

- For an audible indication when approaching a personal POI: the USB device contains personal POIs.
- The USB device is connected with the multimedia system.
- The category in which the personal POI belongs is activated.

Multimedia system:

→ 🔝 → Navigation → 💆

- ▶ Advanced ▶ Announcements
- Activate or deactivate No Driving Recomm.. No navigation announcements are issued if the display button is activated.
- ➤ To select navigation announcements: select an option in the DRIVING RECOMMEN-DATION category •.

The following options are available:

Tone Only

Instead of the spoken navigation announcement you hear a gong. The gong signals a driving maneuver and sounds also during the driving maneuver.

· Reduced Driving Recomm.

If a navigation announcement is available, you hear a short announcement, e.g. "Turn right".

· Detailed Driving Recomm.

If a navigation announcement is available and the Announce Street Names option is activated, you hear a complete announcement, e.g. "Turn right into Station Road at the end of the road in 600 ft (200 m)".

- To have street names announced during a driving maneuver: switch on Announce Street Names
- Select Reduced Driving Recomm. or Detailed Driving Recomm..

The name of the street into which you should turn is announced.

(i) The options in the DRIVING RECOMMENDA-TION category are not available in all countries and in all languages.

Selecting messages for TRAFFIC

Activate a message. The display button is activated.

The following options are available:

Traffic Incidents

Traffic incidents are announced, e.g. roadworks and road blocks.

This function is not available in all countries and languages.

Announce Traffic Warnings

Warning messages are announced, e.g. before tailbacks that pose a risk (if availa-

This function is not available in all countries and languages.

Audible indication when approaching a personal POI

- Select the Personal POIs option in the ALERTS category.
- Activate a category. The display button is activated. When approaching a personal POI in this category an audible indication will be issued.

Showing destination information for the route Requirements:

· A destination is entered.

Multimedia system:

¬→ 🔝 >> Navigation >> 📝

Select Route Overview.

When route guidance is active, the destination and intermediate destinations are shown, if these have been entered and not yet been passed.

The route can include up to four intermediate destinations.

Select a destination or an intermediate destination.

The following information is displayed:

- Remaining driving distance
- Time of arrival
- Remaining journey time
- · Name, destination address
- Phone number (if available)
- Web address (if available)

Planning routes

Multimedia system:

→ Navigation >> Route Overview

- Select Set Way Point.
- Enter the intermediate destination as a POI or address, for example (\rightarrow page 217).
- Select the intermediate destination. After selection of an intermediate destination. the route overview is shown again.
- Calculate the route with intermediate destinations (\rightarrow page 226)
- (i) If there are already four intermediate destinations, delete an intermediate destination $(\rightarrow page 225).$

Editing a route with intermediate destinations

Requirements:

- A destination is entered.
- For the moving function there must also be at least one intermediate destination.

Multimedia system:

→ 🔝 **>>** Navigation >> Route Overview

To change the sequence of destinations: select for an intermediate destination or destination. A menu opens.

Select Move.

is highlighted.

Move the intermediate destination or the destination with or to the desired position.

- Tap on 🕝 .
- To delete a destination: select for an intermediate destination or destination.

The destination is deleted.

Calculating a route with intermediate destinations

Requirements:

 The destination and at least one intermediate destination have been entered.

Multimedia system:

→ Mavigation

Navigation

Route Overview

▶ Select Start Route Guidance.

or

- If the route has been edited, select To Navigation .
- Confirm the prompt with Yes. The route is calculated. Route guidance begins.

Displaying the route list

Multimedia system:

→ 🔝 **>>** Navigation **>>** 📝

► Select Route List

The list shows the route sections. The current vehicle position is marked on the map.

The current vehicle position is shown with the following information:

- The symbol for the current vehicle position is displayed.
- The name of the road on which you are currently driving is shown.
- The road number of the road on which you are currently driving is shown.

The route list is updated during the journey.

To show route sections: swipe up or down on the control element.

The route section is shown on the map.

Selecting an alternative route Requirements:

 The Suggest Alternative Route option is switched on (→ page 223).

Multimedia system:

→ 🞧 >> Navigation >> 📝

Select Alternative Routes.

The routes are displayed in accordance with the setting made in the route settings.

The routes are numbered.

- Select the alternative route.
- To show the route on the map: select Show on Map.
- \blacktriangleright Move the map (\rightarrow page 236).
- ▶ Set the map scale (\rightarrow page 236).
 - To avoid or use route options: select
- Switch the route option, e.g. Highways, on or off.

To avoid: the display button is activated. The alternative route avoids highways.

To use: the display button is off. The alternative route takes account of highways.

Activating a commuter route Requirements:

- You have created a profile (→ page 202).
- The Allow Destination Suggestions option is switched on (→ page 204).
- The Activate Commuter Route option is switched on.
- The multimedia system has gathered sufficient data in order to show destination suggestions.
- Routes have been learned for these destination suggestions.
- (i) This commuter route is not available in all countries.

Multimedia system:

→ Mavigation → O

Activate Activate Commuter Route.

The display button is activated. The navigation system automatically detects that the vehicle is on a commuter route. It automatically starts a route guidance without voice output.

For the daily commuter route, traffic incidents on the route are also reported when driving without active route guidance.

Switching the automatic gas station search on/off

Multimedia system:

→ 🔝 >> Settings >> Vehicle

Activate or deactivate Gas Station Search. When the fuel reserve level is reached, and the display button is switched on, a message appears to start searching for gas stations.

Starting an automatic gas station search Requirements:

• The automatic gas station search is activated $(\rightarrow page 226)$.

Driving situation

The fuel level in the fuel tank reaches the reserve fuel level.

The following notification is shown in the media display Reserve Fuel Tap here to search for gas stations.

Confirm the notification.

The automatic gas station search begins. The available gas stations along the route or in the vicinity of the vehicle's current position are displayed.

- Select a gas station.
 - The address of the gas station is displayed.
- Calculate the route (→ page 222). The gas station is set as the destination or the next intermediate destination.
- If there are already four intermediate destinations: select Yes in the prompt. The gas station is entered in the route overview. Intermediate destination 4 is deleted. Route guidance begins.

Starting the automatic service station search Requirements:

- ATTENTION ASSIST and the Suggest Rest Area function are activated (\rightarrow page 163).
- There are service stations along the route section ahead.

Driving situation

The following notification is shown in the media display ATTENTION ASSIST Tap here to search for rest areas.

Confirm the notification.

The service station search starts. The available service stations along the route or in the vicinity of the vehicle's current position are displayed.

- Select a service station.
 - The service station address is displayed.
- Calculate the route (\rightarrow page 222). The service station is set as the destination or the next intermediate destination.

If there are already four intermediate destinations: select Yes in the prompt. The service station is entered in the route overview. Intermediate destination 4 is deleted. Route guidance begins.

Showing a stored route on the map Requirements:

- A USB device with stored routes is connected. with the multimedia system.
- The route is stored in the "Routes" folder with the GPS Exchange format (.gpx).

Multimedia system:

→ 🙀 **>>** Navigation **>>** 🔎 Where to? >> SAVED ROUTES

- Select a route.
- Select Show on Map.
- Move the map (\rightarrow page 236).

Starting a saved route Requirements:

- A USB device with stored routes is connected with the multimedia system.
- The route is stored in the "Routes" folder with the GPS Exchange format (.gpx).

Multimedia system:

→ Mavigation → Where to? >> SAVED ROUTES

- Select a route.
- Select Start Route Guid, from Beginning of Route or Start Route Guidance from Curr. Position.

Route guidance starts.

i) The route can be saved with in the menu (\rightarrow page 222).

Recording a route Requirements:

 A USB device is connected with the multimedia system.

Multimedia system:

→ Mavigation → Where to? >> SAVED ROUTES

► To start recording: select Start Recording a New Route.

A red recording symbol is shown.

The route is stored on the USB device.

To stop recording: select End Recording.

Saving a recorded route Requirements:

A USB device is connected with the multimedia system.

Multimedia system:

→ Navigation → Where to?
➤ SAVED ROUTES

- Select a route.
- ► Select ☆.
- Select Save in "Previous Destinations". The route is stored in the "Previous destinations" memory and can be called up from there for route guidance.

Editing a stored route Requirements:

 A USB device with stored routes is connected with the multimedia system (→ page 262).

Multimedia system:

→ Mavigation → Mhere to?

SAVED ROUTES

- Select a route with ○.
- ► To enter a name: select Change Name.
- Enter the name.
- Select OK.

or

- When the name has been changed, press the button.
- Select Yes.
- ► To delete a route: select Delete.
- Select Yes.

Route guidance

Notes on route guidance

▲ WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road

and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Route guidance begins once a route has been calculated.

The road and traffic rules and regulations always have priority over multimedia system driving instructions.

Driving instructions are:

- · Navigation announcements
- · Route guidance displays
- · Lane recommendations

If you do not follow the driving instructions or if you leave the calculated route, a new route is calculated automatically.

Driving instructions may differ from the actual road and traffic conditions if:

- · The route is diverted
- The direction of a one-way street has been changed

For this reason, you must always observe road and traffic rules and regulations during your journey as well as the prevailing traffic conditions.

The route may differ from the ideal route due to the following:

- Roadworks
- · Incomplete digital map data

Notes on GPS reception

The correct function of the navigation system depends amongst other things on GPS reception. In certain situations GPS reception can be impaired, defective or even not possible, e.g. in tunnels or in parking garages.

Changing direction overview

Changes of direction are shown in the following displays:

- Detailed image of the intersection
 The display appears when you drive into an intersection.
- 3D image

The display appears when driving on intersection-free, multi-lane roads, for example on freeway exits and freeway interchanges.



Example: detailed image of the crossing with upcoming changes of direction

- Current distance to the change of direction
- Changing direction
- 3 Current vehicle position
- Maneuver point



Example: 3D image of the upcoming change of direction

- ① Current distance to the change of direction
- Changing direction
- Current vehicle position
- Maneuver point

There are three phases when changing direction:

Preparation phase

If there is enough time between the changes of direction, the multimedia system prepares you for the upcoming change of direction. A navigation announcement is issued depending on the settings for driving recommendations, e.g. "Prepare to turn right".

The map appears in full-screen mode.

The status line shows: the direction information or the name of the road which is to be turned into and the distance to the change of direction.

Announcement phase

The multimedia system announces the upcoming change of direction depending on the settings for driving recommendations, e.g. by announcing "In 600 ft (200 m) at the end of the street turn right into Station Road".

The display is split into two parts. The map is displayed on the left; on the right, there is a detailed image of the intersection or a 3D image of the upcoming change of direction.

Change-of-direction phase

The multimedia system announces the imminent change of direction, e.g. by announcing "Now turn right".

The display is split into two parts.

The change of direction takes place when the distance to maneuver point (4) is shown with 0 ft (0 m) and the symbol for vehicle position (3) has reached maneuver point (4).

When the change of direction is complete, the map appears in full-screen mode.

(i) Changes of direction are also shown in the Instrument Display.

Lane recommendations overview

This display appears for multi-lane roads.

The multimedia system can show lane recommendations if the digital map contains the relevant data.



- Recommended lane (white arrow, blue background)
- Possible lane (white arrow)
- 3 Lane not recommended (gray arrow)

Explanation of the displayed lanes:

Recommended lane ①

In this lane, you will be able to complete both the next change of direction and the one after that.

 Possible lane ② In this lane, you will only be able to complete the next change of direction.

Lane not recommended (3)

In this lane, you will not be able to complete the next change of direction without changing lane

During the change of direction, new lanes may be added.

i Lane recommendations can also be shown in the Instrument Display.

Using freeway information Requirements:

 The Highway Information option is switched on (→ page 237).



When driving on the freeway, upcoming freeway facilities (a) and available service facilities (a) are shown in the overview. These include gas stations, parking lots, service stations and freeway exits, for example.

➤ To open the display: select ∑.

The entries are sorted according to increasing distance from the current vehicle position.

To close the display: tap on the map.

or

To use freeway information: select an entry.

If several service facilities are available, select a service facility from the list. The destination address and the map position are shown.

Calculate the route (→ page 222).

or

Search for a POI in the vicinity.

or

 Use other functions, e.g. save the destination address of the service facility.

Using quick-access for a destination, alternative route and POIs Requirements:

- The POI categories are configured for quickaccess (→ page 219).
- If route guidance is active, select the symbol with arrival time and distance to the destination on the map.

The address of the destination or the next intermediate destination is shown.

Using alternative routes

Select Alternative Route.

The routes are displayed in accordance with the setting made in the route settings.

The routes are numbered.

Select the alternative route.

Setting a POI as an intermediate destination

- Select a category symbol, e.g. p for a parking lot.
- Select a POI from the list. The selection takes place on the route. The destination address is shown. The route can be calculated
- ➤ To use POI categories for quick-access: select a search position In the Vicinity, Near Destination or Along the Route.
- Select a POI from the list.

or

- Enter a search entry into the search field and filter the list.
- Select a POI from the list. The destination address is shown. The route can be calculated.

Saving the current vehicle position

Select Save Position.
The current vehicle position is saved to the "Previous destinations" memory.

Destination reached

Once the destination is reached, you will see the checkered flag. Route guidance is finished.

When an intermediate destination has been reached, you will see the intermediate destination flag with the number of your intermediate destination. Route guidance is continued.

Switching navigation announcements on/off

To switch off: during a navigation announcement, press the volume control on the steering wheel or the 💢 / 🖒 button on the multimedia system (\rightarrow page 201). The Voice Guidance has been deactivated. message appears.

or

- Show the navigation menu (\rightarrow page 216).
- Select [1].

The symbol changes to [...].

To activate: select [].

The current navigation announcement is

The symbol changes to [1].

(i) This function can be added and called up from the favorites within the navigation category.

Switching navigation announcements on or off during a phone call

Press the button on the steering wheel.

or

Press and hold the \(\frac{1}{\text{ \lambda}} \) button on the multimedia system.

or

- Tap on in the media display.
- Select Settings.
- Select System.
- Select Audio.
- Select Navigation and Traffic Announcements.
- Activate or deactivate Voice Guidance During

When the option is switched on, the display button is activated.

► To leave the menu: select < .</p>

Adjusting the volume of navigation announcements

Multimedia system:

→ Settings → System → Audio

- >> Navigation and Traffic Announcements
- Select Voice Guidance Volume.
- Set the volume.
- To leave the menu: select <

Route guidance is active

Turn the volume control on the multifunction steering wheel during a navigation announcement.

Press the volume rocker switch on the multimedia system up or down.

Switching audio fadeout on or off during navigation announcements

Press the hotton on the steering wheel.

or

Press and hold the \(\square\) button on the multimedia system.

or

- Tap on in the media display.
- Select Settings.
- Select System.
- Select Audio.
- Activate or deactivate Audio Fadeout.
- To leave the menu: select <

Repeating navigation announcements Requirements:

- · A route has been created.
- Route guidance is active.

Multimedia system:

- ¬→ Navigation
- Select [1]. The current navigation announcement is repeated.
- (i) This function can be added and called up from the favorites within the navigation category.

Canceling route guidance Requirements:

- A route has been created.
- route guidance is active.
- Show the navigation menu.
- Select [in the navigation menu $(\rightarrow page 217)$.

Overview of route guidance to an off-road destination

An off-road destination is within the digital map. The map contains no roads that lead to the desti-

You can enter geo-coordinates or a three word address for off-road destinations on the map. Route guidance guides you for as long as possible with navigation announcements and displays on roads that are known to the multimedia system.

Shortly before you reach the last known position on the map, you will hear the "Please follow the direction arrow" announcement, for example. The display shows a direction arrow and the linear distance to the destination.

Overview of route guidance from an off-road location to a destination

In an off-road position, the current vehicle position is located within the digital map on roads that are not available.

These displays appear when route guidance begins:

- A message appears that the road is not on the map.
- A direction arrow that shows the linear direction to the destination.

When the vehicle is back on a road known to the multimedia system, route guidance continues as normal.

Overview of off-road status during route guidance

Due to roadworks, for example, there may be differences between the data on the digital map and the actual course of the road. In such cases, the multimedia system will temporarily be unable to locate the vehicle's current position on the digital map. The vehicle is off-road.

When the vehicle is off-road, the following displays are shown:

- A message appears that the road is not on the map.
- A direction arrow showing the linear direction to the POI.

When the vehicle is back on a road known to the multimedia system, route guidance continues as normal.

Destination

Saving the current vehicle position

Multimedia system:

→ 🔝 **N**avigation **>** 📝 **>** Position

Select Save Position.

The current vehicle position is saved to the "Previous destinations" memory.

Using quick-access

- If route guidance is active, select the symbol with arrival time and distance to the destination on the map.

 The address of the destination or the next intermediate destination is shown.
- Select Save Position.

Editing the previous destinations Requirements:

- For editing destination suggestions: the Allow Destination Suggestions option is activated (→ page 204).
- The multimedia system has gathered sufficient data in order to show destination suggestions.

Multimedia system:

→ Mavigation → Mhere to?
→ PREV. DESTINATIONS

The following destinations can be edited:

- Destinations
- Destination suggestions
- ➤ To no longer display a destination suggestion: select ⊙ for a destination suggestion.
- Select No Longer Suggest.

Saving the last destination as a favorite

- (i) After saving, the destination can be called up via the favorites (→ page 204).
- ▶ Select for a destination.
- ► Select Save as Favorite .
- To save as a favorite: select Save as Favorite
- To save as "Home" address: select Save as "Home".
- ➤ To save as "Work" address: select Save as "Work".

Deleting a previous destination

- ➤ To delete a destination: select of for the previous destination.
- Select Delete.
- Select Yes.
- To delete all destinations: select
- Select Delete All.
- Select Yes.

Using external destinations and routes

External destinations and routes can be received from Mercedes-Benz Apps.

A prompt appears on the multimedia display. Received destinations and routes are saved in the previous destinations.

- A destination has been received: select Yes.
- Calculate the route.
- If route guidance is already active, select Set as Way Point or Start New Route Guidance.

or

- If a destination was received with photo information, select Start Route Guidance.
- Calculate the route.

or

- If a destination has been received from an app. select Details.
- Calculate the route.
- A route has been received; select Yes.
- Select Start Route Guid. from Beginning of Route or Start Route Guidance from Curr. Position.

Route guidance starts from the selected position.

Route guidance with current traffic reports

Traffic information overview

Traffic reports are received using Live Traffic Information and are used for route guidance.

This service is unavailable in some countries.

(i) There may be differences between the traffic reports received and the actual road and traffic conditions.

Important information on Live Traffic Information:

- Current traffic reports are received via the Internet connection.
- The traffic situation is updated at short, regular intervals.
- · Subscription information shows the status $(\rightarrow page 233)$.

Information on the vehicle's position is regularly sent to Mercedes-Benz AG. The data is immediately rendered anonymous by Mercedes-Benz AG and forwarded to the traffic data provider. Using this data, traffic reports relevant to the vehicle's position are sent to the vehicle. The vehicle acts

as a sensor for the flow of traffic and helps to improve the quality of the traffic reports.

If you do not wish to transmit a vehicle position, you have the following option:

- You can deactivate the service at Mercedes. PRO connect
- You have the service deactivated at an authorized Mercedes-Benz Center.

Displaying information from Live Traffic Information service providers Requirements:

• The vehicle is equipped with Live Traffic Infor-

Multimedia system:

→ 🚡 >> Navigation >> 📝 >> Traffic

- Select Provider Information. The logo of the Live Traffic Information service provider is shown.
- (i) The following options are available for extending the subscription:
 - At an authorized Mercedes-Benz Center.
 - Via a service call with the Mercedes-Benz Customer Assistance Center using the breakdown assistance button on the overhead control panel (\rightarrow page 196)
 - Via a service call with the Mercedes-Benz Customer Assistance Center using the multimedia system (→ page 195)

Showing traffic information Requirements:

- The Traffic display is switched on $(\rightarrow page 234).$
- The following traffic displays are switched on $(\rightarrow page 234)$:

Traffic Incidents

Free Flowing Traffic

Delay

Multimedia system:



Select Navigation.

The map shows the following traffic information:

- traffic incidents, for example:
 - roadworks
 - road blocks
 - warning messages

When route guidance is active, the symbols for traffic incidents will be shown in color on the route. Off the route they are gray.

- · warning message symbols:
 - symbol 🕦
 - road safety notes, e.g. when approaching the end of a traffic jam

If the vehicle approaches a danger area on the route, a warning message is displayed on the map. A warning message may also be issued.

- · traffic flow information:
 - traffic iam (red line)
 - slow-moving traffic (orange line)
 - heavy traffic (yellow line)
 - free-flowing traffic (green line)
- display for traffic delays on the route lasting at least one minute

Displaying traffic incidents Requirements:

 The Traffic Incidents display is switched on (→ page 234).

Multimedia system:

→ 🔝 **>>** Navigation **>> ? >>** Traffic

Select Traffic Announcements.

If there are traffic reports, you will see a list. Traffic reports include accidents and other traffic events, for example. The list is sorted according to distance and shows the traffic reports received both on and off the route.

A traffic incident shows the following information:

- · Street number or street name
- Traffic incident symbol

On the route: color Off the route: gray

- Cause
- Street symbol (traffic incident on the route)
- Distance from current vehicle position
- Select a traffic incident ____. The detailed information is shown, for example the route section.

Showing traffic incidents in the vicinity of the map

- Select a traffic incident symbol on the map. The details about the traffic incident are displayed.
- ► Select ····.
- Select Traffic Incidents in Vicinity.

The map shows the traffic incident symbols in the vicinity.

Traffic incident information is displayed in the status line:

- Traffic incident symbol
- Cause of the traffic incident, e.g. construction work
- Warning message (highlighted red)
- ➤ To select a traffic incident symbol: select
- To select a map section: tap on the touchscreen.

or

- Press the Touch Control.
- Move the map.
- To return to the navigation map: tap on

or

Press the button on the Touch Control.

Switching the traffic information display on Multimedia system:

→ 🔝 >> Navigation >> 🔘

Activate Traffic.

The display button is activated.

Activating Incidents, Free Flow and Delay

- Select Advanced.
- Select View.
- Select Map Elements.
- In the TRAFFIC category, activate the Traffic Incidents, Free Flowing Traffic and Delay entries.

If traffic information has been received, then traffic incidents such as roadworks, road blocks, local area reports (e.g. fog) and warning messages are displayed.

The traffic delay is displayed for the current route. Traffic delays lasting one minute or longer are taken into consideration.

Showing local area messages

Multimedia system:

→ Navigation → Traffic

Select Area Alerts.

Local area messages are shown, for example fog or heavy rain.

Select a local area message. The details are displayed.

Accepting a detour recommendation after a prompt

Requirements:

- On Request is switched on in the DYNAMIC ROUTE GUIDANCE menu $(\rightarrow page 223).$
- · Route guidance is active.
- There are traffic reports for the current route.

If a new route with a shorter driving time is determined, the current and new routes will be shown.

- (i) The notification is shown in another application. Confirm the notification.
- ➤ To accept the new route: select Accept Recommended Detour.
- To maintain the current route: select Keep to Current Route.

Car-to-X-Communication

Overview of Car-to-X-Communication

The following requirements apply for using Carto-X-Communication:

- The vehicle is equipped with a multimedia system featuring navigation and a communication module with an activated, integrated SIM card.
- You have a user account with Mercedes PRO.
- The Car-to-X-Communication service is activated.
- (i) Car-to-X-Communication is available in selected countries.

The communication module automatically establishes an Internet connection once the ignition is switched on. If there are any hazard warnings, they will be provided shortly thereafter. Depending on the mobile phone connection, the provision takes place from within a second up to about a minute.

Benefits of Car-to-X-Communication:

- Hazards are recognized automatically in the background by the vehicle or may be reported by the driver. These are then sent to vehicles with Car-to-X-Communication in the immediate vicinity.
- If available, current details relating to hazard spots near the vehicle's current position are received.

This gives you sufficient time to adapt your driving style to the traffic conditions.

The use of Car-to-X-Communication requires the regular transmission of vehicle data to Mercedes-Benz AG. The data is then immediately pseudonymized by Mercedes-Benz AG. The vehicle data is deleted after an appropriate amount of time has elapsed (several weeks) and is not stored permanently.

(i) Data which serves as identification is replaced during the pseudonymization process. In this way, your identity is protected against access by unauthorized third parties.

Displaying hazard warnings

Multimedia system:

→ 🔐

Select Navigation.

If hazard warnings are available these will be shown on the map.

The following hazard warnings are shown on the

- Broken-down vehicles
- Accidents
- Hazardous weather
- General hazards
- Hazard warning lights, when switched on
- (i) If the vehicle is approaching a hazard spot with a vehicle speed of at least 37 mph (60 km/h) the voice output "Traffic incident ahead" is issued.

The voice output is not issued for hazardous weather.

Sending hazard warnings

Automatically detected hazard warnings are sent by the vehicle.

- To send a hazard warning yourself: tap on the media display when the map is shown. The navigation menu is shown.
- Select .

Select Yes.
 The Thank You for Supporting Accident Prevention message appears.

Map and compass

Setting the map scale

Multimedia system:



Zooming in

When the map is shown, tap twice quickly with one finger on the media display.

or

Move two fingers apart on the media display.

Zooming out

Tap with two fingers on the media display.

or

- Move two fingers together on the media display.
- i You can set the unit of measurement of the map scale (→ page 213).

Moving the map

Multimedia system:



Move the finger in any direction on the touchscreen when the map is shown.

When the map has been moved the following information appears in the status line, for example:

- The distance from the vehicle's current position is shown.
- Information about the current map position is shown, e.g. the name of the road.

The following functions are available:

- Select a destination on the map (→ page 221).
- Select a POI (→ page 219).
- Show traffic incidents on the map (→ page 234).

This function is not available in all countries.

► To reset the map to the current position of the vehicle: tap on symbol ④.

Rotating the map

With two fingers, rotate counter-clockwise or clockwise on the media system display.

Selecting the map orientation

Multimedia system:

→ Mavigation → 🌣

Advanced

- Select View.
- Select Map Orientation.
- Select an option.

The • dot indicates the current setting.

The following options are available:

- 2D Heading Up option: the 2D map view is aligned to the direction of travel.
- 2D North Up option: the 2D map view is displayed so that north is always at the top.
- 3D option: the 3D map view is aligned to the direction of travel.

or

To use quick-access: repeatedly tap or press on the compass symbol on the map. The view changes in the sequence 3D, 2D Heading Up to 2D North Up.

If the map is moved, it can switch between 3D and 2D North Up.

Selecting POI symbols for the map display Multimedia system:



POIs include gas stations and hotels, for example. These can be displayed as symbols on the map. Not all POIs are available everywhere.

Personal POIs are destinations which you have saved on a USB device, for example.

- i The display of POI symbols on the map can be activated or deactivated as a favorite.
- To switch on/off using quick-access: if available, switch POI Symbols on or off. The POI symbols for the selected categories are shown on the map.

or

- To switch on/off in the menu: select Advanced.
- Select View.
- Select Map Elements.

- Select POI Symbols. The POI SYMBOLS menu is shown.
- Switch Display POIs on or off.

Selecting categories

- Select POI SYMBOLS in the All Categories menu >.
- Activate or deactivate Show All. When the option is switched on, the POI symbols for all categories are shown on the map.

٥r

- Select the categories and sub-categories (if available) \(\rightarrow\).
- Activate or deactivate the categories. The POI symbols for the selected categories are shown on the map.

Selecting personal POI categories

- Select POI SYMBOLS in the Personal POIs menu >.
- Select a category \supset .
- Activate or deactivate Show on Map. When the display is switched on and the vehicle approaches a personal POI in this category, a visual and audible notification can be issued.
- To set a notification when approaching: select a category or a personal POI .
- Switch Visual Notification and Acoustic Notification on or off.

Switching display of categories for quickaccess on/off

Switch a category on or off in the POI SYM-BOLS menu.

Resetting the POI symbol display

Select POI SYMBOLS Reset POIs in the menu. The settings are reset to the standard settings.

Selecting text information for display on the map

Multimedia system:

→ 🔝 >> Navigation >> 🔘

- Advanced
- Select View.
- Select Text Information.
- Select an option in the FOOTER category. The • dot indicates the current setting.

The following options are available:

Current Street option

The street you are currently on is shown in the bottom bar.

When the map is moved, the street name, the POI name or the area name appears under the crosshair.

- The Geo-coordinates option shows the following information in the bottom bar:
 - Longitude and latitude
 - Elevation

The elevation shown may deviate from the actual elevation.

Number of satellites from which a signal can be received

When the map is moved, this information does not appear.

• None option

The media display shows no text information in the bottom bar.

Switching freeway information on/off Multimedia system:

→ 🔝 **>>** Navigation **>>** 💍

To use quick-access: switch Highway Information on or off.

The display button is activated or off.

or

- To use the menu: select Advanced.
- Select View.
- Select Text Information.
- Activate or deactivate Highway Information. When the display button is switched on, additional information about the freeway facilities ahead appears during the freeway journey. These include parking lots, service stations and freeway exits, for example.

Displaying the next intersecting street Requirements:

· Route guidance is not active.

Multimedia system:



Advanced

- Select View.
- Select Text Information.

Activate Next Intersecting Street.

The display button is activated. If the option is switched on and the journey continues without route guidance, the name of the next intersecting street will be displayed at the upper edge of the display.

Displaying the map version

Multimedia system:

- → 🔝 **>>** Navigation **>>** 💿
- Advanced
- Select View.
- ► Select Map Version.

The detail information is displayed.

- The online map update service from Mercedes PRO connect can be used to update the map data (→ page 239).
 A message is shown in the media display when a new map version is available.
- i Information about new versions of the digital map can be obtained from an authorized Mercedes-Benz Center.

Overview of avoiding an area for the route

You can define areas along a route that you would like to avoid.

Freeways or multi-lane urban freeways, which are routed through an area to be avoided are taken into account for the route.

Avoiding a new area for the route

Multimedia system:

- → 🔝 **>>** Navigation **>>** 💿
- ➤ Advanced ➤ Route ➤ Avoid Options
- > Avoid Areas
- Select Avoid New Area.
- ▶ To start in the map: select Using Map.
- \blacktriangleright Move the map (\rightarrow page 236).
- ➤ To start via destination search: select Via Address Entry.
- \triangleright Enter the address (\rightarrow page 217).
- Select the destination in the list or accept with OK.

The map appears.

To show an area: tap or press on the control element.

A red rectangle appears. This designates the area that should be avoided.

To change the map scale: move two fingers together or apart on the media display. The map is zoomed in or out.

To set an area: press on the control element.
The area is entered into the list.

Changing an area to be avoided

Multimedia system:

- → 🔝 **>>** Navigation **>>** 💿
- ➤ Advanced ➤ Route ➤ Avoid Options
- > Avoid Areas
- Select an area in the list.
- Select Edit.
- To move an area on the map: swipe in any direction on the control element.
- To change the size of the area: tap or press on the control element.
- Swipe up or down on the control element.
- Tap or press on the control element.
- To take account of an area for the route: select an area from the list.
- Activate Avoid Area.

The display button is activated.

If route guidance is active, a new route is calculated.

If there is no route yet, the setting is carried over to the next route guidance.

The route can include an area that is to be avoided in the following cases:

- the destination is located in an area that is to be avoided.
- the route includes highways or multi-lane expressways which pass through an area to be avoided.
- there is no sensible alternative route.

Deleting an area

Multimedia system:

- → 🔝 ➤ Navigation ➤ 💆
- ➤ Advanced ➤ Route ➤ Avoid Options
- >> Avoid Areas
- To delete an area: select an area in the list.
- Select Delete.
- Confirm the prompt with Yes.
- To delete all areas: if at least two areas to avoid are set, select Delete All.
- Confirm the prompt with Yes.

Overview of updating the map data

Updating at an authorized Mercedes-Benz Center

The digital maps generated by the map software become outdated in the same way as conventional road maps. Optimal route guidance can only be provided by the navigation system in conjunction with the most up-to-date map data. Information about new versions of the digital map can be obtained from an authorized Mercedes-Benz Center

You can receive updates to the digital map there.

Online map update

The online map update service from Mercedes PRO connect can be used to update the map data.

This service is not available in all countries.

You can use the following update options:

- For one region (automatic map update) For automatic map updates the Automatic Online Update system setting must be activated (\rightarrow page 214).
- For several or all regions (manual map update)

The map data will first be downloaded onto a storage medium and then updated on the multimedia system.

Further information on the online map update https://www.mercedes.pro.

Overview of map data

Your vehicle is supplied with map data at the factory. Depending on the country, map data for your region is either pre-installed or the map data is supplied on a data storage medium.

If the map data on your vehicle has been installed at the factory and you wish to reinstall it, you do not need to enter the activation code.

For map data that you have purchased in the form of a data storage medium, you must enter the accompanying activation code.

(i) If you save the map data on a data storage medium with the online map update service, no entry is required. The activation code is stored on the data storage medium during the downloading process.

Observe the following when entering the activation code:

- The activation code can be used for one vehicle
- The activation code is not transferable
- The activation code has six digits

In the event of the following problems, please contact an authorized Mercedes-Benz Center:

- The multimedia system does not accept the activation code
- You have lost the activation code

Displaying the compass

Multimedia system:

→ 🙀 → Navigation → 📝 → Position

Select Compass.

The compass display shows the following information:

- the current direction of travel with bearing (360° format) and compass direction
- longitude and latitude coordinates in degrees, minutes and seconds
- height (rounded)
- number of GPS satellites from which a signal can be received

Setting the map scale automatically

Multimedia system:

→ 🚡 >> Navigation >> 💍 Advanced

- Select View.
- Select Map Orientation.
- Activate Auto Zoom.

The display button is activated. The map scale is set automatically depending on your driving speed and the type of road.

(i) The automatically selected map scale can be changed manually. After a few seconds, this is automatically reset.

Displaying the satellite map

Multimedia system:

→ 🔝 **>>** Navigation **>>** 🔘 Advanced

- Select View.
- Select Map Elements.

Activate or deactivate Satellite Map. If the display button is activated, satellite maps are displayed in map scales from 2 mi (2 km).

If the display button is deactivated, satellite maps are not displayed in map scales from 2 mi (2 km) to 20 mi (20 km).

(i) The satellite maps for these map scales are not available in all countries.

Showing the range Requirements:

. The function is available.

Multimedia system:



- Advanced
- Select View.
- Select Map Elements.
- Activate Range.

The display button is activated.

The range on the map is shown in green for gasoline and diesel vehicles.

When the lower reserve capacity is reached then the range display on the map is switched off.

(i) The range display on the map is not available in all countries.

Displaying weather information and other map contents Requirements:

- You have a user account with Mercedes PRO connect.
- The service is available.
- The service has been activated.

Multimedia system:



- Select View.
- Select Map Elements.
- Scroll up and show the ONLINE MAP CON-TENT category.

The available services are displayed. The services are provided by Mercedes PRO connect.

Switch on a service, e.g. Weather. Current weather information is displayed on the navigation map, e.g. temperature or cloud cover. The service information is not shown in all map scales, e.g. weather symbols.

Further information about available services and about displaying information in the map scales: https://www.mercedes.pro

The services are not available in every country.

Parking service

Notes for the parking service

▲ WARNING Risk of accident and injury due to not observing the maximum permitted access height

If the vehicle height exceeds the maximum permitted access height for parking garages and underground parking lots, the vehicle roof as well as other vehicle parts could be damaged.

There could be a risk of injury to the vehicle occupants.

- Before driving into a parking garage or underground parking lot observe the locally signposted access height.
- If the vehicle height, including any additional equipment, exceeds the maximum permitted access height, do not drive into the parking garage or underground parking lot.

This service is not available in all countries.

Selecting parking options

NOTE Before selecting the parking option

The data is based on information provided by the respective service provider.

Mercedes Benz accepts no liability for the accuracy of the information provided relating to the parking garage/parking lot.

Always observe the local Information and conditions.

Requirements:

• The navigation services option is available, subscribed to and activated in the Mercedes PRO portal.

The parking service is within the scope of the navigation service.

Parking is activated (→ page 241).

Multimedia system:

→ 🔝 **>>** Navigation

- Tap on P on the map.
- Select a parking option.

The map shows the parking options in the vicinity.

The following information is displayed (if available):

- · Destination address, distance from current vehicle position and arrival time
- Information on the parking garage/parking facility

For example, opening times, parking charges, current occupancy, maximum parking time, maximum access height.

The maximum access height shown by the parking service does not replace the need for observation of the actual circumstances.

- Available payment options (Mercedes pay, coins, bank notes, cards)
- Details on parking tariffs
- Number of available parking spaces
- · Payment method (e.g. at the parking machine)
- Services/facilities at the parking option
- Telephone number
- Calculate the route (→ page 222).

The following functions can also be selected (if available):

- · Search for POIs in the vicinity.
- Save the destination.
- · Place a call at the destination.
- Share the destination using NFC or QR code.
- Call up the web address.
- Show the destination on the map.

Displaying parking options on the map Requirements:

• The navigation services option is available. subscribed to and activated in the Mercedes PRO portal.

The parking service is within the scope of the navigation service.

Multimedia system:



Activate Parking.

The display button is activated. The parking options within the vicinity of the current vehicle position are shown.

Telephone

Telephony

Telephone menu overview



- Bluetooth® device name of the currently connected mobile phone/the mobile phones
- Bluetooth® device name of the currently connected mobile phone/the mobile phones (two phone mode)
- Battery status of the connected mobile phone
- Signal strength of the mobile phone network
- Options
- O Device manager
- Messages
- Numerical pad
- Contact search

Bluetooth® profile overview

Bluetooth® profile of the mobile phone	Operation
PBAP (Phone Book Access Profile)	Contacts are automatically displayed in the multimedia system
MAP (Message Access Profile)	Message functions can be used

Telephony operating modes overview

The following telephone operating modes are available:

- One mobile phone is connected to the multimedia system via Bluetooth[®] (→ page 243).
- Two mobile phones are connected with the multimedia system via Bluetooth[®] (two phone mode).
 - You can use all the functions of the multimedia system with the mobile phone in the foreground.
 - You can receive incoming calls and messages with the mobile phone in the background.

You can interchange the mobile phone in the foreground and background any time $(\rightarrow page 244)$.

Irrespective of this, Bluetooth® audio functionality can by used with any mobile phone
(→ page 263).

Notes on telephony

▲ WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paving attention to road and traffic conditions and operate the equipment with the vehicle stationary.
- WARNING Risk of an accident from operating mobile communication equipment while the vehicle is in motion

Mobile communications devices distract the driver from the traffic situation. This could also cause the driver to lose control of the vehicle.

- As the driver, only operate mobile communications devices when the vehicle is stationary.
- As a vehicle occupant, only use mobile communications devices in the areas intended for this purpose, e.g. in the rear passenger compartment.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

Further information can be obtained from an authorized Mercedes-Benz Center or at: https:// www.mercedes-benz-mobile.com/

Information on telephony

The following situations can lead to the call being disconnected while the vehicle is in motion:

- there is insufficient network coverage in the
- you move from one transmission/reception station to another and no communication channels are free

- the SIM card used is not compatible with the network available
- a mobile phone with "Twincard" is logged into the network with the second SIM card at the same time

The multimedia system supports calls in HD Voice® for improved speech quality. A requirement for this is that the mobile phone and the mobile phone network provider of the person you are calling support HD Voice®.

Depending on the quality of the connection, the voice quality may fluctuate.

Connecting a mobile phone Requirements:

- Bluetooth® is activated on the mobile phone (see the manufacturer's operating instructions).
- Bluetooth® is activated on the multimedia system (\rightarrow page 211).

Multimedia system:

¬→ 🔝 >>> Phone

Searching for a mobile phone

- Select 1.
- Select Connect New Device.

Connecting a mobile phone (authorization using Secure Simple Pairing)

- Select a mobile phone.
- A code is displayed in the multimedia system and on the mobile phone.
- If the codes match: confirm the code on the mobile phone.
- (i) For older mobile phone models, enter a one to sixteen-digit number code on the mobile phone and on the multimedia system for authorization.
- (i) Up to 15 mobile phones can be authorized on the multimedia system. Authorized mobile phones are reconnected automatically.
- (i) The connected mobile phone can also be used as Bluetooth® audio equipment $(\rightarrow page 263)$.

Connecting a second mobile phone (two phone mode)

Requirements:

At least one mobile phone is already connected to the multimedia system via Bluetooth[®].

Multimedia system:



- ► Select 🗓 .
- Select Connect New Device.
- Select the mobile phone.
- Select <Mobile phone> + <Mobile phone>. The selected mobile phone is connected to the multimedia system.

Functions of the mobile phone in two phone mode

Functions overview

mobile phone in the foreground	mobile phone in the background
Full range of functions	Incoming calls and messages
	messages

Functions of the

Interchanging mobile phones (two phone mode)

Multimedia system:



Both mobile phones are shown individually in separate tabs.

Select the tab with the desired mobile phone. The mobile phone in the tab selected is the mobile phone in the foreground.

With the exception of the telephone settings, the sub menus in the telephone menu relate to the mobile phone in the foreground. In the telephone settings, settings can be made for both mobile phones.

Changing the function of a mobile phone Multimedia system:



Activating a function

- Select .
- Select a gray symbol in the line of a mobile phone.

The corresponding function is activated.

Deactivating a function

- ► Select 🗓 .
- ▶ A function is active: select the color symbol in the line of a mobile phone.
 - The mobile phone is disconnected from the multimedia system.
- Several functions are active: select a color symbol in the line of a mobile phone. The corresponding function is deactivated.

Replacing a mobile phone

Multimedia system:

- → 🔝 >>> Phone
- ► Select 🗓 .
- No authorized mobile phone available: select Connect New Device.
- Select a mobile phone.
- Newly authorized mobile phone: confirm the number code on the mobile phone.

Using in single telephone mode

Select < Mobile phone>.

A newly authorized mobile phone is connected in single telephone mode.

If the mobile phone has already been authorized and connected in single telephone mode, it is connected again in single telephone mode.

If a mobile phone has already been authorized and connected in two phone mode with another mobile phone, it will be connected in future in single telephone mode.

Using in two phone mode

Select <Mobile phone> + <Mobile phone>. A newly authorized mobile phone is connected with the selected mobile phone in two phone mode.

If the mobile phone has already been authorized and connected in single telephone mode, it will be connected in future with the selected mobile phone in two phone mode.

If the mobile phone was previously connected with another mobile phone, this connection is canceled.

Disconnecting/de-authorizing a mobile phone Multimedia system:

- → 🔝 ➤ Phone
- Select .
- ➤ Select ••• in the line of the mobile phone.

- To disconnect: select Disconnect. If applicable, the mobile phone will be automatically reconnected when the vehicle is next started.
- To de-authorize: select Deauthorize

Information on Near Field Communication (NFC)

NFC enables short-range wireless data transfer or (re)connection of a mobile phone with the multimedia system.


The following functions are available without having authorized a mobile phone:

- Transferring a URL or a contact to be viewed in the multimedia system (see the manufacturer's operating instructions).
- · Setting up the vehicle's Wi-Fi access data via the system settings (\rightarrow page 212).

Further information can be obtained at: https:// www.mercedes-benz-mobile.com/

Using the mobile phone with Near Field Communication (NFC) Requirements:

- NFC is activated on the mobile phone (see the manufacturer's operating instructions)
- The mobile phone's screen is switched on and unlocked (see the manufacturer's operating instructions)



- Open the flap of stowage compartment 1 above the media display.
- To connect a mobile phone: hold the NFC area of the mobile phone (see manufacturer's operating instructions) on mat 2 or place the mobile phone on it.
- Follow the additional prompts on the media system display to connect the mobile phone. Connect the mobile phone in single telephone mode (→ page 243). Connect the mobile phone in two phone mode (\rightarrow page 244).

- To replace a mobile phone: hold the NFC area of the mobile phone (see manufacturer's operating instructions) on mat ② or place the mobile phone on it.
- Follow the additional prompts on the media system display to replace the mobile phone in one or two phone mode (\rightarrow page 244).
- If required, confirm the prompts on your mobile phone (see the manufacturer's operating instructions).

If you wish to charge a mobile phone without connecting it to the multimedia system, place it on the mat without first unlocking the screen.

Further information can be found at: https:// www.mercedes-benz-mobile.com/

Setting the reception and transmission vol-

Requirements:

A mobile phone is connected (→ page 243).

Multimedia system:

This function ensures optimal language quality.

- Select Volume.
- Set Reception Volume and Transmission Vol-

Further information on the recommended reception and transmission volume: https:// www.mercedes-benz-mobile.com/

Setting the ringtone

Multimedia system:

- Select Ringtones.
- Set the ringtone.
- (i) If the mobile phone supports the transfer of the ringtone, you will hear the ringtone of the mobile phone instead of that of the vehicle.

Starting/stopping mobile phone voice recognition

Requirements:

The mobile phone in the foreground is connected with the multimedia system
(→ page 243).

Starting mobile phone voice recognition

▶ Press and hold the the button on the multifunction steering wheel for more than one second.

You can use mobile phone voice recognition.

Stopping mobile phone voice recognition

- Press the sor substant on the multifunction steering wheel.
- i If a mobile phone is connected via Smartphone Integration, the voice recognition of this mobile phone is started or stopped.

Calls

Telephone operation

Multimedia system:



Making a call by entering the numbers

- ► Select :: .
- Enter a number.

Accepting a call

Select Accept.

Rejecting a call

Select Reject.

Ending a call

Select <</p>

Activating functions during a call

The following functions are available during a call:

End Call

Microphone Off

Numeric Keypad (show to send DTMF tones)

+ Add Call

Transfer to Phone (an active call in handsfree mode is transferred over to the telephone) Select a function.

Conducting calls with several participants Requirements:

- There is an active call (→ page 246).
- · Another call is being made.

Switching between calls

Select the contact. The selected call is active. The other call is on hold.

Activating a call on hold

Select the contact of the call on hold.

Conducting a conference call

Select Create Confer. Call.

The new participant is included in the conference call.

Ending an active call

- ► Select End Call.
- (i) On some mobile phones, the call on hold is activated as soon as the active call is ended.

Accepting/rejecting a waiting call Requirements:

• There is an active call (\rightarrow page 246).

If you receive a call while already in a call, a message is displayed.

Depending on the mobile phone and mobile network operator you will hear a call-waiting sound.

In addition, in two phone mode you will hear an acoustic signal when the call goes through to the other (not yet active) mobile phone.

Select Accept.
The incoming call is active.

If only one mobile phone is connected with the multimedia system, the previous call will be put on hold.

If during a call you accept a call with the other mobile phone when in two phone mode then the existing call is ended.

- ► Select Reject.
- This function and behavior depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).

Contacts

Information about the contacts menu

The contacts menu contains all contacts from existing data sources, e.g. mobile phone or data storage medium.

Depending on the data source, you have the following number of contacts:

- Permanently saved contacts: 3,000 entries
- Contacts loaded from the mobile phone: 5.000 entries per mobile phone

From the contacts menu, you can perform the following actions:

- Make a call, for example call a contact $(\rightarrow page 248)$
- Navigation (→ page 221)
- Compose messages (→ page 250)
- Additional options (→ page 248)

If a mobile phone is connected to the multimedia system (→ page 243) and automatic calling up $(\rightarrow page 247)$ is activated, the mobile phone's contacts are displayed in the address book.

The multimedia system can show suggestions based on frequently used contacts as well as incoming and outgoing calls (\rightarrow page 204). These are shown at the top of the contact list.

Downloading mobile phone contacts

Multimedia system:



Select Contacts & Recent Calls.

Automatically

To switch on Synchronize Contacts Automatically: activate the display button.

Manually

- To switch off Synchronize Contacts Automatically: deactivate the display button.
- Select Synchronize Contacts.

Calling up contacts

Multimedia system:



The following options can be used to search for contacts:

- · searching by initials
- · searching by name
- · searching by phone number

- Enter characters into the search field.
- Select the contact.

Details for the contact are shown.

A contact can contain the following details:

Phone numbers

Telephone numbers can be saved as global favorites (\rightarrow page 204).

- Navigation addresses
- Geo-coordinates
- Internet address
- F-mail addresses
- Relation (if set)
- Information on messenger services

Editing the format of a contact's name Multimedia system:

¬→ 🔝 ▶ Phone ▶ 🦁

Select General.

Select Name Format.

The following options are available:

- · Last Name, First Name
- Last Name First Name
- First Name Last Name
- Select an option.

Overview of importing contacts

Contacts from various sources

Source	Requirements:
USB device	The USB device is connected with the USB port.
■* Bluetooth® connection	If the sending of vCards via Bluetooth® is supported, vCards can be received on mobile phones or netbooks, for example. Bluetooth® is activated in the multimedia system and on the respective device (see the manufacturer's operating instructions).

Importing contacts into the contacts menu Multimedia system:

→ 🔝 → Phone → 🐧

>> Import Contacts

- Select a mobile phone <device name>, from which the contacts should be imported.
- Select an option.

Saving a mobile phone contact

Multimedia system:

- Select ____ in the line of the mobile phone contact.
- ► Select ···..
- Select Save to Vehicle.
- Select Yes.

The contact saved in the multimedia system is identified by the formula symbol.

Calling a contact

Multimedia system:

→ 🔝 >> Phone >> 🏨

- Select Search for Contacts.
- Enter characters into the search field.
- Select the contact.
- Select the telephone number.
 The number is dialed.

Selecting further options in the contacts menu

Multimedia system:

→ 🔝 >> Phone >> 🎎

- Select in the line of the contact.
- ➤ Select •••.

Depending on the stored data, the following options are available:

- Add Voice Tag/Delete Voice Tag
- Set Relationship/Delete Relationship
- Send DTMF Tones (for a number with DTMF tones)

The function is available when a call is active.

Select an option.

Selecting options for suggestions in the contacts menu

Requirements:

- A profile has been created (→ page 202).
- The Allow Contact Suggestions setting is switched on (→ page 204).

Multimedia system:

→ 🔝 >>> Phone

- ► Select : Recent Calls.
- Select in the line of a suggested contact.

The following options are available:

Save as Favorite

The suggestions are saved as global favorites and do appear on the home screen.

- No Longer Suggest
- Select an option.

Deleting contacts Requirements:

- The contacts are saved in the vehicle.
- To delete an individual contact, this has been imported manually into the vehicle.

Multimedia system:

¬→ 🔝 >> Phone

Deleting all contacts

- Select 👸 .
- Select General.
- Select Delete Contacts.
- Select an option.

Deleting a contact

- Select .
- ➤ Select > in the line of the contact.
- ➤ Select ····.
- Select Delete Contact.
- Select Yes.

Saving a contact as a favorite

Multimedia system:

→ 🔝 ▶ Phone ▶ + Add Favorites

- Select a contact.
- Select in the line of the contact.
- Select the telephone number. The contact is stored as a favorite in the telephone menu overview.

Deleting favorites in the telephone menu overview

Multimedia system:



- Select a favorite in the telephone menu overview (\rightarrow page 248).
- Press and hold the favorite.
- Select Delete.
- Select Yes.

Deleting all favorites

- Tap on in the media display.
- Select Phone.
- Select 🙍 .
- Select the connected phone.
- Select Contacts & Recent Calls.
- Select Do you want to delete all favorites?.
- Select Yes.

Call list

Overview of the call list

Depending on whether your mobile phone supports the PBAP Bluetooth® profile or not, this can have different effects on the presentation and functions of the call list.

If the PBAP Bluetooth® profile is supported, the effects are as follows:

- The call lists from the mobile phone are displayed in the multimedia system.
- When connecting the mobile phone, you may have to confirm the connection for the PBAP Bluetooth® profile.

If the PBAP Bluetooth® profile is not supported, the effects are as follows:

- The multimedia system generates a call list independently as soon as calls are made in the vehicle.
- The call list is not synchronized with the call lists in the mobile phone.

The multimedia system can show suggestions based on frequently used contacts as well as incoming and outgoing calls (\rightarrow page 204). These are shown at the top of the call list.

Making a call from the call list

Multimedia system:

¬→ 🚡 >> Phone

- ▶ Select : Recent Calls.
- Select an entry.
 - The call is made.

Calling up additional options in the call list Multimedia system:



- Select □ Recent Calls.
- For previously stored contacts: select \(\rightarrow \) in the line of an entry.

The search results are displayed.

For contacts who have not been stored: select .

Selecting options for suggestions in the call

Requirements:

- A profile has been created (→ page 202).
- The Allow Contact Suggestions setting is switched on (\rightarrow page 204).

Multimedia system:



- ▶ Select : Recent Calls.
- Select in the line of a suggested entry.

The following options are available:

- Save as Favorite
- No Longer Suggest
- Select an option.

Deleting the call list

Multimedia system:



- Select Contacts & Recent Calls.
- Select Delete Recent Calls.
- Select Yes.
- (i) This function is only available if your mobile does not support the PBAP Bluetooth® profile.

Text messages

Overview of the messaging functions

In the messages menu you can receive and send text messages.

If the connected mobile phone supports the Bluetooth® MAP profile, the message function can be used on the multimedia system.

You can obtain further information about settings and supported functions of Bluetooth®-capable mobile phones from an authorized Mercedes-Benz Center or at: https://www.mercedes-benz-mobile.com/

Some mobile phones require further settings after being connected to the multimedia system (see manufacturer's operating instructions).

Setting the message display

Multimedia system:



Select Message Display.

The following options are available:

- All Messages
- New and Unread Messages
- · Messages While Driving
- Off (the message function is no longer available.)
- Select a setting.

Reading messages

Multimedia system:



Using the read-aloud function

- Select a contact.
- Select (read aloud. The message is read aloud.

Dictating and sending a new message Requirements:

• There is an Internet connection.

Multimedia system:



Select a new message

Adding a recipient

- Select (+).
- Select a contact.

Dictating text

 Say the message.

After the voice message has been processed, it is shown as text.

Sending a message

- Select Send.
- (i) When the vehicle is stationary you can use the keyboard to write a message. No Internet connection is required to use the keyboard.

Replying to a message in the messaging history

Multimedia system:



A message list is shown.

- ➤ Select next to a contact.

 The messaging history with the contact is opened.
- Select . The dictating function is started.
- Say the message.
 After the voice message has been processed, it is shown as text.
- Select Send.

Using message templates

Multimedia system:



Using a template as a new message

- Select to write a new message.
- Add a recipient using (+).
- Select a template = ...

Answering a message with a template

- Select a message sequence with a contact.
- Select the symbol.
- Select a template = ...

Forwarding a message

Multimedia system:



A message list is shown.

- Select next to a contact. The messaging history with the contact is opened.
- Press and hold on a message.
- To forward a message: select Forward.

Calling a message sender

Multimedia system:



A message list is shown.

- Select > next to a contact. The messaging history with the contact is opened.
- Select
- Select Call.

Using telephone numbers or URLs from a text message

Requirements:

• An Internet connection is available to call up a URL.

Multimedia system:



A message list is shown.

- Select \rightarrow next to a contact. The messaging history with the contact is opened.
- Select a telephone number or a URL in the message.

If a URL is selected the web browser opens. If a telephone number is selected the following options are available:

- Call
- Write New Text Message
- Select an option.

Deleting a message

Multimedia system:



- Select a contact.
- Press and hold on a message.
- To delete the message: select Delete.

Apple CarPlay®

Overview of Apple CarPlay®



WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

iPhone® functions can be used via the multimedia system using Apple CarPlay®. They are operated using the touchscreen, Touch Control or the Siri® voice-operated control system. You can activate the voice-operated control system by pressing and holding the we button on the multifunction steering wheel.

When using Apple CarPlay® via the voice-operated control system, the multimedia system can still be operated via the Voice Control System $(\rightarrow page 184)$.

Only one mobile phone at a time can be connected via Apple CarPlay® to the multimedia system.

Also for use of Apple CarPlay® with two phone mode, only one additional mobile phone can be connected using Bluetooth® with the multimedia system.

The availability of Apple CarPlay® may vary according to the country.

The service provider is responsible for this application and the services and content connected to

Apple CarPlay® is a registered trademark of Apple Inc.

Information on Apple CarPlay®

When Apple CarPlay® is being used, the iPod® media source is not available for the respective iPhone®.

Only one route guidance can be active at a time. If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

Connecting an iPhone® via Apple CarPlay® Requirements:

- The current version of your device's operating system is being used (see the manufacturer's operating instructions).
- The full range of functions for Apple CarPlay® is only available with an Internet connection.
- The iPhone® is connected to the multimedia system via the USB port using a suitable cable (\rightarrow page 262).

Multimedia system:

- → Mercedes PRO & Apps
- ➤ Smartphone ➤ Apple CarPlay
- >> Start Apple CarPlay
- Alternative: If an Apple CarPlay® application is active (e.g. when music is being played or route guidance is active), you can call up the active application using the RADIO , NAVI or TEL application buttons (\rightarrow page 201).

Accepting/rejecting the data protection provisions

For the initial start of the application: a message with the data protection provisions appears.

Select Accept & Start.

Exiting Apple CarPlay®

- Press the 命 button.
- (i) Apple CarPlay® starts automatically when the iPhone® is connected with the system using a cable. If Apple CarPlay® was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Apple CarPlay® in the main menu.

Calling up Apple CarPlay® sound settings Multimedia system:

- → Mercedes PRO & Apps
- Smartphone → Apple CarPlay →
- Select sound settings.

Setting control of the application buttons Multimedia system:

- → Mercedes PRO & Apps
- Smartphone → Apple CarPlay →
- ▶ General
- To switch on Control via Application Buttons: activate the display button.
- To switch off Control via Application Buttons: deactivate the display button.

Ending Apple CarPlay®

- To end the connection of Apple Car-Play®(cable): disconnect the connection via the connecting cable between the iPhone® and multimedia system.
- (i) Mercedes-Benz recommends disconnecting the connecting cable only when the vehicle is stationary.

Android Auto

Android Auto overview

▲ WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Mobile phone functions can be used with Android Auto using the Android operating system on the multimedia system. It is operated using the touchscreen or the voice-operated control system. You can activate the voice-operated control system by pressing and holding the we button on the multifunction steering wheel.

When using Android Auto via the voice-operated control system, the multimedia system can still be operated via the Voice Control System $(\rightarrow page 184)$.

Only one mobile phone at a time can be connected via Android Auto to the multimedia system.

This also applies to two phone mode.

The availability of Android Auto and Android Auto apps may vary according to the country.

The service provider is responsible for this application and the services and content connected to

Information on Android Auto

While using Android Auto, various functions of the multimedia system, for example the media source Bluetooth® audio, are not available.

Only one route guidance can be active at a time. If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

Connecting a mobile phone via Android Auto Requirements:

- The mobile phone supports Android Auto from Android 5.0
- The Android Auto app is installed on the mobile phone.
- In order to use the telephone functions, the mobile phone must be connected to the multimedia system via Bluetooth® (→ page 243). If there was no prior Internet connection, this is established with the use of the mobile phone with Android Auto.
- The mobile phone is connected to the multimedia system via the USB port using a suitable cable (\rightarrow page 262).
- There is an Internet connection for the full. range of functions for Android Auto.

Multimedia system:

- → Mercedes PRO & Apps
- >> Smartphone >> Android Auto
- >> Start Android Auto
- Alternative: If Android Auto is active (e.g. when music is being played or the navigation system is being used), you can call up the application using the RADIO , NAVI OF TEL buttons (\rightarrow page 201).
- (i) The first activation of Android Auto on the multimedia system must be carried out when the vehicle is stationary for safety reasons.

Accepting/rejecting the data protection provisions

A message with the data protection provisions appears.

- Select Accept & Start.
- (i) The first activation of Android Auto on the multimedia system must be carried out when the vehicle is stationary for safety reasons.

Exiting Android Auto

- Press the 命 button.
- (i) Android Auto starts automatically when the mobile phone is connected with the system using a cable. If Android Auto was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Android Auto in the main menu.

Calling up the Android Auto sound settings Multimedia system:

- → Mercedes PRO & Apps
- Smartphone → Android Auto →
- Select sound settings.

Setting control of the application buttons Multimedia system:

- → Mercedes PRO & Apps
- Smartphone → Android Auto →
- **▶>** General
- ► To switch on Control via Application Buttons: activate the display button.
- To switch off Control via Application Buttons: deactivate the display button.

Ending Android Auto

Disconnect the connecting cable between the mobile phone and multimedia system. Mercedes-Benz recommends disconnecting the connecting cable only when the vehicle is stationary.

Transferred vehicle data with Android Auto and Apple CarPlay®

Overview of transferred vehicle data

When using Android Auto or Apple CarPlay®, certain vehicle data is transferred to the mobile phone. This enables you to get the best out of selected mobile phone services. Vehicle data is not directly accessible.

The following system information is transmitted:

- software release of the multimedia system
- system ID (anonymized)

The transfer of this data is used to optimize communication between the vehicle and the mobile phone.

To do this, and to assign several vehicles to the mobile phone, a vehicle ID is randomly generated.

This has no connection to the vehicle identification number (VIN) and is deleted when the multimedia system is reset (\rightarrow page 215).

The following vehicle status data is transmitted:

- · transmission position engaged
- · distinction between parked, standstill, rolling and driving
- day/night mode of the instrument cluster

The transfer of this data is used to alter how content is displayed to correspond to the driving situation.

The following position data is transmitted:

- coordinates
- speed
- compass direction
- acceleration direction

This data is only transferred while the navigation system is active, in order to improve it (e.g. so it can continue functioning when in a tunnel).

Online and Internet functions Internet connection

Information on connecting to the Internet

▲ WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road

and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

WARNING Risk of an accident from operating mobile communication equipment while the vehicle is in motion

Mobile communications devices distract the driver from the traffic situation. This could also cause the driver to lose control of the vehicle.

- As the driver, only operate mobile communications devices when the vehicle is stationary.
- As a vehicle occupant, only use mobile communications devices in the areas intended for this purpose, e.g. in the rear passenger compartment.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

Depending on the vehicle's equipment, you can establish an Internet connection in the following

- Vehicles with a communication module: Internet use including Mercedes PRO connect services and data roaming (\rightarrow page 254). The availability of Mercedes PRO connect is country-dependent. You can check the availability of Mercedes PRO in your country at the
- following page: http://www.mercedes.pro Vehicles without a communication module:
 - via Bluetooth® with a data-enabled mobile phone (\rightarrow page 255)
 - via Wi-Fi with a data-enabled mobile phone (\rightarrow page 255)

The Internet functions can only be used to a limited degree whilst driving.

Internet function via the communication module

On vehicles with a built-in communication module, the Internet connection is established via an integrated SIM card.

To use the Internet function, the vehicle must be equipped with a permanently installed communications module

(i) For most Mercedes PRO connect services. data volume is available when purchasing the service.

Additional data volume is required for the "Internet in the car" service and the associated use of web browsers. Internet Radio or the Wi-Fi hotspot. This can be purchased directly from the mobile phone network provider (\rightarrow page 255).

Contact an authorized Mercedes-Benz Center to find out whether it is possible to purchase data volume in your country.

Purchasing data volume

- To use a Wi-Fi hotspot or the multimedia system web browser: connect the mobile end device with the vehicle hotspot $(\rightarrow page 212)$.
- Register on the website of the mobile phone network provider (only for first booking).
- Book data volume using the mobile end device.

The Internet browser, Internet Radio and Wi-Fi hotspot can be used if data volume is available.

Setting up an Internet connection via Wi-Fi without a communication module Requirements:

- The Wi-Fi function is activated on the multimedia system (\rightarrow page 211).
- The Wi-Fi function is activated on the external device (see the manufacturer's operating instructions).
- Internet access via Wi-Fi is activated (see the manufacturer's operating instructions).

The Internet connection via Wi-Fi is restricted or does not function if:

- The mobile phone is switched off.
- Mobile data use is deactivated on the mobile phone.
- The Wi-Fi function is deactivated on the multimedia system.
- · The Wi-Fi function is deactivated on the external device.
- Internet access via Wi-Fi is deactivated on the external device.

Multimedia system:

- → Settings → System
- Wi-Fi & Bluetooth → Internet Settings
- Connect via Wi-Fi
- Select the network.
- ▶ Log in to a Wi-Fi network (\rightarrow page 211).

Setting up an Internet connection via Bluetooth® without a communication module Requirements:

- The mobile phone support the Bluetooth® profile PAN (Personal Area Network).
- The mobile phone is connected to the multimedia system via Bluetooth[®] (\rightarrow page 243).

The Internet connection via Bluetooth® is restricted or does not function if:

- The mobile phone is switched off.
- The mobile phone is connected a an additional mobile phone.
- The mobile phone network coverage is insufficient.
- Mobile data use is deactivated on the mobile phone.
- The Bluetooth® function on the multimedia system is switched off and the mobile phone is to be connected via Bluetooth®.
- The Bluetooth® function is switched off on the mobile phone and the mobile phone is to be connected via Bluetooth®.
- Neither the mobile phone network nor the mobile phone allow simultaneous use of a phone and an Internet connection.
- The mobile phone has not been enabled for Internet access via Bluetooth®.

If a mobile phone is connected to the multimedia system for the first time via Bluetooth®, you will be assisted through the process of setting up an Internet connection.

The Internet connection can also be configured manually.

Further information can be obtained at https:// www.mercedes-benz-mobile.com/ or at an authorized Mercedes-Benz Center.

Multimedia system:

- → 🔝 >> Settings >> System
- >> Wi-Fi & Bluetooth >> Internet Settings
- >> Connect via Bluetooth
- Select the mobile phone.
- The Internet connection is established.

Establishing an automatic Internet connection

Multimedia system:

- → 🔝 >> Settings >> Wi-Fi & Bluetooth
- >> Internet Settings
- Highlight the mobile phone.
- ➤ Select >.
- Activate Permanent Internet Connection.

Canceling Internet access permission for a mobile phone

Multimedia system:

- → Settings → System

 → Wi-Fi & Bluetooth → Internet Settings
- ► Select in the line of the mobile phone.
- ► Select Delete Configuration.
- Select Yes.

Displaying mobile phone details

Multimedia system:

- → Settings → System
- ➤ Wi-Fi & Bluetooth ➤ Internet Settings
- ➤ Select ∑ in the line of the mobile phone.
- Select Details.

Using an Internet connection with web browsers

Multimedia system:

- → 🔝 **>>** Mercedes PRO & Apps
- Select Browser, for example.
- i The multimedia system usually establishes the Internet connection automatically. If the multimedia system is not connected to the Internet, the Internet connection is established when an Internet application is used.

Setting automatic disconnection of the Internet connection without a communication module

Multimedia system:

- → 😭 >> Settings >> System
- ▶ Wi-Fi & Bluetooth ▶ Internet Settings
- ➤ Select ∑ in the line of the mobile phone.
- Select Disconnect When Inactive.

The following options are available:

- 5 Minutes
- 10 Minutes
- 20 Minutes
- Unlimited
- Select an option.

Connection status

Connection status overview



 Display of existing connection and reception field strength of the communication module or of the connected Bluetooth® device

Displaying the connection status

Multimedia system:

→ Settings → System

- >> Wi-Fi & Bluetooth
- Select Internet Status.
- i In the case of a connection via the communication module the following status information is shown:
 - Type of network
 - Status online/offline

Web browser

Calling up a website



▲ WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Requirements:

• The data volume is available (\rightarrow page 255).

Multimedia system:

→ MERCEDES PRO & APPS **▶ S** Browser


Calling up a new website

- Select URL.
- Entering a web address
- Select ok .
- (i) Websites cannot be shown while the vehicle is in motion.

Calling up a website from the browser history

- To call up the previous or next page from the history: select ← or →.
- (i) The function is country-dependent.

Web browser overview



- URL entry
- Bookmarks
- Web page, back
- Web page, forwards
- To refresh/stop
- Options

Calling up web browser options

Multimedia system:

► MERCEDES PRO & APPS

Browser ► ○

The following functions are available:

- Bookmarks
- · Options with the settings:
 - Browser Settings
 - Delete Browser Data
- Select an option.
- Change the settings.

Calling up the web browser settings

Multimedia system:

→ MERCEDES PRO & APPS

- **▶** Browser **▶** □
- ▶ Browser Settings

The following functions are available:

- Block Pop-ups
- · Activate Javascript
- Allow Cookies

- To switch a function on: activate the display button.
- To switch a function off: deactivate the display button.

Deleting Internet history

Multimedia system:

→ MERCEDES PRO & APPS

▶ Browser

>> Delete Browser Data

The following options are available:

- All
- Cache
- Cookies
- Entered URLs
- Form Data
- Select an option.
- Select Yes.

Managing bookmarks

Multimedia system:

→ MERCEDES PRO & APPS

▶ Select .

Selecting a bookmark

Select an entry.

Creating a bookmark

Select Add Current Page to Bookmarks.

- Enter a name.
- Select Bestätigen (Confirm).

Editing a bookmark

- Select after a bookmark.
- Select Edit.
- Enter a name.
- Select Bestätigen (Confirm).

Deleting a bookmark

- Select after a bookmark.
- Select Delete.
- Select Yes.

Closing the browser

Multimedia system:

- → MERCEDES PRO & APPS
- Select 分.

TuneIn Radio

Calling up TuneIn Radio Requirements:

- . The TuneIn Radio service is activated in the Mercedes me portal.
- The data volume is available.
 - Depending on the country, data volume may need to be purchased.
- · A fast Internet connection for data transmission free of interference.
- (i) New data volume can be purchased directly from a mobile phone network provider via the Mercedes me Portal.
- (i) The functions and services are countrydependent. For more information, consult an authorized Mercedes-Benz Center.

Multimedia system:



Select TuneIn Radio.

The TuneIn Radio menu appears. The last station set starts playing.

(i) The connection quality depends on the local mobile phone reception.

TuneIn Radio overview



- Additional information on the current station.
- Display (if connected to private user account)
- Oata transfer rate
- Options
- 6 Favorites
- To start/end
- To browse
- Station search
- Selected category
- Internet radio provider

Selecting and connecting to TuneIn Radio stations

Multimedia system:



- Select a category.
- Select a station.
 The connection is established automatically.

or

- Select the search field.
- Enter a station name using the entry field.
- i A relatively large volume of data can be transmitted when using TuneIn Radio.

Saving/deleting TuneIn Radio stations as favorites

Multimedia system:

- → 🔝 **>>** Radio **>>>** TuneIn Radio
- Select a station.

➤ Select ★.

The list of saved favorite stations appears.

Select Add to favorites.

or

Create an account for the online provider (TuneIn Radio) and then log in on the multimedia system.

Your favorites are imported to the multimedia system.

Deleting favorites

- Select a station.
- ➤ Select ★.
- Select Delete favorites.

Setting TuneIn Radio options

Multimedia system:

→ 🔝 → Radio → Tuneln Radio → 💍

The following options are available:

- · Select Stream: select the stream quality.
- Login to TuneIn Account: log in to your TuneIn user account.
- Log Out of Account: log out of your TuneIn user account.
- Select an option.

Calling up the station list for the category last selected

Multimedia system:

→ 🕝 >> Radio >>> TuneIn Radio

Press the cover of the current station. Depending on how the station was selected, a station list is shown.

Media

Information about media mode

Information about supported formats and data storage media

WARNING Risk of distraction when handling data storage media

If you handle a data storage medium while driving, your attention is diverted from the traffic conditions. This could also cause you to lose control of the vehicle.

- Only handle a data storage medium when the vehicle is stationary.
- (i) Depending on the equipment installed playback of video formats may not be possible.

The multimedia system supports the following formats and data media:

Permissible file systems	FAT32, exFAT, NTFS
Permissible data carriers	USB devices, iPod®/iPhone®, MTP devices, Bluetooth® audio equipment
Supported formats:	Audio: MP3, WMA, AAC, WAV, FLAC, ALAC Video: MPEG, AVI, DivX, MKV, MP4, M4V, WMV

- · The multimedia system supports a total of up to 50,000 files.
- Data storage media up to 2 TB are supported (32-bit address space).
- (i) Observe the following notes:
 - Due to the large variety of available music and video files regarding encoders, sam-

- pling rates and data transfer rates, playback cannot be guaranteed.
- Due to the wide range of USB devices available on the market, playback cannot be guaranteed for all USB devices.
- Videos up to FullHD (1920x1080) are supported.
- Copy-protected music and video files or DRM (Digital Rights Management) encrypted files cannot be played back.
- MP3 players must support Media Transfer Protocol (MTP).

Information on copyright protection and trademarks

Audio files that you create or reproduce yourself for playback are generally subject to copyright protection. In many countries, reproductions, even for private use, are not permitted without the prior consent of the copyright holder. Make sure that you know about the applicable copyright regulations and that you comply with these.




Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.



Gracenote, the Gracenote logo and logotype, "Powered by Gracenote", MusicID and Playlist Plus are either registered trademarks or trademarks of Gracenote, Inc. in the United States and/or other countries.

Overview of the media menu



- Previous track or fast rewind
- Next track or fast forward
- 3 Album cover
- Active media source
- Track and artist
- Current track number/track in playback list and active data storage medium
- Repeat
- Settings
- Additional options
- Controls playback
- Timeline
- Categories
- Search
- Random playback


Connecting the data storage media to the multimedia system

Connecting USB devices

NOTE Damage caused by high temperatures

High temperatures can damage USB devices.

Remove the USB device after use and take it out of the vehicle.



The multimedia connection unit is found in the stowage compartment in the center console and has two type C USB ports.

- Connect the USB device to the USB port.
- (i) When connecting several Apple® devices simultaneously, pay attention to the order in which the devices are connected. The multimedia system only connects with the device that is connected first. Additional Apple® devices that are connected at the same time are only supplied with power.

Searching for and authorizing a Bluetooth® audio device

Requirements:

- Bluetooth® is activated on the multimedia system and audio equipment.
- The audio equipment supports the Bluetooth[®] audio profiles A2DP and AVRCP.
- The audio equipment is "visible" for other devices.

Multimedia system:



Authorizing a new Bluetooth® audio device

- Select Connect New Device. Detected equipment is displayed in the device list.
- Select an audio device. Authorization starts. A code is displayed on the multimedia system and on the mobile
- If the codes are identical, confirm on the audio equipment.
- Select Only as Bluetooth Audio Device. The Bluetooth® audio equipment is connected with the multimedia system.

Connecting previously authorized Bluetooth® audio equipment

Select a Bluetooth® audio device from the list The connection is established.

Starting media playback

A data storage medium is connected to the multimedia system.

Multimedia system:

→ 🔝 **>>** Media

Select USB or Bluetooth as the media source.

Controlling media playback

Multimedia system:

→ 🔝 >> Media

To pause playback: select | | | |.

To continue playback: select ▶.

To repeat a track: select 17.

For the repeat function there are the following settings:

- Select once: the active playlist is repea-
- Select twice: the current track is repeated.
- Select three times: the repeat function is deactivated.
- To play back tracks in random order: select 🔀.
- To wind a track forwards or backwards: tap on the desired point on the timeline.
- To select the next track: select .
- To select the previous track: select | .
- To scroll through tracks quickly: press and hold or D.
- To show the current track list: select the track image shown.

Additional options for setting media playback

Multimedia system:

→ 🔝 🕨 Media

Calling up additional options

Select 1.

The additional options are shown.

The following options are available:

Plav Similar Tracks

Select during playback of a track in order to create a playlist with similar tracks.

Surprise Mix

A playlist with randomly selected tracks is created.

Add to Favorite Songs

The current track is added to the favorite songs.

Remove from Favorite Songs

The current track is removed from the favorite songs.

Select an option.

Media search

Information about the search function in categories

Under you can search through all available media files. There are several categories available for selection. The categories shown depend on the connected device and data format.

Available categories with Bluetooth® audio equipment:

Current Tracklist

The folders and categories of the connected device are shown.

Available categories with audio files:

- Current Tracklist
- Playlists
- Folder
- Albums
- Artists
- Tracks
- Favorite Songs
- Often Plaved
- · Most Recently Added
- Mood(\rightarrow page 264)
- Music Genres
- Year
- Composers
- · Select By Cover
- Podcasts (Apple[®] devices)
- Audiobooks (Apple[®] devices)

Available categories with video files:

- Folder
- Videos
- (i) The categories are available as soon as the entire media content has been read in and analyzed.

Starting a search in categories

Multimedia system:



Select a category.

The media files are shown corresponding to the selected category, e.g. all albums will be shown for the Albums category.

Sorting results shown or playing back all media found

- Select
- To play back all results found in the categorv: select Play All.

If, for example, the album category is active, all albums found by the desired artist will be played back.

- To sort results alphabetically: select Sort from A-Z.
- To sort results in reverse alphabetical order: select Sort from Z-A.
- (i) The available options depend on the selected category and the connected device.

Using the keyword search

Multimedia system:



In the categories under [] you can use the keyword search with free text input to look for content.

- Select a category.
- Select Search.

A keyboard for character entry appears.

- Enter the term searched for.
- (i) The search begins with the first character entered. The more characters entered the more concrete the search results become.
- Select the desired entry from the result list. If the selected result is an album, song or a playback list then playback is started. If the selected result is a new category then this is opened in the search.

Searching for a track according to mood

Multimedia system:



Using the My Music search, you can find music tracks suitable for a mood.

Select Mood.

A grid with the following moods appears:

- Positive
- Calm
- Dark
- Energetic
- Pull the controller to the desired position. The system searches for tracks that are suitable for the mood entered.

Making video settings

Multimedia system:



- (i) Depending on the equipment installed playback of video formats may not be possible.
- Select Video Settings.
- Select an aspect ratio.

Setting full screen

▶ Select ...

Radio


Switching on the radio

Multimedia system:



Alternatively: press the RADIO button. The radio display appears. You will hear the last station played on the last frequency band selected.

Radio overview



- Station logo
- Active frequency band
- Station name or set frequency
- 4 Artist, title, album and radio text
- 6 HD radio logo
- Options
- Switches the HD radio function on or off
- Mute function
- Calls up the station list

Switching the HD radio function on/off

Multimedia system:

→ Radio → HD FM



- Switch HD on or off.
- i HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see DTS website. HD Radio and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and /or other countries.

Setting the frequency band

Multimedia system:

¬→ 🔝 >> Radio

Select a frequency band.

Selecting a radio station

Multimedia system:

¬→ 🔝 **>>** Radio

Swipe to the left or right on the control element.

Calling up the radio station list

Multimedia system:

¬→ 🚡 → Radio

► Select := .

The station list appears.

Select a station.

Searching for radio stations using station names or direct frequency entry

Multimedia system:

¬→ 🝙 → Radio

► Select := .

- ► Select 🔑 .
- Enter a station name or frequency.
- Select a station.

Storing radio stations

Multimedia system:

¬→ 🞧 >> Radio

Select a radio station.

Memory slots are available in station presets

➤ Select +.

or

Press and hold on the radio station.

Replacing an entry in the station presets

- Press and hold on an entry in the station presets.
- Select Yes.

Editing station presets

Multimedia system:

→ 🔝 >> Radio

Moving stations:

- Press and hold a stored station.
- Select Move.
- Move the station to the new position.

Deleting stations:

- Press and hold a station.
- Select Delete.

Replacing a station:

- Press and hold a station.
- ► Select Replace Radio Station.

Showing accident reports

Multimedia system:

→ 🖟 >> Radio >> 🕡

- i The availability of the function is dependent on the country.
- Switch Display Emergency Warnings on or off.

Displaying radio text

Multimedia system:

- → 🝙 >> Radio >> 👩 >> General
- Switch Display Radio Text Information on or off.

Satellite radio

Information on the satellite radio

SIRIUS XM® satellite radio offers more than 175 digital-quality radio channels providing 100% commercial-free music, sports, news and entertainment, for example, SIRIUS XM satellite radio employs a fleet of high-performance satellites to broadcast around the clock throughout the USA and Canada. The satellite radio program is available for a monthly fee. Information about this can be obtained from a Sirius XM® Service Center and at http://www.siriusxm.com (USA) or http://www.siriusxm.ca (Canada).

(i) Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. and its subsidiaries. All other marks, channel names and logos are the property of their respective owners. All rights reserved.

Limitations of satellite radio

Satellite radio mode may be temporarily unavailable or interrupted for a variety of reasons. These include environmental or topographical conditions beyond the control of Mercedes-Benz USA, LLC. Thus operation at certain locations may not be possible.

Registering satellite radio Requirements:

- · satellite radio equipment
- registration with a satellite radio provider
- if registration is not included when purchasing the system, your credit card details will be required to activate your account

Multimedia system:



- Select Service Information.
 - The service information screen appears showing the radio ID and the current subscription status.
- Establish a telephone connection.

- Follow the service staff's instructions. The activation process may take up to ten minutes
- (i) You can also have the satellite service activated online. To do so, please visit http:// www.siriusxm.com (USA) or http:// www.siriusxm.ca (Canada).

Switching on satellite radio

Multimedia system:

- ¬→ 🔝 🕪 🕴 Radio
- Select SiriusXM (SiriusXM).

Overview of the satellite radio



- Active frequency band
- Logo or album art (if available)
- Channel name
- Track information
- Channel information
- Options
- Shows or hides playback controls
- Pauses playback
- Station list
- Search

Selecting a satellite radio category

Multimedia system:



- Select
- Select Category.
- Select a category.

Selecting a satellite radio channel

Multimedia system:



Saving or deleting a satellite radio channel Multimedia system:



Storing the current channel:

- Press and hold the logo of the current station until the Options menu appears.
- Select Add to Presets.

Moving a channel

- Press and hold a channel in the presets until the Options menu appears.
- Select Move Highlighted Station.
- Move the channel to a new position.

Deleting a channel

- Press and hold a channel in the presets until the Options menu appears.
- Select Delete Highlighted Station.

Setting the parental control

Multimedia system:



- Select Parental Control.
- Determine a four-digit character sequence and select ok.

All channels with adult content are locked.

Unlocking a channel

- Enter the four-digit character sequence and select ok.
 - All channels with adult content are unlocked.

Music and sport alerts function

This function makes it possible to store a program alert for your favorite artists, tracks or sporting events. Music alerts can be saved whilst a track is being played and sport alerts can be saved during a live game. You can also specify sport alerts via the menu option. The system then continuously searches through all the channels. If a match is found with a stored alert, you will be informed.

Setting music and sport alerts

Multimedia system:

¬→ 🙀 >> † Radio >> SiriusXM Radio >> Notes

Activating the music information function

Activate Music Alerts.

Setting a music alert

- Select Add New Alert.
- Select Artists or Song in the dialog window. The alert is set for the current artist or track. If a match is found, a prompt appears asking whether you wish to change to the station.

Activating sports information

Activate Activate Sports Alerts.

Setting a sport alert

- Select Add New Alert.
- Select the team name or league in the dialog window.

Deleting individual sports and music alerts

Select Manage Music Alerts.

or

- Select Manage Sports Alerts.
- Select an artist or track.

or

- Select a team.
- Select Delete Selected Entries. All highlighted alerts are deleted.

Deleting all sports and music alerts

Select Manage Music Alerts.

or

Select Manage Sports Alerts.

Select Delete All Entries. All alerts are deleted.

Information on Smart Favorites and Tune Start

From the station presets you can set up to eight stations as Smart Favorites. Smart Favorites stations are automatically saved to temporary storage in the background. If you change to a Smart Favorites station, you can replay, pause or actively skip forward or back to broadcasts which you have missed. If Tune Start is activated and you change to another Smart Favorites station, the music track currently playing on the station is automatically restarted from the beginning of the track

Creating a TuneMix list

Multimedia system:



In order to listen to seamless music, you can put together a TuneMix list from various stations.

- Select Create TuneMix List.
- If necessary, limit the number of stations shown using the Category entry.
- Select the station shown .
- Press \(\)\to confirm. A TuneMix station logo is created in the radio menu.

Activating/deactivating TuneStart

Multimedia system:




Switch TuneStart on or off.

Switching on satellite radio playback control Multimedia system:

→ Radio → SiriusXM Radio

You can pause the playback of the current station or skip forward or backward in the timeline. This leaves live mode to access the internal temporary storage.

To show the timeline: press



- To pause playback: select .
- To return to live mode: navigate to the end of the timeline.

Displaying satellite radio service information

Multimedia system:



Select Service Information.

Sound

Sound settings

Information about the sound system

The sound system is available for all functions in the radio and media modes. The settings, for example for the equalizer, effect the playback of all media sources.

Calling up the sound menu

Multimedia system:



The following functions are available:

- Equalizer
- Balance and Fader
- · Auto. Volume Adjustment
- Select a sound menu.

Adjusting treble, mid-range and bass settings

Multimedia system:



Set TREBLE, MID or BASS.

Activating/deactivating automatic volume adjustment

Multimedia system:



Automatic volume adjustment compensates for differing volumes when changing between audio sources.

Activate or deactivate Auto. Volume Adjustment.

Adjusting the balance/fader

The availability of this function depends on the vehicle equipment.

Multimedia system:



Adjust the balance and fader.

Notes on loading guidelines

DANGER Risk of poisoning from exhaust gases

Combustion engines emit poisonous exhaust gases, such as carbon monoxide. Exhaust gases can enter the vehicle interior if the rear-end door is open when the engine is running, especially if the vehicle is in motion.

- Always switch off the engine before opening the rear-end door.
- Never drive with the rear-end door open.

WARNING Risk of injury from unsecured objects in the vehicle

When objects are unsecured or inadequately secured, they can slip, tip over or be thrown about, striking vehicle occupants.

This also applies to:

- Luggage or loads
- Seats which have been removed and are being transported in the vehicle in an exceptional case

There is a risk of injury, particularly in the event of braking maneuvers or abrupt changes in direction.

- Always stow objects in such a way that they cannot be tossed about.
- Before traveling, secure objects, luggage or load to prevent them slipping or tipping over.
- When a seat is removed, keep it preferably outside the vehicle.

WARNING Risk of injury due to objects being stowed incorrectly

If you do not adequately stow objects in the vehicle interior, they could slip or be tossed around and thereby strike vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always restrain the objects they contain in the event of an accident.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction

- Always stow objects in such a way that they cannot be tossed about in these or similar situations.
- Always make sure that objects do not project from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the cargo compartment.

WARNING Risk of burns from the tailpipe and tailpipe trims

The exhaust tailpipe and tailpipe trims can become very hot. If you come into contact with these parts of the vehicle, you could burn yourself.

- Always be particularly careful around the tailpipe and the tailpipe trims and supervise children especially closely in this area.
- Allow vehicle parts to cool down before touching them.

If you are using a roof rack, please note the maximum roof load and the maximum load capacity of the roof rack (\rightarrow page 353).

Camera-based driving systems and the sensor functions of the inside rearview mirror may be impaired if you are transporting a load on the roof and it protrudes more than 16 in (40 cm) over the front edge of the roof. Therefore, make sure that the load does not overhang by more than 16 in (40 cm).

The handling characteristics of your vehicle are dependent on the load distribution.

Therefore, please observe the following notes when loading:

- When transporting a load, never exceed the permissible gross mass or the gross axle weight rating for the vehicle (including occupants). The values are specified on the vehicle identification plate on the B-pillar.
- The load must not protrude above the upper edge of the seat backrests.
- If possible, always transport the load in the cargo compartment.

- Fasten the load to the tie-down eyes and distribute the load evenly among them.
- Use tie-down eyes and fastening components which are suitable for the weight and size of the load

Load distribution

NOTE Risk of damage to the floor covering

Excessive point loading on the cargo compartment floor or on the load area can negatively affect the driving characteristics and could damage the floor covering.

- Vehicles with rear-wheel drive: distribute the load uniformly. When doing so, ensure that the overall center of gravity of the load is always as low and close to the center as possible and between the axles near the rear axle.
- Vehicles with all-wheel drive: distribute the load uniformly. When doing so, ensure that the overall center of gravity of the load is always as low and close to the center as possible and between the axles.

For Cargo Vans, buses and Passenger Vans:

- Always transport loads in the cargo compartment.
- Always place the load against the seat backrests of the rear bench seat.
- Move large and heavy loads as far towards the front of the vehicle as possible in the direction of travel against the rear bench seat. Stow loads flush with the rear bench seat.
- Always additionally secure the load with suitable load securing aids or tie downs.
- The load must not protrude above the upper edge of the seat backrests.
- Transport loads behind seats that are not occupied.
- If the rear bench seat is not occupied, insert the seat belts crosswise into the seat belt buckle of the opposite seat belt.

Securing loads

Notes on load securing

A

WARNING Risk of accident and injury due to incorrect use of the lashing straps

If you attach the lashing strap incorrectly when securing loads, the following may occur in the event of abrupt changes in direction, braking maneuver or an accident:

- The tie-down eyes may become detached or the lashing strap may tear if the permissible load is exceeded.
- The load cannot be restrained.

This may cause the load to slip, tip over or be flung about, striking vehicle occupants.

- Always tension the lashing straps in the proper manner and only between the described tie-down eyes.
- Always use lashing straps designed specifically for the loads.
- i Observe the information relating to the maximum loading capacity of the individual cargo tie-down point. If you combine various cargo tie-down points to secure a load, always take the maximum loading capacity of the weakest cargo tie-down point into account. During maximum full-stop braking, forces may act which can multiply the weight of the load. Always use several cargo tie-down points to distribute and spread the load. Spread the load evenly between the cargo tie-down points or tie-down eyes.

Always observe the operating instructions or the lashing strap manufacturer's instructions for the operation of the lashing strap.

Observe the information relating to the maximum loading capacity of the cargo tie-down points (\rightarrow page 353).

As the driver, you are responsible for ensuring the following:

- The load is secured against slipping, tipping, rolling or falling off.
 - Take usual traffic conditions as well as swerving or full brake application and bad roads into account.
- The applicable requirements and guidelines relating to load-securing practices are met.
 If this is not the case, this may constitute a punishable offense, depending on local legis-

lation and any ensuing consequences. Observe country-specific laws.

Make sure that the load is secure before every iourney and at regular intervals during a long journey. Adjust the load securing as necessary. Information on how to secure loads correctly can be obtained from the manufacturers of load securing aids or tie downs for load-securing, for example.

When securing loads, observe the following:

- Fill spaces between the load and the cargo compartment walls or wheel wells. For this purpose, use rigid load securing aids, such as wedges, wooden fixings or padding.
- Attach secured and stabilized loads in all directions.

Use the cargo tie-down points or tie-down eyes and the loading rails in the cargo compartment or on the load surface.

Only use tie downs, such as lashing rods, lock rods or lashing nets and lashing straps, which has been tested in accordance with current standards (e.g. DIN EN). Always use the cargo tie-down points closest to the load; pad sharp

Loads, and heavy loads in particular, should preferably be secured using the tie-down eves.


(i) You can obtain tie downs tested in accordance with current standards (e.g. DIN EN) from any specialist company or from a qualified specialist workshop.

Notes on the partition

Without a partition, vehicles that are approved as commercial vehicles (N1, N2) do not fulfill ISO 27956, which describes the equipment for properly securing a load in delivery vehicles. If the vehicle is used to transport goods, retrofitting the partition is strongly recommended, as properly securing the load in vehicles without a partition will always be a complex operation.


(i) You must not store anything in the area between the back of the seats and the partition.

Overview of cargo tie-down points



Cargo tie-down points (example: Passenger Van)

Tie-down eyes



Cargo tie-down points (example: Cargo Van without loading rails)

Tie-down eves

Secure loose loads with an approved lashing net or a tarps.

Always fasten the lashing net or tarp to all available cargo tie-down points. Make sure that the fastening hooks are secured against accidental opening.

If your vehicle is equipped with loading rails in the cargo compartment floor, you can place lashing rods directly in front of and behind the load. The lashing rods directly absorb the potential shifting forces.

Securing loads on the cargo compartment floor by lashing them down is only recommended for lightweight loads. Lav anti-slip mats underneath the load to secure the load additionally.

Installing and removing tie-down eyes

- To install: slide the tie-down eye through a recess in the loading rail close to the load until locking mechanism engages in the recess.
- (i) When you pull locking mechanism up and out of the recess, the tie-down eve is able to move within the loading rail. Make sure that locking mechanism is always engaged in a recess.
- Check the tie-down eye for firm seating.
- To remove: pull locking mechanism up and pull the tie-down eve towards the locking mechanism and out of the loading rail through a recess.

Carrier systems


Information about the roof rack

WARNING Risk of injury due to the maximum roof load being exceeded

When you place a load on the roof as well as all outer and inner attachments, the vehicle's center of gravity will rise and the familiar driving characteristics as well as the steering and braking characteristics will change. When driving around bends, the vehicle will tilt more heavily and may react more sluggishly to steering movements.

If you exceed the maximum roof load, the driving characteristics, as well as the steering and braking, will be greatly impaired.

Never exceed the maximum roof load and adjust your driving style.



Mounting rails

Information about the maximum roof load can be found in the "Technical data" section $(\rightarrow page 353)$.

Observe the following points for assembling roof racks:

- Tighten the roof rack's screws to a torque of 6.0 lb-ft (8 Nm) - 7.4 lb-ft (10 Nm) in the designated grooved plates.
- The tightened screws should not touch the rails.
- Ensure that the grooved plates are not located in the areas around the plastic caps.
- The grooved plates must have the right crosssection.
- . The insides of the mounting rails must be free
- · Re-tighten the screws uniformly after around 300 miles (500 km).

Mercedes-Benz recommends that you use only roof racks that have been tested and approved for Mercedes-Benz. These help to prevent vehicle damage.

If you want to retrofit the mounting rails, have them installed at a qualified specialist workshop. Otherwise, you could damage the vehicle.

If your vehicle is installed with mounting rails on the roof, you can install a roof rack on the roof. Special fasteners (sliding blocks) are available as accessories for this purpose.

These fasteners are available from any authorized Mercedes-Benz Center.

Using the interior roof carrier system

WARNING Risk of injury due to unsecured loads


When you secure or loosen a load, the load may fall down and injure vehicle occupants.

- When securing or loosening a load, do not stand under the load.
- **NOTE** Risk of damage to the belt straps and slider

Excessive point loading on the belt straps and sliders may cause the belt straps to tear or

cause the sliders to break off from the rack rail.

Distribute the load evenly. When doing so, ensure that the overall center of gravity of the load is always as close to the center as possible and between the roof rails and between the rack rails.



You can use the interior roof rack system to secure loads. It is also suitable for securing long loads.


(i) The interior roof rack system may be subjected to a maximum load of 110 lbs (50 kg).

The interior roof rack system consists of the following components:

- Roof rails (1) are attached to the roof of the vehicle.
- Rack rails are screwed onto the roof rails and can be moved.
- Rack rail ② is equipped with slider pair ④. Slider pair 4 with attached belt strap 5 can be moved. Load 6 is stowed by placing and lashing it in belt strap (5).
- The load has to be secured in the direction of travel and in the opposite direction to the

direction of travel using two head lashings





- To move the rack rails: unscrew star knobs


 counter-clockwise until they are slightly loose.
- ➤ Slide rack rail ② along roof rail ① to the desired position.
- Screw star knobs tight clockwise.
- Check that the rack rail is seated securely.

Moving the sliders

WARNING Risk of injury due to inadequately secured loads


If the slider of the interior roof rack system is not engaged properly, the load may come loose, fall down and injure people, for instance when they enter or load and unload the cargo compartment.

Always engage the slider properly.



- i Ring o of slider must always be at an angle of 90° to rack rail , so that slider is engaged properly.
- When the ring of the slider is at an angle of 90° to the rack rail: pull ring (a) of slider
 down and simultaneously move slider (a) to the desired position.
- Release ring (3) at the desired position.
- Move slider (a) slightly further along on rack rail (2) until slider (4) engages automatically.
- When the ring of the slider is parallel to the rack rail: move slider to the desired position.
- Position ring of of slider of at an angle of 90° to rack rail of slider of is engaged.

Adjusting the belt strap



- Press and hold the locking mechanism on slider ①.
- Pull or release belt strap (5).
 - Release the locking mechanism on slider .
- (i) When securing or loosening a load, be sure to not stand under the load.

Securing and loosening the load

- To secure the load: place the load in the belt straps of the rack rails.
- Fasten the load flush with the partition.
- Secure belt strap ⑤.
- Check that the load is seated securely.
- ➤ To loosen the load: press and hold the locking mechanism on slider ②.
- Pull ring (a) of the slider down and simultaneously move the slider away from the load.
- Loosen belt strap (§) and at the same time make sure that the load does not fall out of the belt straps.
- ▶ Remove the load from the belt straps.

Installing cargo tie down rings



- Turn the ring of cargo tie-down ring a until it is parallel to the longitudinal axis of cargo tiedown ring (12).
- Hold cargo tie-down ring
 between the index finger and middle finger and place your thumb through the ring of cargo tie-down ring and onto the central pressure point.
- Use your thumb to push the locking pin down as far as it will go.
- Push cargo tie-down ring near the load through the notches on rack rail 2 and move it approximately 0.5 in (12 mm).
- Remove your thumb from the pressure point and slide cargo tie-down ring 100 until it engages.
- Turn the ring of cargo tie-down ring (11) until it is perpendicular to the longitudinal axis of cargo tie-down ring (12). Cargo tie-down ring (12) is secured.

Removing cargo tie down rings

- Turn the ring of cargo tie-down ring (11) until it is parallel to the longitudinal axis of cargo tiedown ring (12).
- Grip cargo tie-down ring (12) as described above under installing and use your thumb to push the locking pin down as far as it will go.
- Slide cargo tie-down ring (12) and pull it down and out through the notches of rack rail 2.

Attaching the head lashing

WARNING Risk of injury due to incorrectly secured loads

When the hooks on the head lashing are attached to the rings of the sliders, the sliders could come loose. The load may come loose, fall down and injure people, for instance when they enter or load and unload the cargo compartment.


Only attach the hooks on the head lashing to the rings of the cargo tie-down rings.



- (i) The hooks on head lashing (3) may only be attached to the rings of cargo tie down rings
- Check that the load is seated securely.
- To attach the head lashing: tension head lashing (3) at both ends of load (6) and attach two hooks (10) of the head lashing to the rings of cargo tie down rings (11).

Placing a load on the wheel arch

Comply with the important safety notes under "Notes on loading" (\rightarrow page 271).



- Place the objects on wheel arch 2 and lash them using tie-down eyes \bigcirc (\rightarrow page 273).
- (i) A wheel arch may be subjected to a load of 330 lb (150 kg).

ASSYST PLUS service interval display

Function of the ASSYST PLUS service interval display

The ASSYST PLUS service interval display on the instrument display provides information on the remaining time or distance before the next service due date.

You can hide this service message by using the back button on the left-hand side of the steering wheel

You can obtain further information concerning the servicing of your vehicle from a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Displaying the service due date

On-board computer:

→ Service → ASSYST PLUS

The next service due date is displayed.

To exit the display: press the back button on the left-hand side of the steering wheel.

Bear in mind the following related topic:

· Operating the on-board com $puter(\rightarrow page 176)$

Carrying out maintenance work regularly

1 NOTE Premature wear through failure to observe service due dates

Service work which is not carried out at the right time or incompletely can lead to increased wear and damage to the vehicle.

- Always observe the prescribed service intervals.
- Always have the prescribed service work carried out at a qualified specialist workshop.

Special service requirements

The prescribed service interval is based on normal vehicle use. Maintenance work will need to be performed more often than prescribed if the vehicle is operated under arduous conditions or increased loads.

Examples of arduous operating conditions:

- Regular city driving with frequent intermediate stops
- · Mainly short-distance driving
- Frequent operation in mountainous terrain or on poor road surfaces
- When the engine is often left idling for long periods
- Operation in particularly dusty conditions and/or if air-recirculation mode is frequently used

In these or similar operating conditions, have the interior air filter, engine air cleaner, engine oil and oil filter etc. changed more frequently. If the vehicle is subjected to higher loads, the tires must be checked more frequently. You can obtain further information at a qualified specialist workshop.

Battery disconnection periods

The ASSYST PLUS service interval display can only calculate the service due date when the battery is connected.

Note down the service due date displayed on the Instrument Display before disconnecting the battery (\rightarrow page 278).

Engine compartment

Opening and closing the hood

WARNING Risk of accident if the engine hood is unlatched while driving

An unlocked engine hood may open up when the vehicle is in motion and block your view.

- Never unlatch the engine hood while driving.
- Before every trip, ensure that the engine hood is latched.
- WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

Before opening the hood, allow the engine to cool down.

In the event of a fire in the engine compartment, keep the hood closed and call the fire service

WARNING Risk of injury due to moving

Certain components in the engine compartment may continue to move or suddenly move again even after the ignition has been switched off, e.g. the cooler fan.

Make sure of the following before performing tasks in the engine compartment:

- Switch the ignition off.
- Never touch the danger zone surrounding moving component parts, e.g. the rotation area of the fan.
- Remove jewelry and watches.
- Keep items of clothing and hair away from moving parts.

WARNING Risk of injury from touching component parts under voltage

The ignition system and the fuel injection system work under high voltage. If you touch component parts which are under voltage, you could receive an electric shock.

Never touch component parts of the ignition system or the fuel injection system when the ignition is switched on.

Live components of the fuel injection system include the injectors, for example.

Live components of the ignition system include the following, for example:

- Ignition coils
- Spark plug connectors
- Diagnostic socket

▲ WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.


If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Engine oil filler opening cap
- Washer fluid reservoir cap
- Coolant expansion reservoir cap

WARNING Risk of injury from using the windshield wipers while the engine hood is open

When the engine hood is open and the windshield wipers are set in motion, you can be trapped by the wiper linkage.

Always switch off the windshield wipers and ignition before opening the engine hood.



- Park the vehicle in a safe location and on a level surface if possible.
- Switch off the engine.
- Secure the vehicle against rolling away.


WARNING Risk of injury when the hood is opened

When you open the hood, it may suddenly drop into the end position.

There is a risk of injury for anyone in the hood's range of movement.

- Before releasing the hood, ensure that the support is firmly seated in the holder.
- Open the hood only when there is noone in the hood's range of movement.

- To open: pull handle 1 to release the hood.
- Reach into the gap and push the hood catch handle upwards.
- Open the hood and hold it up.



- Take support **1** from the bracket on the hood and pull it downwards.
- Insert the support into the bracket below ②.
- WARNING Risk of fire due to flammable material in the engine compartment or the exhaust system

Cloths or other flammable materials left in the engine compartment by mistake could ignite upon coming into contact with hot sections of the engine or exhaust system.

- Ensure that there are no flammable external materials in the engine compartment or on the exhaust system after maintenance work has been conducted.
- **WARNING** Risk of accident and injury when opening and closing the engine hood

When opening or closing the engine hood, it may suddenly drop into the end position.

There is a risk of injury for anyone in the engine hood's range of movement.

Only open or close the engine hood when there are no persons in the engine hood's range of movement.

NOTE Damage to the hood

Pushing the hood closed with your hands could damage it.

- To close the hood, let it drop from the specified height.
- To close: lift the hood slightly.
- Move support 1 to the bracket on the hood and apply light pressure to engage it.
- Lower the hood and let it drop from a height of approximately 0.5 ft (15 cm).
- If it is still possible to lift the hood a little, open the hood again and let it drop from a height of approximately 0.7 ft (20 cm) until it engages correctly.

Engine oil

Checking the engine oil level with a dipstick

WARNING Risk of burns from hot component parts in the engine compartment


Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

 Let the engine cool down and only touch the component parts described as follows.

Depending on the engine, the dipstick may be in varying locations in the engine compartment.

Waiting time before checking the oil level:

- engine at normal operating temperature: five minutes
- engine not at normal operating temperature (the engine was only started briefly, for example): 30 minutes



Dipstick (example)

- Park the vehicle on an even surface.
- Remove dipstick (1) and wipe it off.
- Slowly insert dipstick (1) into the dipstick guide tube as far as it will go and pull it out after three seconds.
 - Oil level OK: the oil level is between the MIN and the MAX mark.
 - Oil level too low: the oil level is at the MIN. mark or below.
- If the oil level is too low, add approx. 1.1 US qt (1 liter) engine oil.
- If the oil level is too high, drain off excess engine oil. Visit a qualified specialist workshop.

Checking the engine oil level with the onboard computer Requirements:

- The vehicle is level during the measuring process.
- The hood is not open.
- Depending on the driving profile, the oil level can be displayed only after a driving time of up to 30 minutes and only when the ignition is switched on.

On-board computer:

→ Service → Engine Oil Level

You will see one of the following messages on the multifunction display:

Measuring Engine Oil Level...: measurement of the oil level not yet possible. Repeat the query after driving for a maximum of 30 minutes.

- Engine Oil Level OK and the bar showing the oil level on the multifunction display is green and lies between "MIN" and "MAX": the oil level is OK.
- Engine Oil Level Drive until the engine is warm.: warm up the engine to operating tem-
- Engine Oil Level Correct Measurement Only if Vehicle Is on Level Ground: park the vehicle on a level surface.
- Engine Oil Level Add 1,0 liq.gal. and the bar showing the oil level on the multifunction display is orange and lies below "MIN": add 1.1 US at (1 I) of engine oil.
- Reduce Engine Oil Level and the bar showing the oil level on the multifunction display is orange and lies above "MAX": drain off excess engine oil.
 - Visit a qualified specialist workshop.
- For Engine Oil Level Switch Ignition On: switch on the ignition in order to check the engine oil level.
- Engine Oil Level System Inoperative: the sensor is defective or not connected. Visit a qualified specialist workshop.
- Engine Oil Level System Currently Unavailable: close the hood.
- (i) Vehicles with cold oil level displays: the oil level is automatically displayed on the multifunction display after the vehicle has been non-operational for an extended period. If it is not possible to measure the engine oil level, a corresponding message will appear.

Adding engine oil

WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Engine oil filler opening cap
- · Washer fluid reservoir cap
- Coolant expansion reservoir cap

WARNING Risk of fire and injury from engine oil

If engine oil comes into contact with hot component parts in the engine compartment, it may ignite.

- Make sure that no engine oil is spilled next to the filler opening.
- Allow the engine to cool off and thoroughly clean the engine oil from component parts before starting the vehicle.
- NOTE Engine damage due to incorrect oil filter, incorrect oil or additive
- Do not use engine oil or an oil filter with specifications deviating from those required for the prescribed service intervals.


Mercedes-Benz recommends using original or tested replacement and service parts.

- Do not change the engine oil or oil filter in order to set change intervals longer than those prescribed.
- Do not use any additive.
- Follow the instructions on the service interval display for changing the engine oil


NOTE Damage caused by adding too much engine oil

Too much engine oil can damage the engine or the catalytic converter.

Have excess engine oil removed at a qualified specialist workshop.



Engine OM651



Engine OM642

- ► Turn cap (1) counter-clockwise and remove it.
- Add engine oil.
- Replace cap and turn it clockwise until it engages.
- Check the oil level again. Check using the onboard computer (→ page 281), check with the oil dipstick (→ page 280).

Checking the coolant level

WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following. If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Engine oil filler opening cap
- Washer fluid reservoir cap
- Coolant expansion reservoir cap

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

WARNING Risk of scalding from hot coolant

The engine cooling system is pressurized, particularly when the engine is warm. If you open the cap, you could be scalded by hot coolant spraying out.

- Let the engine cool down before opening the cap.
- When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.


Allow the engine and the engine cooling system to cool down before checking the coolant level or refilling coolant.

NOTE Paintwork damage due to coolant

If coolant gets on painted surfaces, the paintwork can be damaged.

- Add coolant carefully.
- Remove spilled coolant.

Checking the coolant level



Example: coolant expansion reservoir

- Park the vehicle on an even surface.
- Open the hood (\rightarrow page 278).
- Slowly turn coolant expansion reservoir cap
 - half a turn counter-clockwise and allow excess pressure to escape.
- Turn coolant expansion reservoir cap 1 further and remove it.
- Check the coolant level. There is enough coolant in coolant expansion reservoir if the coolant reaches the MAX mark.

Adding coolant

Refill the coolant to the MAX mark on the coolant expansion reservoir.

Only use coolant approved by Mercedes-Benz to avoid damaging the engine cooling system.

- Replace coolant expansion reservoir cap 1 and tighten in a clockwise direction.
- Start the engine.
- After approximately five minutes, switch off the engine again and allow it to cool down.
- Check the coolant level again and add coolant if necessary.
- (i) Observe additional coolant information $(\rightarrow page 347)$.

Filling up the windshield washer system



WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Engine oil filler opening cap
- Washer fluid reservoir cap
- Coolant expansion reservoir cap

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

WARNING - Risk of fire and injury from windshield washer concentrate


Windshield washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

- Make sure that no windshield washer concentrate spills out next to the filler opening.
- **NOTE** Damage to the exterior lighting due to unsuitable windshield washer fluid

Unsuitable windshield washer fluid may damage the plastic surface of the exterior lighting.

Only use windshield washer fluids that are also suitable for use on plastic surfaces, e.g. MB SummerFit or MB Winter-Fit.

Adding washer fluid



Washer fluid reservoir (example)

- Pre-mix the washer fluid in the correct mixing ratio in a container.
- Park the vehicle on a level surface and secure it against rolling away (\rightarrow page 140).
- Open the hood (\rightarrow page 278).
- Pull the cap of the washer fluid container (1) upwards by the tab.
- Pour in the pre-mixed washer fluid.
- Press cap 1 onto the filler opening until it audibly engages.
- Close the hood (\rightarrow page 278).
- (i) Mix the washer fluid with windshield washer concentrate all year round. Comply with the information about windshield washer fluid in the technical data (\rightarrow page 347).
- (i) Comply with the further information about windshield washer fluid (\rightarrow page 347)

Cleaning the water drain valve of the air intake box



WARNING Risk of injury due to moving parts

Certain components in the engine compartment may continue to move or suddenly move again even after the ignition has been switched off, e.g. the cooler fan.

Make sure of the following before performing tasks in the engine compartment:

Switch the ignition off.


- Never touch the danger zone surrounding moving component parts, e.g. the rotation area of the fan.
- Remove iewelry and watches.
- Keep items of clothing and hair away from moving parts.
- WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

If you have to carry out any work in the engine compartment, touch only the following components:

- Hood
- Engine oil filler opening cap
- Washer fluid reservoir cap
- Coolant expansion reservoir cap



- Open the hood (\rightarrow page 278).
- Remove dirt from water drain valve 2 of air intake box 1.

Draining the fuel filter

WARNING Danger of fire and explosion due to fuel

Fuels are highly flammable.

- It is essential to avoid fire, open flames. smoking and creating sparks.
- Before filling up, switch off the engine, and, if applicable, the auxiliary heating.
- **WARNING** Risk of fire and explosion due to fuel


Fuels are highly flammable. There is a risk of fire and explosion due to contact with hot component parts.

- Allow the engine and the exhaust system to cool down.
- NOTE Engine damage due to delayed drainage of the fuel filter

Vehicles with a diesel engine: delayed drainage of the fuel filter can lead to engine damage.

If the indicator lamp lights up, drain the fuel filter immediately.

- **ENVIRONMENTAL NOTE** Environmental Ø pollution due to disposal in a non-environmentally-friendly manner
- Dispose of the water/fuel mixture in an environmentally-friendly manner.



OM642 engine

- Park the vehicle in a safe location and secure it against rolling away.
- Switch off the auxiliary heating $(\rightarrow page 106)$.
- Switch off the engine.
- Open the hood (\rightarrow page 278).

- Place a suitable collector beneath drain hose
- Switch on the ignition.
- Open drain screw until the water/fuel mixture emerges from drain hose 2.
- Close drain screw as soon as around 0.2 gt (0.2 liter) of the water/fuel mixture has been collected.

After 30 seconds, the electrical fuel pump automatically stops the discharge of the water/fuel mixture.

- After draining, switch off the ignition.
- Dispose of the collected water/fuel mixture in an environmentally responsible manner, e.g. at a qualified specialist workshop.
- Check that drain screw has been closed. If the engine is running while drain screw 1 is open, you will lose fuel through drain hose
- Close the hood (→ page 278).
- The indicator lamp does not go out after draining: drain the fuel filter again.
- The indicator lamp does not go out after the second draining: consult a qualified specialist workshop.

Mercedes-Benz recommends that you have the fuel filter drained at a qualified specialist workshop.

Cleaning and care

Notes on washing the vehicle in an automatic car wash

WARNING Risk of accident due to reduced braking effect after washing the vehicle

The braking effect is reduced after washing the vehicle.

- After the vehicle has been washed. brake carefully while paying attention to the traffic conditions until the braking effect has been fully restored.
- **NOTE** Risk of damage to the paintwork 1 and plastic components

If you wash your vehicle in Touchless Automatic Car Wash systems that use special cleaning agents, the cleaning agents used can

damage the paintwork or plastic components of the vehicle.

Do not wash the vehicle in Touchless. Automatic Car Wash systems that use special cleaning agents.

Make sure that the automatic car wash is suitable for the size of the vehicle.

Before washing the vehicle in an automatic car wash, fold in the outside mirrors and remove any additional antennas. Otherwise, the outside mirrors, antennas or the vehicle itself could be damaged.

Make sure any additional antennas are re-installed and that the outside mirrors are fully folded out again when you leave the automatic car wash.

To avoid damage to your vehicle, observe the following before using an automatic car wash:

- the side windows and the sliding window are completely closed.
- the blower for ventilation and heating is switched off.
- the windshield wiper switch is in position [0].

If the vehicle is very dirty, wash off excess dirt before cleaning the vehicle in an automatic car wash.

(i) Removing the wax from the windshield and the wiper rubbers after washing the vehicle, will help avoid smearing and reduce wiper noise.

Notes on use of a power washer

WARNING Risk of accident when using high-pressure cleaning equipment with round-spray nozzles

The water jet from a round-spray nozzle (dirt grinder) may cause damage to tires and suspension components that is not visible.

Components damaged in this way may fail unexpectedly.

- Do not use high-pressure cleaning equipment with round-spray nozzles to clean your vehicle.
- Damaged tires or suspension components must be replaced immediately.

Never use a power washer in the vehicle interior. The pressurized water created by the power

washer and the associated spray could cause considerable damage to the vehicle.

To avoid damage to your vehicle, observe the following when using a power washer:

- maintain a minimum distance of 11.8 in (30 cm) to the vehicle when using 25° flatspray nozzles and dirt grinders or 27.6 in (70 cm) when using round-spray nozzles and observe the information in the equipment manufacturer's operating instructions.
- do not direct the nozzle of the power washer directly at sensitive parts such as tires, slits, electrical components, batteries, light bulbs and ventilation slits.
- maintain a minimum distance of 19.7 in (50 cm) for a rear view camera.

Washing the vehicle by hand

Observe the legal requirements, for example in many countries washing by hand is only allowed at specially designated wash bays. In this case, make sure that a specially designated wash bay is used for washing by hand.

Use a mild cleaning agent, e.g. car shampoo.

- Wash the vehicle with lukewarm water and a soft car sponge. When doing so, do not expose the vehicle to direct sunlight.
- Carefully spray the vehicle with water and dry off with a leather cloth. Be careful not to point the water jet directly towards the air inlet grilles. The blower should be switched off while doing so.
- Do not let the cleaning agent dry on the paintwork.

At the onset of winter, remove all traces of road salt deposits carefully and as soon as possible.

Notes on care of paint and matte finish

NOTE Paintwork damage and corrosion due to inadequate care

Failure to promptly and thoroughly remove dirt from bird droppings or other residue could result in paintwork damage and corrosion at a later date.

Clean dirt off paint and matte finish thoroughly and as soon as possible.

Observe the following notes:

	Notes on cleaning and care	Avoiding paintwork damage
Paint	 Insect remains: soak with insect remover and then wash off. Bird droppings: soak with water and then wash off. Remove coolant, tree resin, oils, fuels and greases: rub gently with a cloth soaked in petroleum ether or lighter fluid. Brake fluid: wash off with water. Tar stains: use tar remover. Wax: use a silicone remover. 	 Do not affix stickers, films or similar. Remove dirt as soon as possible.
Matte finish	Only use care products approved for Mercedes-Benz.	 Do not polish the vehicle and alloy wheels. Do not use a wash program that ends with a hot wax treatment in automatic car washes. Do not use paint cleaners, buffing or polishing products, or gloss preservers, e.g. wax. Have paint repairs carried out in a qualified specialist workshop only.

Notes on the care of vehicle parts

WARNING Risk of entrapment if the windshield wipers are switched on while the windshield is being cleaned

If the windshield wipers are set in motion while you are cleaning the windshield or wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

WARNING Risk of burning from the tailpipe or tailpipe trim

The tailpipe and tailpipe trim can become very hot. If you come into contact with these car parts, you could burn yourself.

- Always be particularly careful when in the vicinity of the tailpipe and tailpipe trims and supervise children very closely when in this area.
- Before any contact, allow the car parts to cool down.

Observe the following notes:

	Notes on cleaning and care	Preventing damage to the vehicle
Wheels/rims	Use water and acid-free wheel cleaner.	 Do not use acidic wheel cleaners to remove brake dust. Otherwise, wheel bolts and brake components may be damaged. To avoid corrosion of brake discs and brakepads, drive for a few minutes after cleaning before parking the vehicle. The brake discs and brakepads warm up and dry out.
Windows	Clean windows inside and outside with a damp cloth and with a cleaning agent recommended for Mercedes-Benz .	Do not use dry cloths or abrasive or solvent-based cleaning agents to clean the inside of windows.
Wiper blades	Carefully clean the folded-away wiper blades with a damp cloth.	Do not clean the wiper blades too often.
Exterior lighting	Clean the lenses with a wet sponge and mild cleaning agent, e.g. car shampoo.	Only use cleaning agents or cloths suitable for plastic lenses.
Sensors	Clean the sensors in the front and rear bumper and in the radiator grill with a soft cloth and car shampoo.	When using a power washer, keep a minimum distance of 11.8 in (30 cm).
Rear view camera and 360° Cam- era	Use clean water and a soft cloth to clean the camera lens.	Do not use a power washer.
Trailer hitch	 Remove traces of rust on the ball, e.g. with a wire brush. Remove dirt with a lint-free cloth. After cleaning, lightly oil or grease the ball head. Observe the notes on care in the trailer hitch manufacturer's operating instructions. 	Do not clean the ball neck with a power washer or solvent.
Sliding door	 Remove foreign objects from the vicinity of the contact plates and contact pins of the sliding door. Clean the contact plates and contact pins with a mild cleaning agent and a soft cloth. 	Do not oil or grease the contact plates and the contact pins.

	Notes on cleaning and care	Preventing damage to the vehicle
Steps	 Clean the electrically operated steps and their housing with a power washer. 	Do not use oil or grease as a lubricant.
	 After cleaning, spray the lateral guides with silicone spray. Clean the steps in the bumper with a power washer. 	
Aluminum dropsides	Brush down the aluminum dropsides with water and a neutral or mild alka- line cleaning agent.	Do not use abrasive cleaning agents to clean the dropsides.

Notes on interior care

WARNING Risk of injury from plastic parts breaking off after the use of solvent-based care products

Care and cleaning products containing solvents can cause surfaces in the cockpit to become porous.

When the airbags are deployed, plastic parts may break away.

Do not use any care or cleaning products containing solvents to clean the cockpit.



WARNING Risk of injury or death from bleached seat belts

Bleaching or dyeing seat belts can severely weaken them.

This can, for example, cause seat belts to tear or fail in an accident.

Never bleach or dye seat belts.

Observe the following notes:

	Notes on cleaning and care	Preventing damage to the vehicle
Seat belts	Clean with lukewarm soapy water.	 Do not use chemical cleaning agents. Do not dry the seat belt by heating above 176°F (80°C) or in direct sunlight.
Display	Clean the surface carefully with a micro- fiber cloth and LCD/TFT display care product.	Switch off the display and let it cool down.Do not use any other agents.
Plastic trim	Clean with a damp microfiber cloth. For heavy soiling: use care product recommended for Mercedes-Benz.	 Do not affix stickers, films or similar. Do not allow to come into contact with cosmetics, insect repellent and sun creams.
Real wood/ trim ele- ments	Clean with a microfiber cloth. Black piano-lacquer look: clean with a damp cloth and soapy water. For heavy soiling: use care product recommended for Mercedes-Benz.	Do not use solvent-based cleaning agents, polishes or waxes.


	Notes on cleaning and care	Preventing damage to the vehicle
Headliner	Clean with a soft brush or dry shampoo.	
Cloth seat covers	Vacuum up dirt such as crumbs or dust and then use a damp microfiber cloth and a 1% soapsuds solution to clean the entire seat cover. Do not spot-clean. Use cleaning and care products recommended for Mercedes-Benz.	Do not use any oil-based cleaning and care products.
Imitation leather seat covers	Vacuum up dirt such as crumbs or dust and then use a damp cotton cloth and a 1% soapsuds solution to clean the entire seat cover. Do not spot-clean. Use cleaning and care products recom- mended for Mercedes-Benz.	Do not use a microfiber cloth. Do not use any oil-based cleaning and care products.
Genuine leather seat covers	Regularly vacuum up dirt such as crumbs or dust and then use a damp cotton cloth to clean the entire seat covers. For heavy soiling: use a leather care agent recommended by Mercedes-Benz for aftertreatment.	Do not use a microfiber cloth. Do not use any oil-based cleaning and care products.
Steering wheel and gear or selector lever	Clean with a damp cloth.	
Pedals and floor mats	Clean with a damp cloth.	Do not use any cleaning and care products.
Vehicle interior	Clean with a damp cloth.	 Do not use a power washer. Allow the vehicle interior to dry completely after cleaning. Do not allow liquids to penetrate into gaps or cavities.
Curtains	The curtains may only be dry cleaned.	Do not wash the curtains.

Emergency

Removing the safety vest

The safety vest is located in the stowage compartment in the driver's door.

- Remove the safety vest from the stowage compartment.
- (i) Safety vests can also be stored in the stowage compartments of the rear doors and the front-passenger door.



- Maximum number of washes
- Maximum wash temperature
- On not bleach
- Do not iron
- O not tumble dry
- O Do not dry-clean
- This is a class 2 yest

The safety vest only fulfills the legally required standards if it is the correct size and is completely closed.

Replace the safety vest:

- if damaged or if the reflex strips are dirty
- if the maximum permitted number of washes is exceeded
- if the safety vest's fluorescence has faded

Removing the first-aid kit (soft sided)

The first-aid kit (soft sided) is located in the stowage compartment in the front passenger door.

Remove first-aid (soft sided) kit from the stowage compartment.

Removing the warning lamp

The warning lamp is located in the stowage compartment in the front-passenger door.

Remove the warning lamp from the stowage compartment.

Emergency Call System

Information on the emergency call system

USA only: Your vehicle is equipped with the Emergency Call System ("eCall"). This feature can help save lives in the event of an accident, eCall in no way replaces assistance provided from dialing 911.

eCall only functions in areas where mobile phone coverage is available from the wireless service providers. Insufficient network coverage from the wireless service providers may result in an emergency call not being transmitted.

eCall is a standard feature in your Mercedes-Benz vehicle. In order to function as intended, the system relies on the transmission of data detailed in the Transmitted Data section that follows (→ page 293). To disable eCall, a customer must visit an authorized Mercedes-Benz Service department to deactivate the vehicle's communication module.

Deactivation of this module prevents the activation of any and all Mercedes PRO connect services. After the deactivation of eCall, automatic emergency call and manual emergency call will not be available.

The ignition must be switched on before an automatic emergency call can be made.

- (i) eCall is activated at the factory.
- (i) eCall can be deactivated by an authorized Mercedes-Benz dealer. Please note that in the event ownership of the vehicle is transferred to another owner in its deactivated state, eCall will remain deactivated unless the new owner visits an authorized Mercedes-Benz dealership to reactivate the system.

Emergency Call System

eCall can help to reduce the time between an accident and the arrival of emergency services at the site of the accident. It helps locate an accident site in places that are difficult to access. However, even if a vehicle is equipped with eCall, this does not mean the system is ON. As such, eCall does not replace dialing 911 in the event of an accident.

The emergency call can be made automatically $(\rightarrow page 293)$ or manually $(\rightarrow page 293)$. Only make emergency calls if you or others are in need of rescue. Do not make an emergency call in the event of a breakdown or a similar situation.

Message in the media display:

SOS NOT READY: the ignition is not on or eCall is not available.

During an active emergency call, (Sos) appears in the display.

You can find more information on the regional availability of eCall at: http://www.mercedesbenz.com/connect ecall

(i) If an emergency call is unavailable or malfunctioning, a message to this effect also appears in the multifunction display of the instrument cluster.

Triggering an automatic emergency call

Requirements:

- The ignition is switched on.
- The starter battery has sufficient charge.

If restraint systems such as airbags or Emergency Tensioning Devices have been activated after an accident, eCall may automatically initiate an emergency call.

The emergency call has been made:

- · A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center. The Mercedes-Benz emergency call center can transmit the vehicle position data to one of the emergency call centers.

The SOS button in the overhead control panel flashes until the emergency call is finished.

It is not possible to immediately end an automatic emergency call.

If no connection can be made to the emergency services either, a corresponding message appears in the media display.

Dial the local emergency number on your mobile phone.

If an emergency call has been initiated:

- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center service provider.
- · Based on the call, the operator decides whether it is necessary to call rescue teams and/or the police to the accident site.
- · If no vehicle occupant answers, an ambulance is sent to the vehicle immediately.

Triggering a manual emergency call

- Using the SOS button in the overhead con**trol panel:** press the SOS button at least one second long.
- Using voice control: Use the Voice Control System Call the Mercedes accident center voice command (\rightarrow page 189).

The emergency call has been made:

- A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center. The Mercedes-Benz emergency call center
 - can transmit the vehicle position data to one of the emergency call centers.
- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center service provider.

If no connection can be made to the emergency services either, a corresponding message appears in the media display.

Dial the local emergency number on your mobile phone.

Ending an unintentional emergency call

Select on the multifunction steering wheel. Depress the button for several seconds.

Transmitted data with the emergency call system

Data transmitted by the eCall includes but is not limited to:

- · Vehicle's GPS position data
- GPS position data on the route ((a few hundred meters before the incident))
- Direction of travel
- Vehicle identification number
- Vehicle drive type
- Estimated number of people in the vehicle
- Whether Mercedes PRO connect is available. or not
- Whether the emergency call was initiated manually or automatically
- · Time of the accident
- Language setting on the multimedia system

Data transmitted is vehicle information. For any questions about the collection, use and sharing of the eCall system data, please contact MBU-SA's Customer Assistance Center at 800-FOR-MFRC.

For Canada, please contact MBC's Customer Assistance Center at 1-800-387-0100.

Customer requests for covered information should be submitted via the same channels.

For accident clarification purposes, the following measures can be taken up to an hour after the emergency call has been initiated:

- The current vehicle position can be deter-
- A voice connection to the vehicle occupants can be established

Flat tire

Notes on flat tires

▲ WARNING Risk of an accident when driving with a flat tire

A flat tire greatly impairs driving characteristics, as well as steering and braking.

- Do not drive with a flat tire.
- Remove the flat tire and install the spare wheel or consult a qualified specialist workshop.

Depending on your vehicle's equipment, in the event of a flat tire you have the following possibilities:

- You can call breakdown assistance via the breakdown assistance call button in the overhead control panel (\rightarrow page 196).
- Change the wheel (\rightarrow page 327).

Battery

Notes on the 12 V battery



WARNING Risk of an accident due to work carried out incorrectly on the bat-

Work carried out incorrectly on the battery can, for example, lead to a short circuit. This can lead to function restrictions in safety-relevant systems, for example the lighting system, ABS (anti-lock braking system) or ESP®

(Electronic Stability Program). The operating safety of your vehicle may be restricted.

You could lose control of the vehicle in the following situations:

- when braking
- in the event of abrupt steering maneuvers and/or when the vehicle's speed is not adapted to the road conditions
- In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately.
- Do not continue driving.
- Always have work on the battery carried out at a qualified specialist workshop.
- Further information on ABS (→ page 146)
- Further information on ESP®(→ page 147)

Mercedes-Benz recommends that you have the 12 V battery replaced at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

Should you want to replace the battery yourself, observe the following information:

- Always replace a faulty battery with a battery which fulfills the vehicle's specific requirements.
- Carry over detachable parts such as the vent hose, elbow fitting or terminal cover from the battery to be replaced.
- Make sure that the vent hose is always connected to its original opening on the battery side.

Install the existing or newly supplied stop plugs.

Otherwise, gases or battery acid could escape.

 Make sure that the detachable parts are connected in the same way as before.

For safety reasons, Mercedes-Benz recommends that you only use batteries that have been tested and approved for your vehicle by Mercedes-Benz. These batteries provide increased impact protection to prevent vehicle occupants from suffering acid burns should the battery be damaged in an accident.

WARNING Risk of explosion due to electrostatic charge

Electrostatic charge can cause sparks which may ignite the highly flammable gas mixture in the battery.

To discharge any electrostatic charge that may have built up, touch the metal vehicle body before handling the batterv.

The highly flammable gas mixture is created while the battery is charging and when jump-starting.

WARNING Danger of chemical burns from the battery acid

Battery acid is caustic.

- Avoid contact with the skin, eyes or clothing.
- Do not lean over the battery.
- Do not inhale battery gases.
- Keep children away from the battery.
- Immediately rinse battery acid off thoroughly with plenty of clean water and seek medical attention immediately.



ENVIRONMENTAL NOTE Environmental damage caused by improper disposal of **batteries**

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.

Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

If the 12 V battery has to be connected, contact a qualified specialist workshop.

Observe the safety notes and protective measures when handling batteries.



Risk of explosion



Fire, open flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes and clothing. Wear suitable protective clothing, in particular gloves, an apron and a safety mask. Immediately rinse electrolyte acid splashes off with clean water. If necessary, seek medical advice.



Wear eye protection.



Keep children at a safe distance.



Observe these Operating Instructions.

If you do not use the vehicle for a long period or drive short distances regularly:

- · Connect the battery to a charger recommended for Mercedes-Benz.
- Consult a qualified specialist workshop to disconnect the battery

Starting assistance and charging the starter battery

Always use the jump-start connection in the engine compartment for starting assistance and when charging the battery.



NOTE Damaging the battery through overvoltage

When charging using a battery charger without a maximum charging voltage, the battery or the vehicle electronics may be damaged.

Only use battery chargers with a maximum charging voltage of 14.8 V.

WARNING Risk of explosion from hydrogen gas igniting

A battery generates hydrogen gas during the charging process. If there is a short circuit or sparks start to form, there is a danger of the hydrogen gas igniting.

- Make sure that the positive terminal of the connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- When connecting and disconnecting the battery, you must observe the described order for the battery clamps.
- When giving starting assistance, always make sure that you only connect battery terminals with identical polarity.
- During starting assistance, you must observe the described order for connecting and disconnecting the jumper cables.
- Do not connect or disconnect the battery clamps while the engine is running.

▲ WARNING Risk of explosion during charging process and starting assistance

During the charging process and starting assistance, the battery may release an explosive gas mixture.

- Avoid fire, open flames, creating sparks and smoking.
- Make sure that there is sufficient ventilation during the charging process and during starting assistance.
- Do not lean over a battery.

▲ WARNING Risk of explosion from a frozen battery

A discharged battery may freeze at temperatures slightly above or below freezing point.

During starting assistance or battery charging, battery gas can be released.

Always allow a battery to thaw before charging it or performing starting assistance.

If the warning/indicator lamps do not light up in the instrument display around or below freezing point, it is very likely that the discharged battery has frozen.

In this case, observe the following points:

- Do not give the vehicle starting assistance or charge the battery
- The service life of a battery that has been thawed may be reduced drastically
- The start-up behavior may deteriorate, particularly at low temperatures
- It is recommended that you have a thawed battery checked at a qualified specialist workaods

NOTE Damage caused by numerous or extended attempts to start the engine

Numerous or extended attempts to start the engine may damage the catalytic converter due to non-combusted fuel.


Avoid numerous and extended attempts to start the engine.

When jump-starting and charging the batteries, observe the following points:

- Only use undamaged jumper cables / charging cables with a sufficient cross-section and insulated terminal clamps
- Non-insulated parts of the terminal clamps must not come into contact with other metal parts while the jumper cables/charging cables are connected to the battery/jumpstart connection point
- The jumper cables/charging cables must not come into contact with any parts which may move when the engine is running
- · Always make sure that neither you nor the battery is electrostatically charged
- · Always keep away from fire and open flames
- Do not lean over a battery
- When charging: only use a battery charger that has been tested and approved by Mercedes-Benz and read the operating instructions for your charger before charging the batteries

Observe the additional following points during starting assistance:

- Starting assistance may only be provided using batteries with a nominal voltage of 12 V
- The vehicles must not touch each other
- Vehicles with a gasoline engine: only perform starting assistance when the engine and exhaust system are cold
- Vehicles with a battery main switch: check whether the battery main switch is inserted $(\rightarrow page 120)$
- Secure the vehicle using the parking brake.
- Vehicles with automatic transmission: shift the transmission to position P.
- Switch off the ignition and all electrical con-
- Open the hood (\rightarrow page 278).



Example: jump-start connection

- (i) Right-hand drive vehicle: the jump-start connection may be on the opposite side.
- Remove the cover from the positive terminal on the donor battery.
- First, connect the positive terminal clamp of the jumper cables/charging cables to the positive terminal of the other vehicle's battery.
- With positive terminal clamp 2 of the jumper cable/charging cable, slide the red protective cap on jump-starting connection back with a clockwise turn.
- Connect the other positive terminal clamp to the positive terminal of jump-start connection

- During starting assistance: start the engine of the donor vehicle and let it run at idle speed.
- First, connect the negative terminal clamp of the jumper cable/charging cable to the negative pole of the donor battery.
- Connect the other negative terminal clamp of the jumper cable / charging cable to a ground point on your own vehicle (a bare metal part in the engine compartment).
- During starting assistance: start the engine on your own vehicle.
- When charging: start the charging process.
- During starting assistance: let the engine run for a few minutes.
- During starting assistance: before disconnecting the jumper cable, switch on an electrical consumer on your own vehicle, e.g. the rear window heater or lighting.

When the starting assistance/charging process is complete:

Remove the jumper cables/charging cables in reverse order: first the negative clamp from the ground point in the engine compartment, then the negative clamp from the donor battery. Then the positive clamp from the positive terminal of jump-start connection (1), then the positive clamp of the donor battery. The red protective cap springs back to its initial position when positive terminal clamp (2) is disconnected from jump-starting connection 1.

You can obtain further information at a qualified specialist workshop.

Installing/removing the floor covering (vehicles with rear wheel drive)


WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.

- Ensure floor mats and carpets cannot slip and provide sufficient room for the pedals.
- Do not lay multiple floor mats or carpets on top of one another.



- Switch off all electrical consumers.
- ➤ To remove: unscrew screws ③ and remove trim ②.
- Remove floor covering ①.
- ➤ To install: insert floor covering and align it at the base of the driver's seat and at the door sill.
- Put trim ② in place and screw screws ③ back in.

Disconnecting the starter battery


I NOTE Damage to electrical assemblies

Electrical assemblies could be damaged if the starter battery is disconnected while the engine is running.

- Switch off the engine. Then, release the battery clamps of the starter battery.
- Always disconnect the starter battery in the battery case in the left footwell first. Otherwise, electrical assemblies, e.g. the alternator, could be damaged.
- ! NOTE Damage to the vehicle's electronics


If you do not disconnect the battery as described here, the vehicle's electronics could be damaged.

Always disconnect the starter battery in following the sequence, and do not reverse the battery terminals under any circumstances. Otherwise, the vehicle's electronics could be damaged.



Vehicles with rear wheel drive

- i) If the vehicle is expected to be parked for an extended period or out of use for longer than four weeks, observe the information on parking the vehicle for an extended period (→ page 144).
- Vehicles with a battery main switch: remove the main switch of the battery (→ page 121).
- Vehicles without a battery main switch: switch off all electrical consumers.
- Switch off the engine and the power supply.
- \triangleright Remove the floor covering (\rightarrow page 297).
- Remove screws and slide battery cover
 in the direction of the arrow.
 The screws must protrude over the larger recesses.
- Remove battery cover ② upwards.



- First loosen and remove the negative terminal clamp on the battery so that the clamp is no longer in contact with the terminal.
- Remove the positive terminal clamp cover.
- Loosen the positive terminal clamp and fold it up to the side, together with the prefuse box.

Removing/installing the starter battery

Vehicles with rear wheel drive: removing the starter battery



- Disconnect the starter battery (\rightarrow page 298).
- Remove breather hose (1) with the connector bracket from the connection on the degassing cover.



- Pull out and remove screws 2 of bracket 3 upwards.
- Slide the starter battery from its anchorage in the direction of travel.
- Fold the bars of the starter battery upwards and remove the starter battery from the battery box.

Vehicles with rear wheel drive: installing the starter battery

When reconnecting the starter battery, observe the safety measures and protection notes (\rightarrow page 295).



- Insert the starter battery into the battery box.
- Fold down the bars of the starter battery.
- Slide the starter battery into its anchorage in the opposite direction to the direction of travel.
- Insert bracket 3.
- Tighten screws 2 on bracket 3 which holds the battery in place.



- Attach breather hose
 with the connector bracket to the connection of the degassing cover.
- Reconnect the starter battery (\rightarrow page 298).

Mercedes-Benz recommends that you have the starter battery replaced at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

If you want to replace the starter battery yourself, observe the following notes:

- Always replace a defective starter battery with a starter battery which meets the specific requirements of the vehicle.
- Carry over detachable parts such as the vent hose, elbow fitting or terminal cover from the starter battery to be replaced.
- Make sure that the vent hose is always connected to its original opening on the battery side.
 - Install the existing or newly supplied stop
 - Otherwise, gases or battery acid could escape.
- Make sure that the detachable parts are connected in the same way as before.

Disconnecting the auxiliary battery in the engine compartment


I NOTE Damage to electrical assemblies

Electrical assemblies could be damaged if the starter battery is disconnected while the engine is running.

- Switch off the engine. Then, release the battery clamps of the starter battery.
- Always disconnect the starter battery in the battery case in the left footwell first. Otherwise, electrical assemblies, e.g. the alternator, could be damaged.
- NOTE Damage to the vehicle's electronics

Incorrectly disconnecting the auxiliary battery can cause damage to the vehicle's electronics.

Always disconnect the auxiliary battery as described in the following sequence. Do not reverse the battery terminals under any circumstances.



- Observe the safety measures and protection notices when disconnecting the auxiliary battery (→ page 295).
- Switch off all electrical consumers.
- Switch off the engine and the power supply.
- ightharpoonup Open the hood (ightharpoonup page 278).
- First loosen and remove the negative terminal clamp on the auxiliary battery so that the clamp is no longer in contact with the terminal.
- Remove the positive terminal clamp cover.
- Loosen and remove the positive terminal clamp.

Towing or tow-starting

Overview of permissible towing methods

In the event of a breakdown, Mercedes-Benz recommends that you have the vehicle transported instead of towed.

- **NOTE** Damage to the vehicle due to towing away incorrectly
- Observe the instructions and notes on towing away.
- i Vehicles with automatic transmission and rear-wheel drive: if there is a malfunction, the automatic transmission may be locked in position P.

If the automatic transmission cannot be shifted to position [N], transport the vehicle (\rightarrow page 303). A towing vehicle with lifting equipment is required for vehicle transport.

Permissible towing methods

	Both axles on the ground	Front axle raised	Rear axle raised
Vehicles with automatic transmission and rear-wheel drive	Yes, no further than 31 miles (50 km) at 31 mph (50 km/h)	Yes, no further than 31 miles (50 km) at 31 mph (50 km/h)	Yes, if the steering wheel is fixed in the center position with a steering wheel lock
Vehicles with all-wheel drive	Yes, no further than 31 miles (50 km) at 31 mph (50 km/h)	No	No

To tow with a raised axle: towing should be performed by a towing company.

Towing away the vehicle with both axles on the ground

- Observe the notes on permissible towing methods (\rightarrow page 300).
- Make sure that the battery is connected and charged.

When the battery is discharged, the following situations occur:

- The engine cannot be started.
- It is not possible to release or apply the electric parking brake.
- Vehicles with automatic transmission: the automatic transmission cannot be shifted to position N or P.
- NOTE Damage due to towing away at excessively high speeds or over long dis-

The drivetrain could be damaged when towing at excessively high speeds or over long dis-

- A towing speed of 30 mph (50 km/h) must not be exceeded.
- A towing distance of 30 miles (50 km) must not be exceeded.
- (i) Vehicles with automatic transmission and rear wheel drive: if there is a malfunction, the automatic transmission may be locked in position P.

If the automatic transmission cannot be shifted to position N, transport the vehicle $(\rightarrow page 303)$. A towing vehicle with lifting equipment is required for vehicle transport.

WARNING Risk of accident when towing a vehicle which is too heavy

If the vehicle being tow-started or towed away is heavier than the permissible gross mass of your vehicle, the following situations can occur:

- The towing eye may become detached.
- The vehicle/trailer combination may swerve or even overturn.
- If another vehicle is tow-started or towed away, its weight must not exceed the permissible gross mass of your own vehicle.

If a vehicle needs to be towed or tow started, its weight should not be greater that the permissible gross mass of the towing vehicle.

- Information on the vehicle's permissible gross mass can be found on the vehicle identification plate (\rightarrow page 338).
- Vehicles with automatic transmission: do not open the driver's or co-driver door, as the automatic transmission will automatically shift to position P.
- Install the towing eye (\rightarrow page 304).
- Secure the towing device.

- NOTE Damage due to incorrect connection of the tow bar
- Only connect the tow rope or tow bar to the towing eyes.
- i You can also secure the towing device to the trailer hitch.
- NOTE Damage and risk of accident when towing with a tow rope

There is a risk of an accident if you do not observe safety and protective measures when towing using a tow rope.

Observe the following points when towing with a tow rope:

- Secure the tow rope on the same side on both vehicles, if possible.
- Make sure the tow rope does not exceed the legally prescribed length.
- Mark the tow rope in the middle, e.g. with a white cloth (30 x 30 cm). This makes other road users aware that a vehicle is being towed.
- Observe the brake lamps of the towing vehicle while driving. Always maintain a distance that ensures the tow rope does not sag.
- Do not use steel cables or chains to tow your vehicle. Otherwise, you could damage the vehicle.
- Deactivate automatic locking (→ page 50).
- Do not activate the HOLD function.
- Deactivate the tow-away alarm (→ page 62).
- Deactivate Active Brake Assist (→ page 150).
- Vehicles with automatic transmission: shift the automatic transmission to position N.
- Release the parking brake.

▲ WARNING Risk of accident due to limited safety-related functions during the towing process

Safety-related functions are limited or no longer available in the following situations:

- · the ignition is switched off.
- the brake system or power steering system is malfunctioning.
- the energy supply or the on-board electrical system is malfunctioning.

When your vehicle is then towed away, significantly more effort may be required to steer and brake than is normally required.

- Use a tow bar.
- Make sure that the steering wheel can move freely, before towing the vehicle away.
- NOTE Damage due to excessive tractive power

If you pull away sharply, the tractive power may be too high and the vehicles could be damaged.

Pull away slowly and smoothly.

Towing a vehicle with the front or rear axle raised

NOTE Damage when the ignition is switched on

If you leave the ignition switched on when towing the vehicle with the front or rear axle raised, ESP® actuation can damage the brake system.

- ▶ The ignition must be switched off.
- NOTE Damage due to incorrect removal or installation of the propeller shafts

When installing the propeller shafts, they can be damaged if you do not use new screws.

Always use new screws when installing the propeller shafts.

Only have the propeller shafts installed or removed by qualified, skilled personnel.

- (i) If the front axle is damaged, raise the vehicle at the front axle and if the rear axle is damaged, raise the vehicle at the rear axle.
- (i) Vehicles with automatic transmission and rear-wheel drive: if there is a malfunction, the automatic transmission may be locked in position **P**. If the automatic transmission cannot be shif-


ted to position N, transport the vehicle (→ page 303). A towing vehicle with lifting equipment is required for vehicle transport.

- Observe the notes on permissible towing methods (\rightarrow page 300).
- The propeller shafts to the drive axles must be removed if the maximum permissible towing distance is exceeded.
- Vehicles with automatic transmission: shift the automatic transmission to position
- Release the parking brake.
- Switch off the ignition.

Loading the vehicle for transport

- Observe the notes on permissible towing methods (\rightarrow page 301, 302).
- Connect the tow bar to the towing eye to load the vehicle
- Vehicles with automatic transmission: shift the automatic transmission to position
- (i) Vehicles with automatic transmission: in the event of damage to the electrics, the automatic transmission may be locked in position P. To shift to position N, provide the on-board electrical system with power $(\rightarrow page 295).$
- Load the vehicle onto the transporter.
- Vehicles with automatic transmission: shift the automatic transmission to position Ρ.
- Use the parking brake to secure the vehicle against rolling away.
- Only secure the vehicle by the wheels.

Vehicles with all-wheel drive/vehicles with automatic transmission



- Make sure that the front and rear axles come to rest on the same transportation vehicle.
- NOTE Damage to the drivetrain due to incorrect positioning
- ▶ Do not position the vehicle above the connection point of the transport vehicle.
- **NOTE** Vehicle damage due to improper loading


An all-wheel drive vehicle may be damaged if it is tilted, pushed or moved while being loaded using a hydraulic platform.

- When loading a vehicle with all-wheel drive, the vehicle should only be moved and positioned by its own power.
- ▶ The vehicle and the surface it is positioned on should no longer be moved when the key is removed or if the door is open.

Towing eye storage location


The towing eye is located in the vehicle tool kit in the front-passenger footwell (\rightarrow page 305).

Installing/removing the towing eye



Installing and removing the front towing eye

- To install the front towing eye: press the top of the cover and remove the cover.
- Screw in towing eye (1) clockwise to the stop and tighten.
- To remove the front towing eye: unscrew towing eve (1) counter-clockwise.
- Insert the cover with the tabs at the top and push in at the bottom until the cover engages.



Rear towing eye (vehicles with passenger vehicle approval)

- (i) Rear towing eye (2) is permanently attached to the vehicle.
- **NOTE** Damage to the vehicle due to incorrect use of the towing eye

When a towing eye is used to recover a vehicle, the vehicle may be damaged in the process.



Only use the towing eye to tow away or tow start the vehicle.

Tow starting vehicle (emergency engine start)

Vehicles with automatic transmission

NOTE Damage to the automatic transmission due to tow starting

The automatic transmission may be damaged in the process of tow starting vehicles with automatic transmission

- Vehicles with automatic transmission must not be tow started.
- Do not tow start vehicles with automatic transmission.

Electrical fuses

Notes on electrical fuses

WARNING Risk of accident and injury due to overloaded lines

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric line could be overloaded.

This could result in a fire.

- Always replace faulty fuses with specified new fuses containing the correct amperage.
- **NOTE** Damage due to incorrect fuses

Electrical components or systems could be damaged by incorrect fuses.

Only use fuses which have been approved by Mercedes-Benz and which have the correct fuse rating.

The electrical fuses in your vehicle switch off defective circuits. If a fuse blows, all the components on the circuit and their functions will cease to operate.

Blown fuses must be replaced with fuses of an equivalent specification, which you can determine by the color and fuse rating. The fuse allocation chart and further information on the electric fuses and relays can be found in the "Fuse allocation chart" supplement.

NOTE Damage or malfunctions caused by moisture

Moisture may cause damage to the electrical system or cause it to malfunction.

- When the fuse box is open, make sure that no moisture can enter the fuse box.
- When closing the fuse box, make sure that the seal of the lid is positioned correctly on the fuse box.

If the new fuse which has been inserted also blows, have the cause traced and rectified at a qualified specialist workshop.


Make sure of the following before replacing a fuse:

- the vehicle is secured such that it does not roll away
- · all electrical consumers are switched off
- the ignition is switched off

The fuses are located in various fuse boxes:

- fuse box in the front-passenger footwell $(\rightarrow page 305)$
- fuse box in the seat base of the driver's seat $(\rightarrow page 305)$

Opening the fuse box in the seat base of the driver's seat



- To open: press down and unclip fasteners (1) on the cover.
- Remove the cover.
- To close: press the cover firmly into the seat base until fasteners (1) clip in.

Opening and closing the fuse box in the codriver's footwell

Opening the fuse box

Unlocking and removing the stowage compartment cover in the co-driver's footwell $(\rightarrow page 306)$.



Example: vehicle tool kit insert

- Lift the insert at marked positions ①.
- Pull the insert out of clips 2.

Closing the fuse box

- Slide the insert into clips 2.
- Close the insert by pressing on marked positions 1.
- Put on the stowage compartment cover in the co-driver's footwell and lock it (\rightarrow page 306).

Vehicle tool kit

Information on the vehicle tool kit

The vehicle tool kit is located in the stowage compartment in the footwell on the front-passenger side (\rightarrow page 306).


The vehicle tool kit contains:

- · a towing eye
- a screwdriver with Torx. Phillips and slotted

The vehicle tool kit may also contain the following, for example:

- an open-end wrench
- a wheel wrench

Unlocking and removing the stowage compartment cover



- Remove the rubber mat from the frontpassenger footwell.
- To unlock: turn the quick-release fastener (1) counter-clockwise to position 1.
- Slightly raise and pull out the cover.

Inserting and locking the cover

- Slide in the cover and press it downwards.
- Press down the quick-release fastener 1 until it engages.
- To lock: turn the quick-release fastener 1 clockwise to position 2.

Removing the vehicle tool kit



Example: vehicle tool kit insert


- Raise the insert at marked points ①.
- Pull the insert out of clips 2.

Storing the vehicle tool kit

- Slide the insert into clips 2.
- Close the insert by pressing on marked points

Hydraulic jack

Information on the hydraulic jack



The hydraulic jack is located in side compartment above the co-driver door step.

The jack has a maximum weight of 16.5 lbs (7.5 kg) depending on the vehicle's equipment. You will find the maximum load capacity of the iack stated on the adhesive label attached to the iack. If there is a malfunction, please contact a qualified specialist workshop.


lack maintenance:

- Clean and grease all moving parts after use.
- Extend and retract the pistons fully every six months.

Removing the pump lever rod and the jack

Requirements:

• The co-driver door is open.



- To open: press down and unclip fasteners (1) on the cover.
- Remove the cover.
- Pull out the holder completely and place it on the step.



- Remove jack 2 and unclip the pump lever
- (i) It is recommended to wear gloves for this work.
- To close: press the cover firmly into the door sill so that fasteners (1) engage.

Information on noise or unusual driving characteristics

While driving, pay attention to vibrations, noises and unusual driving characteristics, e.g. pulling to one side. This may indicate damage to the wheels or tires. If you suspect that a tire is defective, reduce your speed. Stop the vehicle as soon as possible to check if wheels and tires have been damaged or are no longer functioning properly. Hidden tire damage could also be causing the unusual driving characteristics. If no signs of damage can be detected, have the tires and wheels checked at a qualified specialist workshop.

Notes on regularly inspecting wheels and tires

vehicle.

▲ WARNING Risk of accident from damaged tires

Damaged tires can cause tire pressure loss. As a result, you could lose control of your

Check the tires regularly for signs of damage and replace any damaged tires immediately.

Check the wheels and tires of your vehicle for damage regularly, i.e. at least every two weeks, as well as after driving off-road or on rough roads. Damaged wheels can lead to a loss of tire pressure.

Look out for the following types of damage, for example:

- Cuts in the tires
- Punctures in the tires
- Tears in the tires
- Bulges on tires
- Deformation or severe corrosion on wheels

WARNING Risk of hydroplaning because tire tread is too low

Insufficient tire tread will result in reduced tire traction. The tire tread will no longer be able to dissipate water.

This increases the risk of hydroplaning on wet road surfaces, particularly when traveling at an inappropriate speed.

If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire tread.

Regularly check the tire tread depth and the condition of the tire tread across the entire width of all tires.

Minimum tread depth for use:

- In summer: 1/8 in (3 mm)
- In winter: 1/6 in (4 mm)
- For safety reasons, have the tires replaced before the legally prescribed limit for the minimum tire tread depth is reached

Conduct the following checks regularly on all wheels, at least once a month or as required, e.g. before a long journey or when driving off-road:

- Check the tire pressure (→ page 310)
- · Check the valve caps
 - Valves must be protected from moisture and dirt with valve caps specifically approved by Mercedes-Benz for your vehicle.
- Visually inspect the tread depth and the tire tread across the whole tire width For use in summer, the minimum tread depth is 1/8 in (3 mm) and for use in winter 1/8 in (4 mm).



Markings (1) show in which places the bar indicators (arrow) are integrated into the tire tread. They are visible as soon as the tread depth is approximately 1/16 in (1.6 mm).

Information on driving with summer tires

At temperatures below 50 °F (10 °C) Summer tires lose elasticity and therefore traction and braking power. Change the tires on your vehicle to M+S tires. Using summer tires at very cold temperatures could cause tears to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

Always observe the maximum permissible speed specified for the summer tires you have installed $(\rightarrow page 321)$.

Once you have installed the summer tires:

- Check the tire pressure (→ page 310)
- Restart the tire pressure monitor $(\rightarrow page 316)$

Information on M+S tires

At temperatures below 50 °F (10 °C) use winter tires or all-season tires - both are marked with M+S

Only winter tires bearing the 🙏 snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

Only these tires will allow driving safety systems such as ABS and ESP® to also function optimally in winter. These tires have been developed specifically for driving in snow.

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.

Always observe the maximum permissible speed specified for the M+S tires you have installed $(\rightarrow page 321)$.

If you install M+S tires that have a lower maximum permissible speed than the maximum design speed of the vehicle, affix an appropriate warning sign in the driver's field of vision. You can obtain this at a qualified specialist workshop. Once you have installed the winter tires, take the following measures:

- Check the tire pressure (→ page 310)
- Restart the tire pressure monitor $(\rightarrow page 316)$

Notes on snow chains

▲ WARNING Risk of accident due to incorrect installation of snow chains

Vehicles with rear-wheel drive: if you have installed snow chains to the front wheels, they may drag against the vehicle body or chassis components.

This could cause damage to the vehicle or the tires.

- Never install snow chains on the front wheels
- Only install snow chains on the rear wheels in pairs.
- Vehicles with twin tires: install the snow chains to the outer wheels.



WARNING Risk of accident due to unsuitable snow chains

Vehicles with all-wheel drive do not have sufficient clearance on the front axle for commercially available snow chains.

When you install commercially available snow chains, the snow chains may come loose and damage chassis components or brake hoses.

Only install snow chains approved by Mercedes-Benz for these tires.

For safety reasons. Mercedes-Benz recommends that you only use snow chains that have been checked and approved. You can obtain information about snow chains from any qualified specialist workshop.



NOTE Damage to the wheel trim from mounted snow chains

If snow chains are mounted to steel wheels. the wheel trims can be damaged.

Remove the wheel trims of steel wheels before mounting snow chains.

Observe the following notes when using snow chains:

- Snow chains are only permissible for certain wheel/tire combinations. You can obtain information on them at a qualified specialist workshop.
- For safety reasons, only use snow chains that have been specifically approved for your vehicle by Mercedes-Benz, or snow chains with the same quality standard.
- The snow chains must be retightened after driving approximately 0.6 miles (1 km). This is the only way to ensure the snow chains are optimally seated with clearance to adjacent components.
- Vehicles with all-wheel drive: install snow chains to the wheels on the rear axle. On vehicles with twin tires, install the snow chains to the outer wheels. Observe the manufacturer's installation instructions.

- Use snow chains only when the road surface is completely snow-covered. Remove the snow chains as soon as possible when you come to a road that is not snow-covered.
- Local regulations may restrict the use of snow chains. Observe the applicable regulations before installing snow chains.
- Activate all-wheel drive before driving off with snow chains (→ page 125, 124, 125).
- If snow chains are installed, the maximum permissible speed is 30 mph (50 km/h).
- Vehicles with Parking Assist: do not use Parking Assist PARKTRONIC if snow chains are installed
- You can deactivate ESP[®] to pull away
 (→ page 148). This allows the wheels to
 spin, achieving an increased driving force.

Tire pressure

Notes on tire pressure

WARNING Risk of accident due to insufficient or excessive tire pressure

Underinflated or overinflated tires pose the following risks:

- The tires may burst, especially as the load and vehicle speed increase.
- The tires may wear excessively and/or unevenly, which may greatly impair tire traction.
- The driving characteristics, as well as steering and braking, may be greatly impaired.
- Comply with the recommended tire pressure and check the tire pressure of all tires including the spare wheel regularly:
- at least once a month
- · when the load changes
- before embarking on a longer journey
- if operating conditions change, e.g. offroad driving
- Adjust the tire pressure as necessary.

Driving with tire pressure that is too high or too low has the following consequences:

- Shorten the service life of the tires.
- · Cause increased tire damage.
- Adversely affect handling characteristics and thus driving safety, e.g. due to hydroplaning.

WARNING Risk of an accident due to insufficient tire pressure

Tires with pressure that is too low can overheat and burst as a result.

In addition, they also suffer from excessive and/or irregular wear, which can significantly impair the braking properties and the handling characteristics.

Avoid excessively low tire pressures in all the tires, including the spare wheel.

Tire pressure which is too low can cause:

- Tire faults as a result of overheating
- · Impaired handling characteristics
- Irregular wear
- Increased fuel consumption

WARNING Risk of accident from excessive tire pressure

Tires with excessively high pressure can burst because they are damaged more easily by highway fill, pot holes etc.

In addition, they also suffer from irregular wear, which can significantly impair the braking properties and the handling characteristics.

Avoid excessively high tire pressures in all the tires, including the spare wheel.

Excessively high tire pressure can result in:

- Increased braking distance
- Impaired handling characteristics
- Irregular wear
- · Impaired driving comfort
- · Susceptibility to damage

WARNING Risk of accident caused by repeated drop in tire pressure

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged.

Insufficient tire pressure can cause the tires to burst.

- Inspect the tire for signs of foreign objects.
- Check whether the wheel or valve has a leak.
- If you are unable to rectify the damage, contact a qualified specialist workshop.

You can find information on recommended tire pressure for the vehicle's factory-installed tires on the following labels:

- Tire and Loading Information placard on the B-pillar of your vehicle (→ page 317).
- Tire pressure table on the inside of the fuel filler flap.

Observe the maximum tire pressure $(\rightarrow page 321)$.

Use a suitable pressure gauge to check the tire pressure. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure.



ENVIRONMENTAL NOTE Environmental damage due to insufficient or excessive tire pressure

Insufficient or excessive tire pressure shortens the service life of the tires.

Check the tire pressure regularly, but at least every 14 days.

Vehicles with a tire pressure monitor: you can also check the tire pressure using the on-board computer.

Only check tire pressure when the tires are cold. Conditions for cold tires:

- The vehicle has been parked with the tires out of direct sunlight for at least three hours.
- The vehicle has traveled less than 1 mile (1.6 km).

A rise in the tire temperature of 18°F (10°C) increases the tire pressure by approx. 10 kPa (0.1 bar/1.5 psi). Take this into account when checking the tire pressure of warm tires.

The tire pressure recommended for increased load/speed in the tire pressure table may affect the ride comfort.

A

WARNING Risk of accident due to unsuitable accessories on tire valve

If you mount unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause a loss of tire pressure. Aftermarket tire pressure monitoring systems will cause the tire valve to remain open, depending on the design. This can also result in a loss of tire pressure.

Only screw standard valve caps or valve caps specifically approved by Mercedes-Benz for your vehicle onto the tire valve.

Notes on trailer operation

The applicable tire pressure for the tires of the rear axle is always the recommended tire pressure for a full load.

Overview of the tire pressure table

The tire pressure table can be found on the seat base or on the B-pillar on the driver's side.

i The data shown in the images is example data.



The tire pressure table shows the recommended tire pressure for the tires installed at the factory on this vehicle. The recommended tire pressures are valid for cold tires and different vehicle load conditions.

If one or more tire sizes precede a tire pressure, the tire pressure information following is only valid for those tire sizes.

If the preceding tire sizes are supplemented by the [1] symbol, the tire pressure information following shows alternative tire pressures.

The load conditions "partially laden" and "fully laden" are defined in the table for varying weights.

Some tire pressure tables only show the rim diameter instead of the complete tire size, e.g. **R16**. The rim diameter is part of the tire size and can be found on the side wall of the tire $(\rightarrow page 321)$.

Front axle tire pressures on vehicles with all-wheel/rear wheel drive and single tires Max. front axle load 4101 lbs (1860 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4101 lbs (1860 kg)
LT245/75R16 120/116Q	Fully laden	320 kPa (3.2 bar/46 psi)

Front axle tire pressures on vehicles with rear wheel drive and single tires Max. front axle load 4409 lbs (2000 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4409 lbs (2000 kg)
LT245/75R16 120/116Q	Fully laden	360 kPa (3.6 bar/52 psi) 1)

¹⁾ Only valid for vehicles with a long wheelbase 171 in (4350 mm) and a permissible gross weight of over 7716 lbs (3.5 t).

Rear axle tire pressures on vehicles with all-wheel/rear wheel drive and single tires Max. rear axle load 5357 lbs (2430 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load 5357 lbs (2430 kg)
LT245/75R16 120/116Q	Fully laden	480 kPa (4.8 bar/70 psi)
LT245/75R16 120/116Q	Partially laden ²⁾	420 kPa (4.2 bar/61 psi) ²⁾

²⁾ It is only permissible to use this reduced tire pressure if it can be guaranteed by weighing the vehicle that the rear axle load of 4960 lbs (2250 kg) will not be exceeded. In case of doubt, inflate to 480 kPa (4.8 bar/70 psi).

Front axle tire pressures for vehicles with all-wheel/rear wheel drive and twin tires Max. front axle load 4079 lbs (1850 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4079 lbs (1850 kg)
LT215/85R16 115/112Q	Fully laden	380 kPa (3.8 bar/55 psi)

Max. front axle load 4409 lbs (2000 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4409 lbs (2000 kg)
LT215/85R16 115/112Q	Fully laden	420 kPa (4.2 bar/61 psi)

Max. front axle load 4630 lbs (2100 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4630 lbs (2100 kg)
LT215/85R16 115/112Q	Fully laden	450 kPa (4.5 bar/65 psi)

Rear axle tire pressures for vehicles with all-wheel/rear wheel drive and twin tires Max. rear axle load 7055 lbs (3200 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load up to 7055 lbs (3200 kg)
LT215/85R16 115/112Q	Fully laden	370 kPa (3.7 bar/54 psi)

Max. rear axle load 7716 lbs (3500 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load 7716 lbs (3500 kg)
LT215/85R16 115/112Q	Fully laden	400 kPa (4.0 bar/58 psi)

Max. rear axle load 7937 lbs (3600 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load 7937 lbs (3600 kg)
LT215/85R16 115/112Q	Fully laden	420 kPa (4.2 bar/61 psi)

Front axle tire pressures on vehicles with Super Single tires Max. front axle load 4079 lbs (1850 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4079 lbs (1850 kg)
225/75R16C 121/120R (122L)	Fully laden	340 kPa (3.4 bar/49 psi)

Max. front axle load 4409 lbs (2000 kg)

Tires/disc wheel	Vehicle load	Max. front axle load 4409 lbs (2000 kg)
225/75R16C 121/120R (122L)	Fully laden	370 kPa (3.7 bar/54 psi)

Rear axle tire pressures on vehicles with rear wheel drive and Super Single tires Max. rear axle load 7055 lbs (3200 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load 7055 lbs (3200 kg)
285/65R16C 131R	Fully laden	460 kPa (4.6 bar/67 psi)

Max. rear axle load 7716 lbs (3500 kg)

Tires/disc wheel	Vehicle load	Max. rear axle load 7716 lbs (3500 kg)
285/65R16C 131R	Fully laden	520 kPa (5.2 bar/75 psi)

Be sure to also observe the following further related subjects:

- Notes on tire pressure (→ page 310)
- Tire and Loading Information placard (→ page 317)
- Maximum tire pressure (→ page 321)

Overview of the tire pressure table for emergency spare wheels

Tires/emergency spare wheel	Air pressure	In combination with vehicle tires
225/75 R16C 121/120R (122L) 1)	370 kPa (3.7 bar/54 psi)	225/75 R16C 121/120R (122L)
225/75 R16C 121/120R (122L) 1)	690 kPa (6.9 bar/100 psi)	285/65 R16C 131R

¹⁾ Valid to use for a short time as an emergency spare wheel on Super Single vehicles for a distance of maximum 100 km (62 miles) and at a maximum speed of 55 km/h (34 mph).

Tire pressure monitoring system

Function of the tire pressure monitor on single tires



DANGER Risk of accident due to incorrect tire pressure

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should deter-

mine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation

has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate that the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the indicator lamp will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

The system checks the tire pressure and the temperature of the tires installed on the vehicle by means of a tire pressure sensor.

New tire pressure sensors, e.g. in winter tires, are automatically taught-in during the first journey they are used.

The tire pressure and the tire temperature appear in the multifunction display (\rightarrow page 177).

If there is a substantial loss of tire pressure, a warning is issued:

- Via display messages (→ page 369)
- Via the (!) warning lamp in the instrument cluster

It is the driver's responsibility to set the tire pressure to the recommended cold tire pressure suitable for the operating situation. Set the tire pressure for cold tires using a tire pressure gauge. Note that the correct tire pressure for the current operating situation must first be taught-in to the tire pressure monitoring system.

In most cases, the tire pressure monitoring system will automatically update the new reference values after you have changed the tire pressure. You can, however, also update the reference values by restarting the tire pressure monitoring system manually (\rightarrow page 316).

System limits

The system may be impaired or may not function in the following situations:

- If the tire pressure is set incorrectly
- If there is a sudden pressure loss caused by a foreign object penetrating the tire, for exam-
- If there is a malfunction caused by another radio signal source
- . If there is a change of tire size

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 310)

Checking the tire pressure with the tire pressure monitoring system Requirements:

• The ignition is switched on.

On-board computer:

→ Service → Tires

One of the following displays appears:

 The current tire pressure and tire temperature of the individual wheels.



Instrument Display with color display

• The current tire pressure for each wheel.



Instrument Display with black and white display

- Tire pressure will be displayed after driving a few minutes: the teach-in process of the system is not yet complete. The tire pressures are already being monitored.
- Compare the tire pressure with the recommended tire pressure for the current operating condition (→ page 311). Observe the notes on tire temperature (→ page 310).
- The values displayed in the multifunction display may deviate from those of the tire pressure gauge as they refer to sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those

shown by the on-board computer. In this case, do not reduce the tire pressure.

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 310)

Restarting the tire pressure monitor Requirements:

- The recommended tire pressure is correctly set for the respective operating condition on each of the wheels (→ page 310).
- Restart the tire pressure monitoring system in the following situations:
 - The tire pressure has changed.
 - The wheels or tires have been changed or newly installed.

On-board computer:

¬→ Service → Tires

- Scroll down in the menu. The Use Current Pressures as New Reference Values message appears in the multifunction display.
- Confirm the message to initiate a restart.
 The Tire Press. Monitor Restarted message appears in the multifunction display.

Current warning messages are deleted and the \(\text{\(\! \) \) yellow warning lamp goes out.

After you have driven for a few minutes, the system checks whether the current tire pressures are within the specified range. The current tire pressures are then accepted as reference values and monitored.

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 310)

Radio-equipment approval of the tire pressure monitoring system

Radio equipment approval numbers

Country	Radio equipment approval number
Canada	IC: 4008C-TSSRE4A
	Operation is subject to the following two conditions:
	(1) this device may not cause harmful interference, and
	(2) this device must accept any interference received, including interference that may cause undesired operation.
Mexico	Model: TSSRE4A & TSSSG4G6, IFETEL: RLVHUTS17-0806
USA	FCC ID: YGOTSSRE4A
	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
	WARNING: Any changes or modifi- cation not expressly approved by the party responsible for compli- ance could void the user's author- ity to operate this equipment.

Loading the vehicle

Tire and Loading Information placard




WARNING Risk of an accident when driving with an overloaded tire

Overloaded tires may overheat and burst as a consequence. Overloaded tires can also impair the steering and handling characteristics and lead to brake failure.

Observe the load rating of the tires.

- The load rating must be at least half the gross axle weight rating of the vehicle. Mercedes-Benz recommends you use the load-bearing index, which is given in the vehicle documents.
- Never overload the tires by exceeding the maximum load.

Only vehicles with a gross vehicle weight of less than 10,000 lbs (4,536 kg) have a Tire and Loading Information placard on the B-pillar on the driver's side.



Tire and Loading Information placard



(i) The data shown in the illustration is sample

The Tire and Loading Information placard shows:

- The maximum number of seats indicates the maximum number of occupants permitted to travel in the vehicle.
- The maximum permissible load equals the gross weight of all vehicle occupants, the luggage and cargo.
- The recommended tire pressures for cold tires. The recommended tire pressures apply to the maximum permissible load and up to the maximum permissible speed of the vehi-

Also observe the following information:

- The information about permissible weights on the vehicle identification plate (\rightarrow page 338).
- The information about tire pressure on the tire pressure table.

Additional related subjects:

- Determining the maximum load (→ page 318).
- Notes on tire pressure (→ page 310).

Steps to determining the correct critical load

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 in accordance with the "National Traffic and Motor Vehicle Safety Act of 1966".

- Step 1: locate the statement, "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on the Tire and Loading Information placard of your vehicle.
- Step 2: determine the combined weight of the driver and passengers that will be traveling in your vehicle.
- Step 3: subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- ➤ Step 4: the resulting figure equals the permissible amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1,400 750 (5 x 150) = 650 lbs).
- ➤ Step 5: determine the combined weight of luggage and cargo being loaded on the vehicle. For safety reasons, this weight must not exceed the cargo and luggage load capacity calculated in step 4.
- Step 6:

Even if you have calculated the total load carefully, you should still make sure that the maximum permissible gross weight and the maximum gross axle weight rating of your vehicle are not exceeded. Information for this can be found on the vehicle identification plate.

Weigh the laden vehicle, including driver, passengers and load, on a suitable vehicle weighbridge.

The measured values must not exceed the maximum permitted values listed on the vehicle identification plate.

Additional related subjects:

- Sample calculation for determining the maximum load (→ page 318)
- Tire and Loading Information placard (→ page 317)
- Tire pressure table
- Vehicle identification plate

Sample calculation for determining the maximum load

The following table has examples of how to calculate total and cargo load capacities with varying seating configurations and different numbers and sizes of occupants. The following examples use a maximum load of 1,500 lbs (680 kg). **This value is for illustrative purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard (→ page 317).

The higher the weight of all the occupants, the smaller the maximum load for luggage.

Step 1

	Example 1	Example 2
Combined maximum weight of occupants and load (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)


Step 2

	Example 1	Example 2
Number of people in the vehicle (driver and occupants)	5	1
Distribution of the occupants	Front: 2 Rear: 3	Front: 1
Weight of occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg)
Total weight of all occupants	750 lbs (340 kg)	200 lbs (91 kg)

Step 3

	Example 1	Example 2
Permissible load (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 200 lbs (91 kg) = 1300 lbs (589 kg)

Tire labeling Overview of tire labeling



- Uniform Tire Quality Grading Standards $(\rightarrow page 319)$
- DOT (Department of Transportation), (TIN) Tire Identification Number (\rightarrow page 320)
- Maximum tire load (→ page 321)
- Maximum tire pressure (→ page 321)

- Manufacturer
- 6 Characteristics of the tire (→ page 321)
- Tire size designation, load-bearing capacity, speed rating and load index (\rightarrow page 321)
- Tire name
- (i) The data shown in the illustration is sample

Information on tire quality grades

According to the requirements of the U.S. Department of Transportation's "Uniform Tire Quality Grading Standards" tire manufacturers must grade their tires using the following three performance factors:

- Tread wear grade
- Traction grade
- Temperature grade
- The data shown in the illustration is sample data.
- i) This grading is not legally prescribed for Canada, but specified in most cases anyway.

Tread wear grade

The tread wear grade is a comparative grading based on tread wear grade tests conducted under controlled conditions on a specified U.S. Department of Transportation test track. For example, a tire graded 150 would wear one and one-half times as well on the government test track as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

Traction grade

DANGER Risk of accident due to inadequate traction

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include either acceleration, cornering, hydroplaning or peak traction characteristics.

- Always adapt your driving style and drive at a speed to suit the prevailing traffic and weather conditions.
- **NOTE** Damage to the drivetrain from wheelspin
- Avoid wheelspin.

The traction grades - from highest to lowest are AA, A, B and C. These grades relate to the tire's ability to come to a standstill on a wet pavement under controlled conditions on a specified U.S. government test surface made from asphalt and concrete.

Temperature grade

▲ WARNING Risk of accident from tire overheating and tire failure

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

- Observe the recommended tire pressures and regularly check the tire pressure of all tires including the spare wheel.
- Adjust the tire pressure as necessary.

The temperature grades are A (highest grade), B and C. These relate to a tire's resistance to heat and its ability to release heat on a specified test wheel in laboratory tests under controlled conditions. Sustained high temperatures can cause the material of the tire to degenerate and reduce tire life. In addition, excessively high temperatures can lead to sudden tire failure. Grade C refers to a performance which all passenger vehicle tires must exhibit, according to the U.S. Department of Transportation's requirements.

Information on DOT and TIN (Tire Identification Number)

U.S. tire regulations indicate that every tire manufacturer or retreader must imprint a TIN in or on the sidewall of each tire produced.



(i) The data shown in the illustration is sample data.

The TIN is a unique identification number for tires. and consists of the following components:

- DOT (Department of Transportation): tire symbol indicates that the tire complies with the requirements of the U.S. Department of Transportation.
- Manufacturer identification code: manufacturer identification code 2 provides information about the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols. For further information about retreaded tires, see $(\rightarrow page 324).$
- Tire size: identifier (3) describes the tire size.
- **Tire type code:** tire type code **(4)** can be used by the manufacturer as a code to describe specific characteristics of the tire.
- Date of manufacture: date of manufacture (5) provides information about the age of a tire. The 1st and 2nd numbers indicate the calendar week and the 3rd and 4th numbers indicate the year of manufacture (e.g. "3208" refers to the 32nd week of the year 2008).

Information on maximum tire load



(i) The data shown in the illustration is sample data.

Maximum tire load (1) is the maximum permissible weight for which the tire is approved.

Do not overload the tires by exceeding the maximum permissible load. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (\rightarrow page 317).

Information on maximum tire pressure



(i) The data shown in the illustration is sample data.

Maximum permitted tire pressure (1), which is permitted for the tires must not be exceeded.

Exception: when using the 225/75 R16C 121/120R (122L) tires as a spare wheel on the rear axle of Super Single vehicles with a distance limit of 62 mi (100 km) and speed limit of 34 mph (55 km/h).

Information on tire characteristics



(i) The data shown in the illustration is sample data.

This information describes the type of tire cord and the number of layers in sidewall 1 and under tire tread 2.

Tire size designation, load-bearing capacity, speed rating and load index

WARNING Risk of injury through exceeding the specified tire load rating or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

Therefore, only use tire types and sizes approved for your vehicle model.

Observe the tire load rating and speed rating required for your vehicle.



- Prefixing letter
- Nominal tire width in millimeters
- Aspect ratio (in percent)
- Tire code
- 6 Rim diameter
- 6 Load-bearing index
- Speed rating
- Output
 <p
- i The data shown in the illustration is sample data.

Further information about reading tire data can be obtained from any qualified specialist workshop.

Prefixing letter 1:

- "LT": light truck tires in accordance with US manufacturer standards.
- "C": tires for commercial usage in accordance with European manufacturer standards.

Aspect ratio (in percent) 3:

The size ratio between the tire height and tire width and is shown in percent (tire height divided by tire width).

Tire code (1) (tire type):

· "R": radial tire

Rim diameter 5:

The diameter of the bead seat (not the diameter of the rim flange). The rim diameter is specified in inches (in).

Load-bearing index 6:

Numerical code which specifies the maximum load-bearing capacity of a tire ("91" equals, e.g. 1356 lb (615 kg)).

The tire load-bearing capacity must be at least half the gross axle weight rating of the vehicle.

Do not overload the tires by exceeding the maximum permissible load.

See also:

- Maximum permissible load on the Tire and Loading Information placard (→ page 317)
- Maximum tire load (→ page 321)
- Load index

Speed rating 2:

Specifies the approved maximum speed of the tire.

 An electronic speed limiter prevents your vehicle from exceeding a speed of 130 mph (210 km/h).

Ensure that your tires have the required speed rating. You can obtain information on the required speed rating at an authorized Mercedes-Benz Center.

Summer tires

Index	Speed rating
L	Up to 75 mph (120 km/h)
M	Up to 81 mph (130 km/h)
N	Up to 87 mph (140 km/h)
Р	Up to 93 mph (150 km/h)
Q	Up to 100 mph (160 km/h)
R	Up to 106 mph (170 km/h)

Summer, all-season and winter tires

Index	Speed rating
L M+S ¹	Up to 75 mph (120 km/h)
M M+S ¹	Up to 81 mph (130 km/h)
N M+S ¹	Up to 87 mph (140 km/h)
P M+S ¹	Up to 93 mph (150 km/h)
Q M+S ¹	Up to 100 mph (160 km/h)
R M+S ¹	Up to 118 mph (170 km/h)

1: or "M+S A " for winter tires

Winter tires are marked with the Association (RMA) and the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow.

Load index @:

"Light load": light load tires

"C": commercial tires

Information on definitions (tires and loading)

Tire structure and characteristics: describes the number of lavers or the number of rubbercoated lavers in the tire tread and the tire wall. These are made of steel, nylon, polyester and other materials.

Bar: metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

DOT (Department of Transportation): DOT marked tires fulfill the requirements of the U.S. Department of Transportation.

Average weight of vehicle occupants: the number of occupants for which the vehicle is designed multiplied by 150 lbs (68 kg).

Uniform Tire Quality Grading Standards: a uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. The quality grading assessment is made by the manufacturer in accordance with test specifications of the U.S. government. The quality grade of a tire is imprinted on the sidewall of the tire.

Recommended tire pressure: the recommended tire pressure is the pressure specified for the tires installed on the vehicle at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires, the maximum permissible load and the maximum permissible vehicle speed.

The tire pressure table contains the recommended tire pressures for cold tires under various operating conditions, i.e. load and/or speed of the vehicle.

Increased vehicle weight due to optional equipment: the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Rim: the part of the wheel on which the tire is installed.

GAWR (Gross Axle Weight Rating): GAWR is the gross axle weight rating. The actual load on an axle must never exceed the Gross Axle Weight

Rating, You can find the Gross Axle Weight Rating on the B-pillar on the driver's side.

Speed rating: the speed rating is part of the tire identification. It specifies the speed range for which a tire is approved.

GVW (Gross Vehicle Weight): the Gross Vehicle Weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the trailer drawbar noseweight if applicable. The Gross Vehicle Weight must never exceed the Gross Vehicle Weight Rating (GVWR) specified on the B-pillar on the driver's side.

GVWR (Gross Vehicle Weight Rating): the GVWR is the maximum permitted gross weight of the fully laden vehicle (weight of the vehicle including all accessories, occupants, fuel, luggage and the trailer drawbar noseweight if applicable). The Gross Vehicle Weight Rating is specified on the vehicle identification plate on the Bpillar on the driver's side.

Maximum weight of the laden vehicle: the maximum weight is the sum of the vehicle's curb weight, weight of the accessories, maximum load and the weight of the factory installed optional equipment.

Kilopascal (kPa): metric unit for tire pressure. 6.9 kPa are the equivalent of 1 psi. Another unit for tire pressure is bar. 100 kilopascals (kPa) are the equivalent of 1 bar.

Load index: in addition to the load-bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load-bearing capacity more precisely.

Curb weight: the weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the airconditioning system and optional equipment if these are installed on the vehicle, but does not include passengers or luggage.

Maximum tire load: the maximum tire load is the maximum permissible weight in kilograms or lbs for which a tire is approved.

Maximum permissible tire pressure: maximum permissible tire pressure for one tire.

Maximum load on one tire: maximum load on one tire. This is calculated by dividing the maximum axle load for one axle by two.

PSI (pounds per square inch): standard unit of measurement for tire pressure.

Aspect ratio: relationship between tire height and tire width in percent.

Tire pressure: pressure inside the tire applying an outward force to every square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

Tire pressure on cold tires: the tires are cold when the vehicle has been parked with the tires out of direct sunlight for at least three hours and the vehicle has been driven less than 1 mile (1.6 km).

Tire contact surface: the part of the tire that comes into contact with the road.

Tire bead: the purpose of the tire bead is to ensure that the tire sits securely on the wheel rim. There are several wire cores in the tire bead to prevent the tire from changing length on the wheel rim.

Side wall: the part of the tire between the tread and the tire bead.

Special equipment weight: the combined weight of those optional extras that weigh more than the replaced standard parts and more than 5 lbs (2.3 kg). These optional extras, such as high-performance brakes, level control system, a roof luggage rack or a high-performance battery, are not included in the curb weight and the weight of the accessories.

TIN (Tire Identification Number): a unique identification number which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer identification code, tire size, tire type code and the manufacturing date.

Load-bearing index: the load-bearing index (also load index) is a code that contains the maximum load-bearing capacity of a tire.

Traction: traction is the result of friction between the tires and the road surface.

Wear indicator: narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of 1/16 in (1.6 mm) has been reached.

Distribution of vehicle occupants: distribution of vehicle occupants over designated seat positions in a vehicle.

Maximum permissible payload weight: nominal load and luggage load plus 150 lbs (68 kg) multiplied by the number of seats in the vehicle.

Changing a wheel

Notes on selecting, installing and replacing

You can ask for information regarding permitted wheel/tire combinations at a qualified specialist workshop.



WARNING Risk of accident due to incorrect sizes of wheels and tires

If wheels and tires of the wrong size are used, the wheel brakes or wheel suspension components may be damaged.

Always replace wheels and tires with ones that fulfill the specifications of the original part.

For wheels, pay attention to the following:

- Designation
- Type
- Permissible wheel load
- Wheel offset

For tires, pay attention to the following:

- Designation
- Manufacturer
- Tvpe
- · Load-bearing index
- Speed rating



WARNING Risk of injury through exceeding the specified tire load rating or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.

NOTE Vehicle and tire damage through tire types and sizes that have not been approved

For safety reasons, only use tires, wheels and accessories which have been specially approved by Mercedes-Benz for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or FSP[®]

Otherwise, certain properties, such as handling characteristics, vehicle noise and consumption could be adversely affected. Furthermore, other tire size could result in the tires rubbing against the body and axle components when loaded. This could result in damage to the tire or the vehicle.

- Only use tires, wheels and accessories that have been checked and recommended by Mercedes-Benz.
- NOTE Driving safety put at risk by retreaded tires

Retreaded tires are not checked or recommended by Mercedes-Benz, as previous damage is not always detected during the retread

Driving safety cannot, therefore, be guaranteed.

- Do not use used tires when their previous usage is unknown.
- **NOTE** Damage to electronic component parts through the use of tire-installing tools

Vehicles with a tire pressure monitoring system: there are electronic component parts in the wheel. Tire-installing tools should not be applied in the area of the valve.

Otherwise, the electronic component parts could be damaged.

Always have tires changed at a qualified specialist workshop.

Accessories that are not approved for your vehicle by Mercedes-Benz, or are not being used correctly, can impair operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- Suitability
- Legal stipulations
- Factory recommendations

Observe the following points when selecting, installing and replacing tires:

- Use only tires and wheels of the same type, design (winter tires, all-season tire) and make.
- Only install wheels of the same size and tread design on one axle (left and right).
 - It is only permissible to install a different wheel size to this in the event of a flat tire in order to drive to the specialist workshop.
- Only install tires of the correct size onto the wheels.
- Vehicles with a tire pressure monitoring system: all installed wheels must be equipped with functioning sensors for the tire pressure monitoring system.
- At temperatures below 50 °F (10 °C), use winter tires or all-season tires marked M+S for all wheels.

Winter tires bearing the 🛕 snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

- · Only use tires with the same tread.
- Observe the maximum permissible speed for the installed tires.

If this is below the vehicle's maximum permissible speed, this must be indicated in an appropriate label in the driver's field of vision.

- Break in new tires at moderate speeds for the first 60 miles (100 km).
- Replace the tires after six years at the latest, regardless of wear.

For more information on wheels and tires, contact a qualified specialist workshop.

(i) Vehicles with twin tires:

For vehicles with twin tires with a GVW of 11.030 lbs or 12.125 lbs, only use tires with the dimension LT 215/85 R16 which have been approved for this vehicle by the manufacturer. It is not permissible to use tires with different dimensions; doing so may lead to a general operating permit being rendered invalid.

(i) Vehicles with single tires:

For vehicles with single tires with a GVW less than or equal to 9,480 lbs, only use tires with the dimension LT 245/75 R16 which have been approved for this vehicle by the manufacturer. It is not permissible to use tires with different dimensions; doing so may lead to a general operating permit being rendered invalid.

(i) Vehicles with Super Single tires:

For vehicles with single tires with a GVW of 11,030 lbs, only use tires with the dimensions 225/75 R16C (FA) and 285/65 R16C (RA) which have been approved for this vehicle by the manufacturer. It is not permissible to use tires with different dimensions; doing so may lead to a general operating permit being rendered invalid.

Be sure to also observe the following further related subjects:

- Notes on tire pressure (→ page 310)
- Tire and Loading Information placard $(\rightarrow page 317)$
- Tire size designation, load-bearing capacity. speed rating and load index (\rightarrow page 321)
- Tire pressure table
- Notes on the emergency spare wheel $(\rightarrow page 332)$

Notes on changing wheels



▲ WARNING Risk of injury through different wheel sizes

Interchanging the front and rear wheels if the wheels or tires have different dimensions may severely impair the driving characteristics.

The wheel brakes or wheel suspension components may also be damaged.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

On vehicles that have the same size front and rear wheels, rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If this is not available. rotate the tires every 3.000 (5.000) to 6,000 miles (10,000 km), depending on the degree of wear. Ensure that the direction of rotation is maintained.

It is imperative to observe the instructions and safety notes on "Changing a wheel" when doing SO.

Wheel size categories of wheels

The determined vehicle speed is displayed in the instrument cluster and is important for controlling the driving safety systems and driving systems. The display accuracy of the speedometer and the odometer is legally prescribed. Determining the speed is dependent on the tire size or the rolling circumference of the tires. The rim diameter is always specified in inches.

For this reason, the vehicle control units can be coded for the following wheel size categories:

Wheel size category 3

- 225/75 R16C FA
- 285/65 R16C RA
- LT245/75 R16
- LT215/85 R16
- (i) Mercedes-Benz recommends that you stay within a wheel size category when changing a tire. In this way, you avoid recoding the control units.

If you change the wheel size of your vehicle, for instance when changing wheels for winter operation, check that it is assigned to the correct wheel size category. If the wheel size category changes, you must have your vehicle's control units recoded at a qualified specialist workshop.

Otherwise, the display accuracy of the speedometer and the odometer will be outside the legally prescribed tolerance. It may also be lower, i.e. the current road speed is then higher than the speed shown on the speedometer. If a deviation is outside the range of tolerance, driving safety systems and driving systems may be operationally impaired or may detect a malfunction and switch themselves off.

Information on the direction of the tires' rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is observed.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

You may also install a spare wheel against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the spare wheel.

Information on storing wheels

Observe the following when storing wheels:

- Wheels that have been removed should be stored in a cool, dry and, if possible, dark place.
- Protect the tires from oil, grease and fuel.


Overview of the tire-change tool kit

Necessary tire-changing tools may include, for example:

- lack
- Wheel wrench
- (i) You will find the maximum load capacity of the jack stated on the adhesive label attached to the jack. The jack is maintenance-free. If there is a

malfunction, please contact a qualified specialist workshop.

Vehicles with rear wheel drive



The tire-change tool kit is located in stowage compartment 1 above the step of the co-driver's door and in the stowage compartment in the footwell on the co-driver side

Preparing the vehicle for a wheel change

Requirements:

- The required tire-change tool is available.
- The vehicle is not on a slope.
- The vehicle is on solid, non-slippery and level ground.
- Apply the parking brake.
- Move the front wheels to the straight-ahead position.
- Vehicles with automatic transmission: shift the transmission to position **P**.
- Switch off the engine.
- Make sure that the engine cannot be started.
- Take the vehicle tool kit from the footwell on the co-driver side (\rightarrow page 305).



Vehicles with rear-wheel drive

- Take the jack and the tire-change tool kit out of the stowage compartment (\rightarrow page 327).
- If necessary, remove the hub cab.
- Assemble the lug wrench extension using the middle rod and the rod with the largest diameter from the three-piece jack pump lever.
- Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.
- Using the lug wrench, loosen the wheel nuts or bolts on the wheel you wish to change by

- about one full turn. Do not unscrew the wheel nuts or bolts completely.
- Raise the vehicle (→ page 328).

Raising the vehicle when changing a wheel

WARNING Risk of injury from jack tipping

If you park a vehicle with air suspension, the air suspension may remain activated for up to one hour, even when the ignition is switched off. If you then raise the vehicle with the jack, the air suspension will attempt to adjust the vehicle level.

The jack may tip.

Press the Service button on the air suspension remote control before raising the vehicle.

This prevents automatic readjustment of the vehicle level and prevents it from being raised or lowered manually.

WARNING Risk of injury from incorrect positioning of the jack

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip with the vehicle raised.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically under the jacking point of the vehicle.

WARNING Risk of injury from vehicle tipping

On slopes, the jack could tip with the vehicle raised.

- Never change a wheel on a slope.
- Consult a qualified specialist workshop.

NOTE Vehicle damage from the jack

If you do not position the jack correctly at the appropriate jack support point of the vehicle, the jack could tip over with the vehicle raised.

The jack is designed exclusively for jacking up the vehicle at the jack support points.

Requirements:

- There are no persons in the vehicle.
- The vehicle is prepared for changing a wheel (→ page 327).

Only position the jack on the jack support points intended for this purpose. You could otherwise damage the vehicle.


Important notes on using the jack:

- Only use the vehicle-specific jack that has been tested and approved by Mercedes-Benz to raise the vehicle. If the jack is used incorrectly, it could tip over while the vehicle is raised.
- The jack is designed only to raise the vehicle for a short time while a wheel is being changed and is not suitable for carrying out maintenance work under the vehicle.
- Avoid changing a wheel on uphill and downhill slopes.
- The jack must be placed on a firm, flat and non-slip surface. If necessary, use a large, flat, load bearing and non-slip underlay.
- The base of the jack is positioned vertically under the jack support point.

Safety instructions while the vehicle is raised:


- Do not put your hands or feet under the vehicle.
- Do not lie underneath the vehicle.
- Do not start the vehicle and do not release the parking brake.
- Do not open or close any doors.

Vehicles with rear wheel drive




Jack support points


Only use the middle rod and the pump lever rod with the largest diameter for the jack as a lug wrench extension. Only insert the middle rod on the lug wrench, and always as far as it will go. Otherwise, the rods could bend and deform so much that they can no longer be used as pump levers for the jack.




- To prepare the hydraulic jack: insert the third rod of pump lever (1) for the jack into the lug wrench extension.
- Close pressure release screw 3.
- To do this, use the flattened section on pump lever 1 to turn pressure release screw 3 clockwise to the stop.
- (i) Do not turn pressure release screw (3) more than one or two full turns. Hydraulic fluid could otherwise escape.
- Insert pump lever (1) with the largest rod into the recess on the jack and secure by turning it clockwise.
- Place the jack vertically beneath the jack support points described below.




Jack support point, front axle



Jack support point, rear axle (example: chassis up to 3.5 t)



Jack support point, rear axle (example: Cargo Van and Passenger Van up to 4.0 t)



Jack support point, rear axle (vehicles 5.0 t)

- Place the jack beneath the jack support point.
- Vehicles with all-wheel drive: turn jack spindle ② counter-clockwise as far as it will go.
- Raise the vehicle until the tire is raised a maximum of 1.2 in (3 cm) off the ground.
- ▶ Loosen and remove the wheel (\rightarrow page 330).

Removing a wheel

Requirements:

- The vehicle is raised (→ page 328).
 When changing a wheel, avoid applying any force to the brake discs since this could impair the level of comfort when braking.
- I NOTE Damage to threading from dirt on wheel bolts
- Do not place wheel bolts in sand or on a dirty surface.
- Unscrew the wheel bolts or nuts with the wheel nut wrench.
- On front wheels with wheel nuts, remove the wheel nut cover.
- Remove the wheel.

Installing a new wheel

Requirements:

- The wheel is removed (\rightarrow page 330).
- **WARNING** Risk of accident from losing a wheel

Oiled, greased or damaged wheel bolt/wheel nut threads or wheel hub/wheel mounting bolt threads can cause the wheel bolts/wheel nuts to come loose.


As a result, you could lose a wheel while driving.

- Never oil or grease the threads.
- In the event of damage to the threads, contact a qualified specialist workshop immediately.
- Have the damaged wheel bolts or damaged hub threads replaced.
- ▶ Do not continue driving.
- **WARNING** Risk of injury from tightening wheel bolts and nuts

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip.

- Only tighten wheel bolts or wheel nuts when the vehicle is on the ground.
- Observe the notes on the choice of tires (→ page 324).
- For safety reasons, only use wheel bolts or wheel nuts which have been approved by Mercedes-Benz and for the wheel in question.

When you install the steel spare wheel, it is essential you use short wheel bolts for a steel wheel. Using other wheel bolts when installing the steel spare wheel may lead to damage to the brake system.



- Wheel bolt for alloy wheel
- Wheel bolt for steel wheel
- Clean the wheel and wheel hub contact surfa-
- Vehicles with Super Single tires: first install the adapter for the narrow spare wheel on the wheel hub
- Slide the wheel which is to be re-installed onto the wheel hub or the adapter for the spare wheel and push it on.

Vehicles with light alloy wheels

- Use the suitable short wheel bolts for the spare steel wheel found in the vehicle tool kit.
- Screw in the wheel bolts until they are fingertight.

Wheels with wheel nuts

- Front wheels with wheel nut cover: press the wheel nut cover onto the wheel nuts.
- Screw in three wheel nuts over the fixing discs of the wheel nut cover.
- Turn the wheel so that the wheel bolts are in the middle of the holes.
- Screw in the remaining wheel nuts.
- Slightly tighten all the wheel nuts.

Lowering the vehicle after a wheel change

WARNING Risk of injury through incorrect tightening torque

The wheels could come loose if the wheel bolts or wheel nuts are not tightened to the prescribed tightening torque.

- Make sure the wheel bolts or wheel nuts are tightened to the prescribed tightening torque.
- If you are not sure, do not move the vehicle. Consult a qualified specialist workshop and have the tightening torque checked immediately.

Requirements:

 The new wheel has been installed $(\rightarrow page 330)$.

Observe the notes on raising the vehicle $(\rightarrow page 328)$.

Vehicles with rear wheel drive


Only use the middle rod and the pump lever rod with the largest diameter for the jack as a lug wrench extension. Only insert the middle rod on the lug wrench, and always as far as it will go. Otherwise, the rods could bend and deform so much that they can no longer be used as pump levers for the jack.

Vehicles with Super Single tires: if you mount the spare wheel to the rear axle, do not exceed the maximum speed of 34 mph (55 km/h) and the maximum distance of 62 miles (100 km). Otherwise, the transmission could be damaged due to the different rotational speeds of the wheels.

- Using the pump lever, slowly turn the drain screw on the jack approximately one revolution and carefully lower the vehicle.
- Place the iack to one side.
- Pull the rod with the smallest diameter off the pump lever.

The shortened pump lever serves as a lug wrench extension.

Starting with the middle rod, slide the lug wrench extension as far as it will go onto the lug wrench.



Tighten the wheel bolts or nuts evenly in the sequence indicated (1) to (6).

Specified tightening torque:

- Steel wheel bolts: 177 lb-ft (240 Nm)
- Wheel nuts: 133 lb-ft (180 Nm)
- Alloy wheel bolts: 133 lb-ft (180 Nm)
- Push the piston on the hydraulic jack in again and close the pressure release screw.
- Vehicles with all-wheel drive: turn the jack spindle clockwise as far as it will go.
- You can now install the hub caps on steel wheels with wheel bolts. The installation procedure depends on whether the hub cap acts as a trim that covers the whole wheel, or just covers the center.
- Wheel with hub cap: position the opening for the tire valve in the hub cap over the tire valve.
- Push the edge of the hub cap onto the wheel rim with both hands until it engages into place. Make sure the hub cap retaining catches engage on the steel wheel.
- Wheel with central hub cap: position the retaining lugs of the central hub cap over the wheel bolts.
- Hit the middle of the hub cap to engage it on the wheel.
- Secure the faulty wheel in the spare wheel bracket.
- Vehicles with Super Single tires: transport the faulty rear wheel on the load area. The rear wheel is too large for the spare wheel bracket.
- Check the tire pressure of the newly installed wheel and adjust it if necessary.

- Retighten the wheel bolts or wheel nuts to the specified tightening torque after the vehicle has been driven 31 miles (50 km).
- When using a wheel or spare wheel with a new or newly painted wheel rim, have the wheel bolts or nuts retightened after approximately 620 miles (1,000 km) to 3,100 miles (5,000 km).
- (i) Vehicles with the tire pressure monitor system: all installed wheels must be equipped with functioning sensors.

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 310)

Spare wheel

Notes on the emergency spare wheel and spare wheel

Spare wheel: wheel and tire dimensions as well as the type of tire correspond to the other installed wheels.

Emergency spare wheel: wheel and/or tire dimensions as well as the type of tire are different from the wheel to be replaced. A label with a speed limit can be found on the emergency spare wheel.

An installed emergency spare wheel or spare wheel changes the driving characteristics and hears risks

WARNING Risk of accident caused by incorrect wheel and tire dimensions

When the emergency spare wheel or the spare wheel is installed, driving characteristics may be severely affected.

There is an increased risk of an accident.

To prevent hazardous situations:

- Once the spare wheel or the emergency spare wheel has been installed, check the tire pressure and adjust if necessary.
- The emergency spare wheel may only be used temporarily and must be replaced with a standard wheel as soon as possible.
- Never install more than one emergency spare wheel.
- When operating your vehicle with the emergency spare wheel installed, adapt

your driving style accordingly and drive carefully.

- Do not switch off ESP®.
- Snow chains must not be installed on the emergency spare wheel.
- Replace the emergency spare wheel after a maximum of six years, regardless of wear.
- When using an emergency spare wheel (which is different from the wheel to be replaced) a top speed of 50 mph (80 km/h) must not be exceeded.
- The tire pressure of the emergency spare wheel must be checked before starting a journev (\rightarrow page 314).
- Have the emergency spare wheel replaced by a qualified specialist workshop.

WARNING Risk of accident from damaged spare wheel with Super Single tires

Vehicles with Super Single tires

The tire of the spare wheel exposed to aboveaverage loads after being installed on the rear axle. If you exceed the maximum speed or the maximum distance, or install the spare wheel again, the tire of the spare wheel may be damaged. The tire damage may not be visible and not detectable.

A damaged tire may cause a loss of tire pressure. This could cause you to lose control of the vehicle.

- Only use the spare wheel if it has not vet been installed on the rear axle with the current tires.
- If the spare wheel had been installed on the rear axle, have the tire of the spare wheel replaced after changing the wheel again, irrespective of the distance.
- For safety reasons, when changing a tire ensure that only the tire valve type approved for the tires is used.
- **NOTE** Damage to the transmission

Vehicles with Super Single tires: when you install the spare wheel on the rear axle, the transmission may be damaged by the different rotational speeds of the wheels.

- When the spare wheel is installed on the rear axle, observe the maximum speed of 34 mph (55 km/h) and the maximum driving distance of 62 miles (100 km).
- (i) It is possible, without restrictions, to use the spare wheel only on the front axle of a vehicle with Super Single tires.

The following should be checked regularly, particularly prior to long journeys:


- The secure positioning of the spare wheel
- The tire pressure of the spare wheel (adjust the tire pressure if necessary) (\rightarrow page 311)
- The fastenings of the spare wheel bracket

Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel.


(i) If you have installed an emergency spare wheel or spare wheel, the tire pressure monitor will not function for this wheel. The emergency spare wheel or spare wheel is not equipped with a sensor for monitoring tire pressure.

Installing/removing the spare wheel

Vehicles with rear wheel drive: removing the spare wheel (Cargo Van/Passenger Van)



Bolt covers for the safety hooks (example: Cargo Van)




- Open the rear-end doors.
- Place a screwdriver into recesses ② and then pry off covers ①.
- Using the lug wrench from the vehicle tool kit, unscrew the now visible bolts counter-clockwise by approximately 20 turns.
- Slightly raise spare wheel carrier **(a)** and unhook left-hand safety hook **(3)**.
- Assemble the pump lever for the jack and slide it into sleeve so on the right-hand side of spare wheel carrier 4.
- Raise spare wheel carrier (a) with the pump lever and unhook right-hand safety hook (a).
- Slowly lower spare wheel carrier 4 to the ground.
- Lift spare wheel carrier 4 slightly and pull the pump lever out of the sleeve.
- Use the pump lever to lift the spare wheel beyond the rear edge of spare wheel carrier
 4.
- ➤ Carefully remove the spare wheel from spare wheel carrier ②. The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes due to the heavy weight of the wheel. The spare wheel may slip down or tip over.

Vehicles with rear wheel drive: installing the spare wheel (Cargo Van/Passenger Van)


Carefully place the spare wheel onto spare wheel carrier <a>®. The spare wheel is heavy. When you place the spare wheel onto spare wheel carrier <a>®, the center of gravity changes due to the weight of the wheel. The spare wheel may slip down or tip over.


- Slide the pump lever for the jack into sleeve
 on spare wheel carrier
- Raise spare wheel carrier **(a)** with the pump lever and attach right-hand safety hook **(3)**.
- Slightly raise spare wheel carrier **(4)** and attach left-hand safety hook **(3)**.
- Pull the pump lever out of sleeve 6.
- Using the lug wrench, tighten safety hook bolts (3) by turning them clockwise.
- Replace and engage covers ①.
- Close the rear-end doors.

Vehicles with rear wheel drive: removing the spare wheel (vehicle with lowered chassis)



Bolt covers for the safety hooks (example: Cargo Van)






- Open the rear-end doors.
- Place a screwdriver into recesses 2 and then pry off covers 1.
- Using the lug wrench from the vehicle tool kit. unscrew the now visible bolts counter-clockwise by approximately 20 turns.
- Slightly raise spare wheel carrier 4 and unhook left-hand safety hook 3.
- Assemble the pump lever for the jack and slide it into sleeve (5) on the right-hand side of spare wheel carrier 4.
- Raise the spare wheel carrier with the pump lever and unhook right-hand safety hook 3.
- Position loop 7 of extraction device 6 on the spare wheel so that you will later be able to attach lug wrench (3).
- Prepare the jack.
- Place the jack beneath the corresponding jack support point.

- Move the pump lever up and down until the tire is raised a maximum of 1.18 in (3 cm) off the ground.
- Hook lug wrench (3) into loop (7) of extraction device 6 on the spare wheel.
- Carefully remove the spare wheel from spare wheel carrier (4). The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes due to the heavy weight of the wheel. The spare wheel may slip down or tip over.
- Remove the spare wheel extraction device and store it in a safe place. You can now install the spare wheel on your vehicle.
- Lower the vehicle.

Vehicles with rear wheel drive: installing the spare wheel (vehicle with lowered chassis)

- (i) In the event of a flat tire, you may store the faulty wheel inside the vehicle only. An intact wheel may be stored in the spare wheel carrier only when the vehicle is unladen. A laden vehicle must first be raised.
- Carefully place the spare wheel onto spare wheel carrier (4). The spare wheel is heavy. When you place the spare wheel onto spare wheel carrier (4), the center of gravity changes due to the weight of the wheel. The spare wheel may slip down or tip over.
- Slide the pump lever for the jack into sleeve (5) on spare wheel carrier (4).
- Raise spare wheel carrier 4 with the pump lever and attach right-hand safety hook 3.
- Slightly raise spare wheel carrier (4) and attach left-hand safety hook 3.
- Pull the pump lever out of sleeve (5).
- Using the lug wrench, tighten safety hook bolts (3) by turning them clockwise.
- Replace and engage covers 1.
- Close the rear-end doors.

Vehicles with rear wheel drive: removing the spare wheel (chassis)



- Loosen wing nuts (3) manually and then remove them.
- Loosen nuts a as far as the thread end.
- Slightly raise spare wheel carrier **(a)** and unhook left-hand safety hook **(1)**.
- Assemble the pump lever for the jack and slide it into the sleeve on the right-hand side of spare wheel carrier (4).
- Raise spare wheel carrier (a) with the pump lever and unhook right-hand safety hook (a).
- Slowly lower spare wheel carrier 4 to the ground.
- Lift spare wheel carrier (a) slightly and pull the pump lever out of the sleeve.
- Use the pump lever to lift the spare wheel beyond the rear edge of the spare wheel carrier.
- Carefully remove the spare wheel from the spare wheel carrier. The spare wheel is heavy. When the spare wheel is removed, the center of gravity changes due to the heavy weight of the wheel. The spare wheel may slip down or tip over.

Vehicles with rear wheel drive: installing the spare wheel (chassis)

- Carefully place the spare wheel onto spare wheel carrier (a). The spare wheel is heavy. When you place the spare wheel onto the spare wheel carrier, the center of gravity changes due to the weight of the wheel. The spare wheel may slip down or tip over.
- Slide the pump lever for the jack into the sleeve on spare wheel carrier 4.

- Raise spare wheel carrier **(4)** with the pump lever and attach right-hand safety hook **(1)**.
- Slightly raise the spare wheel carrier and attach left-hand safety hook (1).
- Pull the pump lever out of the sleeve.
- Tighten nuts 2.
- Put wing nuts (3) in place and tighten them.

Information on technical data

The given data only applies to vehicles with standard equipment. Further information can be obtained at a qualified specialist workshop.

On-board electronics

Notes on work on the engine electronics

NOTES Premature wear through improper maintenance

Improper maintenance may cause vehicle components to wear more quickly and the vehicle's operating permit may be invalidated.

Always have work on the engine electronics and related components carried out at a qualified specialist workshop.

Two-way radios

Installation notes for two-way radios

WARNING Risk of accident due to improper work on two-way radios

The electromagnetic radiation from two-way radios can interfere with the on-board electronics if RF transmitters are manipulated or retrofitted incorrectly.

This could jeopardize the operating safety of the vehicle.

You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

▲ WARNING Risk of accident from incorrect operation of two-way radios

If you operate two-way radios incorrectly in the vehicle, the electromagnetic radiation could interfere with the on-board electronics. e.g.:

- if the two-way radio is not connected to an exterior antenna
- if the exterior antenna is not correctly mounted or is not of low reflection

This could jeopardies the operating safety of the vehicle.

▶ Have the low-reflection exterior antenna installed at a qualified specialist workshop.

- When operating two-way radios in the vehicle, always connect them to the low-reflection exterior antenna
- NOTE Invalidation of the operating permit due to failure to comply with the instructions for installation and use

The operating permit may be invalidated if the instructions for installation and use of twoway radios are not observed.

- Only use approved frequency bands.
- Observe the maximum permissible output power in these frequency bands.
- Only use approved antenna positions.

Use Technical Specification ISO/TS 21609 (Road Vehicles - EMC guidelines for installation of aftermarket radio frequency transmitting equipment) when retrofitting two-way radios. Comply with the legal requirements for detachable parts.

If your vehicle has installing for two-way radio equipment, use the power supply or antenna connections intended for use with the installing. Observe the manufacturer's supplement during installation.

Information on two-way radio transmission output

The maximum transmission outputs (PEAK) at the base of the antenna must not exceed the values in the following table:

Frequency band and maximum transmission output

Frequency band	Maximum transmis- sion output
Short wave 3 – 54 MHz	100 W
4 - m - waveband 74 - 88 MHz	30 W
2 - m - waveband 144 - 174 MHz	50 W
Trunked radio system/Tetra 380 — 460 MHz	10 W

Frequency band	Maximum transmis- sion output
70 - cm - waveband 420 - 450 MHz	35 W
Two-way radio (2G/3G/4G)	10 W

The following can be used in the vehicle without restrictions:


- two-way radios with a maximum transmission output of up to 100 mW
- two-way radios with transmitter frequencies in the 380 – 410 MHz frequency band and a maximum transmission output of up to 2 W (trunked radio system/Tetra)
- mobile phones (2G/3G/4G)

There are no restrictions when positioning the antenna on the outside of the vehicle for the following frequency bands:

- Trunked radio system/Tetra
- 70 cm waveband
- 2G/3G/4G


Vehicle identification plate, vehicle identification number (VIN) and engine number

Vehicle identification plate



Depending on the vehicle model, the vehicle identification plate is located on the seat base of the driver's seat or on the B-pillar.

i The data is vehicle-specific and can differ from that shown. Always observe the specifications on your vehicle's identification plate.




Vehicle identification plate (example: USA, complete vehicles)

- Vehicle manufacturer
- 2 VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Permissible front axle load
- O Permissible rear axle load
- Date of manufacture
- Paint code




Vehicle identification plate (example: USA, incomplete vehicles)

- Vehicle manufacturer
- 2 VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Permissible front axle load
- Permissible rear axle load
- Date of manufacture
- Paint code



Vehicle identification plate (example: Canada, complete vehicles)

- Vehicle manufacturer
- VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Permissible front axle load
- Permissible rear axle load
- Date of manufacture
- Paint code



Vehicle identification plate (example: Canada, incomplete vehicles)

- Vehicle manufacturer
- VIN (vehicle identification number)
- Permissible gross mass
- Permissible gross mass of vehicle combination
- Permissible front axle load
- Permissible rear axle load
- Date of manufacture
- Paint code


The maximum permissible gross vehicle weight is made up of the vehicle weight, all vehicle occupants, the fuel and the load. The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle).

Never exceed the maximum permissible gross vehicle weight or the maximum gross axle weight rating for the front or rear axle.

The vehicle identification plate may also contain the following data:

- Pavload
- · Curb weight
- Number of passenger seats

VIN engraved underneath the hood



Engraved VIN (1) is located underneath the hood.

VIN underneath the windshield



The VIN is also attached as a label on the lower section of windshield 2.

Emission Control Information label



Example: Emission Control Information label

(i) The data is vehicle-specific and can differ from that shown.

Engine number

The engine number is stamped onto the crankcase. You can obtain further information from any qualified specialist workshop.

Operating fluids and capacities Notes on operating fluids

▲ WARNING Risk

WARNING Risk of injury from operating fluids harmful to your health

Operating fluids may be poisonous and harmful to your health.

- Observe the text on the original containers when using, storing or disposing of operating fluids.
- Always store operating fluids sealed in their original containers.
- Always keep children away from operating fluids.

ENVIRONMENTAL NOTE Environmental pollution due to disposing of operating fluids in a non-environmentally responsible manner

Operating fluids include the following:

- fuels
- exhaust gas aftertreatment additives, e.g. DFF
- lubricants

Incorrect disposal of operating fluids can cause considerable damage to the environment.

Dispose of operating fluids in an environmentally responsible manner.

Operating fluids include the following:

- Fuels
- Exhaust gas aftertreatment additives, e.g. DEF
- Lubricants
- Coolant
- Brake fluid
- · Windshield washer fluid
- · Climate control system refrigerants

Use only products recommended by Mercedes-Benz. Damage caused by the use of products that have not been approved is not covered by the Mercedes-Benz guarantee or goodwill gestures.

You can identify operating fluids approved by Mercedes-Benz by the following inscriptions on the container:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB-Approval (e.g. MB-Approval 229.51)

Further information on approved operating fluids is available at the following locations:

- In the MB Specifications for operating fluids at http://bevo.mercedes-benz.com (by entering the designation)
- At a qualified specialist workshop

WARNING Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, open flames, smoking and creation of sparks must be avoided.
- Switch off the ignition and, if available, the stationary heater, before and while refueling the vehicle.

WARNING Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eyes or clothing.
- Do not inhale fuel vapor.
- ► Keep children away from fuel.
- Keep doors and windows closed during the refueling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical attention immediately.
- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- Change immediately out of clothing that has come into contact with fuel.

Fuel

Notes on fuel grades on vehicles with a gasoline engine

Observe the notes on operating fluids $(\rightarrow page 340)$.

NOTE Do not use diesel to refuel vehicles with a gasoline engine.

If you accidentally refuel with the wrong fuel:

- · Do not switch on the ignition. Otherwise fuel can enter the engine.
 - Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high.
- Contact a qualified specialist workshop.
- Have the fuel tank and fuel lines drained completely.

Only refuel using low-sulfur regular fuel with at least 87 AKI/91 RON.

- (i) E10 fuel contains an additive of up to 10% ethanol. Your vehicle is suitable for use with E10 fuel. You can fuel your vehicle with E10 fuel.
 - **NOTE** Damage caused by the wrong fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, engine and exhaust system.

- Only refuel with the recommended fuel.
- NOTE Damage caused by the wrong fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, engine and exhaust system.

Never refuel with the following:

- Gasoline with more than 10% ethanol by volume, e.g. E15, E20, E85, E100
- Gasoline with more than 3% methanol by volume, e.g. M15, M30, M85, M100
- · Gasoline with additives containing metal
- Do not mix such fuels with the fuel recommended for your vehicle.
- (i) To ensure the longevity and performance of the engine, only unleaded regular gasoline may be used.

Note that the higher quality premium grade gasoline can be refueled at any time.

If you are using drums or canisters to refuel the vehicle, you should filter the fuel before filling. This will prevent malfunctions in the fuel system. due to contaminated fuel.

Usually you will find information about the fuel grade on the fuel pump. If there is no identification on the fuel pump, consult a gas station attendant.

(i) For further information, contact a qualified specialist workshop or visit http:// www.mbusa.com (USA only).

Notes on additives in gasoline

Observe the notes on operating fluids $(\rightarrow page 340)$.

NOTE Damage from use of unsuitable additives

Even small amounts of the wrong additive may lead to malfunctions.

Only add cleaning additives recommended by Mercedes-Benzto the fuel.

Mercedes-Benz recommends using brand-name fuels with additives.

In some countries, the available fuel may not contain sufficient amounts of additives. Deposits could build up in the fuel injection system as a result.

In this case, in consultation with an authorized Mercedes-Benz Center, the fuel should be mixed with the cleaning additive recommended by Mercedes-Benz.

You must observe the notes and mixing ratios indicated on the container.

Notes on fuel grades on vehicles with diesel engines

General notes

Observe the notes on operating fluids $(\rightarrow page 340)$.

▲ WARNING Risk of fire from fuel mixture

If you mix diesel fuel with gasoline, the flash point of the fuel mixture is lower than that of pure diesel fuel.

While the engine is running, component parts in the exhaust system may overheat without warning.

- Never refuel using gasoline in diesel engines.
- Never mix gasoline with diesel fuel.
- ! NOTE Damage due to incorrect fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and emission control system.

Never refuel with:

- Gasoline
- Marine diesel
- · Heating oil
- · Pure bio-diesel or vegetable oil
- Paraffin or kerosene
- Do not mix such fuels with diesel fuel and do not use any special additives.

If you have accidentally refueled with the wrong fuel, observe the following:

- Do not switch on the ignition.
- Consult a qualified specialist workshop.
- NOTE Malfunctions due to contaminated fuel

Fuel contamination can lead to malfunctions in the fuel system.

- If you are using drums or canisters to refuel the vehicle, you should filter the fuel before filling.
- I NOTE Damage due to incorrect fuel

Incorrect fuel can lead to engine damage.

Refuel only ULSD or diesel fuel with a sulfur content of maximum 15 ppm.

Usually you will find information about the fuel grade on the fuel pump. If there is no identification on the fuel pump, consult a gas station attendant.

The fuel grade recommended for your vehicle is found on the instruction label in the fuel filler flap.

Notes on low outside temperatures

A

WARNING Risk of fire and explosion due to fuel igniting

If you heat fuel system components, e.g. with a heat gun or open flame, these components could be damaged.

Fuel may leak out and ignite. Depending on the type of damage, fuel might not escape until the engine is running.

- Never heat fuel system components.
- Consult a qualified specialist workshop to have the malfunction rectified.

Refill only with commercially available ULTRA-LOW SULFUR DIESEL (ULSD, maximum sulfur content 15 ppm), which fulfills the ASTM D975 standard.

The flow properties of diesel fuel may be inadequate at low outside temperatures due to paraffin separation.

(i) Malfunctions resulting from paraffin separation can only be rectified by heating the entire fuel system. Park the vehicle in a heated garage, for example.

To prevent malfunctions, diesel fuel with improved flow characteristics is available in the winter months. You can obtain further information on this at the gas station or from your fuel supplier.

Your vehicle is equipped with a fuel preheating system. This additionally improves the flow characteristics of the diesel fuel by about 14.5 °F (8 °C). ULTRA-LOW SULFUR DIESEL can be used without risk of malfunction down to an outside temperature of approximately 14.5 °F (-10 °C).

NOTE Damage due to gasoline or paraffin

Gasoline or paraffin in diesel fuel impairs the lubricity of the fuel. This can result in damage to the fuel injection system, for example.

 Do not add any gasoline or paraffin to diesel fuel to improve its flow characteristics.

B20 fuels with bio-diesel content

! NOTE Damage due to incorrect fuel

Continuous use of fuels with bio-diesel content over 5% (B20 fuels) can lead to fuel filter

clogging. Deposits may also form on the fuel injector. This may reduce the engine output. Unburned fuel can get into the oil pan. This causes the engine oil level to rise. This can cause engine mechanical damage.

Observe the following points to avoid damage and reducing the engine output:

- Fill up with fuels with bio-diesel content of 5% (ULSD) or less, whenever possi-
- Regularly check your engine oil level if you use B20 fuels on a regular basis.
- Strictly follow the oil change intervals quoted in the instrument cluster and within your Maintenance Booklet.
- Use only engine oils and filters approved for use in your vehicle.
- If you do not plan to drive your vehicle for several weeks, completely fill the fuel tank in advance with ULSD fuel.

For more information, consult the gas station staff. The identification of fuels with bio-diesel content (ULSD or B20) must be clear. If the identification is not clear, do not refuel. Do not refuel with any fuels that have not been approved for vour vehicle.

Tank content and fuel reserve

The total capacity of the fuel tank may vary, depending on the vehicle equipment.

Tank content and fuel reserve

Gasoline engine	Total capacity
M274	approx. 22.5 gal (85 liters)
Diesel engine	Total capacity

Gasoline engine	Of which reserve fuel
Models with approx. 22.5 gal (85 l) total capacity	approx. 5 gal (19 liters)
Diesel engine	Of which reserve
	fuel

DFF

Notes on DEF

Observe the notes on operating fluids $(\rightarrow page 340)$.

DEF is a water-soluble fluid for the exhaust gas aftertreatment of diesel engines.

NOTE Damage caused by additives in DEF or by diluting DEF


The DEF exhaust gas aftertreatment system could be destroyed by the following:

- Additives in DFF
- Diluting DEF
- Only use DEF in accordance with ISO 22241.
- Do not mix additives.
- Do not dilute DFF.

NOTE Damage and malfunctions caused by impurities in DEF

Impurities in DEF result in the following:

- · Higher emission values
- Damage to the catalytic converter
- Engine damage
- · Malfunctions in the DEF exhaust gas aftertreatment system
- Avoid impurities in DEF.



DEF residue crystallizes after some time and stain the affected surfaces.

Immediately rinse surfaces that come in contact with DEF when filling with water or remove DEF with a damp cloth and cold water.

If DEF has already crystallized, clean using a sponge and cold water.

If you open the DEF tank, small amounts of ammonia vapor may be released. Do not inhale any ammonia vapor that may be released. Fill the DEF tank only in well-ventilated areas.

DEF consumption and filling capacity

DEF consumption

Like fuel consumption, DEF consumption is highly dependent upon driving style and operating conditions. DEF consumption is usually within a range of 0 and 10% of the fuel consumption. If necessary, DEF must be refilled in accordance with the instructions when the refill message is displayed in the instrument cluster. This may also be necessary between the scheduled maintenance.

Total capacity of DEF tank

Vehicle	Total capacity
All models	5.8 gal (22 liters)

Exhaust gas aftertreatment

The vehicle must be operated with DEF if the exhaust gas aftertreatment system is to function correctly.

If you operate the vehicle without DEF or with emissions-relevant malfunctions, the legal MOT approval is invalidated. The vehicle could be prohibited from public road use by an official ordinance.

It may be improper or punishable in some countries to operate a vehicle that uses no DEF or one that does not comply with the specifications of these operating instructions.

Engine management monitors the exhaust gas aftertreatment components for compliance with emissions laws and regulations. If you attempt to operate the vehicle without DEF, with diluted DEF or with a different reducing agent, this will be detected by the engine management system. Other emissions-relevant malfunctions, e.g. metering malfunctions or sensor errors, are also detected and logged.

The engine management system subsequently prevents the engine being restarted after issuing a warning message.

Therefore add DEF tank regularly during vehicle operation or, at the latest, after receiving the first warning message via the instrument cluster.

Engine oil

Notes on engine oil

Observe the notes on operating fluids (\rightarrow page 340).



- NOTE Engine damage caused by an incorrect oil filter, incorrect oil or additives
- Do not use engine oils or oil filters other than those which meet the specifications necessary for the prescribed service intervals.
- Do not alter the engine oil or oil filter in order to achieve longer change intervals than prescribed.
- Do not use additives.
- Have the engine oil changed after the prescribed intervals.

Mercedes-Benz recommends having the oil changed at a qualified specialist workshop.

Further information on engine oil and oil filter:

- in the MB Specifications for operating fluidsat http://bevo.mercedes-benz.com (by entering the designation)
- at a qualified specialist workshop

Quality and capacity of engine oil

(i) The containers of the various engine oils are marked with the ACEA (Association of European Automotive Manufacturers) and/or API (America Petroleum Institute) classifications. Only use approved engine oils that correspond to the MB Specifications for operating fluids and the prescribed ACEA and/or API classifications named below. Engine oils of other grades are not permissible and can result in the loss of the New Vehicle Limited Warranty. The use of other engine oils not approved for diesel engines can damage the diesel particulate filter (DPF).

MB-Freigabe or MB-Approval

Gasoline engine	MB-Freigabe orMB- Approval
M274	229.5
D: 1 :	
Diesel engines	MB-Freigabe orMB- Approval

* Recommended for lowest possible fuel consumption (lowest SAE viscosity class in each case; observe possible restrictions of the approved SAE viscosity classes).

To achieve the lowest possible fuel consumption, it is recommended to use the engine oil specifications marked in the table for the lowest SAE viscosity class. Observe any possible restrictions of the approved SAE viscosity classes.

If the engine oils listed in the table are not available, you may add a maximum 1.1 US gt (1.0 liter) of the following engine oils once only:

- Vehicles with a gasoline engine: MB-Freigabe or MB-Approval 229.3 or ACEA A3/B4
- Vehicles with a diesel engine: MB-Freigabe or MB-Approval 228.5, 229.3 or 229.5

Multigrade engine oils of the prescribed SAE classification (viscosity) may be used all year round, taking the outside temperature into account.

Viscosity of the engine oil



NOTE Engine damage due to incorrect SAE classification (viscosity) of the engine oil

If the SAE classification (viscosity) of the engine oil added is not suitable for prolonged low outside temperatures, it may cause engine damage.

The temperature readings of the SAE classification are always based on fresh oil. Engine oil ages when driving as a result of soot and fuel residue. The characteristics of engine oil deteriorate significantly at low outside temperatures.

- Use an engine oil of the appropriate SAE classification at low outside tempera-
- Use oil for all-year-round operation.

The temperature readings of the SAE classification are always based on fresh oil. The temperature characteristics of the engine oil, especially at low outside temperatures, can deteriorate significantly due to aging when driving.

Therefore, Mercedes-Benz recommends that you change the engine oil before the start of the cold season. Only use an approved engine oil in the prescribed SAE classification for this purpose.



The viscosity indicates the flow characteristics of a fluid. With regard to engine oil, a high viscosity is synonymous with thick liquid and a low viscosity with thin liquid. Depending on the outside temperatures, select the engine oil according to the SAE classification (viscosity). The table shows the SAE classifications to be used. The low temperature characteristics of engine oils can deteriorate significantly during operation due to aging and soot and fuel accretion, for example. A regular oil change with an approved engine oil in the appropriate SAE classification is therefore strongly recommended.

Additive

!

NOTE Engine damage due to use of additives in the engine oil

The use of additional additives in the engine oil can damage the engine.

Do not use any additional additives in the engine oil.

Miscibility of engine oil

The benefits of high-quality engine oils are reduced by mixing oil.

We recommend that you only use engine oil of the same grade and SAE classification as the oil filled at the last oil change. If, in exceptional cases, engine oil of the type in the engine is not available, use another approved mineral or synthetic engine oil.

Vehicles with a diesel engine: if the grade is not available, you may also refill with engine oils according to MB-Freigabe or MB-Approval 228.5, 229.3 or 229.5. The refill quantity is then limited to maximum 1.1 US qt (1.0 liter).

You must then have an oil change carried out at the earliest possible opportunity.

Vehicles with a gasoline engine: if the grade is not available, you may refill with engine oils according to MB-Freigabe or MB-Approval 229.3 or ACEA A3/B4. The refill quantity is then limited to maximum 1.1 US qt (1.0 liter).

You must then have an oil change carried out at the earliest possible opportunity.

Engine oils are differentiated according to:

- · Engine oil brand
- Grade (MB-Freigabe or MB-Approval)
- SAE classification (viscosity)

Oil change interval

The on-board computer automatically shows the date of the next oil change as an event message on the display.

Mercedes-Benz recommends having the oil changed at a qualified specialist workshop.

Engine oil capacities

Engine	Engine oil
M274	Approx. 11.1 qt (10.5 liters)
OM642	Approx. 13.2 qt (12.5 liters)
OM651 (rear wheel drive)	Approx. 12.2 qt (11.5 liters)

Information on oil consumption

Depending on the driving style, the vehicle consumes a maximum of 1.1 US qt (1.0 liter) of engine oil per 620 miles (1000 km).

In the following cases, oil consumption may also exceed this limit:

- . The vehicle is new.
- You use the vehicle mostly under arduous conditions.
- You drive frequently at a high engine speed.

Regular maintenance is a prerequisite for favorable consumption figures. You can only assess the oil consumption after a long journey. Check the oil level in the engine regularly, e.g. weekly or every time you refuel.

Notes on brake fluid

Observe the notes on operating fluids (\rightarrow page 340).



WARNING Risk of an accident due to vapor pockets forming in the brake system

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point is too low, vapor pockets may form in the brake system when the brakes are applied hard.

This causes the braking effect to be impaired.



Have the brake fluid renewed at the specified intervals.



NOTE Damage to paint, plastic or rubber by brake fluid

There is a risk of damage to property if brake fluid comes into contact with paint, plastic or rubber.

If paint, plastic or rubber comes into contact with brake fluid, rinse with water immediately.

Observe the notes on paintwork/matte finish paintwork care (\rightarrow page 287).

Have the brake fluid replaced regularly at a qualified specialist workshop.

Only use brake fluid approved by Mercedes-Benz in accordance with MB-Freigabe or MB-Approval 331.0.

Further information on brake fluid:

- in the MB Specifications for operating fluids at http://bevo.mercedes-benz.com
- at a qualified specialist workshop

Coolant

Notes on coolant

Observe the notes on operating fluids $(\rightarrow page 340).$

WARNING - Risk of fire and injury from antifreeze

If antifreeze comes into contact with hot component parts in the engine compartment, it may ignite.

- Allow the engine to cool down before adding antifreeze.
- Make sure that no antifreeze spills out next to the filler opening.
- Thoroughly clean off any antifreeze from component parts before starting the vehicle.
- **NOTE** Damage caused by incorrect cool-
- Only add coolant that has been premixed with the required antifreeze protection.

Information on coolant is available at the following locations:

- In the MB Specifications for operating fluids
 - At http://bevo.mercedes-benz.com
 - In the BeVo app
- At a qualified specialist workshop

NOTE Overheating at high outside temperatures

If an inappropriate coolant is used, the engine cooling system is not sufficiently protected against overheating and corrosion at high outside temperatures.

- Always use a coolant approved by Mercedes-Benz.
 - Observe the instructions in the MB Specifications for operating fluids310.1.
- NOTE Paintwork damage due to coolant
- Do not spill coolant on painted surfaces.

Have the coolant regularly replaced at a qualified specialist workshop.

Note the proportion of anti-corrosion agent/antifreeze in the engine cooling system within the following temperature ranges:

- At least 50% (antifreeze protection up to about -35°F (-37°C))
- Maximum 55% (antifreeze protection up to -49°F (-45°C))

Coolant capacities

Engine cooling system

Engine	Coolant
M274	approx. 3.0 gal (11.5 liters)
OM642	approx. 2.6 gal (10 liters)
OM651	approx. 2.5 gal (9.5 liters)

Windshield washer fluid

Notes on windshield washer fluid

Observe the notes on operating fluids $(\rightarrow page 340)$.

WARNING - Risk of fire and injury from windshield washer concentrate

Windshield washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

- Make sure that no windshield washer concentrate spills out next to the filler opening.
- NOTE Damage to the exterior lighting due to unsuitable windshield washer fluid

Unsuitable windshield washer fluid may damage the plastic surface of the exterior lighting.

- Only use windshield washer fluid which is also suitable for use on plastic surfaces, e.g. MB SummerFit or MB Winter-Fit
- I NOTE Blocked spray nozzles caused by mixing windshield washer fluids
- Do not mix MB SummerFit and MB WinterFit with other windshield washer fluids.

Do not use distilled or de-ionized water. Otherwise, the fill level sensor may give a false reading.

Information on the windshield washer fluid

Recommended windshield washer fluid:

- above freezing point: e.g. MB SummerFit
- below freezing point: e.g. MB WinterFit

Mixing ratio

For the correct mixing ratio, refer to the information on the anti-freeze container.

Mix the washer fluid with windshield washer fluid all year round.

Filling capacities

Windshield washer system

Washer fluid 5.8 qt (5.5 l)

Refrigerant

Notes on refrigerant

Observe the notes on operating fluids (\rightarrow page 340).

(i) Your vehicle's climate control system can be filled with R-134a refrigerant. The refrigerant R-134a contains fluorinated greenhouse gas.

If your vehicle is filled with R-134a refrigerant, the following information applies:

NOTE Damage caused by incorrect refrigerant

If the incorrect refrigerant is used, this can damage the climate control system.

- Use only R-134a refrigerant or the PAG oil approved for your vehicle by Mercedes-Benz
- ➤ The approved PAG oil may not be mixed with any other PAG oil that is not approved for R-134a refrigerant.

Maintenance work, such as adding refrigerant or replacing components, may be carried out only by a qualified specialist workshop. All the applicable regulations relating to this and the SAE J639 standard must be adhered to.

All work on the climate control system should always be carried out at a qualified specialist workshop.



Example: refrigerant warning label

- Warning symbols
- Refrigerant capacity
- Applicable standards
- PAG oil part number
- 6 Refrigerant type

Warning symbols 1 refer to the following:

- Potential dangers
- The performance of maintenance work at a qualified specialist workshop

Vehicle data

Information on vehicle dimensions

The following section contains important technical data for your vehicle. Your vehicle documents contain further vehicle-specific and equipment-dependent technical data such as vehicle dimensions and weights.

Trailer hitch

Notes on the trailer hitch



WARNING Risk of accident due to aftermarket installation of a trailer hitch that is not permissible

If aftermarket installation of a trailer hitch is not permissible and you install a trailer hitch or other assembly parts, the longitudinal frame member will be weakened and may break. In this case, the trailer may come loose from the vehicle.

There is a risk of an accident.

Only install a trailer hitch aftermarket if it is permissible.

Observe the notes on trailer operation $(\rightarrow page 169)$.

Retrofitting a trailer hitch is only permissible if a towing capacity is specified in your vehicle documents.

You can obtain further information on the trailer hitch at a qualified specialist workshop.

Mercedes-Benz recommends that you have a trailer hitch retrofitted at an authorized Mercedes-Benz Center.

Only use a trailer hitch which has been tested and specially approved by Mercedes-Benz for vour vehicle.

Use only a ball neck that has been approved for your vehicle and for your Sprinter trailer hitch. Notes on the permissible dimensions of the ball neck can also be found on the identification plate of the trailer hitch.

The maximum permissible towing capacity for trailers without a separate braking system is 1,653 lbs (750 kg).

Trailer loads

The permissible weights and loads which must not be exceeded can also be obtained from the following sources of information:

- Vehicle documents
- The identification plates of the trailer hitch, trailer and vehicle

The values approved by the manufacturer can be found in the following table. If the values differ, the lowest value applies. Use a calibrated weighing machine to check the weight restrictions have been complied with before you start your journey.

Maximum permissible weights and loads Vehicle type, gross vehicle weight and curb weight

Vehicle model	Permissible gross vehicle weight GVWR	Permissible curb weight 7)	
1500	8550 lbs (3.878 t)	7400 lbs (3.357 t)	
2500	8550 lbs (3.878 t)		
	9050 lbs (4.105 t)		
	9480 lbs (4.300 t)	7000 lbs (3.175 t) (gasoline only)	
		7400 lbs (3.357 t) (diesel only)	
3500	9900 lbs (4.490 t) (For Canada only)	7400 lbs (3.357 t)	
	9989 lbs (4.531 t) (For USA only)		
3500 XD	11030 lbs (5.003 t)	10470 lbs (4.749 t)	
4500	12125 lbs (5.500 t)	9375 lbs (4.252 t)	

⁷⁾ Maximum permissible curb weight of a roadworthy vehicle without driver or occupants, including all fluids and their tanks when filled up to 100%.

Front axle load, rear axle load, gross weight of vehicle combination (series, optional) Vehicle types 1500 and 2500 with a max. permissible gross weight of 8,550 lbs $(3.878\ t)$, 9,050 lbs $(4.105\ t)$ and 9,480 lbs $(4.300\ t)$

Permissible front axle load GAWR (FA)	Permissible rear axle load GAWR (RA)
4100 lbs (1.860 t) ⁵⁾	5360 lbs (2.431 t)
4410 lbs (2.000 t) ¹⁾	

Vehicle type 3500 with a max. permissible gross weight of 9900 lbs (4.490 t) (For Canada only) and 9989 lbs (4.531 t) (For USA only)

Permissible front axle load GAWR (FA)	Permissible rear axle load GAWR (RA)
4080 lbs (1.851 t) ⁵⁾	7060 lbs (3.202 t)
4410 lbs (2.000 t) ¹⁾	

Vehicle type 3500 XD with a max, permissible gross weight of 11,030 lbs (5.003 t)

Permissible front axle load GAWR (FA)	Permissible rear axle load GAWR (RA)
4080 lbs (1.851 t) ⁵⁾	7720 lbs (3.502 t)
4410 lbs (2.000 t) ¹⁾	

Vehicle type 4500 with a max. permissible gross weight of 12,125 lbs (5.500 t)

Permissible front axle load GAWR (FA)	Permissible rear axle load GAWR (RA)
4630 lbs (2.100 t)	7935 lbs (3.599 t)

¹⁾ Front axle with increased load capacity.

Gross weight of vehicle combination, trailer load, tongue weight Vehicle types 1500 and 2500 with a max. permissible gross weight of 8,550 lbs (3.878 t)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
13550 lbs (6.146 t)	5000 lbs (2.268 t) ²⁾	500 lbs (0.227 t) ²⁾

Vehicle type 2500 with a max. permissible gross weight of 9,050 lbs (4.105 t)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
13930 lbs (6.319 t)	5000 lbs (2.268 t) ²⁾	500 lbs (0.227 t) ²⁾

Vehicle type 2500 with a max. permissible gross weight of 9,480 lbs (4.300 t)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
9480 lbs (4.300 t)	_	-

⁵⁾ Not in combination with all-wheel drive (4x4) and not in combination with model series 907.745 (combination vehicles with a vehicle length of 290 inch (7,367 mm))

Vehicle type 3500 with a max. permissible gross weight of 9,900 lbs (4.490 t) (For Canada only)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
14900 lbs (6.759 t) ²⁾ , only for model series 907.657 ⁸⁾	5000 lbs (2.268 t) ²⁾ , only for model series 907.657 ⁸⁾	500 lbs (0.227 t) $^{2)}\!,$ only for model series 907.657 $^{8)}$
15250 lbs (6.917 t) ³⁾ , not for model series 907.657 ⁸⁾	7500 lbs (3.402 t) ³⁾ , not for model series 907.657 ⁸⁾	750 lbs (0.340 t) $^{3)}$, not for model series 907.657 $^{8)}$

Vehicle type 3500 with a max. permissible gross weight of 9,990 lbs (4.531 t) (For USA only)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
14990 lbs (6.799 t) ²⁾ , only for model series 907.657 ⁸⁾	5004 lbs (2.270 t) ²⁾ , only for model series 907.657 ⁸⁾	500 lbs (0.227 t) $^{2)}\!,$ only for model series 907.657 $^{8)}$
15250 lbs (6.917 t) ³⁾ , not for model series 907.657 ⁸⁾	7500 lbs (3.402 t) ³⁾ , not for model series 907.657 ⁸⁾	750 lbs (0.340 t) $^{3)}$, not for model series 907.657 $^{8)}$

Vehicle type 3500 XD with a max. permissible gross weight of 11,030 lbs (5.003 t)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
15250 lbs (6.917 t) ⁴⁾	5004 lbs (2.270 t) ²⁾ , only for model series 907.657 ⁸⁾	500 lbs (0.227 t) $^{\rm 2)}$, only for model series 907.657 $^{\rm 8)}$
	optional: 7500 lbs (3.402 t) ³⁾ , not for model series 907.657 ⁸⁾	optional: 750 lbs (0.340 t) $^{3)}$, not for model series 907.657 $^{8)}$

Vehicle type 4500 with a max. permissible gross weight of 12,125 lbs (5.500 t)

Permissible gross weight of vehicle/trailer combination GCWR ^{6), 9)}	Permissible trailer load GTW, braked ⁶⁾	Permissible noseweight TWR
15250 lbs (6.917 t) ⁴⁾	5004 lbs (2.270 t) ²⁾ , only for model series 907.657 ⁸⁾	500 lbs (0.227 t) $^{2)}\!,$ only for model series 907.657 $^{8)}$
	optional: 7500 lbs (3.400 t) ³⁾ , not for model series 907.657 ⁸⁾	optional: 750 lbs (0.340 t) $^{3)}$, not for model series 907.657 $^{8)}$

 $^{^{2)}}$ Only NAFTA trailer cross member, towing capacity 5,000 lbs.

³⁾ Only NAFTA trailer cross member, towing capacity 7,500 lbs.

- 4) Only NAFTA trailer cross member, towing capacity 5.000 or 7.500 lbs.
- 6) In trailer operation, no individual maximum permissible gross weight of those specified in the table may be exceeded.
- 8) The vehicle length for vehicles with the model series 907.657 (Cargo Van) is 290 in (7,367 mm).
- 9) It is not possible to tow a trailer on vehicles which have not been equipped with a trailer coupling as standard. In this case, the maximum permissible gross vehicle weight corresponds to the maximum permissible gross weight of the vehicle combination.
- i If the trailer coupling is retrofitted, the identification plates should be adapted accordingly with the altered, maximum permissible weights. Please consult an authorized Mercedes-Benz Center if you have any further questions.

DAIMLER AG IMPORTANT INFORMATION FOR BODY BUILDERS INFORMATIONS IMPORTANTES POUR LES CARROSSIERS This vehicle and engine conform to all applicable US EPA. CARB. lle véhicule et le moteur sont conformen aux directives EPA CARB (E-IL) et du Canada appli-tables à la date de production du véhicule ayant un PNBV inférieur à 10000 lo et un poids and Canadian regulations at the time of manufacture for vehicles under 10000 los GVWR and has a muximum aploaded vehicle weight (LIVW) of 7400 lbs à vide max, de 7450 lb

The body builder label is found on the front-end module above the radiator and contains the maximum permissible curb weight for the vehicles.

Lashing points and carrier systems Information about the cargo tie-down points

NOTE Risk of accident if the maximum loading capacity of the cargo tie-down point is exceeded

If you combine various cargo tie-down points to secure a load, always take the maximum loading capacity of the weakest cargo tiedown point into account.

During maximum full-stop braking, forces may act which can multiply the weight of the load.

Always use several cargo tie-down points to distribute and spread the load. Distribute the load on the cargo tiedown points evenly.

The nominal tensile strength is the maximum permissible tensile force.

Further information on the cargo tie-down points and tie-down eves can be obtained in the "Transporting" section (\rightarrow page 272).

Tie-down eves

Nominal tensile strength of the tie-down eyes

Tie-down eyes	Nominal tensile strength
Passenger Van	350 daN
Cargo Van	800 daN

Loading rails

Nominal tensile strength of the cargo tiedown points in the cargo compartment

Cargo tie-down point	Nominal tensile strength
Loading rails on cargo compartment floor	500 daN
Lower loading rail on side wall	200 daN
Upper loading rail on side wall	125 daN

The values specified apply only to loads resting on the cargo compartment floor if you observe the following:

- The load is secured to two cargo tie-down points on the rail
- The distance to the nearest load-securing point on the same rail is approximately 1 m

Information about roof racks

WARNING Risk of injury if maximum roof load is exceeded

If you place a load on the roof as well as any external and internal attachments, the vehicle's center of gravity will be raised and the usual driving characteristics, as well as the steering and braking characteristics, will change. During cornering, the vehicle will tilt more severely and may react more sluggishly to steering movements.

If you exceed the maximum roof load, the driving characteristics, as well as the steering and braking characteristics, will be greatly impaired.

Always comply with the maximum roof load and adjust your driving style.

WARNING Danger of accident due to uneven loading

If you load the vehicle unevenly, the handling characteristics as well as the steering- and braking characteristics can be heavily impaired.

- ▶ Load the vehicle evenly.
- Secure the load against sliding.

The driving, braking and steering characteristics of the vehicle will change with the type of load, the weight and the center of gravity of the load.

NOTE Risk of accident if the maximum permitted roof load is exceeded.

If the weight of the roof luggage, including the roof rack, exceeds the maximum permitted roof load, there is a risk of an accident.

- Ensure that the weight of the roof luggage and roof rack together does not exceed the maximum permitted roof load.
- The roof rack's supporting feet must be arranged at a uniform distance from each other.
- Mercedes-Benz recommends you install a stabilizer bar on the vehicle's front axle.

Further information about safety measures can be found in the "Transport" section $(\rightarrow page 272)$.

Max. roof load/pairs of supporting roof rack feet

Vehicles with	Maximum roof load	Minimum number of pairs of sup- porting feet
Normal roof	661 lbs (300 kg)	6
High roof	331 lbs (150 kg)	3

This information applies if the load is distributed evenly across the entire roof area.

If the roof rack is shorter, reduce the load proportionately. The maximum load per pair of supporting roof rack feet is 110 lbs (50 kg).

The loading guidelines and other information about load distribution and load securing can be found in the "Transport" section (\rightarrow page 272).

Display messages

Introduction

Function of display messages

The display messages appear on the multifunction display.

The display messages with graphic displays can be displayed in simplified format in the Operator's Manual and may deviate from the display on the multifunction display. The multifunction display shows high-priority display messages in red. In addition, a warning tone sounds for specific display messages.

Act in accordance with the display messages and comply with the additional instructions in this Operator's Manual.

In addition, symbols are shown for some display messages:

i	Further information
	Hide display messages

You can use the left-hand Touch Control to select between the symbols by swiping to the left or right. Pressing i displays further information on the multifunction display. Pressing hides the display message.

You can hide low-priority display messages by pressing the 🖆 button or with the left-hand Touch Control. The display messages are saved in the message memory.

Rectify the cause of a display message as quickly as possible.

You cannot hide high-priority display messages. The multifunction display will show these display messages until their causes have been rectified.

Calling up saved display messages

On-board computer:



If there are no display messages, No Messages appears on the multifunction display.

- Browse through the display messages by swiping upwards or downwards on left-hand Touch Control.
- Exiting the message memory: press the **≐** button.

Safety systems

Display messages



Left Side Curtain Airbag Malfunction Service Required (example)

Possible causes/consequences and > Solutions

* The respective window curtain airbag is malfunctioning $(\rightarrow page 35)$.

WARNING Risk of injury or fatal injury due to malfunctions in the window airbag

If the window airbag is malfunctioning, it might be triggered unintentionally or might not be triggered at all in the event of an accident with high deceleration.

- Have the window airbag checked and repaired immediately at a qualified specialist workshop.
- Consult a qualified specialist workshop immediately.



Front Left Malfunction Service Required (example)

* The respective restraint system is malfunctioning (\rightarrow page 31).

WARNING Risk of injury due to malfunctions in the restraint

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or may not deploy as intended during an accident. This may affect the Emergency Tensioning Devices or airbags, for example.

► Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system malfunction:

- The prestraint system warning lamp does not light up when the ignition is switched on.
- The prestraint system warning lamp lights up continuously or repeatedly during a journey.
- Consult a qualified specialist workshop immediately.



SRS Malfunction Service Required

* The restraint system is malfunctioning (\rightarrow page 31).

WARNING Risk of injury due to malfunctions in the restraint system

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or may not deploy as intended during an accident. This may affect the Emergency Tensioning Devices or airbags, for example.

► Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system malfunction:

- The prestraint system warning lamp does not light up when the ignition is switched on.
- The prestraint system warning lamp lights up continuously or repeatedly during a journey.
- Consult a qualified specialist workshop immediately.

Display messages



Parking Brake Inopera-

Possible causes/consequences and > Solutions

* A malfunction has occurred in the system; the parking brake is inoperative

▲ WARNING Risk of an accident due to a brake system malfunction

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Park the vehicle on a level surface only and secure it against rolling away.
- Vehicles with automatic transmission: shift the transmission to position P.
- Have the brake system checked at a qualified specialist workshop immediately.



Incline Too Steep See Operator's Manual

* The on-board electrical system voltage is low or a malfunction has occurred in the system; the holding force may not be sufficient for the incline.

A WARNING Risk of accident if the electrical parking brake has insufficient holding force

If the electrical parking brake does not have sufficient holding force on a steep incline, the vehicle may roll away.

- Park the vehicle on a level surface only and secure it against rolling away.
- Shift the automatic transmission to position **P**.

Observe the notes on parking the vehicle (\rightarrow page 140).



Parking Brake See Operator's Manual

* The on-board electrical system voltage is low or a malfunction has occurred in the system; the closing force may not be sufficient for the incline.

WARNING Risk of an accident due to a brake system malfunction

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Park the vehicle on a level surface only and secure it against rolling away.
- Vehicles with automatic transmission: shift the transmission to position **P**.
- Have the brake system checked at a qualified specialist workshop immediately.

driving safety systems will be available again.

If the display message does not disappear, proceed as follows:

Dianlay massassa	Descible severe (semeseveness and b. Califfren
Display messages	Possible causes/consequences and Solutions
	Stop in accordance with the traffic conditions.
	Clean all sensors (→ page 288).
OOO NOT BEADY	Restart the engine.
SOS NOT READY	* The emergency call system is not available.
	Possible causes for this include:
	The ignition is switched off.The emergency call system is malfunctioning.
	_
	Switch on the ignition. If an emergency call is unavailable, a message to this effect will
	appear on the multifunction display of the instrument cluster.
	Visit a qualified specialist workshop.
	(i) You can find more information on the regional availability of the
	emergency call system at: http://www.mercedes-benz.com/ connect_ecall
	* EBD, ABS and ESP® are malfunctioning.
FRD	Other driving systems and driving safety systems may also be mal-
	functioning.
	▲ WARNING Risk of skidding if EBD, ABS and ESP® are mal-
	functioning
	If EBD, ABS and ESP® are malfunctioning, the wheels can lock
	when braking and ESP® cannot carry out vehicle stabilization.
Inoperative See Opera-	The steering capability and braking characteristics are thus
tor's Manual	severely impaired. The braking distance in an emergency brak- ing situation can increase. In addition, other driving safety sys-
	tems are switched off.
	Drive on carefully.
	Have the brake system checked immediately at a qualified
	specialist workshop.
	Drive on carefully.
	Consult a qualified specialist workshop immediately.
	* ESP® is malfunctioning.
	Other driving systems and driving safety systems may also be mal-
Inoperative See Opera-	functioning.
tor's Manual	The brake system continues working with the normal effect. The braking distance may increase in emergency braking situations.
	▲ WARNING Risk of skidding if ESP [®] is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabili-
	zation. In addition, other driving safety systems are switched off. Drive on carefully.
	Have ESP® checked at a qualified specialist workshop.
	mave Lor - checked at a qualified specialist workshop.



tor's Manual

* ABS and ESP® are malfunctioning.

Other driving systems and driving safety systems may also be malfunctioning.

The brake system continues working with the normal effect. The braking distance may increase in emergency braking situations.

Display messages	Possible causes/consequences and ▶ Solutions
	▲ WARNING Risk of skidding if ABS and ESP [®] are malfunctioning
	If ABS and ESP® are malfunctioning, the wheels could lock when braking and ESP® cannot carry out vehicle stabilization.
	The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off.
	Drive on carefully.
	Have ABS and ESP® checked immediately at a qualified specialist workshop.
	Drive on carefully.
	Consult a qualified specialist workshop immediately.

Driving systems

Display messages	Possible causes/consequences and ▶ Solutions
120 km/h! Maximum Speed Exceeded	 You have exceeded the maximum permitted speed (specific countries only). Drive more slowly.
Cruise Control Inoperative	 * Cruise control is malfunctioning. Visit a qualified specialist workshop.
	* Cruise control has been deactivated.
Off (Sold)	If a warning tone also sounds, this means cruise control has deactivated itself automatically (\rightarrow page 151).
mph	 Cruise control cannot be activated as not all activation conditions have been met. Description Observe the activation conditions of cruise control (→ page 151).
Active Distance Assist Inoperative	 * Active Distance Assist DISTRONIC is malfunctioning. Other driving systems and driving safety systems may also be malfunctioning. Visit a qualified specialist workshop.
Active Distance Assist Currently Unavailable See Operator's Manual	 * Active Distance Assist DISTRONIC is temporarily unavailable. The ambient conditions are outside the system limits (→ page 152). Drive on. When the ambient conditions are within the system limits, the system will be available again.

Display messages	Possible causes/consequences and ▶ Solutions
Currently Unavailable Camera Dirty	 * The camera view is restricted. Possible causes: Dirt on the windshield in the camera's field of vision Heavy precipitation or fog Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driving safety systems will be available again. If the display message does not disappear: Stop in accordance with the traffic conditions. Clean the windshield. If necessary, consult a qualified specialist workshop.
OFF Currently Unavailable Radar Sensors Dirty	 * The radar sensor system is malfunctioning. Possible causes: Dirt on the sensors Heavy precipitation Extended country driving without other traffic, e.g. in the desert The following systems may be affected: Active Distance Assist DISTRONIC (→ page 152) Blind Spot Assist (→ page 164) Active Brake Assist (→ page 149) Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driving safety systems will be available again. If the display message does not disappear: Stop in accordance with the traffic conditions. Clean all sensors (→ page 288). Restart the engine. If necessary, consult a qualified specialist workshop.
Active Distance Assist Now Available	* Active Distance Assist DISTRONIC is operational again and can be activated (→ page 153).
HOLD	 * The HOLD function has been deactivated because the vehicle is slipping or an activation condition has not been met. ▶ Reactivate the HOLD function later on or check the HOLD function's activation conditions (→ page 155).
Traffic Sign Assist Inoperative	 * Traffic Sign Assist is malfunctioning. > Visit a qualified specialist workshop.
Traffic Sign Assist Camera View Restricted See Operator's Manual	 * The camera view is restricted. Possible causes: • Dirt on the windshield in the camera's field of vision • Heavy precipitation or fog

Display messages	Possible causes/consequences and ▶ Solutions
	Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driving safety systems will be available again. If the display message does not disappear: Stop in accordance with the traffic conditions. Clean the windshield.
Traffic Sign Assist Currently Unavailable See Operator's Manual	 * Traffic Sign Assist is temporarily unavailable (→ page 163). ▶ Drive on. When the causes have been eliminated, the system will be available again. * The windshield is dirty. Clean the windshield.
Blind Spot Assist Inoperative	 * Blind Spot Assist is malfunctioning (→ page 164). ▶ Visit a qualified specialist workshop.
Blind Spot Assist Trailer Not Monitored	 * When you establish an electrical connection with the trailer, Blind Spot Assist will remain available but the area beside the trailer will not be monitored. The function of Blind Spot Assist may be restricted as a result (→ page 164). ▶ Press the left-hand Touch Control and acknowledge the display message.
Blind Spot Assist Currently Unavailable See Operator's Manual	 * Blind Spot Assist is temporarily unavailable (→ page 164). The system limits have been reached (→ page 164). Drive on. When the causes have been eliminated, the system will be available again. or If the display message does not disappear, stop in accordance with the traffic conditions and restart the engine. If necessary, clean the rear bumper. If the bumper is very dirty, the sensors in the bumper may malfunction.
Active Lane Keeping Assist Camera View Restricted See Opera- tor's Manual	 * The camera view is restricted (→ page 167). Possible causes: • Dirt on the windshield in the camera's field of vision • Heavy precipitation or fog Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driving safety systems will be available again. If the display message does not disappear: Stop in accordance with the traffic conditions. Clean the windshield.

Display messages	Possible causes/consequences and ▶ Solutions
Active Lane Keeping Assist Inoperative	 * Active Lane Keeping Assist is malfunctioning (→ page 167). ▶ Visit a qualified specialist workshop.
Active Lane Keeping Assist Currently Unavail- able See Operator's Man- ual	 * Active Lane Keeping Assist is temporarily unavailable (→ page 167). The ambient conditions are outside the system limits (→ page 167). ▶ Drive on. When the ambient conditions are within the system limits, the system will be available again. If the display message does not disappear: ▶ Stop in accordance with the traffic conditions. ▶ Clean the windshield.
ATTENTION ASSIST Inoperative	* ATTENTION ASSIST is malfunctioning. Visit a qualified specialist workshop.
ATTENTION ASSIST:	 * ATTENTION ASSIST has detected fatigue or increasing inattentiveness on the driver's part (→ page 162). ▶ If necessary, take a break.

Engine

Take a Break!

Display messages	Possible causes/consequences and ▶ Solutions
Fuel Level Low	 * The fuel supplies have reached the reserve level. Refuel.
Replace Air Filter	 * Vehicles with a diesel engine: The engine air filter is clogged and must be replaced. Visit a qualified specialist workshop.
₩	 * The fan motor is defective. Without a high engine load, continue to the nearest qualified specialist workshop. Ensure that the coolant temperature display remains below 248 °F (120 °C).
Check Fuel Filter	 * The water that has accumulated in the water separator has reached the maximum level. ▶ Drain the water separator (→ page 285).

Display messages Possible causes/consequences and > Solutions * The electrical connection to the oil level sensor has been interrupted or the oil level sensor is faulty. Visit a qualified specialist workshop. **Engine Oil Level Cannot** Be Measured * Display message for certain engines only: The engine oil pressure is too low. **NOTE** Engine damage caused by driving with insufficient Engine Oil Pressure Stop engine oil pressure Switch Off Engine Avoid driving with insufficient engine oil pressure. Stop in a safe location immediately. Do not continue driving. Consult a qualified specialist workshop. * The engine oil level has fallen to the minimum level. **NOTE** Engine damage caused by driving with insufficient engine oil Check Engine Oil Level Avoid long journeys with insufficient engine oil. (Add 1 Liter) Check the engine oil level at the next fuel stop. Refill engine oil (\rightarrow page 281). Observe the notes on engine oil (\rightarrow page 344). * Display message for certain engines only: The engine oil level is too high. **NOTE** Engine damage caused by driving with excess engine Engine Oil Reduce Oil oil Level Avoid long journeys with excess engine oil. Visit a qualified specialist workshop immediately and have the engine oil suctioned off. * Display message for certain engines only: The engine oil level is too low. **NOTE** Engine damage caused by driving with insufficient Engine Oil Level Low engine oil Stop Vehicle Turn **Engine Off** Avoid long journeys with insufficient engine oil. Stop in a safe location immediately. Do not continue driving. Switch off the engine. Check the engine oil level. Add engine oil (\rightarrow page 281). Observe the notes on engine oil (\rightarrow page 344).

Dienlay massages	Possible squage /consequences and Solutions
Display messages	Possible causes/consequences and Solutions
Check Engine Oil At	* The engine oil level has fallen to the minimum level.
	NOTE Engine damage caused by driving with insufficient engine oil
Next Refueling	Avoid long journeys with insufficient engine oil.
	► Check the engine oil level at the next fuel stop.
	Top up engine oil (\rightarrow page 281). Observe the notes on engine oil (\rightarrow page 344).
Stop Vehicle Leave Engine Running	 * The battery's charge level is too low. Stop in a safe location immediately. Do not continue driving! Let the engine run. Do not continue driving until the display message goes out.
- +	* The battery is no longer being charged and has reached an excessively low battery charge level.
Stop Vehicle See Opera-	NOTE Possible engine damage if you continue driving
tor's Manual	Do not continue driving under any circumstances.Consult a qualified specialist workshop.
	 Stop in a safe location immediately. Do not continue driving. Switch off the engine. Consult a qualified specialist workshop.
12 V Battery See Operator's Manual	 * The engine is off and the battery charge level is too low. Switch off electrical consumers that are not required. Let the engine run for a few minutes or drive an extended distance. The battery is charged.
ر مــــــــــــــــــــــــــــــــــــ	* The battery is no longer being charged.
	NOTE Possible engine damage if you continue driving
See Operator's Manual	Do not continue driving under any circumstances.Consult a qualified specialist workshop.
	Stop in a safe location immediately and switch off the engine.Consult a qualified specialist workshop.
Coolant Too Hot Stop Vehicle Turn Engine Off	* The coolant is too hot. Stop immediately in accordance with the traffic conditions and switch off the engine.

Display messages

Possible causes/consequences and > Solutions

▲ WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- ▶ Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

▲ WARNING Risk of scalding from hot coolant

The engine cooling system is pressurized, particularly when the engine is warm. If you open the cap, you could be scalded by hot coolant spraying out.

- Let the engine cool down before opening the cap.
- ▶ When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.
- Wait until the engine has cooled down.
- Ensure that the air supply to the engine radiator is not obstruc-
- Avoiding high engine loads, continue to the nearest qualified specialist workshop. Ensure that the coolant temperature display remains below 248°F (120°C).



Check Coolant Level See Operator's Manual

* The coolant level is too low.

WARNING Risk of scalding from hot coolant

The engine cooling system is pressurized, particularly when the engine is warm. If you open the cap, you could be scalded by hot coolant spraying out.

- Let the engine cool down before opening the cap.
- When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.

NOTE Engine damage due to insufficient coolant

- Avoid long journeys with insufficient coolant.
- Top up coolant (→ page 282).

Regeneration Not Possible

- * Not all conditions have been met for regeneration of the diesel particulate filter.
 - Continue driving as normal until all conditions have been met for regeneration of the diesel particulate filter.

The load condition of the diesel particulate filter is over 50% and the message still appears on the instrument cluster.

Display messages Possible causes/consequences and > Solutions * In addition, the yellow 📤 DEF indicator lamp lights up on the instrument cluster and a warning tone sounds. The DEF supply has fallen below the first warning threshold. Refill Additive See Opera-Add at least 2.5 gal (9.5 l) of DEF (\rightarrow page 137). tor's Manual The DEF indicator lamp only disappears when the vehicle is stationary, at the latest after 20 seconds, as soon as you switch on the ignition or start the engine after topping up. * In addition, the yellow DEF indicator lamp lights up and a warning tone sounds. The DEF supply has fallen below the reserve mark. Refill Additive Starts After the message appears for the first time, the remaining DEF supuntil Emerg. Op.: XXX ply will last for approximately 1200 miles (1900 km). The engine can See Operator's Manual then only be started another 16 times. The number of remaining engine starts XX (16 to 1) is shown in the message every time the engine is started. Add at least 2.5 gal (9.5 l) of DEF (\rightarrow page 137). The $\stackrel{\triangle}{\Longrightarrow}$ DEF indicator lamp only disappears when the vehicle is stationary, at the latest after 20 seconds, as soon as you switch on the ignition or start the engine after topping up. * In addition, the yellow DEF indicator lamp lights up on the instrument cluster and a warning tone sounds. If the Refill Additive Emergency Op.: XXX mph See Operator's Manual display message is shown, you can only drive the vehicle at a Refill Additive Emermaximum speed of 5 mph (8 km/h). gency Op.: XXX mph See Operator's Manual Add at least 2.5 gal (9.5 l) of DEF (\rightarrow page 137). The DEF indicator lamp only disappears when the vehicle is stationary, at the latest after 20 seconds, as soon as you switch on the ignition or start the engine after refilling. * In addition, the yellow Check Engine warning lamp on the



Additive System Fault See Operator's Manual

Additive System Fault Starts until Emerg. Op.: XXX See Operator's Manual

instrument cluster lights up and a warning tone sounds.

The DEF reducing agent is contaminated, diluted or is not compliant with ISO 22241.

► Have the DEF supply tank cleaned and refilled at a qualified specialist workshop as soon as possible.

instrument cluster lights up and a warning tone sounds.

The DEF reducing agent is contaminated, diluted or is not compliant with ISO 22241.

The exhaust gas aftertreatment system is defective or an emissionsrelevant malfunction has occurred. This malfunction or defect can damage the exhaust gas aftertreatment system.

Display messages	Possible causes/consequences and ▶ Solutions
	After the message appears for the first time, the engine can only be started another 10 times. The number of remaining engine starts XX (10 to 1) is shown in the message every time the engine is started. Visit a qualified specialist workshop immediately.
Additive System Fault Emergency Op.: XXX mph See Operator's Manual	 * In addition, the yellow Check Engine warning lamp on the instrument cluster lights up and a warning tone sounds. You can only drive the vehicle at a maximum speed of 5 mph (8 km/h). Visit a qualified specialist workshop immediately.

Tires

Display messages	Possible causes/consequences and ▶ Solutions
Tire Pressure Monitor Inoperative No Wheel Sensors	 * The installed wheels do not have suitable tire pressure sensors. The tire pressure monitor has been switched off. Install wheels with suitable tire pressure sensors.
Tire Press. Sen. Missing	 * The tire pressure sensor signal is missing from one or more tires. No pressure value is displayed for the tire in question. Have the faulty tire pressure sensor replaced at a qualified specialist workshop.
Tire Press. Monitor Currently Unavailable	 * There is interference from a powerful source of radio waves As a result, no signals from the tire pressure sensors are received. The tire pressure monitor is temporarily unavailable. Continue driving. As soon as the cause has been eliminated, the tire pressure monitor automatically switches on.
(!)	* The pressure in one or more tires suddenly falls. The wheel position is shown.
Warning Tire Malfunction	▲ WARNING Risk of an accident from driving with a flat tire
warning the Manufiction	Flat tires are dangerous in the following ways:
	The tires can overheat and cause a fire.
	 The driving characteristics, as well as steering and braking, may be greatly impaired.
	You could then lose control of the vehicle.
	Do not drive with a flat tire.
	Observe the notes on flat tires.
	 Information about flat tires (→ page 294). Stop the vehicle in accordance with the traffic conditions. Check the tires.

Display messages	Possible causes/consequences and ▶ Solutions
(!)	* The pressure in one or more tires has fallen significantly. The wheel position is shown.
Check Tires	▲ WARNING Risk of an accident due to insufficient tire pressure
	Tire pressures that are too low pose the following hazards:The tires may burst, especially as the load and vehicle speed increase.
	The tires may wear excessively and/or unevenly, which may greatly impair tire traction.
	 The driving characteristics, as well as steering and braking, may be greatly impaired.
	You could then lose control of the vehicle.
	Observe the recommended tire pressure.Adjust the tire pressure if necessary.
	 Stop in accordance with the traffic conditions. Check the tire pressure (→ page 310) and the tires.
(1)	* The pressure in at least one tire is too low or the pressures of the individual tires deviate too much from each other.
Please Correct Tire Pressure	 Check the tire pressure, and add air if necessary. When the tire pressure has been set correctly, re-start the tire pressure monitor (→ page 316).
Tire Pressure Monitor Inoperative	 * The tire pressure monitor is malfunctioning. > Visit a qualified specialist workshop.

Kev

ite y	
Display messages	Possible causes/consequences and ▶ Solutions
Don't Forget Your Key	 * This message reminds you not to leave your SmartKey in the vehicle. Take the SmartKey with you when you get out of the vehicle.
Place the Key in the Marked Space See Oper- ator's Manual	 * SmartKey detection is malfunctioning. ▶ Change the SmartKey's position in the vehicle. ▶ Start the vehicle with the SmartKey in the marked space (→ page 110).

Display messages	Possible causes/consequences and ▶ Solutions
Key Not Detected (red display message)	 * The SmartKey is not detected and may no longer be in the vehicle. The SmartKey is no longer in the vehicle and you switch the engine off: You can no longer start the engine. You cannot lock the vehicle centrally. Ensure that the SmartKey is in the vehicle. If the SmartKey detection function has a malfunction due to a strong radio signal source, proceed as follows: Stop the vehicle immediately in accordance with the traffic conditions. Place the SmartKey in the marked space for starting with the SmartKey (→ page 110).
Key Not Detected (white display message)	 * The SmartKey is currently not detected. ▶ Change the SmartKey's position in the vehicle. ▶ If the SmartKey is still not detected, start the engine with the SmartKey in the marked space (→ page 110).
Replace Key Battery	 * The SmartKey's battery is discharged. ▶ Changing the battery (→ page 47).
Obtain a New Key	 * The SmartKey must be replaced. Visit a qualified specialist workshop.

Vehicle

Display messages	Possible causes/consequences and ▶ Solutions
Check Washer Fluid	 * The washer fluid level in the washer fluid reservoir has fallen below the minimum. ▶ Adding washer fluid (→ page 284).
	* At least one door is open. Close all the doors.
	* The hood is open.

Display messages	Possible causes/consequences and ▶ Solutions				
	WARNING Risk of accident if the engine hood is unlatched while driving				
	An unlocked engine hood may open up when the vehicle is in motion and block your view.				
	 Never unlatch the engine hood while driving. Before every trip, ensure that the engine hood is latched. 				
	 Stop the vehicle immediately in accordance with the traffic conditions. Close the hood. 				
	* The stationary heater is temporarily malfunctioning.				
Inoperative See Operator's Manual	 When the vehicle is at a standstill in a horizontal position and the engine has cooled down: try to switch on the stationary heater four times, leaving a gap of several minutes between each attempt. If the stationary heater does not switch on: consult a qualified 				
	specialist workshop.				
Inoperative Refuel Vehicle	 * There is too little fuel in the fuel tank. The stationary heater cannot be switched on. Refuel the vehicle. 				
* * * *	* The on-board electrical system voltage is too low.				
(%)	The stationary heater has switched off.				
Inoperative Battery Low	 Drive an extended distance until the battery has been suffi- ciently charged again. 				
	* The steering power assistance is malfunctioning.				
Steering Malfunction	▲ WARNING Risk of an accident due to altered steering characteristics				
Increased Physical Effort See Operator's Manual	If the power assistance of the steering fails partially or completely, you will need to use more force to steer.				
	If safe steering is possible, drive on carefully.				
	Visit or consult a qualified specialist workshop immediately.				
	If safe steering is possible, drive on carefully.				
	Visit or consult a qualified specialist workshop immediately.				
	* The steering is malfunctioning. Steerability is heavily impaired.				
	▲ WARNING Risk of accident if steering capability is impaired				
Steering Malfunction Stop Immediately See Operator's Manual	If the steering does not function as intended, the vehicle's operating safety is jeopardized.				

Display messages	Possible causes/consequences and ▶ Solutions
	 Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop.
	 Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. Consult a qualified specialist workshop.
Shift to 'P' or 'N' to Start Engine	 You have attempted to start the engine in transmission position D or R. Shift the transmission to position P or N.
To Engage Transmiss. Position R First Depress the Brake	 You have attempted to shift from position D or N to position R. Depress the brake pedal. Shift the transmission to position R.
Air Conditioning Malfunction See Operator's Man- ual	 * The function of the climate control system is temporarily restricted. The quantity of air and flow of fresh air are controlled automatically. Have the climate control system checked at a qualified specialist workshop.
Auxiliary Battery Mal- function	 * The auxiliary battery for the transmission is no longer being charged. > Visit a qualified specialist workshop. > Until then, always shift the transmission to position P manually before you switch off the engine. > Before leaving the vehicle, apply the parking brake.
Reversing Not Possible Service Required	 * The transmission is malfunctioning. It is no longer possible to select reverse gear. Visit a qualified specialist workshop.
Transmission Malfunction Stop	 * The transmission is malfunctioning. The transmission automatically shifts to position N. > Stop the vehicle immediately in accordance with the traffic conditions. > Shift the transmission to position P. > Consult a qualified specialist workshop.
Vehicle Operational Switch the Ignition Off Before Exiting	 You are about to exit the vehicle when it is in a ready-to-drive state. When you exit the vehicle, switch off the ignition and take the key with you. If you do not exit the vehicle, switch off the electrical consumers, e.g. the seat heating. Otherwise, the 12-V battery may discharge and it will be possible to start the vehicle only with the aid of a second battery (starting assistance).
Service Required Do Not Shift Gears Visit Dealer	* The transmission is malfunctioning. The transmission position can no longer be changed.

Display messages	Possible causes/consequences and ▶ Solutions
	 If the transmission is in position D, visit a qualified specialist workshop, without changing the transmission position. For all other transmission positions, park the vehicle in a safe location. Inform a qualified specialist workshop or breakdown service.
Only Shift to 'P' when Vehicle is Stationary	* The transmission can only be shifted to position \boxed{P} if the vehicle is at a standstill.
N Permanently Active Risk of Rolling Away	 * While the vehicle is rolling or driving, the transmission was shifted to position N. To stop, depress the brake pedal and, when the vehicle is at a standstill, shift the transmission to position P. To continue your journey, shift the transmission to position D or R.
Driver's Door Open & Transmission Not in P Risk of Vehicle Rolling Away	 * The driver's door is not fully closed and the transmission is in position R, N or D. When parking the vehicle, shift the transmission to position P.
Apply Brake to Shift from 'P'	 You have attempted to shift to a different transmission position from position P. Depress the brake pedal.
Vehicle Tracker has been activated. Details: see manual or associated mobile app. or Vehicle locating activated – see manual or mobile app.	 * The vehicle features activated services from Mercedes PRO. Locating the vehicle may be possible within the framework of Mercedes PRO connect. Check the status of the activated services at http://mercedes.pro. Ask the vehicle owner for the details.
Step Not Extended See Operator's Manualor Step Not Extended Mal- function	 * The electrical step is not, or is only partially, extended. ▶ Ensure there is sufficient clearance for the electrical step. ▶ Open or close the sliding door again. ▶ If the electrical step does not completely extend again, push it in manually (emergency release) (→ page 58). ▶ Inform passengers that the step is missing before they exit the vehicle.
Step Not Retracted See Operator's Manualor Step Not Retracted Mal- function	 * The electrical step is not, or is only partially, retracted. ▶ Ensure there is sufficient clearance for the electrical step. ▶ Open or close the sliding door again. ▶ If the electrical step does not completely retract again, push it in manually (emergency release) (→ page 58).

Lights

Display messages	Possible causes/consequences and ▶ Solutions
Adaptive Highbeam Assist Camera View Restricted See Opera- tor's Manual	* The camera view is reduced. Possible causes: • Dirt on the windshield in the camera's field of vision • Heavy precipitation or fog Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. When the causes have been eliminated, the driving systems and driving safety systems are available again. If the display message does not go out: Stop in a safe location. Clean the windshield.
Adaptive Highbeam Assist Currently Unavail- able See Operator's Man- ual	 * Adaptive Highbeam Assist is temporarily unavailable. The system limits have been reached (→ page 86). ▶ Continue driving. When the causes have been eliminated, the system will be available again. The display message Adaptive Highbeam Assist Now Available appears.
Adaptive Highbeam Assist Inoperative	 * Adaptive Highbeam Assist is malfunctioning. Visit a qualified specialist workshop.
Switch On Headlamps	 You are driving without a low beam. Turn the light switch to position . Turn the light switch to the Auto position.
Switch Off Lights	 You are leaving the vehicle and the light is still switched on. Turn the light switch to position <u>AUTO</u>.
Auto Lamp Function Inoperative	 * The light sensor is malfunctioning. Visit a qualified specialist workshop.
Malfunction See Operator's Manual	 * The exterior lighting is malfunctioning. ▶ Visit a qualified specialist workshop. * Vehicles with trailer hitch: a fuse may have blown. ▶ Stop in accordance with the traffic conditions. ▶ Check the fuses, and replace them if necessary(→ page 304).

Display messages



Check Left Low Beam (example)

Possible causes/consequences and > Solutions

- * The bulb in question is faulty.
- Visit a qualified specialist workshop.

or

Check whether changing the bulb is permitted.

Indicator and warning lamps

Overview of indicator and warning lamps

When the ignition is switched on, many systems perform a self-test. Some indicator and warning lamps may switch on or flash temporarily during this time. This behavior is no cause for alarm. These indicator and warning lamps indicate a malfunction only if they light up or flash after the engine has been started or during a journey.



~£~

A

00

(i)

Check Engine (\rightarrow page 384)

Fuel reserve with fuel filler cap location indicator (\rightarrow page 384)

Coolant too hot/cold (\rightarrow page 384)

Distance warning (\rightarrow page 383)

Preglow

Tire pressure monitor

Indicator and warning lamns

Indicator and warning lamps:			
■ D	Low beam (\rightarrow page 84)		
- 00€	Parking lamps (→ page 84)		
≣D	High beam (\rightarrow page 85)		
\$	Turn signal lights (\rightarrow page 85)		
0\$	Rear fog light (→ page 84)		
*	Seat belt not fastened (→ page 383)		
BRAKE and	USA: Brakes (red) (\rightarrow page 377)		

(I)

Canada: Brakes (red) (\rightarrow page 377) (I) Brakes (yellow) (\rightarrow page 377) (I)

ABS malfunction (\rightarrow page 377) (ABS) Off-road gear

LOW $ESP^{\mathbb{R}} (\rightarrow page 377)$ Ħ

OFF. $ESP^{\mathbb{R}} OFF (\rightarrow page 377)$

એ!હ-Active Brake Assist switched off

 $(\rightarrow page 149)$

USA: Electric parking brake applied PARK and (P)

 $(red) (\rightarrow page 377)$

Canada: Electric parking brake (P) applied (red) (\rightarrow page 377) Electric parking brake (yellow) (P)

 $(\rightarrow page 377)$

Power-assisted steering malfunction **⊕!** ∣

 $(\rightarrow page 383)$

- - Electrical malfunction

 $(\rightarrow page 384)$

»; Restraint system (→ page 377)

Safety systems

Warning/indicator lamp



and



Electric parking brake applied red indicator lamp (USA) does not light up



Electric parking brake applied red indicator lamp (Canada) does not light up



Electric parking brake malfunctioning yellow indicator lamp lights up

Possible causes / consequences and ▶ Solutions

Vehicles with electric parking brake: the electric parking brake red indicator lamp does not light up. The electric parking brake yellow indicator lamp lights up.

- *Meaning of the indicator lamps:
- The red indicator lamp does not light up: the electric parking brake has been released.
- The yellow indicator lamp lights up: the electric parking brake is malfunctioning.
- Observe the messages on the multifunction display.
- Switch the ignition off and back on.
- If the fault message persists, consult a qualified specialist workshop.
- Park the vehicle only on level ground and secure it against rolling away (\rightarrow page 143).

Warning/indicator



and



Red electric parking brake applied indicator lamp (USA) lights up



Red electric parking brake applied indicator lamp (Canada) lights up



Electric parking brake malfunctioning yellow indicator lamp lights up

Possible causes/consequences and ▶ Solutions

Vehicles with electric parking brake: the red and yellow electric parking brake indicator lamps light up.

- *Meaning of the indicator lamps:
 - The electric parking brake red indicator lamp lights up: the electric parking brake has been applied.
 - The electric parking brake yellow indicator lamp lights up: the electric parking brake is malfunctioning.
- Dbserve the messages on the multifunction display.
- Switch the ignition off and back on.
- If the fault message persists, consult a qualified specialist workshop.
- If it is not possible to release the electric parking brake, do not drive the vehicle.



and



Red electric parking brake applied indicator lamp (USA) flashes



Red electric parking brake applied indicator lamp (Canada) flashes



Electric parking brake malfunctioning yellow indicator lamp lights up Vehicles with electric parking brake: the electric parking brake red indicator lamp flashes. The electric parking brake yellow indicator lamp lights up.

- *Meaning of the indicator lamps:
 - The electric parking brake red indicator lamp flashes: the activation status of the electric parking brake is unknown.
 - The electric parking brake yellow indicator lamp lights up: the electric parking brake is malfunctioning.
 - Observe the messages on the multifunction display.
 - Switch the ignition off and back on.
 - Engage and release the electric parking brake using the switch while depressing the brake pedal.
 - If the fault message persists, park the vehicle on level ground and secure it against rolling away (→ page 143).
 - Consult a qualified specialist workshop.
 - When the red indicator lamp flashes, the vehicle must not be driven as the brake system may overheat.



and



Red electric parking brake applied indicator lamp (USA) lights up



Red electric parking brake applied indicator lamp (Canada) lights up



The electric parking brake malfunctioning yellow indicator lamp does not light up

Possible causes/consequences and ▶ Solutions

Vehicles with electric parking brake: the electric parking brake red indicator lamp lights up. The electric parking brake vellow indicator lamp does not light up.

- *Meaning of the indicator lamps:
- The electric parking brake red indicator lamp lights up: the electric parking brake has been applied.
- The electric parking brake yellow indicator lamp does not light up: there are no faults with the electric parking brake.
- Do not drive the vehicle if the electric parking brake has been applied.



and



Red parking brake applied indicator lamp (USA) lights up



Red parking brake applied indicator lamp (Canada) lights up



Brake system warning lamp (yellow)

Vehicles with manual parking brake: the parking brake red indicator lamp lights up.

- *Meaning of the indicator lamp:
 - The parking brake red indicator lamp lights up: the parking brake has been applied.
- Do not drive the vehicle if the parking brake has been applied.

The brake system yellow warning lamp lights up while the engine is on.

WARNING Risk of an accident due to a brake system malfunction

If the brake system is malfunctioning, braking characteristics may be impaired.

Drive on carefully.

Possible causes/consequences and > Solutions

- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully at an adjusted speed and at a sufficient distance from the vehicle in front.
- If the multifunction display shows a display message, comply with
- Visit a qualified specialist workshop.



and



Brake warning lamp (red) (USA)



Brake warning lamp (red) (Canada)

The brake system red warning lamp lights up while the engine is on.

- *Possible causes:
 - The brake force boosting is malfunctioning.
 - The EBD (electronic brake force distribution) is malfunctioning.
 - There is not enough brake fluid in the brake fluid reservoir.

WARNING Risk of accident and injury if brake force boosting is malfunctioning

If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.

- Stop in a safe location immediately. Do not continue driving.
- Consult a qualified specialist workshop.

WARNING Risk of an accident if the EBD (electronic brake force distribution) malfunctions

If the EBD malfunctions, the wheels may lock during braking.

The braking characteristics may be impaired.

The braking distance can increase in emergency situations.

- Stop in a safe location immediately. Do not continue driving.
- Consult a qualified specialist workshop.

WARNING Risk of an accident due to low brake fluid level

If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Consult a qualified specialist workshop.
- Do not add brake fluid.
- Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.
- Consult a qualified specialist workshop.



and



Brake warning lamp (red) (USA)

Possible causes/consequences and ▶ Solutions

Only in the USA: The brake system red warning lamp lights up while the engine is on.

- *Possible cause:
 - The brakepads have reached their wear limit.

WARNING Risk of accident due to restricted braking power

When the brake pads have reached their wear limit, the braking power may be restricted.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Consult a qualified specialist workshop immediately.



Restraint system warning lamp

The restraint system red warning lamp is lit while the engine is on.

*The restraint system is malfunctioning.

WARNING Risk of injury due to malfunctions in the restraint system

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or may not deploy as intended during an accident. This may affect the Emergency Tensioning Devices or airbags, for example.

- ► Have the restraint system checked and repaired immediately at a qualified specialist workshop.
- Drive on carefully.
- Observe the messages on the multifunction display.
- Consult a qualified specialist workshop immediately.

The ESP® yellow warning lamp lights up while the engine is on.

*ESP® is malfunctioning.

Other driving systems and driving safety systems may also be malfunctioning.



ESP® warning lamp lights up

WARNING Risk of skidding if ESP® is malfunctioning

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.

- Drive on carefully.
- ► Have ESP[®] checked at a qualified specialist workshop.
- Drive on carefully.
- Observe the messages on the multifunction display.
- Visit a qualified specialist workshop.

Warning/indicator Possible causes / consequences and ▶ Solutions lamp The ESP® vellow warning lamp flashes during a journey. *ESP® intervenes (\rightarrow page 147). Adapt your driving style to the weather and road conditions. ESP® warning lamp flashes The ESP® OFF yellow warning lamp lights up while the engine is on. *FSP® has been switched off. **WARNING** Risk of skidding when driving with ESP® deactiva-ESP® OFF warning lamp ted If ESP® is deactivated, ESP® cannot carry out vehicle stabilization. The availability of further driving safety systems is also limited. Drive on carefully. Only deactivate ESP® for as long as the situation requires. If ESP® cannot be activated, ESP® is malfunctioning. ► Have ESP® checked immediately at a qualified specialist workshop. ► Comply with instructions to switch ESP® off (\rightarrow page 147). The ABS yellow warning lamp lights up while the engine is on. *ABS is malfunctioning. If an additional warning tone sounds, this means the EBD is malfunc-ABS warning lamp tioning. Other driving systems and driving safety systems may also be malfunctioning. **WARNING** There is risk of skidding if EBD or ABS is malfunctioning If EBD or ABS is malfunctioning, the wheels could lock when brak-The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off. Drive on carefully. Have the brake system checked immediately at a qualified specialist workshop. Drive on carefully. Observe the messages on the multifunction display.

Visit a qualified specialist workshop.

Seat belt

Warning/indicator Possible causes/consequences and ▶ Solutions lamp The seat belt red warning lamp flashes and an intermittent warning tone sounds. *The driver or front passenger does not have their belt on while the vehicle is in motion (speeds above 15 mph (25 km/h)). Seat belt warning lamp flashes Put on the seat belt (→ page 34). *There are objects on the front passenger seat. Remove the objects from the front passenger seat. The seat belt red warning lamp lights up after the engine has started. A warning tone may also sound. *When the vehicle is stationary: The seat belt warning lamp reminds Seat belt warning lamp drivers and front passengers to put on their seat belt. lights up \triangleright Put on the seat belt (\rightarrow page 34). Objects on the front passenger seat may prevent the seat belt warning lamp from going out.

Driving systems

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	The red distance warning lamp lights up while you are driving and a warning tone sounds. * You are approaching an obstacle at too high a speed.
Distance warning lamp	 Be ready to apply the brakes immediately. Increase the distance.

Vehicle

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions			
⊕!	The power steering system red warning lamp lights up while the engine is on. *The power steering assistance or the steering itself is malfunctioning.			
Power steering system warning lamp	▲ WARNING Risk of accident if steering capability is impaired			
	If the steering no longer functions as intended, the vehicle's operating safety is jeopardized.			
	Consult a qualified specialist workshop.			
	Observe the messages on the multifunction display.			



Coolant warning lamp

Possible causes/consequences and > Solutions

The red coolant warning lamp lights up while the engine is running.

- *Possible causes:
 - temperature sensor malfunctioning
 - coolant level too low
 - air supply to the engine radiator obstructed
 - engine radiator fan faulty

If a warning tone also sounds, the coolant has exceeded the temperature of 248 °F (120 °C).

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- ▶ Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.
- Stop immediately in accordance with the traffic conditions and switch off the engine. Do not continue driving.
- Observe the messages on the multifunction display.

If the coolant temperature display is at the lower end of the temperature scale:

Consult a qualified specialist workshop.

Otherwise:

- Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
- Check the coolant level(→ page 282).
- Ensure that the air supply to the engine radiator is not obstructed.
- Without subjecting the engine to excessive strain, continue to the nearest qualified specialist workshop. Ensure that the coolant temperature display remains below 248 °F (120 °C).



Electrical malfunction warning lamp

The electrical malfunction red warning lamp lights up.

- * A malfunction has occurred in the electrics.
- Read the messages on the multifunction display.



Fuel reserve warning lamp

The fuel reserve yellow warning lamp lights up while the engine is on.

- * The fuel supplies have reached the reserve level.
- Refuel.



Engine diagnosis warning lamp

Possible causes / consequences and ▶ Solutions

The yellow Check Engine warning lamp lights up while the engine is on.

*A malfunction has occurred in the engine, the exhaust system or the fuel system.

The emissions limit value may have been exceeded and the engine may be running in emergency operation mode.



Have the vehicle checked as soon as possible at a qualified specialist workshop.

Tires

Warning/indicator lamp



Tire pressure monitoring system warning lamp flashes

Possible causes/consequences and ▶ Solutions

The yellow tire pressure monitoring system warning lamp (pressure loss/malfunction) flashes for roughly one minute and then lights up permanently.

*The tire pressure monitoring system is malfunctioning.



WARNING There is a risk of an accident if the tire pressure monitoring system is malfunctioning

If the tire pressure monitoring system is malfunctioning, it is not able to issue a warning if there is pressure loss in one or more of the tires.

Underinflated tires may, for example, impair the driving, steering and braking characteristics.

- ► Have the tire pressure monitoring system checked at a qualified specialist workshop.
- Visit a qualified specialist workshop.



Tire pressure monitoring system warning lamp lights up

The tire pressure monitor vellow warning lamp (pressure loss/malfunction) lights up.

*The tire pressure monitor has detected a tire pressure loss in at least one tire.



WARNING Risk of an accident due to insufficient tire pres-

Tire pressures that are too low pose the following hazards:

- The tires may burst, especially as the load and vehicle speed increase.
- The tires may wear excessively and/or unevenly, which may greatly impair tire traction.
- . The driving characteristics, as well as steering and braking, may be greatly impaired.

You could then lose control of the vehicle.

- Observe the recommended tire pressure.
- Adjust the tire pressure if necessary.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions			
	Stop the vehicle in a safe location.Check the tire pressure and the tires.			

1, 2, 3		Add-on equipment guidelines	22
3-zone automatic climate control		Additional turn signal light (all-	
(operating unit)	101	wheel drive vehicles)	92
12 V socket		Additive	344
see Socket (12 V)		DEF 136,	
115 V socket		Engine oil	344
see Socket (115 V)		Additives	
360° Camera	159	Fuel	341
Care	288	Additives (DEF)	
Function	159	see DEF	
Selecting a view	161	Additives (engine oil)	
Switching automatic operation		see Additive	
on/off (rear view camera)	161	Additives (fuel)	
A		see Fuel	
	4.4.6	Address book	
ABS (Anti-lock Braking System)	146	see Contacts	
Acceleration		ADR (working speed control)	
see Using kickdown		Adjusting	169
Access data		Function	168
Setting (Bluetooth®)	255	Switching on/off	169
Acoustic locking verification signal Activating/deactivating	47	After-sales service center see ASSYST PLUS	
Activating/deactivating the HOLD		Air nozzles	
function	155	see Air vents	
Active Brake Assist	149	Air vents 104,	105
Function/notes	149	adjusting (front)	104
Setting	150	Adjusting (roof)	105
Active Distance Assist DISTRONIC	152	Rear passenger compartment	105
Calling up a speed	153	Airbag	
Function	152	Activation	32
Increasing/decreasing speed	153	Front airbag (driver, front	35
Requirements	153	passenger) Installation locations	
Steering wheel buttons	153 153	Overview	
Storing a speedSwitching off/deactivating	153	Protection impaired	
Switching on/activating	153	Protection provided	
System limitations	152	Side airbag	
Active Lane Keeping Assist	167	Window curtain airbag	. 35
Function	167	Alarm system	
System limitations	167	see ATA (Anti-Theft Alarm system)	
Trailer operation	167	Alertness assistant	
Active Parking Assist		see ATTENTION ASSIST	
Maneuvering assistance	161	All-wheel drive	
Adaptive cruise control		Engaging	125
see Active Distance Assist DISTRONIC		Engaging/disengaging	125
Adaptive Highbeam Assist		LOW range	126
Function	86	Notes	124
Switching on/off		Alternative route	
Add as a sufficient	0.0	see Route	

Android Auto		Attachments	22
Connecting a mobile phone	253	ATTENTION ASSIST 162,	163
Control using the application but-		Function	162
tons	253	Setting	163
Ending	253	System limitations	162
Note	253	Authorized workshop	
Overview	252	see Qualified specialist workshop	
Sound settings Transferred vehicle data	253 253	Automatic distance control	
	203	see Active Distance Assist DISTRONIC	
Animals	4.5		0.4
Pets in the vehicle	45	Automatic driving lights	84
Anti-lock braking system		Automatic transmission	400
see ABS (Anti-lock Braking System)		DIRECT SELECT lever	122
Anti-skid chains		Engaging drive position	123
see Snow chains		Engaging neutral	122 122
Anti-theft Alarm system		Engaging reverse gear Kickdown	124
see ATA (Anti-Theft Alarm system)		Restricting the shift range	124
Anti-theft protection		Selecting park position	123
Immobilizer	. 61	Transmission position display	122
Anti-theft protection		Transmission positions	122
see ATA (Anti-Theft Alarm system)		Auxiliary heating	105
	0.54	Function	105
Apple CarPlay®			
Connecting an iPhone®	252	Axle load	338
Control using the application but-	050	D	
tons	252	В	
Ending Notes	252	Back support	
Overview		see Lumbar support (4-way)	
Sound settings		BAS (Brake Assist System)	146
Transferred vehicle data		Battery	
Ashtrays			295
In the windshield stowage com-			295
partment	79	Disconnecting the auxiliary battery	
•			300
ASR (acceleration skid control)	147	Disconnecting the starter battery	298
Assistance graphic (on-board com-		Jump-starting (vehicle)	295
puter)	179	Key	47
ASSYST PLUS	278	Notes (vehicle)	294
Battery disconnection periods	278	Removing or installing the starter	299
Displaying the service due date		battery Starter battery	297
Function/notes	278		271
Regular maintenance work	278	Battery main switch	100
Special service requirements	278	Notes	120
ATA (Anti-Theft Alarm system)	. 61	01 117 /	121
Activating/deactivating the interior		Belt	
motion sensor		see Seat belt	
Function		Belt warning	
Interior motion sensor function		see Seat belt	
Stopping the alarm	. 62	Blind Spot Assist	164
Switching the tow-away alarm	62	Activating/deactivating	165
on/off Tow-away alarm function	62 62	Function	164
TOW-away alam full cultil	. 02	Rear Cross Traffic Alert	166

Custom limitations	1//		
System limitations		C	
Bluetooth®	211	Call list	
Activating/deactivating	211	Calling up options	249
Information		Deleting	249
Setting up an Internet connection	255	Making a call	249
Bottle holder	78	Overview	249
Brake		Calls	246
ABS (Anti-lock Braking System)	146	Accepting	246
Activating/deactivating the HOLD	110	Activating functions during a call	246
function	155	Calls with several participants	246
Active Brake Assist	149	Declining	246
BAS (Brake Assist System)	146	Ending a call	246
Braking with parking brake:	114	Incoming call during an existing	
Downhill gradient	114	call	246
	, 114	Making	246
EBD (electronic brake force distri-		Camera	
bution)	148	see 360° Camera	
Heavy and light loads	114	see Rear view camera	
HOLD function	155	Car wash	
New brake discs and brake pads/		see Care	
linings	114		20/
Restricted braking effect (salt-trea-		Car wash (care)	286
ted roads)	114	Car-to-X-Communication	
Wet road surfaces	114	Displaying hazard warnings	235
Brake Assist System		Overview	235
see BAS (Brake Assist System)		Sending hazard warnings	235
Brake Assistance		Care	290
see BAS (Brake Assist System)		Car wash	286
Brake fluid		Carpet	290
Notes	346	Display	290
Brake force distribution		Exterior lighting Headliner	288 290
EBD (electronic brake force distri-		Matte finish	287
bution)	148	Paint	287
Brakes		Plastic trim	290
Breaking-in notes	111	Power washer	286
New/replaced brakepads/brake		Real wood/trim elements	290
discs	111	Rear view camera/360° Camera	288
Breakdown		Seat belt	290
Assistance overview	18	Seat cover	290
Changing a wheel		Sensors	288
Roadside Assistance		Tailpipes	288
Tow starting		Trailer hitch	288
Towing away		Washing by hand	287
Transporting the vehicle		Wheels/rims	288
	000	Windows	288
Breakdown		Wiper blades	288
see Flat tire	444	Cargo compartment lighting	
Breaking-in notes	111	Motion detector	. 89
Bulbs		Cargo compartment ventilation	
Reversing light	. 94	Deactivating	108
Buttons		Setting	108
Steering wheel	176	Cargo tie-down point	273

Cargo tie-down points	Cleaning	
Information 35	see Care	
Carpet (care)	Cleaning water drain valve of th intake box	
Change bulbs		204
Additional turn signal light (all-	Climate control	
wheel drive vehicles)	Ο,	
Changing a bulb	Adjusting rear-compartment h	
see Changing bulbs	ing	
Changing a wheel	Air distribution settings	103
Lowering the vehicle 33	automatically controlling (rear	103
Preparing	passenger compartment,	
Raising the vehicle	Auxiliary fleatiling	
Removing a wheel	oargo compartment ventuation	
Changing address	Olcaring logged up williaows	
	and the office and a contract	
Changing bulbs	Cambrallina automobicallu	
High beam	The boundary of the section	
Indicator (front)	0	
Interior lamps (rear compartment)	mantin alimanta annual	
License plate lamp	Definierant	
Light bulb types halogen headlamps 9	Catting at the animalist with this is	
Low beam	Contraling a singua singua da biga a man	
Notes	on/off	
Tail lamp bulb types (Cargo Van	Contrabination of the second and the second	
and Passenger Van)	on /off (control nonel)	
Tail lamp bulb types (chassis)	Constabling the A (C formation and	
Turn signal light (rear) (chassis)	Switching the rear window	, 011 1. 102
Changing lamps	defroster on/off	104
see Changing bulbs	Switching the windshield heate	
Changing owner	on/off	
Characteristics of the tire		
Charging	ence opening)	
Battery 29	Ventilation nozzles at front	
Mobile phone (wireless)	ventilation nozzies in the roof	
	ventilation nozzies, rear passe	
	compartment	
Child seat	Cockpit (overview)	6
Attaching (notes)	Combination Switch	
Basic instructions	SEE HIGH NEAM	
Front-passenger seat (notes)	see High-beam flasher	
LATCH-type (ISOFIX) (installing)	see indicator	
Notes on risks and dangers	Compass	239
Rearward-facing child restraint sys-	•	207
tem (Information)		
seat	see On-board computer	
Securing on the rear seat	Connection status	0.5.4
Top Tether	Displaying	
Children	Overview	256
Avoiding dangers in the vehicle	Contacts	
Basic instructions	Calling up	
Special seat belt retractor	Deleting	
Cigarette lighter	Deleting ravorites	249
LICALATTA HONTAL		

Downloading (from mobile phone)		Dealership	
Importing		see Qualified specialist workshop	
Importing (overview)		DEF	343
Information		Additive 136,	
Making a call		Displaying the fill level	137
Name format		0 1 7	344
Options		Purity 136,	
Selecting options for suggestions		Refilling	137
Storing		Definitions (tires and loading)	323
Convenience closing		Destination	232
Convenience opening			225
Conversions		Editing the previous destinations External	232
Coolant		Quick-access to destination infor-	
Filling capacities	3/17	mation	230
• .	547	Saving (current vehicle position)	232
Coolant (engine)	202	Destination entry	217
Checking level Notes		Entering 3 word addresses	22
	34/	Entering a POI or address	217
Copyright	0.0	Entering an intermediate destina-	
License			225
Trademarks		Entering geo-coordinates	22
Cornering light	85	Notes	217
Crosswind Assist		Selecting a contact	22
Function/notes	148	Selecting a POI	219
Cruise control	151	0 0	222
Activating	151	Selecting from the map	22
Buttons	151	Selecting previous destinations	219
Calling up a speed	151	Detecting inattentiveness	
Deactivating	151	see ATTENTION ASSIST	
Function		Diagnostics connection	25
Requirements	151	Dial telephone number (on-board	
Selecting	151	computer)	182
Setting the speed			.02
Storing a speed		Diesel	34
System limitations	151	Low outside temperatures Notes	34
Customer Assistance Center (CAC)		Diesel particulate filter	0.
Customer Relations Department	. 27	Automatic regeneration	120
		Displaying load	120
D		Notes	120
Dashboard		Digital Operator's Manual	20
see Cockpit (overview)		Digital speedometer	179
Dashboard lighting see Instrument lighting		Dimming the inside rearview mirror	98
• •	010	DIRECT SELECT lever	122
Data import/export		Engaging drive position	123
Function/notes		Engaging neutral	122
Importing/exporting		Engaging park position automati-	
Data recording (vehicle)	. 28	cally	123
Date		Engaging reverse gear	122
Setting the time and date automat-		Function	122
ically	210	Selecting park position	123

Direction indicator		Check Washer Fluid	37
see Indicator		Coolant Too Hot Stop Vehicle	
Display (care)	290	Turn Engine Off	366
Display (MBUX multimedia system)		Currently Unavailable Cam-	
Settings	209	era Dirty	362
Display (multimedia system)	200	© Currently Unavailable See	
Home screen Notes	199 198	Operator's Manual	360
Operating	200	Surrently Unavailable See	
Setting acoustic operating feed-		Operator's Manual	360
back	200	Don't Forget Your Key	370
Display (on-board computer)	177	Engine Oil Level Cannot Be	0, (
Display message	355	Measured	365
Calling up (on-board computer)	355	Engine Oil Level Low Stop	000
Notes	355	Vehicle Turn Engine Off	365
Display messages	244	Engine Oil Pressure Stop	500
	364	Switch Off Engine	365
(S) mph	361	Engine Oil Reduce Oil Level	365
12 V Battery See Operator's	244	Front Left Malfunction	500
Manual Sustant Fault France	366		356
Additive System Fault Emer-		Service Required (example)	364
gency Op.: XXX mph See Opera-	240	(D) Incline Too Steep See Opera-	302
tor's Manual	369		357
Additive System Fault See	0.40	tor's Manual	372
Operator's Manual	368	Inoperative Battery Low	
Additive System Fault Starts		Inoperative Refuel Vehicle	372
until Emerg. Op.: XXX See Opera-	0.40	Inoperative See Operator's	244
tor's Manual	368	Manual See Operatorile	360
ATTENTION ASSIST Inopera-	0/4	Inoperative See Operator's	250
tive	364	Manual	359
ATTENTION ASSIST: Take a	0/4	EBD Inoperative See Operator's	250
Break!	364	Manual	359
Auto Lamp Function Inopera-	075	Inoperative See Operator's	070
tive	375	Manual	372
(D) Check Brake Fluid Level	358	Key Not Detected (red dis-	07.
Check Coolant Level See		play message)	37
Operator's Manual	367	Key Not Detected (white dis-	07.
Check Engine Oil At Next		play message)	37
Refueling	366	Left Side Curtain Airbag Mal-	
Check Engine Oil Level (Add		function Service Required (exam-	
1 Liter)	365	ple)	356
Check Fuel Filter	364	Malfunction See Operator's	
本 Check Left Low Beam (exam-		Manual	375
ple)	376	Maximum Speed Exceeded	36
(!) Check Tires	370	Obtain a New Key	37

⊗ Off	361	cle locating activated - see manual	
HOLD Off	362	or mobile app	374
Parking Brake Inoperative	357	(!) Warning Tire Malfunction	369
Parking Brake See Operator's		Active Brake Assist Functions Cur-	
Manual	357	rently Limited See Operator's Man-	
Place the Key in the Marked		ual	358
Space See Operator's Manual	370	Active Brake Assist Functions Limi-	
(!) Please Correct Tire Pressure	370	ted See Operator's Manual	358
Refill Additive Emergency		Active Distance Assist Currently	
Op.: XXX mph See Operator's Man-		Unavailable See Operator's Manual	
ual	368		361
Refill Additive See Operator's		Active Distance Assist Inoperative	361
Manual	368	Active Distance Assist Now Availa-	
Refill Additive Starts until		ble	362
Emerg. Op.: XXX See Operator's		Active Lane Keeping Assist Camera	
Manual	368	View Restricted See Operator's	
Replace Air Filter	364	Manual	363
Replace Key Battery	371	Active Lane Keeping Assist Cur-	
See Operator's Manual	366	rently Unavailable See Operator's	
SRS Malfunction Service		Manual	364
Required	356	Active Lane Keeping Assist Inoper-	
⊚! Steering Malfunction		ative	364
Increased Physical Effort See		Adaptive Highbeam Assist Camera	
Operator's Manual	372	View Restricted See Operator's	
⊚! Steering Malfunction Stop		Manual	375
Immediately See Operator's Man-		Adaptive Highbeam Assist Cur-	
ual	372	rently Unavailable See Operator's	
Step Not Extended See Oper-	0, 2	Manual	375
ator's Manual or Step Not Exten-		Adaptive Highbeam Assist Inopera-	
ded Malfunction	374	tive	375
Stop Vehicle Leave Engine		Air Conditioning Malfunction See	
Running	366	Operator's Manual	373
Stop Vehicle See Operator's		Apply Brake to Shift from 'P'	374
Manual	366	Auxiliary Battery Malfunction	373
Switch Off Lights	375	Blind Spot Assist Currently	
Switch On Headlamps	375	Unavailable See Operator's Manual	
(1) Tire Press. Sen. Missing	369		363
↑ Vehicle Operational Switch	00,	Blind Spot Assist Inoperative	363
the Ignition Off Before Exiting	373	Blind Spot Assist Trailer Not Moni-	
✓ Vehicle Tracker has been	2. 3	tored	363
activated. Details: see manual or		Check Brake Pads See Operator's	
associated mobile app. or Vehi-		Manual	358
accounted modifie app. Of Your		Cruise Control Inoperative	361

Currently Unavailable Radar Sen-		DOT, Tire Identification Number	
sors Dirty	362	(TIN)	320
Driver's Door Open & Transmission		Drinking and driving	111
Not in P Risk of Vehicle Rolling		Drive Away Assist	165
Away	374	Driver's seat	
N Permanently Active Risk of Roll-	0/4	see Seats	
	374	Driving and drinking	111
ing Away	3/4	Driving characteristics (unusual)	308
Only Shift to 'P' when Vehicle is	074	Driving instructions	
Stationary	374	Foreign trip (information)	113
Radar Sensors Dirty See Opera-	050	Driving light	
tor's Manual	358	see Automatic driving lights	
Regeneration Not Possible	367	Driving notes	
Reversing Not Possible Service		Brake subject to load	114
Required	373	Braking	114
Service Required Do Not Shift		Breaking-in notes	111
Gears Visit Dealer	373	Downhill gradient	114
Shift to 'P' or 'N' to Start Engine	373	Drinking and driving	111 111
SOS NOT READY	359	General driving tips New brake discs and brake pads/	111
	007	linings	114
Tire Press. Monitor Currently		Parking brake	114
Unavailable	369	Restricted braking effect (salt-trea-	
Tire Pressure Monitor Inoperative	370	ted roads)	114
Tire Pressure Monitor Inoperative		Transport by rail	114
No Wheel Sensors	369	Wet road surfaces	114
To Engage Transmiss. Position R		Driving Safety System	
First Depress the Brake	373	ABS (Anti-lock Braking System)	146
Traffic Sign Assist Camera View	0,0	ASR (acceleration skid control)	147
•	0.40	BAS (Brake Assist System) EBD (electronic brake force distri-	146
Restricted See Operator's Manual	362	bution)	148
Traffic Sign Assist Currently		ESP® Crosswind Assist	148
Unavailable See Operator's Manual		ESP® trailer stabilization	148
	363	Overview	146
Traffic Sign Assist Inoperative	362	Radar sensors	145
Transmission Malfunction Stop	373	Responsibility	145
Display range (trip menu)	179	Driving safety system	
,		see Active Brake Assist	
Display total distance (trip menu)	179	see ESP® (Electronic Stability Program)
Distance control		Driving system	
see Active Distance Assist DISTRONIC		see 360° Camera	
Distance recorder		see Activating/deactivating the	
see Trip distance		HOLD function	
DISTRONIC		see Active Distance Assist DISTRONIC see Active Lane Keeping Assist	
see Active Distance Assist DISTRONIC		see ATTENTION ASSIST	
Door	F.0	see Blind Spot Assist	
Locking (emergency key)		see Cruise control	
Unlocking (emergency key)		see HOLD function	
Door control panel	16	see Lane Keeping Assist	

see Parking Assist PARKTRONIC see Rear view camera see Traffic Sign Assist		FunctionObstaclePreventing extending	. 57
Driving tips		Electronic Stability Program	
Driving abroad (symmetrical low		see ESP® (Electronic Stability Program)
beam)	84	Electronics	
Driving in winter	115		007
Driving off-road	116	Emergency Assistance overview	. 18
Driving on flooded roads	115	First-aid kit (soft sided)	292
Driving on wet roads	115	Safety vest	292
Hydroplaning	115	Warning lamp	292
Drowsiness detection		Emergency braking	
see ATTENTION ASSIST		Electric parking brake	144
DSR (Downhill Speed Regulation)	407	Manual parking brake	142
Activating/deactivating	127	Emergency call system	
Notes	126	Automatic emergency call	293
Dual-zone automatic climate con-		Information	292
trol (control panel)	100	Manual emergency call	293
DYNAMIC SELECT		Overview	292
Displaying vehicle data	215	Transferred data	293
E		Emergency engine start	304
		Emergency operation mode	
E10	341	Starting the vehicle	110
EBD (electronic brake force distri-		Emergency Tensioning Devices	
bution)	148	Activation	32
ECO display		Engaging drive position (automatic	
Function	119	transmission)	123
Resetting	180	Engaging neutral (automatic trans-	
Electric parking brake	143	mission)	122
Applying automatically	143		
Applying or releasing manually	144	Engaging reverse gear	122
Emergency braking	144	Engaging/disengaging LOW RANGE	126
Notes	142	Engine	
Releasing automatically	143	Engine number	338
Electric sliding door		Parking (start/stop button)	140
Function	52	Problems	135
Opening with button		Starting (in emergency operation	110
Opening (closing with the key	54 54	mode)Starting (start/stop button)	110 110
Opening/closing with the key Programming the key	54	Starting (starty stop buttori)	295
Resetting			2/0
Unlocking manually	54	Engine data Showing	214
Electrical closing assist		•	
Notes	52	Engine electronics (notes)	
Electrical consumption		Engine number	338
Key	47	Engine oil	28
Electrical fuses	.,	Additive	344
see Fuses		Checking the oil level (on-board	0.5
		computer)	28
Electrical step	50	Checking the oil level with a dip-	200
Emergency release		stick	280 34F

Topping up	281	Foreign trip	
Engine output		Instructions	113
Notes on changes	. 26	symmetrical low beam	84
ENR (electronic level control)	128	Free software	30
Function	128	Frequencies	
Lowering the vehicle	129	Mobile phone	337
Manually inflating air bellows	132	Two-way radio	
Problems	133	Front airbag (driver, front passenger)	
Raising the vehicle	129	Front door	
Entering and exiting	. 50	Opening (from inside)	49
Entering characters	207	Unlocking (from inside)	
Function/notes	207	Front passenger bench seat	
Setting the keyboard	209	Folding the seat cushion forwards/	
Using the media display	208	backwards	7
Environmental protection		Front seats	,
Notes	. 21	8-way adjustment options	67
ESC (Electronic Stability Control)		Adjusting (electrically)	
see ESP® (Electronic Stability Program	1)	Adjusting (manually)64	
· · · · · · · · · · · · · · · · · · ·	')	Memory function	
ESP®	140	Turning	
Crosswind Assist	148	With Seat Comfort Package	
Trailer stabilization	148	Without Seat Comfort Package	64
ESP® (Electronic Stability Program)	147	Fuel	34
Activating/deactivating	148	Additives	34
Function/notes	147	Diesel	34
Exhaust emission monitoring	113	Draining the filter	285
Exterior lighting		E10	34
Care	288	Flexible fuel vehicles	34
Exterior lighting		Fuel reserve	343
see Lights		Gasoline	34
		Low outside temperatures	34 ⁻
F		Problems Quality (diesel)	34
Fatigue detection		Quality (diesel)	34
see ATTENTION ASSIST		Refueling	133
Favorites		Sulfur content	34
Adding	204	Tank capacity	343
Calling up	204	Fuel consumption (on-board com-	
Deleting	205	puter)	179
Moving	205	Fuel consumption indicator	
Overview	204	Calling up	216
Renaming	205	Fuses	
First-aid kit (soft sided)	292		
Flat tire		Before replacingFuse box in the front-passenger	304
Changing a wheel		footwell	305
Notes		Fuse box in the seat base of the	500
Floor covering	-	driver's seat	305
Installing/removing (starter bat-		Notes	304
tery)	297		
Floor mat			

		0 1: 11 (65 1:1 :1	
G		Switching on/off with the on- board computer	107
Gas station search			107
Starting automatic search	227	Hotspot Setting up (Wi-Fi)	212
Switching automatic search on/off	226	Hydroplaning	115
Gasoline	341	Trydropianing	113
	341	I .	
General operating permit number (EU)	338	Identification plate	
Genuine parts		Engine	338
		Refrigerant	348
Getting into and out of the vehicle		Vehicle	338
Glasses compartment	/8	Ignition key see Key	
Global search Function	207	•	41
Overview	207	Immobilizer	
Grab handles		Indicator	
Using		Activating/deactivating Changing bulbs (front)	
Gross axle weight rating		Changing bulbs (rear) (Cargo Van	/ 1
Gross mass		and Passenger Van)	92
01055 111855	330	Changing bulbs (rear) (chassis)	94
Н		Installations	22
Handbrake (electrical)		Instrument Display	
see Electric parking brake		Function/notes	
Handbrake (manual)		Overview	1/5
see Manual parking brake			170
Handling control system		Instrument Display see Warning/indicator lamp	
see ESP® (Electronic Stability Program))	Instrument lighting	178
Hazard warning lights	85	Intelligent light system	170
Switching on/off	85	Adaptive Highbeam Assist	86
Hazardous substances		Cornering light	85
Information	24	Interior lamps (rear compartment)	
Head restraint	7.	(replacing the light bulbs)	94
Adjusting mechanically		Interior lighting	
Headliner (care)		Bus equipment	88
Heating system (control panel)		Cargo compartment	89
High beam		Reading lamp above the passenger seat	89
Activating/deactivating		Rear compartment	
Adaptive Highbeam Assist Changing bulbs		Setting	87
High-beam flasher		Switch-off delay time	90
Hill start assist		Interior motion sensor	
		Function	
HOLD function	155	Switching on/off	
Home screen (media display)	199	Interior roof carrier system	275
Hot-water auxiliary heater	106	Intermediate destination	
Function	106 108	Calculating a route with intermediate destinations	226
Problemsswitching on/off with the button	108	Entering	225
Stolling on, on with the button	.00	Modifying	225

Starting an automatic gas station search	227 227	Overview	46
Internet			
Calling up a web page Calling up the web browser settings Calling up web browser options Closing the browser Deleting a bookmark Deleting history	257 258 258 259 258 258	L Labeling (tires) see Tire labeling Lane detection (automatic) see Active Lane Keeping Assist Lane Keeping Assist Function	166
Managing bookmarks	258	System limitations	166
Internet connection Automatic disconnection	256 254 256 256 256 256 256 254 256 254 255	Trailer operation Lane Keeping Assist see Active Lane Keeping Assist see Lane Keeping Assist Language Notes Setting LATCH-type (ISOFIX) child seat securing system Installing Level control see ENR (electronic level control) License plate lamp (changing bulbs)	213 213 213 41
Setting up (Bluetooth®) Setting up (Wi-Fi)			84
Internet radio Calling up the station list (category last selected) Internet radio		Light switch (overview) Lighting see Lights Lights Adaptive Highbeam Assist	84
see TuneIn		Automatic driving lights	
iPhone® see Apple CarPlay®	_	Combination switch Cornering light Driving abroad (symmetrical low beam)	85
	0.07	Hazard warning lamps	85
Hydraulic	327 306 307 306	High beam High-beam flasher Indicator Light switch Low beam	85 85 85 84
Jump-start connection	295	Parking light	84
K Key Battery Electrical consumption	47 47	Rear fog light	84 84 86 178
Functions Key ring attachment		on/off	87
Mechanical key		Limited Warranty (vehicle)	27

Limiting speed	113	Map 233,	236
Live Traffic Information		0	238
Displaying the traffic map	233	Avoiding an area (overview)	238
Displaying traffic incidents	234	Changing an area	238
Provider information	233	8	238
Showing local area messages	235	Displaying the compass	239
Switching the traffic information	200	Displaying the map version	238
display on	234	Displaying the next intersecting	
	201	street	237
Load	010	Displaying the satellite map	239
Determining the maximum	318	Displaying the traffic map	233
Sample calculation	318	Displaying weather information	240
Load distribution	272		239
Load index (tire)	321		236
Load securing		3 ,	236
Cargo tie-down point	273	Selecting text information	237
Installing and removing tie-down			236
eyes	274	0 1 1 1	236
Notes	272	Setting the map scale automati-	
			239
Load-bearing capacity (tire)	321	Showing the range	240
Loading		Switching freeway information	007
Definitions	323	on/off	237
Loading guidelines	271	1 0	239
Loading information table		Matte finish (cleaning instructions)	287
	017	Maximum load	
Low beam	0.4	Determining	318
Activating/deactivating		Sample calculation	318
Changing bulbs		Maximum tire load	321
LOW range		Maximum tire pressure	321
•	120	MBUX multimedia system	
Lubricant additives		-	200
see Additive		0 0 1 7 0	209
Lumbar support (4-way)	69	MBUX multimedia system (over-	100
		view)	198
M		Mechanical key	
M+S tires	309	Locking door	50
Maintenance		Removing/inserting	47
Vehicle	24	Unlocking door	50
	. 24	Media	
Maintenance		Menu (on-board computer)	182
see ASSYST PLUS		Operating media playback	182
Malfunction		Selecting a media source	182
Restraint system	. 31	Media display	
Malfunction message		Entering characters	200
see Display message		Home screen	
	111	Notes	199
Manual parking brake	141		198
Applying/releasing	141	Media mode	
Emergency braking	142	5	263
Folding up/down	142	Connecting Bluetooth® audio	
Manually inflating air bellows (ENR)	132		263
			262
		Controlling media playback	263

Copyright and trademarks	261 265	Calling a message sender	249 251 250
categories	264	Configuring the displayed text	250
Overview of the media menu	262		250
Playing back similar music tracks			251
Removing a favorite song	263	8	250
Searching for a music track			249
according to mood	264		250
Starting a search in categories	264	_	250
Starting media playback	263		250
Supported format and data storage			251
media	261		250
Surprise mix	263	Voice commands (Voice Control	
Using the keyword search	264	System)	193
Memory function (seat)	. 69	Mirrors	
Menu (on-board computer)		Adjusting the inside rearview mirror	98
Assistance graphic	179	Mirrors	
Media	182	see Outside mirrors	
Navigation	181		00-
Overview	176	•	337
Radio	181	Canceling permission for Internet	05/
Service	178		256
Settings	183	- 1	337
Telephone	182	1 \	337
Trip	179	Wireless charging	82
Mercedes me		Mobile phone	
Information	195	see Android Auto	
	175	see Apple CarPlay®	
Mercedes me connect		see Mobile phone	
Breakdown assistance call via the	10/	see Telephone	
breakdown assistance button	196	Mobile phone voice recognition	
Calling the Customer Center Consenting to data transfer	195 196	Starting	246
Information	195	Stopping	246
Making a call via the overhead con-	193	Model series	338
trol panel	196	Mounting a load	271
Transferred data	196		
Mercedes PRO	1,0	Multi Purpose Vehicle (MPV)	26
Information	195	Multifunction display (on-board computer)	177
Mercedes PRO connect		Multifunction steering wheel	
Breakdown assistance call via the	40.6	Button overview	176
breakdown assistance button	196	Multifunction steering wheel	
Calling the Customer Center	195	see Steering wheel	
Consenting to data transfer	196	3	
Information	195	Multimedia system	000
Making a call via the overhead control panel	196	Adjusting the volume	
Transferred data	196	Main functions	
	170	Restoring (factory settings)	
Message (multifunction display)		Switching the sound on/off	ZU I
see Display message		Multimedia system	
Message memory	355	see Display (multimedia system)	
		see Entering characters)
		see MBUX multimedia system (overviev	V)

see Touch Control see Restraint system see Seat belt Odometer Navigation see Display total distance (trip menu) Menu (on-board computer) 181 Oil see Engine oil On-board computer 176 Switching on 216 Adjusting the stationary heater/ Updating the map data 239 ventilation Voice commands (Voice Control Assistance graphic menu 179 System) Diesel particulate filter load display Navigation 120 see Destination Displaying the service due date see Destination entry Media menu see Parking service Menu navigation 181 see Route Menus overview 176 see Route guidance Multifunction display see Traffic information Operating 176 Radio menu Navigation announcements Activating/deactivating 230 Service menu 178 Adjusting the volume 231 Settings menu Repeating 231 Telephone menu Switching audio fadeout on/off 231 179 Trip menu Navigation instructions (on-board On-board diagnostics interface see Diagnostics connection computer) 181 On-board electronics Near Field Communication (NFC) 245 Connecting a mobile phone to the MBUX multimedia system 245 Notes 337 General information 245 Switching mobile phones 245 Open-source software 245 Using a mobile phone Opening and closing the lockable NFC compartment above the windshield 78 see Near Field Communication (NFC) Opening the cup holder in the rear 205 Notification types passenger compartment 78 **Notifications Center** Opening/closing the hood Calling up notifications 206 Operating fluids Editing notifications 206 Additives (fuel) 341 Global search 207 Brake fluid 346 Notification types 205 Coolant (engine) 347 Selecting actions for notifications 206 Engine oil 344 Using the global search 207 Fuel (diesel) 341 **Notifications Center** Fuel (gasoline) 341 see Notification types Notes Nozzles Windshield washer fluid 347, 348 see Air vents Operating Instructions (vehicle equipment) Operating safety Occupant safety Changes in the engine power outsee Airbag put 26 see Pets in the vehicle Information

On-board computer	Operating system	Placing a load on the wheel arch 2	77
Outside mirrors 97 Golding in / out 97 Selecting 215 Selecting 216 Selecting 217 Selecting 218 Selecting 219 Selecting 219 Selecting 219 Selecting 236 Selecting 236 Selecting 236 Selecting 236 POWER supply Battery main switch 12 Selecting 236 Power supply Battery main switch 12 Selecting 236 Power supply Battery main switch 12 Switching on (start / stop button) 100 Power windows see Side window See Side window Previous destinations 266 Power windows see Sidet window Previous destinations 266 Power windows see Side window Previous destinations 266 Power windows see Side window Previous destinations 266 Configuring suggestions 204 266 Configuring suggestions 204 Configuring suggestions 204 204 Selecting and parking and parking option and the parking option and parking option on the map 240	On-board computer 17	Plastic trim (care) 2	90
Selecting 97 Selecting 97 Selecting 97 Setting 97 Selecting 97 Selecti	Operator's Manual (digital) 2	O POI	
Setting options 16 Overhead control panel Adjusting the interior lighting 87 Overview 11 Paint (cleaning instructions) 287 Paint code 338 Park position 128 Engaging 123 Engaging automatically 123 Barking Assist PARKTRONIC 156 Activating Assist PARKTRONIC 156 Activating warning tones 156 Drive Away Assist 165 Function 156 Switching off 58 Switching brake (electrical) see Electric parking brake Parking brake (manual) see Manual parking brake Parking service 240 Notes 240 Selecting parking options 240 Selecting parking options 240 Selecting parking option 156 Selecting 156 Selecting 203 Selecting	Outside mirrors 9		
Setting options 16 Overhead control panel Adjusting the interior lighting 87 Overview 11 Paint (cleaning instructions) 287 Paint code 338 Park position Engaging 123 Engaging automatically 123 Parking aid see Parking Assist PARKTRONIC 156 Activating 40 Adjusting warning tones 156 Drive Away Assist 165 Enuction 156 Switching off 156 Switching off 156 System limitations 156 System limitations 156 Parking brake (electrical) see Electric parking brake Parking for an extended period 144 Parking options see Parking service 240 Notes Aring parking options see Parking service 240 Notes 240 Selecting parking options 240 Selecting parking options 156 From the driver's compartment 57 From the driver's compartment 56 Permissible gross mass 338 Selecting power supply Battery main switch 122 Switching on (start/stop button) 100 Power supply Battery main switch 122 Switching on (start/stop button) 100 Power washer (care) 286 Power washer (care) 286 Power windows see Side window Previous destinations Selecting 216 Calling up suggestions 200 Configuring suggestion	3 ,		19
Overhead control panel Adjusting the interior lighting 87 Overview 11 Paint (cleaning instructions) 287 Paint (cleaning instructions) 287 Park position 338 Engaging automatically 123 Engaging automatically 123 Parking aid see Parking Assist PARKTRONIC 56 Activating 156 Adjusting warning tones 156 Adjusting warning tones 156 Adjusting warning tones 156 Drive Away Assist 165 Function 156 Switching off 156 Switching off 156 System limitations 156 Parking brake (electrical) see Electric parking brake See Electring profile options 203 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Suggestions (overview) </td <td></td> <td>, i di ayilibola</td> <td></td>		, i di ayilibola	
Adjusting the interior lighting Overview 11 Battery main switch 121 Switching on (start/stop button) 109 Paint (cleaning instructions) 287 Paint code 338 Park position		Selecting 2	36
Paint (cleaning instructions) 287		Power supply	
Paint (cleaning instructions) 287 Paint code 338 Park position Engaging 123 Engaging automatically 123 Parking aid see Parking Assist PARKTRONIC 156 Activating 156 System limitations 156 System limitations 156 Parking brake (electrical) see Electric parking brake Parking options see Parking service Parking service 240 Notes 240 Rack systems (information) 274 Selecting parking option on the map 241 Partition sliding door From the cargo compartment 57 From the driver's compartment 56 Permissible gross mass 338 Provious destinations See Side window Previous destinations Selecting a new profile 203 Configuring suggestions 204 Amaximum number of profiles 202 Amaximum number of profiles 202 Overview 202 Amaximum number of profiles 203 Selecting a profile options 203 Selecting profile options 203 Selecting profile selection when starting the vehicle 203 Suggestions (overview) 203 Configuring suggestions 204 Maximum number of profiles 202 Amaximum number of profiles 202 Overview 202 Selecting profile options 203 Selecting profile options 203 Selecting profile selection when starting the vehicle 203 Suggestions (overview) 203 Configuring suggestions 204 Amaximum number of profiles 202 Overview 202 Selecting profile 203 Selecting profile options 203 Selecting profile options 203 Selecting profile options 204 Rack systems (information) 274 Rack systems (information) 274 Rack systems (information) 274 Rack systems (information) 274 Racking for a cativating 265 Calling up the station list 266 Deleting stations 266 Deleting suggestions 204 Portile 202 Careating a new profile 202 Corating a new profile 203 Configuring suggestions 204 Recaming options 204 Recaming opt		, Dattery main switch	
Paint (cleaning instructions) 287 Paint code 338 Park position Engaging 123 Engaging automatically 123 Parking aid see Parking Assist PARKTRONIC 156 Activating 156 Adjusting warning tones 156 Drive Away Assist 165 Switching off 55 Switching off 55 Switching off 156 System limitations 156 Parking brake (electrical) see Electric parking brake Parking brake (manual) see Manual parking brake Parking service Parking service Parking service 240 Notes 26ecting parking option on the map 241 Partition sliding door From the driver's compartment 57 From the driver's compartment 56 Permissible gross mass 338 Power windows see Side window Previous destinations see Side window Previous destinations Selecting . 219 Profile Calling up suggestions 204 Configuring suggestions 204 Adiaximg up suggestions 204 Adaximum number of profile 203 Configuring suggestions 204 Amaximum number of profiles 203 Poverview 202 Creating a new profile 203 Selecting a profile 203 Selecting a profile 203 Selecting a profile 203 Selecting profile options 203 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Profile see User profile 203 Creating a new profile 202 Configuring suggestions 204 Maximum number of profiles 202 Configuring suggestions 204 Maximum number of profiles 202 Configuring suggestions 204 Maximum number of profiles 202 Configuring suggestions 204 Maximum number of profile 203 Selecting a profile 203 Selecting a profile 203 Selecting a profile 203 Selecting profile 203 Selecting profile 203 Selecting a	Overview	Switching on (Start/Stop button)	09
Paint code 338 see Side window Park position Previous destinations Engaging 123 Engaging automatically 123 Parking aid 203 see Parking Assist PARKTRONIC 156 Parking Assist PARKTRONIC 156 Adjusting warning tones 156 Adjusting warning tones 156 Drive Away Assist 165 Function 156 Switching off 156 System limitations 156 System limitations 156 Parking brake (electrical) See Electring a profile options 203 see Electric parking brake Selecting profile options 203 Parking brake (manual) See User profile 203 see Parking service 240 Activating service 240 Parking service 240 Rack systems (information) 274 Radio Activating 265 Partition sliding door 240 Activating Activating feactivating radio text 267 From	P	` '	86
Paint code 338 Previous destinations Park position Selecting 219 Engaging automatically 123 Profile 203 Parking aid see Parking Assist PARKTRONIC 156 Configuring suggestions 204 Parking Assist PARKTRONIC 156 Maximum number of profile 202 Parking Service way Assist 156 Maximum number of profiles 202 Adjusting warning tones 156 Maximum number of profiles 202 Adjusting warning tones 156 Maximum number of profiles 202 Punction 156 Selecting a profile 203 System limitations 156 Selecting profile options 203 System limitations 156 Selecting profile selection when starting the vehicle 203 Parking brake (manual) see Harking brake Parking for an extended period 144 Parking service 240 Qualified specialist workshop 26 Parking service 240 Rack systems (information) 274 Radar sensors 145 Radar sensors 145<	Paint (cleaning instructions) 28	,	
Park position Selecting 219 Engaging 123 Profile 203 Parking aid Configuring suggestions 204 See Parking Assist PARKTRONIC 156 Creating a new profile 202 Parking Assist PARKTRONIC 156 Deleting suggestions 204 Activating 156 Maximum number of profiles 202 Adjusting warning tones 156 Maximum number of profiles 202 Purction 156 Renaming suggestions 202 Switching off 156 Selecting a profile 203 System limitations 156 Selecting profile options 203 System limitations 156 Selecting profile options 203 See Electric parking brake Parking brake (manual) see Electric parking brake Profile 203 Parking options 204 See User profile 204 Parking options 240 Recting parking option on the map 240 Showing a parking option on the map 240 Recting parking option on the map 241	Paint code	3	
Engaging 123	Park position		19
Parking aid see Parking Assist PARKTRONIC Parking Assist PARKTRONIC Parking Assist PARKTRONIC Activating Activating Adjusting warning tones Drive Away Assist Function System limitations System limitations See Electric parking brake Parking brake (electrical) see Manual parking brake Parking for an extended period Parking options see Parking service Parking options See Parking service Parking options See Varking options See Varking options See Varking option on the map See Varking brake vehicle Selecting a profile options See User profile See Varking the vehicle Suggestions (203 Showing the profile selection when starting the vehicle Suggestions (203 Showing		Brofile	,
Parking aid Configuring suggestions 204 See Parking Assist PARKTRONIC 156 Deleting suggestions 204 Activating 156 Maximum number of profiles 202 Adjusting warning tones 156 Maximum number of profiles 202 Drive Away Assist 165 Renaming suggestions 204 Function 156 Selecting a profile 203 Switching off 156 Selecting a profile options 203 System limitations 156 Selecting profile options 203 System limitations 156 Showing the profile selection when starting the vehicle 203 Parking brake (electrical) Suggestions (overview) 203 Suggestions (overview) 203 Parking brake (manual) 84 OR code (rescue card) 27 Parking options 240 Qualified specialist workshop 26 Parking service 240 Rack systems (information) 274 Radar sensors 145 Activating 265 Partition sliding door <td>Engaging automatically 12</td> <td>₹</td> <td>03</td>	Engaging automatically 12	₹	03
See Parking Assist PARKTRONIC			
Activating 156 Maximum number of profiles 202 Adjusting warning tones 156 Overview 202 Drive Away Assist 165 Renaming suggestions 204 Function 156 Selecting a profile 203 Switching off 156 Selecting profile options 203 System limitations 156 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Suggestions (ove	see Parking Assist PARKTRONIC		
Adjusting warning tones 156 Overview 202 Drive Away Assist 165 Renaming suggestions 204 Function 156 Selecting a profile 203 Switching off 156 Selecting profile options 203 System limitations 156 Showing the profile selection when starting the vehicle 203 See Electric parking brake Parking brake (manual) see Manual parking brake Parking for an extended period 144 Parking light 84 OR code (rescue card) 27 Parking options see Parking service 240 Notes 240 Selecting parking option on the map 241 Radio Partition sliding door From the driver's compartment 56 Permissible gross mass 338 Adjusting warning tones 204 Renaming suggestions 204 Selecting a profile 203 Selecting profile options 203 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Profile see User profile Q QR code (rescue card) 27 Qualified specialist workshop 26 Rack systems (information) 274 Radio Activating 266 Calling up the station list 266 Deleting stations 266 Direct frequency entry 266		0 00	
Drive Away Assist Function			
Function		Renaming suggestions	
Switching off System limitations 156 System limitations 156 System limitations 156 Parking brake (electrical) see Electric parking brake Parking brake (manual) see Manual parking brake Parking for an extended period 144 Parking light 84 Parking options see Parking service Parking service Parking service Parking service Parking parking options 240 Selecting parking option on the map 241 Showing a parking option on the map 241 Partition sliding door From the cargo compartment 57 From the driver's compartment 56 Permissible gross mass 338 Selecting profile options 203 Showing the profile selection when starting the vehicle 203 Suggestions (overview) 203 Puggestions (overview) 203 Puggestio			
System limitations		0 1	
Parking brake (electrical) see Electric parking brakestarting the vehicle Suggestions (overview)203Parking brake (manual) see Manual parking brakeProfile see User profileParking for an extended period144QParking light84QR code (rescue card)27Parking service240 NotesQualified specialist workshop26Parking service240 Selecting parking options240 Showing a parking option on the map241Partition sliding door From the cargo compartment From the driver's compartment From the driver's compartment57 Calling up the station list Deleting stations Direct frequency entry203 203 204 204 205 206 207 208 209 209 209 209 209 209 209 209 200	•	Showing the profile selection when	
Suggestions (overview) 203 Parking brake (manual) see Manual parking brake Parking for an extended period 144 Parking light 84 Parking options see Parking service Parking service 240 Notes 240 Selecting parking options 240 Showing a parking option on the map 241 Partition sliding door From the cargo compartment 57 From the driver's compartment 56 Permissible gross mass 338 Profile see User profile OR code (rescue card) 27 Qualified specialist workshop 26 Rack systems (information) 274 Radio Activating 265 Activating deactivating radio text 267 Calling up the station list 266 Deleting stations 266 Direct frequency entry 266			
see Manual parking brake Parking for an extended period		'	03
see Manual parking brake Parking for an extended period	Parking brake (manual)		
Parking light84OR code (rescue card)27Parking options see Parking serviceQualified specialist workshop26Parking service240RNotes240Rack systems (information)274Selecting parking options240Radar sensors145Showing a parking option on the map241RadioPartition sliding door From the cargo compartment57 From the driver's compartment57 Calling up the station list266Permissible gross mass338Direct frequency entry266	see Manual parking brake	see User profile	
Parking options see Parking service Parking service	Parking for an extended period 14	4 a	
see Parking service Parking service	Parking light 8	QR code (rescue card)	27
Parking service		Qualified specialist workshop	26
Notes 240 Selecting parking options 240 Showing a parking option on the map 241 Partition sliding door From the cargo compartment 57 From the driver's compartment 56 Permissible gross mass 338 Rack systems (information) 274 Radar sensors 145 Radio Activating 265 Activating/deactivating radio text 267 Calling up the station list 266 Deleting stations 266 Direct frequency entry 266	_		
Selecting parking options			
Showing a parking option on the map		Rack Systems (IIIIO) IIIation) 2	274
map		Radar sensors 1	45
Partition sliding door Activating 265 From the cargo compartment 57 Activating/deactivating radio text 267 From the driver's compartment 56 Calling up the station list 266 Permissible gross mass 338 Deleting stations 266 Direct frequency entry 266		1 Radio	
From the cargo compartment	•		65
From the driver's compartment 56 Permissible gross mass	•	Activating/deactivating radio text 2	
Permissible gross mass			
Direct frequency entry	Permissible gross mass	,	
Pets in the vehicle 45 Displaying information 267	-	Displaying differences time	
Phone hook Displaying radio text		Displaying radio text 2	
See Contacts Editing station presets		Editing station presets 2	
Menu (on-board computer) 181			
PIN protection Moving stations	•		00

Overview	Reversing lights (Cargo Van and
Searching for stations	Passenger Van) 92
Setting a channel	Reporting safety defects 27
Setting the waveband	Rescue card 27
Switching the HD Radio function	Reset function (multimedia system) 215
on/off	Restoring (factory settings) see Reset function (multimedia system)
System) 190	Restraint system 3
Radio connection	Basic instructions for children 36
Key 46	Function in an accident
Real wood (care)	Functionality 3
Rear	Malfunction
Motion detector 89	Protection limited
Rear bench seat	Protection provided
see Seats	Self-test 3° Warning lamps 3°
Rear Cross Traffic Alert 166	
Rear fog light 84	Restricting the shift range 124
	Reversing light
Rear view camera	Changing bulbs 94
Care	Reversing lights
Switching automatic operation	Replacing light bulbs (Cargo Van
on/off (360° Camera)	and Passenger Van) 92
Rear window wiper	Rims (care) 288
Replacing	Roadside Assistance (breakdown) 24
Switching on/off	Roll away protection
Rear-compartment heating 102	see Activating/deactivating the
	HOLD function
Rear-end doors Opening and closing (from inside) 56	see HOLD function
Opening and closing (from outside) 55	Roof carrier (inside) 275
	Roof rack 353
Reducing agent see DEF	Roof rack (information) 274
Refrigerant (air conditioning)	Route 222, 226
Notes	Accepting a detour recommenda-
Refuel	tion after a prompt
Displaying the DEF level	Activating a commuter route 226
Refilling DEF	Alternative route (quick-access) 230
Refueling	Calculating 222
Refueling the vehicle	Displaying destination information 225
Regeneration	Displaying the route list
Notes 120	Editing a stored route
Registration	Planning 225
Vehicle	Recording a route
	Saving a recorded route 228
	Selecting a type 223
Replacing a wheel	Selecting an alternative route 226
Installing a new wheel	Selecting notifications
Replacing light bulbs	Selecting options
Indicators (rear) (Cargo Van and	Showing a stored route on the map
Passenger Van) 92	

Starting a saved route Starting the automatic service sta-	227	Adjusting the seat backrests (rear bench seat)	75
tion search Switching the automatic gas sta-	227	Adjusting the seat cushion (twin co-driver's seat)	. 71
tion search on/off	226	correct driver's seat position	
With intermediate destinations	226	Folding the folding seat up/down	
Route guidance	228	front (adjust electrically)	
Canceling	231	Front (adjusting manually, with	
Changing direction	228	Seat Comfort Package)	66
Destination reached	230	Front (adjusting mechanically,	
Freeway information	230	without Seat Comfort Package)	
From an off-road location		Front (adjusting mechanically)	66
Lane recommendations	229	Installing and removing rear bench	7.0
Notes	228	seat	
Off-road	232	Memory function	
To an off-road destination	231	Operating the memory function	
		Setting options	
S		Turning (front seat)	
Safety vest	292	With Seat Comfort Package	
Satellite radio		Without Seat Comfort Package	64
Activating/deactivating TuneStart	260	Securing luggage	271
Deleting a channel	268	Selector lever	
Displaying service information	270	see DIRECT SELECT lever	
Information	267	Sensors (care)	288
Information about Smart Favorites		Service	
and TuneStart	269	see ASSYST PLUS	
Logging in	267		170
Moving a channel	268	Service (on-board computer)	1/8
Music and sport alerts function	269	Service center	
Overview	268	see Qualified specialist workshop	
Pause and playback function	269	Service interval display	
Restrictions	267	see ASSYST PLUS	
Selecting a category	268	Service products	
Selecting a channel	268	Refrigerant (air conditioning)	348
Setting music and sport alerts	269	Service station search	
Setting the parental control	268	Starting automatic search	227
Storing a channel	268	•	
Switching on		Setting the date format	210
Seat belt 32		Setting the distance unit	213
Adjusting the height		Setting the map scale	
Care		see Map	
Fastening		Setting the speed	
Protection impaired		see Cruise control	
Protection provided			102
Releasing		Settings (on-board computer)	103
Warning lamps		Short messages	
Seat cover (care)	290	see Messages	
Seats		Short-distance trips	113
4-way lumbar support		Side airbag	35
8-way adjustment options		Side window	58
Adjusting armrests	71	Closing	58
Adjusting the head restraints		9	58
mechanically	75	Closing (all)	50

Closing using the key	60 60	Speech dialog system see Voice Control System	
Convenience opening	60	Speed rating (tire)	321
Opening	58	Speedometer (digital)	179
Opening (all)	58		179
Opening with the key Side windows	60	Standby mode Activating/deactivating	145
Problem	61	Start/stop button	
Resetting		Parking the vehicle	140
Size designation (tire)	321	Starting the vehicle	110
Sliding door		Switching on the power supply or	100
B-pillar door sill (button)	52	the ignition	109
Center console (button)		Starting	
Child safety lock	44	see Vehicle	
Closing (from inside)		Starting assistance	
Closing (from outside)	51	see Jump-start connection	
Opening (from inside) Opening (from outside)	51 51	Starting-off aid	
	51	see Hill start assist	
SmartKey	17	Station	
Acoustic locking verification signal	4/	Deleting	266
Smartphone		Direct frequency entry	266 266
see Android Auto		Moving Searching	266
see Apple CarPlay [®] see Telephone		Setting	266
'	000	Storing	266
	309	Station list	
Socket (12 V)		Calling up	266
Cargo compartment		Station presets	
Driver's seat Front center console	80 80	Modifying	266
		Stationary heating	
Socket (115 V)		Problems	108
Lower control panel		Stationary heating/ventilation	
Software update		Adjusting (on-board computer)	107
Information Performing		Stationary heating/ventilation	107
System updates		see Auxiliary heating	
Sound	217	see Hot-water auxiliary heater	
see Sound settings		Steering wheel	176
-	270	Adjusting	
Sound settings Adjusting the balance/fader	270	Buttons	176
Adjusting trie balance/rader	270	Stopping the alarm (ATA)	62
	270		02
	270	Stowage areas see Stowage space	
	270	.	
Information	270	Stowage compartments see Stowage space	
Spare wheel			77
Installing/removing		Stowage space	
Notes	332	Center console	
Special seat belt retractor	40	Cockpit	
Specialist workshop	26	Door	
•		Glasses compartment	

Telephone 182, 2	Glove box	77	Tire pressure monitor	317
Surround lighting Switching on/off Surround View see 360° Camera Switch-off delay time Exterior 86 Interior 90 Switching air-recirculation mode on/off 91 Switching on ignition (start/stop button) 109 Switching seat heating on/off 76 Switching synchronization function on/off (control panel) 103 Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 104 System settings Activating/deactivating PIN protection	Sulfur content	341	Vehicle identification plate	338
Surround lighting Switching on/off 87	Summer tires	308		
Switching on of f	Surround lighting			246
Surround View See 360° Camera Switch-off delay time Exterior 86 Interior 90 Switching air-recirculation mode on/off 104 Switching on ignition (start/stop button) 109 Switching seat heating on/off 104 Switching synchronization function on/off (control panel) 103 Switching the Pair window defroster on/off 104 Switching the Windshield heater on/off 104 Switching the Windshield heater on/off 104 System settings Activating/deactivating PIN protection 213 Reset function (multimedia system) 215 Setting the distance unit 213 Setting the time and date automatically 210 Setting the time and date automatically 210 Setting the time date format 210 System settings See Bluetooth® see Data import/export see Language see Software update see Wi-Fi Talipipes (care) 288 Tank capacity Fuel		87		246
Switch-off delay time	• .			244
Switch-off delay time Exterior			•	244
Exterior 86 Interior 90 Switching air-recirculation mode on/off 91 Switching on ignition (start/stop button) 109 Switching seat heating on/off 76 Switching synchronization function on/off (control panel) 103 Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 105 System settings Activating/deactivating PIN protection 107 Exterior 90 Switching seat heating on/off 76 Switching synchronization function on/off 102 Switching the a/C function on/off 102 Switching the windshield heater on/off 104 System settings 104 System settings 105 Activating/deactivating PIN protection 105 Exterior 90 Exterior 90 Connecting a mobile phone (Secure Simple Pairing) 20 Connecting a mobile phone 125 Importing contacts (overview) 104 Importing contacts (overview) 20 Importing contacts (overview) 20 Incoming call during an existing call 105 Information 102 Interchanging mobile phones (two phone mode) 104 Menu (on-board computer) 114 Mobile phone voice recognition 105 Notes 105 Operating modes 105 Extension the distance unit 105 Switching mobile phone 105 Switching the distance unit 105 Setting the distance unit 105 Setting the time and date automatically 105 Setting the time zone 105 Switching mobile phones (two phone mode) 105 Switching mobile phones (two phone mode) 105 Switching mobile phones 105 Switching mobile phones 105 Switching mobile phones 105 Switching the zone 105 Switching the zone 105 Switching the zone 1				245
Interior Switching air-recirculation mode on/off Switching on ignition (start/stop button) 109 Switching seat heating on/off 76 Switching seat heating on/off 76 Switching synchronization function on/off (control panel) 103 Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 105 System settings Activating/deactivating PIN protection 104 System yetting the distance unit 104 Setting the distance unit 105 Setting the time and date automatically 105 Setting the time and date automatically 105 Setting the time zone 105 System settings 105 See Data import/export 105 see Data import/export 105 see Data import yexport 105 see Data import yexport 106 see Wi-Fi 105 Tailpipes (care) 288 Tank capacity Fuel 105 Tark capacity Fuel 105 Tark content 105 Telephone operating modes 105 Telephone operating modes 105 System 105 System 105 System 105 System 105 Switching a mobile phone (Secure Simple Pairing) 205 Connecting a mobile phone 216 Secure Simple Pairing) 205 Importing contacts (overview) 205 Importing contacts (overview) 206 Importing contacts (overview) 207 Importing contacts (overview) 208 Importing contacts (overview) 209		0.6		2-10
Switching air-recirculation mode on/off				243
Switching an intercertain mode on /off		70		
Switching on ignition (start/stop button) 109	•	104	(Secure Simple Pairing)	243
button)		104		
Switching seat heating on/off		100		244
Switching synchronization function on/off (control panel) 103 Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 104 Switching the windshield heater on/off 104 System settings	button)	109		244
Switching synchronization function on/off (control panel) 103 Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 104 System settings Activating/deactivating PIN protection 105 Setting the distance unit 105 Setting the time and date automatically 105 Setting the time zone 105 Setting the time zone 105 Setting the time/date format 105 System settings 105 See Bluetooth® 105 See Bluetooth® 106 System settings 107 See Software update 105 See Software update 105 See Wi-Fi 106 Tailpipes (care) 107 Tailpipes (care) 108 Incoming call during an existing 22 Information 102 Interchanging mobile phones (two phone mode) 105 Interchanging mobile phones (two phone mode) 105 Menu (on-board computer) 116 Mobile phone voice recognition 105 Menu (on-board computer) 117 Mobile phone voice recognition 105 Notes 105 Reception and transmission volume 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone menu overview 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone mode (Incurion) 105 Telephone mode (Incurion) 105 Telephone mode (Incurion) 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone mode (Incurion) 105 Telephone mode (Incurion) 105 Switching mobile phones (Near 1616 Communication (NFC)) 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC) 105 Switching mobile phones (Near 1616 Communication (NFC) 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC) 105 Telephone menu overview 105 Switching mobile phones (Near 1616 Communication (NFC) 105 Telephone menu overview 105 Telephone menu overview 105 Telephone menu ove	Switching seat heating on/off	76	1 0	248
Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 105 System settings 105 Activating/deactivating PIN protection 213 Reset function (multimedia system) 215 Setting the distance unit 213 Setting the time and date automatically 210 Setting the time zone 210 Setting the time/date format 210 System settings 210 System settings 210 Setting the distance unit 210 System settings 320 System settings 4210 Setting the time zone 210 Setting the time/date format 210 System settings 322 System settings 323 Setting the time/date format 210 System settings 324 Talipipes (care) 288 Tank capacity Fuel 343 Reserve (fuel) 343 Tank content 344 Tank content 344 Tating function on/off 102 Information 102 Information 102 Information 102 Information 102 Information 102 Information 104 Menu (on-board computer) 11 Mobile phone voice recognition 2 Menu (on-board computer) 12 Mobile phone voice recognition 2 Notes 20 Operating mobile phones (Nea Reception and transmission volume 22 Ringtone volume 22 Ring	Switching synchronization function			247
Switching the A/C function on/off 102 Switching the rear window defroster on/off 104 Switching the windshield heater on/off 104 System settings	on/off (control panel)	103		246
Switching the rear window defroster on/off		102		243
Description				240
Switching the windshield heater on/off 104 System settings 2. Activating/deactivating PIN protection 213 Reset function (multimedia system) 215 Setting the distance unit 213 Setting the time and date automatically 210 Setting the time zone 210 Setting the time/date format 210 System settings 210 System settings 210 System settings 210 Setting the time/date format 210 System settings 210 Setting the time/date format 210 System settings 210 Set Data import/export see Language see Software update see Wi-Fi 210 Tailpipes (care) 288 Tank capacity Fuel 343 Reserve (fuel) 343 Taik content 210 System settings 343 Reserve (fuel) 343 Tank content 344 Menu (on-board computer) 11 Mobile phone voice recognition 22 Notes 20 Notes 20 Notes 21 Notes 21 Section and transmission volume 22 Reception and transmission volume 22 Ringtone volume 22 Ringtone volume 22 Ringtone volume 22 Tilephone operation (NFC)) 22 Telephone operation 22 Telephone operation 22 Two phone mode (function) 22 Voice commands (Voice Control System) 11 Wireless charging (mobile phone) 343 Text messages 344 Text messages 344 Text messages 344		104		244
on/off 104 System settings Operating modes 2.2 Activating/deactivating PIN protection 213 Reception and transmission volume tection 213 Reset function (multimedia system) 215 Switching mobile phones 2.2 tem) 215 Switching mobile phones 2.2 Setting the distance unit 213 Switching mobile phones (Near Field Communication (NFC)) 2.2 Setting the time and date automatically 210 Telephone menu overview 2.2 Setting the time zone 210 Telephone menu overview 2.2 System settings Using Near Field Communication see Bluetooth® Using Near Field Communication see Data import/export Voice commands (Voice Control System) see Wi-Fi Telephony operating modes Tailpipes (care) 288 Tank capacity Telephony operating modes Fuel 343 Reserve (fuel) 343 Tank content 344	•	104	• • • • • • • • • • • • • • • • • • • •	182
System settings Activating/deactivating PIN protection 213 Reset function (multimedia system) 215 Setting the distance unit 213 Setting the time and date automatically 210 Setting the time zone 210 Setting the time/date format 210 System settings see Bluetooth® see Data import/export see Language see Software update see Wi-Fi Tailpipes (care) 288 Tank capacity Fuel 290 Fuel 201 Fuel 20		104	Mobile phone voice recognition	246
Activating/deactivating PIN protection		104		243
tection	,		Operating modes	242
Reset function (multimedia system)		010		
tem)		213		245
Setting the distance unit	· · · · · · · · · · · · · · · · · · ·	215		245
Setting the time and date automatically				244
ically		210		245
Setting the time zone	=	210		242
Setting the time/date format	,		• .	246
System settings see Bluetooth® see Data import/export see Language see Software update see Wi-Fi Tailpipes (care) Tank capacity Fuel				244
see Bluetooth® see Data import/export see Language see Software update see Wi-Fi Tailpipes (care) Tank capacity Fuel 343 Reserve (fuel) See Bluetooth® (Voice Control System) 11 System) 12 Telephony operating modes Bluetooth® Telephony 22 Temperature grade 3 Text messages Voice commands (Voice Control System) 12 Text messages Text messages See Messages Text messages See Messages	System settings			
See Data import/export See Language See Software update See Wi-Fi Tailpipes (care) Fuel Fuel Fuel Fuel Fuel Fuel Fuel Fuel			(NFC)	245
see Language see Software update see Wi-Fi Telephony operating modes Bluetooth® Telephony				
Telephony operating modes Bluetooth® Telephony 22 Temperature grade 3 Text messages Tank capacity Fuel 343 Reserve (fuel) 343 Text messages Tank content 5 Text messages Text messages Text messages Text messages See Messages Text messages See Messages	· · · · ·			189
Bluetooth® Telephony 22 Temperature grade 3 3 Text messages	see Software update		Wireless charging (mobile phone)	82
Temperature grade	see Wi-Fi			
Tailpipes (care)	_		Bluetooth® Telephony	242
Tailpipes (care) 288 Text messages Voice commands (Voice Control System) System) 1º Reserve (fuel) 343 Text messages Tank content see Messages See Messages	T		Temperature grade	319
Tank capacity Voice commands (Voice Control Fuel 343 System) 1 Reserve (fuel) 343 Text messages Tank content see Messages 344	Tailpipes (care)	288		
Fuel 343 System) 1 Reserve (fuel) 343 Text messages Tank content see Messages DEF 344	Tank capacity			
Reserve (fuel)		343		193
Tank content see Messages		343	_ * *	
DEE 344	Tank content			
		344		274
Tochnical data			Tie-down eyes	۷/4
Information 337		337		010
Notes (trailer hitch)			ivianuai time setting	210

Setting the time and date automat-		Checking	308
ically	210	Checking the tire pressure (tire	
Setting the time zone	210	pressure monitoring system)	316
Setting the time/date format	210	Definitions	323
Tire and Loading Information plac-		Direction of rotation	327
ard	317	DOT, Tire Identification Number	
Tire Identification Number (TIN)	320	(TIN)	320
		Flat tire	294
Tire information table	317	Installing	330
Tire labeling	319	Load hagging apposity	321
Characteristics	321	Load-bearing capacity	321 309
DOT, Tire Identification Number		M+S tires Maximum tire load	321
(TIN)	320	Maximum tire pressure	321
Load index	321	Noise	308
Load-bearing capacity	321	Notes on installing	324
Maximum tire load	321	Overview of tire labeling	319
Maximum tire pressure	321	Removing	330
Overview	319 321	Replacing 324,	
Size designationSpeed rating	321	Restarting the tire pressure moni-	
Temperature grade	319	tor	316
Tire quality grades	319	Selecting	324
Traction grade	319	Size designation	321
Tread wear grade	319	Snow chains	309
		Speed rating	321
Tire load (maximum)	321	Storing	327
Tire pressure		Summer tires	308
Checking (tire pressure monitoring	047	Temperature grade	319
system)	316	Tire and Loading Information plac-	
Maximum	321	ard	317
Notes	310	Tire pressure (notes)	310
Restarting the tire pressure moni-	214	Tire pressure monitoring system	014
tor	310	(function)	314
Tire pressure monitoring system	314	Tire pressure table	
(function)		Tire quality grades Traction grade	319 319
•	. 514	Tread wear grade	319
Tire pressure monitor	01/	Unusual driving characteristics	308
Checking the tire pressure		Wheel size categories	326
Checking the tire temperature Function			
Restarting		Tool see Removing the vehicle tool kit	
Technical data		see Vehicle tool kit	
		see Vehicle tool kit stowage compartm	ent
Tire pressure table		Top Tether	
Tire quality grades	017	•	42
Tire temperature		Topping up the windshield washer	201
Checking (tire pressure monitoring		system	
system)	316	Touch Control	199
Tire pressure monitoring system	214	On-board computer	176
(function)	314	Operating	199
Tire tread	308	Setting acoustic operating feed- back	200
Tire-change tool kit	327	Setting the sensitivity	200
Tires		- G	
Characteristics	321		

Touchscreen (media display)		Trailer stabilization	148
Operating	200	Transferred vehicle data	
Setting acoustic operating feed-	200	Android Auto	253
back	200	Apple CarPlay®	253
Tow starting	304	Transmission position display	122
Tow-away alarm		Transmission ratio	
Function		LOW range	126
Switching on/off		Transmission ratio	
Towing away		see Engaging/disengaging LOW RANG	E
	302	Transport by rail	114
Towing eye	204	Transporting (vehicle breakdown)	303
Installing/removing Storage location	303	Tread wear grade	319
Towing eye (storage location)		Trim element (care)	290
see Vehicle tool kit			270
Towing methods	300	Trip Display total distance	179
	319	Menu (on-board computer)	179
Traction grade		Trip computer	1, ,
Traffic information	233	Resetting	180
Displaying the traffic map Displaying traffic incidents	233 234	Showing	179
Live Traffic Information	233	Trip distance	179
Overview	233	Showing	179
Switching on the display	234	Trip odometer	., ,
Traffic map		Resetting	180
see Map		Trip odometer	
Traffic Sign Assist	163	see Trip distance	
Function/notes	163	Tuneln	259
Setting	164	Calling up	259
System limitations	163	Calling up the station list (category	,
Trailer hitch		last selected)	261
Care	288	Deleting stations	260
General notes	349	Logging out	260
Information	172 169	Overview	260
Information about trailer operation Permissible trailer loads and trailer	109	Registering	260 260
drawbar noseweights	173	Saving stations	200
Power supply	174	tion	260
Socket	172	Selecting stream	260
Trailer loads	349	Setting options	260
Trailer operation		Terms of use	260
Active Lane Keeping Assist	167	TuneMix	
Coupling/Decoupling the trailer		Creating a list	269
Gross axle weight rating		Turn signal light	
Information	172	Additional turn signal light (all-	
Lane Keeping Assist	166	wheel drive vehicles)	
Notes Permissible trailer loads and trailer	169	Twin co-driver's seat	71
drawbar noseweights	173	Two-way radio telephone	
Power supply	174	see Mobile phone	
Socket	172	Two-way radios	
Trailer loads	349	Frequencies	337

Installation notes	337	Vehicle data	
Transmission output (maximum)	337	-1-7 6 (215
		0	215
U		0	253
Units of measurement			253 348
Setting			348
Unlocking setting	47		348
Unlocking/locking			348
Switching automatic locking fea-		Vehicle data memory	
ture on/off	50	Electronic control units	28
Unlocking and opening front doors		Service providers	29
from inside	49	Vehicle data storage	_ /
Updates		Event data recorders	29
Important system updates			-,
Performing			348
Software updates	214	Vehicle identification number	
USB socket in the rear passenger		see VIN	
compartment	81	Vehicle identification plate	
User profile	202	EU general operating permit num-	
Using a sun visor	98		338
Using kickdown			338 338
•	124		338
Using the telephone see Calls			338
see Calls		Vehicle identification plate	
V		see Model series	
Vehicle	110	Vehicle key	
Correct use		see Key	
Data recording		Vehicle level	
Diagnostics connection	25	Lowering	129
Equipment			129
Limited Warranty		Vehicle maintenance	
Locking (automatic)		see ASSYST PLUS	
Locking/unlocking (emergency key)	50	Vehicle operation	
Lowering		Outside the USA or Canada	23
Notifying problems		Vehicle tool kit	
Parking (start/stop button)	140		303
Parking for an extended period	144	Vehicle tool kit stowage compart-	204
QR code rescue card	27		306
Qualified specialist workshop	26		338
0	328		338
Registration	26	8	338
Starting (in emergency operation	440		338 338
mode)	110		330
Starting (start/stop button)	110	Voice command types (Voice Con-	105
Switching on power supply (start/ stop button)	109		185
Unlocking (from inside)			184
Ventilating (convenience opening)		Application specific voice com-	105
Voice commands (Voice Control			185
System)	193		186 185
		FUITEINIS HUINDEIS	100

Global voice commands Improving speech quality Language setting Media player voice commands Message voice commands	185 186 185 191 193	© Electric parking brake mal- functioning yellow indicator lamp lights up	378
Multifunction steering wheel (operating)	184 187	ing lamp Engine diagnosis warning	384
Notes on the voice commands	187	lamp	385
Online voice control	186	SF ESP® OFF warning lamp	382
Operable functions	185	ESP® warning lamp flashes	382
Operating safetyRadio voice commands	184 190	ESP® warning lamp lights up	381
Setting (MBUX multimedia system)	185		384
Switch voice commands	187	Power steering system warn-	
Telephone voice controls Text message voice commands	189 193		383
Types of voice commands	185	(P) Red electric parking brake	
Vehicle voice commands	193	applied indicator lamp (Canada)	
Voice prompting	184	flashes	378
Voice control system see Voice Control System		(P) Red electric parking brake	
		applied indicator lamp (Canada)	
W		lights up 378,	379
Warning and indicator lamps		PARK Red electric parking brake	
Overview		applied indicator lamp (USA)	
Warning lamp	292	flashes	378
Warning system see ATA (Anti-Theft Alarm system)		PARK Red electric parking brake applied indicator lamp (USA) lights	
Warning/indicator lamp		up 378,	379
ABS warning lamp		(P) Red parking brake applied	
(P) and 377, 378, 379, 380,	381	indicator lamp (Canada) lights up	379
(n) Brake system warning lamp		PARK Red parking brake applied	
(yellow)	3/9	indicator lamp (USA) lights up	379
(D) Brake warning lamp (red)	000	Restraint system warning	
(Canada)	380	lamp	381
BRAKE Brake warning lamp (red)	201	🚁 Seat belt warning lamp	
(USA)		flashes	383
Coolant warning lamp		Seat belt warning lamp lights	
Distance warning lamp	383	1	383
Electric parking brake applied red indicator lamp (Can-		(P) The electric parking brake	
ada) does not light up	377	malfunctioning yellow indicator	
PARK Electric parking brake	377		379
applied red indicator lamp (USA)		Tire pressure monitoring sys-	005
does not light up	377	9 1	385
asso not light up	<i>5, ,</i>	Tire pressure monitoring sys-	005
		0 1 0 1	385
	Wa	rranty	27

Warranty terms and conditions	23	Tire pressure monitoring system	
Washer fluid		(function)	314
see Windshield washer fluid (notes)		Tire pressure table	
Washing by hand (care)	287	Tire quality grades Traction grade	319 319
Weather information	240	Tread wear grade	319
Web browser		Unusual driving characteristics	308
Calling up a web page	257	Wi-Fi	211
Calling up options	258	Adjusting	211
Calling up the settings	258	Overview	211
Deleting a bookmark	258	Setting up a hotspot	212
Deleting Internet history	258	Setting up an Internet connection	255
Ending	259	Window curtain airbag	35
Managing bookmarks	258	_	00
Overview	258	Windows see Side window	
Website			288
Calling up	257	Windows (care)	
Wheel rotation	326	Windshield	
Wheel size categories	326	Replacing the wiper blades	95
Wheel wrench		Replacing the wiper blades (WET WIPER SYSTEM)	96
Wheels	027	Windshield	70
Care	288	see Windshield	
Characteristics of the tire	321		
Checking	308	Windshield washer fluid	0.40
Checking the tire pressure (tire	000	Information	348
pressure monitoring system)	316	Windshield washer fluid (notes)	347
Definitions	323	Windshield wipers	
DOT, Tire Identification Number		Replacing the wiper blades	95
(TIN)	320	Replacing the wiper blades (WET	
Flat tire	294	WIPER SYSTEM)	96
Installing	330	Switching on/off	95
Load index	321	Winter driving (snow chains)	309
Load-bearing capacity	321	3 (309
Maximum tire load			309
Maximum tire pressure		Wiper blades	
Noise			288
Notes on installing		Replacing (rear window)	
Overview of tire labeling	319	Replacing (WET WIPER SYSTEM)	
Removing	330	Replacing (windshield)	95
	327	Wireless charging	
Restarting the tire pressure moni-	01/	Function/notes	
tor		Mobile phone	82
Rotating Selecting	326 324	Workshop	
Size designation	321	see Qualified specialist workshop	
Snow chains			
Speed rating			
Storing	327		
Temperature grade	319		
Tire and Loading Information plac-	317		
ard	317		
Tire pressure (notes)			

Publication details

Internet

Further information about Mercedes-Benz vehicles and about Mercedes-Benz AG can be found on the following websites:

https://www.mercedes-benz.com

https://www.mbusa.com (USA only)

https://www.mercedes-benz.ca (Canada only)

Documentation team

© Daimler VANS USA, LLC

[®]Mercedes-Benz AG: not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Mercedes-Renz AG

Vehicle manufacturer

Mercedes-Benz AG Mercedesstraße 120 70372 Stuttgart

Germany

Vehicle dealer

Daimler VANS USA, LLC

One Mercedes-Benz Drive Sandy Springs, GA 30328

https://www.mbusa.com (USA only)

http://www.mbsprinterusa.com

Customer Assistance Center:

1-877-762-8267

Mercedes-Benz Canada, Inc.

98 Vanderhoof Avenue

Toronto, ON M4G 4C9

https://www.mercedes-benz.ca (Canada only)

Customer Relations Department:

1-800-387-0100

Daimler VANS USA, LLC and Mercedes-Benz Canada, Inc. are Daimler Companies.

Canada only: "Authorized Sprinter Dealer" is defined as an authorized Mercedes-Benz Sprinter Dealer.

Your Operating Instructions

(i)

Digital in the vehicle

Familiarize yourself with the contents of the Operating Instructions directly via the vehicle's multimedia system (Menu item "Vehicle"). Start with the quick guide or deepen your knowledge with practical tips.



Vehicle document wallet in the vehicle

Here you can find information on operation, service work and the guarantee for your vehicle in printed form.